																													• •	
																														l.
		• •		• •			• •			•				• •	• •						• •	• •		• •		• •				

Me

Mercedes-Benz SLR McLaren. Operator's Manual.



Mercedes-Benz

Mercedes-Benz SLR McLaren. Operator's Manual.

SLR. UNLIMITED.



Thank you for choosing Mercedes-Benz.

Our company and staff congratulate you on the purchase of your new Mercedes-Benz SLR McLaren.

Your selection of our product is a demonstration of your trust in our company name. Furthermore, it exemplifies your desire to own an automobile that will be as easy as possible to operate and provide years of service.

Should you have any questions, please contact your dealer contact for your Mercedes-Benz SLR McLaren or call us at

1-800-FOR-MERCedes (in the USA) or 1-888-881-6611 (in Canada). Your dealer contact will co-ordinate appointments for servicing of your vehicle and clarify any issues arising from the use of your Mercedes-Benz SLR McLaren.

Your Mercedes-Benz represents the efforts of many skilled engineers and craftsmen. To help assure your driving pleasure, and also the safety of you and your passengers, we ask you to make a small investment of time:

- Please read this manual carefully, then return it to your vehicle where it will be handy for your reference.
- Please follow the recommendations contained in this manual. They are designed to acquaint you with the operation of your Mercedes-Benz SLR McLaren.
- Please pay attention to the warnings and cautions contained in this manual. They are designed to help improve the safety of the vehicle operator and occupants.

We extend our best wishes for many miles of safe, pleasurable driving.

Mercedes-Benz USA, LLC

A DaimlerChrysler Company

Contents

	10
Introduction	12
Product information	13
Operator's Manual	14
Service and warranty information	14
Important notice for California	
retail buyers and lessees of	
Mercedes-Benz automobiles	15
Maintenance	16
Roadside Assistance	16
Change of address or ownership	16
Operating your vehicle outside the	
USA or Canada	17
Mercedes-Benz SLR McLaren	
compliance	17
Where to find it	18
Symbols	19
Operating safety	20
Proper use of the vehicle	20
Problems with your vehicle	21
Reporting safety defects	22
Reporting safety defects	22
Vehicle data recording	23
Information regarding electronic	
recording devices	23

At a glance	24
Cockpit	26
Instrument cluster	28
Multifunction steering wheel	30
Center console	31
Upper part	31
Lower part	32
Overhead control panel	33
Control panel on the door sill	34

Getting started	36
Unlocking	38
Starter switch positions	40
Adjusting	42
Seats	42
Steering wheel	43
Mirrors	44
Driving	46
Fastening the seat belts	46
Starting the engine	49
Parking brake	
Driving off	51
Switching on headlamps	52
Turn signals	53
Windshield wipers	54
Problems while driving	56
Parking and locking	57
Parking brake	57
Switching off headlamps	58
Turning off the engine	58
Releasing seat belts	59
Locking	59

Contents

Safety and Security	60
Occupant safety	62
Airbags	63
Seat belts	69
Children in the vehicle	72
Panic alarm	78
Activating	78
Deactivating	78
Driving safety systems	79
ABS	79
BAS	81
ESP [®]	81
Electrohydraulic brake system	84
Performance enhancement system	87
Airbrake	87
Anti-theft systems	90
Immobilizer	90
Anti-theft alarm system	90
Tow-away alarm	92

Controls in detail	. 94
Locking and unlocking	. 96
SmartKey	. 96
Opening the doors	100
Opening the trunk	100
Closing the trunk lid	10
Trunk emergency release	102
Automatic locking	103
Locking and unlocking from	
the inside	103
Lighting	105
Exterior lamp switch	105
Combination switch	109
Hazard warning flasher	11(
Interior lighting	11
Trunk lamp	112
Courtesy lighting	112
Instrument cluster	113
Instrument cluster illumination	113
Coolant temperature gauge	114
Resetting the trip odometer	115
Tachometer	115
Outside temperature indicator	115

Control system	117
Multifunction display	117
Multifunction steering wheel	118
Menus	120
Standard display menu	122
AUDIO menu	123
Vehicle status message memory	
menu	124
Settings menu	126
Trip computer menu	137
TEL menu	139
Audio system	143
Audio and telephone, operation	143
Operating safety	143
Location of the audio system	143
Operating and display elements	144
Button and soft key operation	146
Operation	146
Radio operation	149
Cassette operation	152
CD changer operation	156
Telephone operation	160
Automatic transmission	167
One-touch gearshifting	168
Gear ranges	170
Gear selector lever positions	171

Shift program mode selector

switch	173
Driving tips	173
Steering wheel gearshift control	174
Manual gearshift program	176
Emergency operation	
(Limp Home Mode)	178
Good visibility	179
Headlamp cleaning system	179
Rear view mirrors	179
Sun visors	180
Rear window defroster	181
Automatic climate control	182
Adjusting the temperature	185
Adjusting air volume	186
Adjusting air distribution	187
Maximum cooling MAXCOOL	187
Defrosting the windshield	188
Air recirculation mode	188
Residual heat and ventilation	190
Deactivating the automatic	
climate control system	191
Air conditioning	192

Power windows 193
Opening and closing the
windows 193
Synchronizing power windows 195
Summer opening feature 195
Convenience closing feature 196
Driving systems 197
Cruise control 197
Useful features 200
Map pocket in passenger
footwell 200
Storage compartments 200
Parcel net in trunk 201
Ashtray and cigarette lighter 202
Power outlet 203
Telephone 203
Tele Aid 208
Garage door opener 216
Floormats 223
Dust cover 224
Roof and trunk lid racks 227

Operation	228
The first 1000 miles (1500 km)	230
Driving instructions	231
Drive sensibly – save fuel	231
Drinking and driving	231
Pedals	231
Power assistance	232
Brakes	232
Driving off	234
Parking	234
Tires	235
Hydroplaning	236
Tire traction	236
Tire speed rating	236
Winter driving instructions	237
Standing water	238
Passenger compartment	
Driving abroad	238
Control and operation of radio	
transmitters	238
Catalytic converter	239
Emission control	240
Coolant temperature	240

Contents

At the gas station	241
Refueling	241
Check regularly and before	
a long trip	242
Engine compartment	244
Hood	244
Engine oil	247
Transmission fluid level	249
Coolant	250
Trunk	251
Batteries	251
Windshield washer system and	
headlamp cleaning system	252
Tires and wheels	254
Important guidelines	254
Tire care and maintenance	
Direction of rotation	257
Loading the vehicle	257
Recommended tire inflation	
pressure	264
Checking tire inflation pressure	266
Tire labeling	271
Load identification	
DOT, Tire Identification Number	
(TIN)	276
Maximum tire load	

Maximum tire inflation pressure	278
Uniform Tire Quality Grading	
Standards (U.S. vehicles)	279
Tire ply material	281
Tire and loading terminology	281
Rotating tires	284
Anti-theft wheel nuts	285
Winter driving	287
Winter tires*	287
Snow chains	288
Maintenance	289
Clearing the maintenance	
service indicator message	289
Maintenance service term	
exceeded	290
Calling up the service due date	290
Resetting the maintenance	
service indicator	291
Vehicle care	292
Cleaning and care of the vehicle	292
Vehicle washing	293

Practical hints	296
What to do if	298
Lamps in instrument cluster	298
Lamp in center console	306
Vehicle status messages in the	
multifunction display	307
Symbol messages	315
Where will I find?	342
First aid kit	342
TIREFIT kit, electric air pump,	
towing eye bolt and	
vehicle literature portfolio	342
Compact guide (Canada only)	343
Unlocking in an emergency	344
Unlocking the vehicle	344
Replacing SmartKey batteries	346
Replacing bulbs	348
Front lamps	349
Rear lamps	349
Replacing the wiper blades	350
Removing wiper blades	350
Installing wiper blades	350

Contents

Flat tire	351
Preparing the vehicle	351
Sealing tires with TIREFIT kit	351
Batteries	356
Charging the batteries	358
Towing the vehicle	360
Installing/reinstalling	
towing eye bolt	362
Points to bear in mind	362
Transporting the vehicle	362
Fuses	363

Technical data	364
Spare parts service	366
Warranty coverage	367
Loss of Service and Warranty	
Information Booklet	367
Identification labels	368
Engine number	368
Layout of poly-V-belt drive	369
Engine	370
Rims and tires	371
Mixed size tires	372
Winter tires*	373
Electrical system	374
Main dimensions	375
Weights	376

Fuels, coolants, lubricants, etc	377
Capacities	377
Engine oils	378
Engine oil additives	378
Air conditioning refrigerant	378
Brake fluid	379
Premium unleaded gasoline	379
Fuel requirements	380
Gasoline additives	380
Coolants	381
Windshield and headlamp	
washer system	383

Technical terms		384
------------------------	--	-----

Index	390

Product information

Product information

Please observe the following in your own best interest:

We recommend using Genuine Mercedes-Benz parts as well as conversion parts and accessories explicitly approved by us for your vehicle model.

We have tested these parts to determine their reliability, safety and special suitability for Mercedes-Benz vehicles. We are unable to make an assessment for other products and therefore cannot be held responsible for them, even if in individual cases an official approval or authorization by governmental or other agencies should exist. Use of such parts and accessories could adversely affect the safety, performance or reliability of your vehicle. Please do not use them. Genuine Mercedes-Benz parts as well as conversion parts and accessories approved by us are available at an authorized Mercedes-Benz Center where you will receive comprehensive information, also on permissible technical modifications, and where proper installation will be performed.

Operator's Manual

This Operator's Manual contains a great deal of useful information. We urge you to read it carefully and familiarize yourself with the vehicle before driving.

For your own safety and longer service life of the vehicle, we urge you to follow the instructions and warnings contained in this manual. Ignoring them could result in damage to the vehicle or personal injury to you or others. Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

Your vehicle may have some or all of the equipment described in this manual. Therefore, you may find explanations for optional equipment not installed in your vehicle. If you have any questions about the operation of any equipment, your authorized Mercedes-Benz Center will be glad to demonstrate the proper procedures. We continuously strive to improve our product, and ask for your understanding that we reserve the right to make changes in design and equipment. Therefore, information, illustrations, and descriptions in this Operator's Manual might differ from your vehicle.

Optional equipment is also described in this manual, including operating instructions wherever necessary. Since they are special-order items, the descriptions and illustrations herein may vary slightly from the actual equipment of your vehicle.

If there are any equipment details that are not shown or described in this Operator's Manual, an authorized Mercedes-Benz Center will be glad to inform you of correct care and operating procedures.

The Operator's Manual and Maintenance Booklet are important documents and should be kept with the vehicle.

Service and warranty information

The Service and Warranty Information Booklet contains detailed information about the warranties covering your Mercedes-Benz, including:

- New Car Limited Warranty,
- Emission System Warranty,
- Emission Performance Warranty,
- California, Maine, Massachusetts and Vermont¹ Emission Control System Warranty (California, Maine, Massachusetts and Vermont¹ only),
- State Warranty Enforcement Laws (Lemon Laws).

¹ At time of printing, the decision regarding compliance with Vermont certification regulations was still pending. The vehicle may not be permitted to be registered in Vermont. Check with an authorized Mercedes-Benz Center for details.

Operator's Manual

Important notice for California retail buyers and lessees of Mercedes-Benz automobiles

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty after a reasonable number of repair attempts. During the period of 18 months from original delivery of the vehicle or the accumulation of 18000 miles (approx. 29000 km) on the odometer of the vehicle, whichever occurs first, a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- (1) the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair,
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified us in writing of the need for its repair, or

(3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Written notification should be sent to us, not a dealer, at Mercedes-Benz USA, LLC, Customer Assistance Center, Attn: SLR Liaison, Three Paragon Drive, Montvale, NJ 07645-0350.

Operator's Manual

Maintenance

The Maintenance Booklet describes all the necessary maintenance work which should be performed at regular intervals.

Always have the Maintenance Booklet with you when you take the vehicle to your authorized Mercedes-Benz Center for service. The service advisor will record each service in the booklet for you.

Roadside Assistance

The Mercedes-Benz Roadside Assistance Program provides factory trained technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance number:

1-800-FOR-MERCedes (in the USA) 1-888-881-6611 (in Canada)

will be answered by Mercedes-Benz Customer Assistance Representatives 24 hours a day, 365 days a year.

For additional information refer to the Mercedes-Benz Roadside Assistance Program brochure in your vehicle literature portfolio.

Change of address or ownership

If you change your address, be sure to send in the "Change of Address Notice" found in the Service and Warranty Information Booklet, or simply call the Mercedes-Benz Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-888-881-6611. It is in your own interest that we can contact you should the need arise.

If you sell your Mercedes, please leave all literature with the vehicle to make it available to the next operator.

If you bought this vehicle used, be sure to send in the "Notice of Purchase of Used Car" found in the Service and Warranty Information Booklet, or call the Mercedes-Benz Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-888-881-6611.

Operator's Manual

Operating your vehicle outside the USA or Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- service facilities or replacement parts may not be readily available,
- unleaded gasoline for vehicles with catalytic converters may not be available; the use of leaded fuels will damage the catalysts,
- gasoline may have a considerably lower octane rating, and improper fuel can cause engine damage.

Mercedes-Benz SLR McLaren compliance

The Mercedes-Benz SLR McLaren vehicle does not comply with the state certification regulations of select states. It is not permitted to register the vehicle in such states. Check with an authorized Mercedes-Benz Center for details.

Where to find it

This Operator's Manual is designed to provide comprehensive support information for you, the vehicle operator. Each section has its own reference color.

At a glance

Here you will find an overview of all the controls that can be operated from the driver's seat.

Getting started

Here you will find all the information you need for your first drive. You should read this section first if this is your first Mercedes-Benz vehicle or if you are renting or borrowing this vehicle.

Safety and Security

Here you will find descriptions of the safety and security features in your vehicle.

Controls in detail

Here you will find detailed information about the equipment installed on your vehicle. This section expands on the "Getting started" section and also describes technical innovations. If you are already familiar with the basic functions of your vehicle, this section will be of particular interest to you.

Operation

Here you will find all the information you need for the proper operation of your vehicle.

Practical hints

This section provides fast assistance for dealing with problems you may encounter.

Technical data

All important technical data for your vehicle can be found in this section.

Indexes

The glossary provides explanations of the most important technical terms.

The table of contents and the index are designed to help you find information quickly and easily.

The following publications are part of your vehicle documentation:

- this Operator's Manual
- the Maintenance Booklet

Separate operating instructions will be provided as required depending on the equipment options installed in your vehicle.

Symbols

Symbols

Trademarks:

- ESP[®] is a registered trademark of DaimlerChrysler.
- HomeLink[®] is a registered trademark of Prince, a Johnson Controls Company.
- BabySmart[™] is a trademark of Siemens Automotive Corp.

The following symbols are found in this Operator's Manual:

* Optional equipment is identified with an asterisk.

Warning!

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

/!\

->

!

Highlights hazards that may result in damage to your vehicle.

1

Helpful hints or further information you may find useful.

- This symbol points to instructions for you to follow.
- A number of these symbols appearing in succession indicates a multiple-step procedure.
- Page This symbol tells you where to look for further information on a topic.
- This continuation symbol marks an interrupted procedure which will be continued on the next page.
 - In the glossary of technical terms, this symbol is used to indicate cross-references to term definitions.
- Display Words appearing in the multifunction display are printed in the type shown here.

Operating safety

Warning!

 \triangle

Work improperly carried out on electronic components and associated software could cause them to cease functioning. Because the vehicle's electronic components are interconnected, any modifications made may produce an undesired effect on other systems. Electronic malfunctions could seriously impair the operating safety of your vehicle.

See an authorized Mercedes-Benz Center for repairs or modifications to electronic components.

Other improper work or modifications on the vehicle could also have a negative impact on the operating safety of the vehicle.

Some safety systems only function while the engine is running. You should therefore never turn off the engine while driving.

Warning!

Heavy blows against the vehicle underbody or tires/wheels, for example when running over an obstacle, road debris or a pothole, may cause serious damage and impair the operating safety of your vehicle. If you feel a sudden significant vibration or ride disturbance, or you suspect that damage to your vehicle has occurred, you should turn on your hazard warning flashers, carefully slow down, and drive with caution to an area which is a safe distance from the road.

 Λ

Inspect the vehicle underbody and tires/wheels for possible damage. If the vehicle appears unsafe, have it towed to the nearest authorized Mercedes-Benz Center or other qualified maintenance or repair facility for further inspection or repairs.

Proper use of the vehicle

Proper use of the vehicle requires that you are familiar with the following information and rules:

- the safety precautions in this manual
- the "Technical data" section in this manual
- traffic rules and regulations
- motor vehicle laws and safety standards

/!\

Warning!

Various warning labels are attached to your vehicle. These warning labels are intended to make you and others aware of various risks. You should not remove any of these warning labels unless explicitly instructed to do so by information on the label itself. Removal of any of these labels may cause you and others to be unaware of certain risks which may result in an accident and/or personal injury.

Problems with your vehicle

Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to immediately contact an authorized Mercedes-Benz Center to have the problem diagnosed and corrected if required. If the matter is not handled to your satisfaction, please discuss the problem with the Mercedes-Benz Center management, or if necessary contact us at one of the following addresses:

In the USA:

Customer Assistance Center Attn: SLR Liaison Mercedes-Benz USA, LLC Three Paragon Drive Montvale, NJ 07645-0350

In Canada:

Customer Relations Department Mercedes-Benz Canada, Inc. 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Reporting safety defects

For the USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-888-327-4236 (or 366-0123 in Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

Vehicle data recording

Vehicle data recording

Information regarding electronic recording devices

(Including notice pursuant to California Code § 9951)

Please note that your vehicle is equipped with devices that can record vehicle systems data and, if equipped with the Tele Aid system, may transmit some data in certain accidents.

This information helps, for example, to diagnose vehicle systems after a collision and to continuously improve vehicle safety. DaimlerChrysler may access the information and share it with others

- for safety research or vehicle diagnosis purposes
- with the consent of the vehicle owner or lessee
- in response to an official request by law enforcement or other government agency
- for use in dispute resolution involving DaimlerChrysler, its affiliates or sales/service organization and/or
- as otherwise required or permitted by law.

Please check the Tele Aid subscription service agreement for details regarding the information that may be recorded or transmitted via that system.

Cockpit

Instrument cluster

Multifunction steering wheel

Center console

Overhead control panel

Control panel on the door sill



Cockpit



Cockpit

Item	Page	Item	Page
1 Hood lock release	244	(9) Steering wheel adjustment	t 43
② Cruise control lever	197	stalk	
③ Instrument cluster	28,	(10) Headlamp washer button	179
-	113	(1) Exterior lamp switch	52,
④ Multifunction steering wheel	30,		105
	118	(12) Combination switch	
5 Overhead control panel	33	Turn signals	53
6 Center console	31, 32	Windshield wipers	54
⑦ Starter switch	40	High beam	109
(8) Horn			

At a glance

Instrument cluster



P54.32-3499-31

Instrument cluster

Item		Page
Coola with	nt temperature gauge	114
****	Coolant temperature warning lamp	302
Speed	lometer with	
BRAKE	Brake warning lamp, USA only	300
(①)	Brake warning lamp, Canada only	300
	ABS/ESP [®] warning lamp	298
<u>1</u> =	Gearshift indicator Iamp	303
ول	Airbrake warning lamp	303
¢	Left turn signal indicator lamp	
\$	Right turn signal indicator lamp	
	Coolar with Speed BRAKE	Coolant temperature gauge with Image: Speeimeter with Speeimeter with Brake warning lamp, USA only Image: Speeimeter with Brake warning lamp, USA only Image: Speeimeter with Image:

	Item	Item		
3	Left n with			
	• Ou	itside temperature	115	
	• Ma	ain odometer	117	
4	Reset	button	113	
5	Tacho	ometer with	115	
	≣D	High beam headlamp indicator	109	
	CHECK ENGINE	Engine malfunction in- dicator lamp, USA only	301	
	Ċ	Engine malfunction in- dicator lamp, Canada only	301	
	(100)	Antilock Brake System (ABS) indicator lamp	299	
	(!)	Tire pressure warning lamp	305	

I	ltem	Page
	SRS Supplemental Restraint System (SRS) indicator lamp	304
	Seat belt telltale	304
\sim	Right multifunction display with	
·	Current gear selector lever position/gear range	117, 170, 171
•	 Trip odometer 	117
ľ	 Automatic transmission shift program mode 	117, 173
	Clock	131
	() Engine oil temperature indicator	303
7	Fuel gauge with	
1	For Fuel reserve warning lamp	303

Multifunction steering wheel



	Item	Page	
D	Left multifunction display in the speedometer	117	(5
2)	Right multifunction display in the tachometer	117	
	Operating control system		(6
3)	Selecting the submenu or set- ting the volume: Press button	118	
	+ up/to increase		
	down/to decrease		
Ð	Telephone: Press button	118	
	戻 to take a call		
	🙊 to end a call		

	Item	Page
5	Menu systems: Press button	118
	for next menu	
	for previous menu	
6	Moving within a menu: Press button	118
	for next display	
	for previous display	

Center console

V Center console

Upper part



	Item	Page
1	Central locking switch	103
2	Hazard warning flasher on/off switch	110
3	Central unlocking switch	104
4	Center and side air vent adjustment	182
5	Selects the shift program mode	173

	Item	Page
6	Selects the Airbrake mode	87
7	Selects the manual shift program mode	176
8	Audio system	120, 143
9	Automatic climate control	182
10	Engine start button	49

Center console


Lower part



	Item	Page
1	Exterior rear view mirror adjustment	44
2	Remote trunk opening switch	101
3	Tow-away alarm switch	92
4	ESP [®] control switch	83
5	PASSENGER AIRBAG OFF indicator lamp	75
6	Gear selector lever for automatic transmission	171
0	Parking brake	50, 57


Overhead control panel

Overhead control panel



	Item	Page
1	Left reading lamp on/off	111
2	Temperature sensor for automatic climate control	182
3	Right reading lamp on/off	111
4	Interior lighting control	111
5	Hands-free microphone for Tele Aid (emergency call system) and telephone (see separate operating instructions)	203
6	Interior rear view mirror	44, 179
0	Garage door opener	216
8	Tele Aid (emergency call system) button	208

Control panel on the door sill



	Item	Page
1	Door handle	100
2	Switches for opening/closing windows	193
3	Switch for seat adjustment	42






Unlocking

The "Getting started" section provides an overview of the vehicle's most basic functions. First-time Mercedes-Benz owners should pay special attention to the information given here.

If you are already familiar with the basic functions described here, the "Controls in detail" section will provide you with further information. The corresponding page references are located at the end of each segment.



SmartKey with remote control

1	Ð	Lock b
2	\Rightarrow	Unlock
(3)	Ð	Unlock

- outton button for trunk
- button
- **PANIC** Panic button (\triangleright page 78) (4)



(5) Door handle

► Press unlock button 🔐 on the SmartKey.

All turn signal lamps flash once. The anti-theft alarm system is disarmed.

A

The electrohydraulic brake system is activated.

Unlocking

Warning!

 \triangle

Always stand to the rear of the door before opening it, otherwise the opening action may cause injury. Outside temperature may affect door opening speed.

!

Ensure sufficient side- and overhead clearance prior to opening the doors, see "Main dimensions" (▷ page 375).

Warning!

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

 \triangle

 Press the front part of the door handle (5).

The door swings outwards and upwards automatically.

• Get in the vehicle and insert the SmartKey in the starter switch.

You will find further information in the "Controls in detail" section (\triangleright page 96).

Unlocking

Starter switch positions

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.



Starter switch

0 For removing SmartKey

- **1** Power supply for some consumers
- 2 Ignition (power supply for all consumers) and drive position. All lamps (except high beam headlamp indicator lamp and turn signal indicator lamps unless activated) in the instrument cluster come on. If a lamp in the instrument cluster fails to come on when the ignition is switched on, have it checked and replaced if necessary. If a lamp in the instrument cluster remains on after starting the engine or comes on while driving, see "Lamps in instrument cluster" (▷ page 298).

Unlocking

1

When you switch on the ignition, the indicator and warning lamps (except high beam headlamp indicator lamp and turn signal indicator lamps unless activated) in the instrument cluster come on. The indicator and warning lamps (except high beam headlamp indicator lamp and turn signal indicator lamps if activated) should go out when the engine is running. This indicates that the respective systems are operational.

!

If the SmartKey is left in the starter switch position **0** for an extended period of time, it can no longer be turned in the starter switch.

• Remove the SmartKey from the starter switch and reinsert.

If the SmartKey can still not be turned in the starter switch, the starter battery may not be sufficiently charged.

 Have the starter battery checked and charged if necessary (▷ page 358). Contact an authorized Mercedes-Benz Center.

To prevent accelerated battery discharge and a possible dead battery, always remove the SmartKey from the starter switch when the engine is not in operation.

Adjusting

Warning!

 \triangle

 $/ \$

All seat, steering wheel, and rear view mirror adjustments, as well as fastening of seat belts, must be done before the vehicle is put into motion.

Seats

Warning!

Do not adjust the driver's seat while driving. Adjusting the seat while driving could cause the driver to lose control of the vehicle.

Never place hands under the seat or near any moving parts while a seat is being adjusted.

Never ride in a moving vehicle with the seat back in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or fatal injuries. The seat back and seat belts provide the best restraint when the wearer is in a nearly upright position and belts are properly positioned on the body. Your seat must be adjusted so that you can correctly fasten your seat belt (\triangleright page 46).

Warning!

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle.

Even with the SmartKey removed from the starter switch or the vehicle, the seats can be operated. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

The seat adjustment switch is located on the door sill.



(1) Seat fore and aft adjustment

Seat height

/!\

③ Seat angle

Adjusting

Seat fore and aft adjustment

 Slide the switch forwards or backwards in the direction of arrow (1).

Adjust seat to a comfortable seating position that still allows you to reach the accelerator/brake pedal safely. The position should be as far rearward as possible, consistent with ability to properly operate controls.

!

When moving the seat, make sure that there are no items in the footwell or behind the seat. Otherwise you could damage the seat.

Seat height

 Slide the switch up or down in the direction of arrow (2).

Seat angle

 Slide the switch up or down in the direction of arrow (3).


Steering wheel

Warning!

Do not adjust the steering wheel while driving. Adjusting the steering wheel while driving could cause the driver to lose control of the vehicle.

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle.

Even with the SmartKey removed from the starter switch or the vehicle, the steering wheel can be adjusted. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury. The stalk for steering wheel adjustment is located on the lower left of the steering column.



Adjusting steering column, in or out
 Adjusting steering column, up or down

Adjusting

Adjusting steering column in or out

Move stalk forward or back in the direction of arrow ① until a comfortable steering wheel position is reached with your arms slightly bent at the elbow.

Adjusting steering column up or down

Press the lever up or down in the direction of arrow (2). Make sure that you can move your legs freely and that you can see all the displays in the instrument cluster clearly.

Mirrors

Adjust the interior and exterior rear view mirrors before driving so that you have a good view of the road and traffic conditions.

Warning!

In case of an accident, liquid electrolyte may escape the mirror housing if the mirror glass breaks.

Electrolyte has an irritating effect. Do not allow the liquid to come into contact with eyes, skin, clothing, or respiratory system. In case it does, immediately flush affected area with water, and seek medical help if necessary.

!

Electrolyte drops coming into contact with the vehicle paint finish can be completely removed only while in the liquid state and by applying plenty of water.

Interior rear view mirror

► Manually adjust the rear-view mirror.

For more information, see "Rear view mirrors" (\triangleright page 179).

Exterior rear view mirrors

shoulder before changing lanes.

Warning!

/!\


Exercise care when using the passenger-side exterior rear view mirror. The mirror surface is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your interior rear view mirror or glance over your

/!\

44

Adjusting

The buttons are located on the lower part of the center console.



- Driver's side exterior rear view mirror button
- (2) Passenger-side exterior rear view mirror button
- ③ Adjustment button

- Switch on the ignition (\triangleright page 40).
- Press button ① for the driver's side exterior rear view mirror or button ② for passenger-side exterior rear view mirror.
- Push adjustment button ③ up, down, left, or right according to the desired setting.

1

At low ambient temperatures, the exterior rear view mirrors will be heated automatically.

For more information, see "Rear view mirrors" (\triangleright page 179).

Driving

Warning!

 \triangle

Do not lay any objects in the driver's footwell. Be careful that floor mats or carpets in the driver's footwell have sufficient clearance for the pedals.

During sudden driving or braking maneuvers the objects could get caught between the pedals. You could then no longer brake or accelerate.

Fastening the seat belts

Warning!

 \land

Always fasten your seat belt before driving off. Always make sure your passenger is properly restrained, even pregnant women.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident. You and your passenger should always wear seat belts. If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are wearing your seat belt. The airbags can only provide the protection they were designed to afford if the occupants are using their seat belts (\triangleright page 69).

Warning!

Children 12 years old and under must never ride in this vehicle, except in a Mercedes-Benz authorized BabySmart[™] compatible child seat, which operates with the BabySmart[™] system installed in the vehicle to deactivate the passenger front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury will result.

Infants and small children must be seated in an appropriate BabySmartTM compatible infant or child restraint system, which is properly secured with the vehicle's seat belt and top tether strap, fully in accordance with the child seat manufacturer's instructions.



Driving

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

Warning!

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a nearly upright position and the belt is properly positioned on the body.

Warning!

Never let more people ride in the vehicle than there are seat belts available. Be sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

/!\

 \triangle

Warning!

Read and observe the additional warning notices printed in the "Safety and Security" (\triangleright page 67) and (\triangleright page 69).



Seat belt holder
 Latch plate
 Buckle
 Release button

Driving

- ▶ Pull the belt smoothly from seat belt holder ①.
- Place the shoulder portion of the belt across the top of your shoulder and the lap portion across your hips.
- Push latch plate (2) into buckle (3) until it clicks.
- If necessary, tighten the lap portion to a snug fit by pulling shoulder portion up.

Proper use of seat belts

- Do not twist the belt when fastening.
- Adjust seat belt so that the shoulder portion is located as close as possible to the middle of the shoulder (it should not touch the neck). Never pass the shoulder portion of the belt under your arm.
- Position the lap belt as low as possible on your hips (over hip joint) and not across the abdomen.

- Place the seat backrest in a nearly upright position.
- Never use a seat belt for more than one person at a time.
- Do not fasten a seat belt around a person and another object at the same time. When using a seat belt to secure infant or toddler restraints or children in booster seats, always follow the child seat manufacturer's instructions.
- Check your seat belt during travel to make sure that it is properly positioned.
- Make sure that the seat belt is always fitted snugly. Take special care of this when wearing loose clothing.

Warning!

Do not pass belts over sharp edges. They could tear.

/!\

Do not allow the belt to get caught in the door or in the seat adjustment mechanism. This could damage the belt.

Never attempt to make modifications to seat belts. This could impair the effectiveness of the belts.

Do not bleach or dye seat belts as this may severely weaken them. In a crash, they may not be able to provide adequate protection.

Damaged seat belts or belts that were highly stressed in an accident must be replaced. Contact an authorized Mercedes-Benz Center.

Driving

Starting the engine

Warning!



Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide, and inhaling it can cause unconsciousness and possible death.


Do not run the engine in confined areas (such as garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open.



Gearshift pattern

- P Park position with gear selector lever lock
- **R** Reverse gear
- N Neutral
- **D** Drive position

For more information, see "Automatic transmission" (\triangleright page 167).



Cover
 Start button

- Make sure the gear selector lever is set to **P**.
- Do not depress the accelerator.
- Switch on the ignition (\triangleright page 40).
- ▶ Lift up cover ①.
- Press start button ② once.
 - The engine starts.

 $\triangleright \triangleright$

Driving

 $\triangleright \triangleright \blacktriangleright$ Close cover (1).

Warning!



Make sure the cover of the start button is closed after starting the engine. Otherwise you could be injured on the open cover in an accident or during driving maneuvers.

For information on turning off the engine, see "Turning off the engine" (\triangleright page 58).

Starting difficulties


If the engine does not start as described, carry out the following steps:

- ► Turn the SmartKey in the starter switch to position **0** and repeat starting procedure (▷ page 49).
- Remember that extended starting attempts can drain the battery.

If the engine does not start after several starting attempts, there could be a malfunction in the engine electronics or in the fuel supply system.

 Notify an authorized Mercedes-Benz Center.

Parking brake



Release button
 Parking brake lever





When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake, which could result in an accident and/or serious injury.

Driving

 Pull lever (2) upwards slightly, press release knob (1) and move the lever down to the stop.

The warning lamp BRAKE (USA only) or (Canada only) in the instrument cluster goes out.

Driving off

Depress the brake pedal.

The gear selector lever lock is released.

 Place the gear selector lever in position D or R.

Warning!

It is dangerous to shift the gear selector lever out of \mathbf{P} or \mathbf{N} if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

On slippery road surfaces, never downshift

in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not pre-

vent this type of loss of control.

Warning!

 \land

!

In order to avoid damage to the transmission:

- Wait for the gear selection process to complete before setting the vehicle in motion.
- Place the gear selector lever in position **R** or **P** only when the vehicle is stopped.
- Release the brake pedal.
- Carefully depress the accelerator pedal.

Once the vehicle is in motion, the automatic central locking system engages. $\triangleright \triangleright$

Driving

H

$\triangleright \triangleright$

If you hear a warning signal and the message:

Release

parking brake

appears in the multifunction display when driving off, you have forgotten to release the parking brake.

Release the parking brake.

After a cold start, the transmission engages at a higher revolution. This allows the catalytic converter to reach its operating temperature earlier.

!

Do not run cold engine at high engine speed. Running a cold engine at high engine speed may shorten the service life of the engine.

!

Simultaneously depressing the accelerator pedal and applying the brake reduces engine performance and causes premature brake and drivetrain wear.

1

You can open a locked door from the inside. Open door only when conditions are safe to do so.

You can deactivate the automatic locking using the control system (\triangleright page 137).

Switching on headlamps

Low beam headlamps

The exterior lamp switch is located on the dashboard to the left of the steering wheel.



Exterior lamp switch

Lights off
 Low beam headlamps on

► Turn switch to ■D.

For more information on headlamps, see "Lighting" (\triangleright page 105).

Driving

High beam

The combination switch is located on the left of the steering column.



Combination switch

High beam
 High beam flasher


 Push combination switch in direction of arrow (1).

The high beam indicator **D** in the instrument cluster comes on.

For more information on high beam, see "Combination switch" (▷ page 109).

Turn signals

The combination switch is located on the left of the steering column.



Combination switch

Turn signals, right
 Turn signals, left

down ②. The corresponding turn signal indicator

lamp 🗢 or 🖒 in the instrument cluster flashes.

Press the combination switch up (1) or

The combination switch automatically returns to its original position once the steering wheel has been turned far enough.


1

To signal minor directional changes, such as a lane change, move combination switch to point of resistance only and release. The turn signal flashes three times.

Driving

Windshield wipers

The combination switch is located on the left of the steering column.



Combination switch

(1) Single wipe Wiping with windshield washer fluid

- (2) Switching on windshield wipers
- Switch on the ignition (\triangleright page 40).

!

Do not operate the wipers when the windshield is dry. Dust that accumulates on a windshield might scratch the glass and/or damage the wiper blades when wiping occurs on a dry windshield. If it is necessary to operate the wipers in dry weather conditions, always operate the wipers with windshield washer fluid (▷ page 55).

Switching on windshield wipers

- Turn the combination switch to the desired position depending on the intensity of the rain.
 - 0 Windshield wipers off
 - I Intermittent wiping
 - II Normal wiper speed
 - **III** Fast wiper speed

Intermittent wiping

!

Do not leave windshield wipers in intermittent setting when the vehicle is taken to an automatic car wash or during windshield cleaning. Wipers will operate in the presence of water sprayed on the windshield, and wipers may be damaged as a result.

Intermittent wiping interval is dependent on wetness of windshield.

► Set the wiper switch to position I.

After the initial wipe, pauses between wipes are automatically controlled by the rain sensor.

1

Intermittent wiping is interrupted when the vehicle is at a standstill and a front door is opened.

Driving

Single wipe

 Press combination switch briefly in direction of arrow (1).

The windshield wipers wipe one time without washer fluid.

Wiping with windshield washer fluid

 Press combination switch in direction of arrow (1) past the resistance point.

The windshield wipers operate with washer fluid.

To prevent smears on the windshield, wipe with windshield washer fluid every now and then even when it is raining.

For information on filling up the washer reservoir, see "Windshield washer system and headlamp cleaning system" (> page 252).

!

If anything blocks the windshield wipers (leaves, snow, etc.), switch them off immediately.

- For safety reasons, stop the vehicle in a safe location, withdraw SmartKey from starter switch before attempting to remove any blockage.
- The hood must be opened

 (> page 244) before folding the wiper arms away from the windshield. You could otherwise damage the hood and/or the wiper arm.
- Remove blockage.
- Turn the windshield wipers on again.

If windshield wipers fail to function at all in switch position **I**,

- set the combination switch to the next highest wiper speed
- have the windshield wipers checked at the nearest authorized Mercedes-Benz Center

¹

Driving

Problems while driving

The engine runs erratically and misfires

- An ignition cable may be damaged.
- The engine electronics may not be operating properly.
- Unburned gasoline may have entered the catalytic converter and damaged it.
- ► Give very little gas.
- Have the problem repaired by an authorized Mercedes-Benz Center as soon as possible.

The coolant temperature is above 248°F (120°C)

The coolant is too hot and is no longer cooling the engine.

- Stop the vehicle as soon as possible in a safe location and turn off the engine. Allow engine and coolant to cool.
- ► Check the coolant level and add coolant if necessary (▷ page 250).

In case of accident

If the vehicle is leaking gasoline:

- Do not start the engine under any circumstances.
- Notify local fire and/or police authorities.

If the extent of the damage cannot be determined:

 Notify an authorized Mercedes-Benz Center.

If no damage can be determined on the

- major assemblies
- fuel system
- engine mount:
- ► Start the engine in the usual manner.

Parking and locking

Parking and locking

You have now completed your first drive. You have properly stopped and parked your vehicle. End your drive as follows.

Warning!



With the engine not running, there is no power assistance for the brake and steering system. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.

Warning!

Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

To reduce the risk of personal injury as a result of vehicle movement, before turning off the engine and leaving the vehicle always:

- Keep right foot on brake pedal.
- Pull the parking brake lever up as many notches as possible.
- Move the gear selector lever to position P.
- Slowly release brake pedal.
- When parked on an incline, turn front wheels towards the road curb.
- Turn the SmartKey in the starter switch to position **0** and remove the SmartKey from the starter switch.
- Take the SmartKey and lock the vehicle when leaving.

Parking brake

 $/! \$



1 Parking brake lever

 Pull parking brake lever ① up as many notches as possible.

When the engine is running, the warning lamp BRAKE (USA only) or ((1)) (Canada only) in the instrument cluster will be illuminated. DD

Parking and locking

 $\triangleright \triangleright$

Warning!

 \triangle

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake and/or move the gear selector lever from position **P**, either of which could result in an accident and/or serious injury.

Warning!

Getting out of your vehicle with the gear selector lever not fully engaged in position **P** is dangerous. Also, when parked on an incline, position **P** alone may not prevent your vehicle from moving, possibly hitting people or objects.

Always set the parking brake in addition to shifting to position P (\triangleright page 49).

When parked on an incline, turn front wheels towards the road curb.

Switching off headlamps

► Turn the exterior lamp switch to o (▷ page 52).

For more information on headlamps, see "Lighting" (\triangleright page 105).

Turning off the engine

 Place the gear selector lever in position P.

1

 \triangle

Always set the parking brake in addition to shifting to position **P**.

On slopes, turn the front wheels towards the road curb.

► Turn the SmartKey in the starter switch to position **0** and remove the SmartKey from the starter switch.

The immobilizer is activated.

0

The SmartKey can only be removed from the starter switch with the gear selector lever in position **P**.

Parking and locking

Releasing seat belts

 Press the seat belt release button (> page 47).

Allow the retractor to completely rewind the seat belt by guiding the latch plate.

!

Make sure the seat belt retracts fully so that the seat belt and/or latch plate cannot get caught or pinched in the door or in the seat mechanism. This can damage the seat belt and impair the effectiveness of the seat belt, and/or cause damage to the door and/or door trim panel. Such damage is not covered by the Mercedes-Benz Limited Warranty.

Damaged seat belts must be replaced. Contact an authorized Mercedes-Benz Center.

Locking

Warning!

To prevent possible personal injury, always keep hands and fingers away from the door openings when closing the doors. Be especially careful when small children are around.

Before closing doors, make sure there is no possibility of someone getting caught in a door during closing.

∕!∖

Warning!

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

1

With the SmartKey removed from the starter switch and the driver's door open, a warning sounds and the message Turn off lamps appears in the multifunction display if the vehicle's exterior lamps are not switched off.

► After exiting the vehicle, press the lock button for on the SmartKey (▷ page 38).

With the hood, trunk and all doors closed, all turn signal lamps flash three times. The anti-theft alarm system is armed.

For more information, see "Locking and unlocking" (▷ page 96).

Occupant safety

Panic alarm

Driving safety systems

Performance enhancement system

Anti-theft systems



Occupant safety

In this section you will learn the most important facts about the restraint systems of the vehicle.

The restraint systems are

- Seat belts
- Emergency tensioning device
- Airbags
- Child seats
- Child seat recognition

As independent systems, their protective effects work in conjunction with each other.

Ð

For information on infants and children traveling with you in the vehicle and restraint systems for infants and children, see "Children in the vehicle" (\triangleright page 72).

The **SRS** indicator lamp in the instrument cluster comes on

- for about 4 seconds when you turn the SmartKey in the starter switch to position **1**. It then goes out briefly, comes on again and remains lit until you start the engine or turn the SmartKey to position **2**.
- for about 4 seconds when you turn the SmartKey in the starter switch to position **2**.
- for about 4 seconds when you start the engine using the start button (▷ page 49).

The **SRS** indicator lamp goes out shortly after you start the engine. This shows that the restraint systems are operational.

A malfunction in the system has been detected if the **SRS** indicator lamp

- fails to go out after approximately 4 seconds
- does not come on at all
- comes on after the engine was started or while driving

For more information, see the "Practical hints" section (\triangleright page 304).

Occupant safety

Warning!

In the event that the **SRS** indicator lamp comes on during driving or does not come on at all, the SRS self-check has detected a malfunction. For your safety, we strongly recommend that you visit an authorized Mercedes-Benz Center immediately to have the system checked, otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

In addition, improper repair work creates a risk of rendering the SRS inoperative or causing unintended airbag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.

Airbags

 $/ \mathbb{N}$

Warning!

Airbags are designed to reduce the potential of injury and fatality in certain frontal impacts (front airbags, knee airbags) or side impacts (head-thorax airbags). However, no system available today can totally eliminate injuries and fatalities.

The activation of the airbags temporarily releases a small amount of dust from the airbags. This dust, however, is neither injurious to your health, nor does it indicate a fire in the vehicle. The dust might cause some temporary breathing difficulty for people with asthma or other breathing trouble. To avoid this, you may wish to get out of the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the airbag inflates, then get fresh air by opening a window or door.

Warning!



To reduce the risk of injury when the front airbags inflate, it is very important for the driver and front passenger to always be in a properly seated position and to wear your seat belts.

For maximum protection in the event of a collision always be in normal seated position with your back against the backrest. Fasten your seat belt and make sure that it is properly positioned on your body (\triangleright page 46).

Since the airbag inflates with considerable speed and force, a proper seating and hands on steering wheel position will help to keep you at a safe distance from the airbag. Occupants who are unbelted, out of position or too close to the airbag can be seriously injured or killed by an airbag as it inflates with great force in the blink of an eye:

• Sit properly belted in a nearly upright position with your back against the seat backrest.

 $\triangleright \triangleright$

Occupant safety

 $\triangleright \triangleright$

- Adjust the driver seat as far as possible rearward, still permitting proper operation of vehicle controls. The distance from the center of the driver's breastbone to the center of the airbag cover on the steering wheel must be at least ten inches (25 cm) or more. You should be able to accomplish this by a combination of adjustments to the seat and steering wheel. If you have any problems, please see an authorized Mercedes-Benz Center.
- Do not lean with your head or chest close to the steering wheel or dashboard.
- Keep hands on the outside of steering wheel rim. Placing hands and arms inside the rim can increase the risk and potential severity of hand/arm injury when driver front airbag inflates.

- Adjust the front passenger seat as far as possible rearward from the dashboard when the seat is occupied.
- Occupants, especially children, should never lean their heads in the area of the door where the head-thorax airbag inflates. This could result in serious injuries or death should the airbag be triggered. Always sit nearly upright, properly use the seat belts and appropriate size infant or child restraint system.
- Children 12 years old and under must never ride in this vehicle, except in a Mercedes-Benz authorized BabySmartTM compatible child seat, which operates with the BabySmartTM system installed in the vehicle to deactivate the passenger front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury will result.

Failure to follow these instructions can result in severe injuries to you or other occupants.

If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

Occupant safety

Warning!

Should you choose to place a child 12 years old or under in the passenger seat of your vehicle, you must properly use a BabySmart[™] child restraint which will turn off the passenger front airbag (▷ page 72). BabySmart[™] will not, however, turn off any side impact airbag.

∕!∖

It should be noted, however, that there is a possibility for a head-thorax airbag related injury if occupants, especially children, are not properly seated or restrained when next to a head-thorax airbag which needs to deploy rapidly in a side impact in order to do its job. To help avoid the possibility of injury, please follow these guidelines:

- Occupants, especially children, should never place their bodies or lean their heads in the area of the door where the head-thorax airbag inflates. This could result in serious injuries or death should the head-thorax airbag be activated.
- (2) Always sit nearly upright, properly use the seat belts and use an appropriately sized infant or child restraint system for all children 12 years old or under.
- (3) Always wear seat belts properly.

If you believe that, even with the use of these guidelines, it would be safer for your passenger seat occupants to have the passenger side head-thorax airbag deactivated, then deactivation can be accomplished upon your written election to do so at an authorized Mercedes-Benz Center at an additional cost. Please contact your local authorized Mercedes-Benz Center or call our Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) for details.

Occupant safety

1

Airbags are designed to activate only in certain frontal impacts (front airbags, knee airbags) and side impacts (head-thorax airbags) which exceed preset thresholds. Only during these types of impacts, if of sufficient severity to meet the deployment threshold, will they provide their supplemental protection.

The driver and passengers should always wear their seat belts. Otherwise it is not possible for the airbags to provide their intended supplemental protection. In cases of other frontal impacts, angled impacts, roll-overs, other side impacts, rear collisions, or other accidents and impacts below airbag deployment thresholds, the airbags will not be activated. The driver and passenger will then be protected to the extent possible by a properly fastened seat belt.

We caution you not to rely on the presence of the airbags in order to avoid wearing your seat belt. Your vehicle was originally equipped with airbags which are designed to activate in certain impacts exceeding a preset threshold to reduce the potential and severity of injury. It is important to your safety and that of your passenger that you replace deployed airbags and repair any malfunctioning airbags to ensure that the vehicle will continue to provide supplemental crash protection for occupants.

Occupant safety

Safety guidelines for the seat belt, emergency tensioning device and airbag

Warning!

- Damaged seat belts or belts that were highly stressed in an accident must be replaced and their anchoring points must also be checked. Only use belts installed or supplied by an authorized Mercedes-Benz Center.
- Airbags and ETDs (Emergency Tensioning Devices) are designed to function on a one-time-only basis. An airbag or ETD that was activated must be replaced.
- No modifications of any kind may be made to any components or wiring of the SRS. This includes changing or removing any component or part of the SRS, the installation of additional trim material, badges, etc. over the steering wheel hub, passenger front airbag cover, outboard sides of the front seat backrests, door trim panels, or door trim panels, and installation of additional

electrical/electronic equipment on or near SRS components and wiring. Keep area between airbags and occupants free from objects (e.g. packages, purses, umbrellas, etc.).

- Do not pass belts over sharp edges. They could tear.
- Do not make any modification that could change the effectiveness of the belts.
- Do not bleach or dye seat belts as this may severely weaken them. In a crash, they may not be able to provide adequate protection.
- Airbag system components will be hot after an airbag has inflated. Do not touch.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.

- In addition, improper repair work on the SRS creates a risk of rendering the SRS inoperative or causing unintended airbag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.
- For your protection and the protection of others, when scrapping the airbag unit or emergency tensioning device, our safety instructions must be followed. These instructions are available from your authorized Mercedes-Benz Center.
- Given the considerable deployment speed and the textile structure of the airbags, there is the possibility of abrasions or other injuries resulting from airbag deployment.

When you sell your vehicle, we strongly urge you to give notice to the subsequent owner that it is equipped with an SRS by alerting them to the applicable section in the Operator's Manual.



Occupant safety

Front airbags

Driver and passenger airbags are deployed:

- in the event of certain frontal impacts
- if impact exceeds a preset deployment threshold
- independently of the head-thorax airbags

The airbags will not deploy in impacts which do not exceed the system's deployment thresholds. You will then be protected by the fastened seat belts.

The passenger airbag will only be deployed if:

- the passenger seat is occupied
- the PASSENGER AIRBAG OFF indicator lamp in the lower part of the center console is not lit (▷ page 75)
- the impact exceeds a preset deployment threshold




Driver airbag
 Passenger airbag

!

Do not place objects heavier than 20 lbs (9 kg) on the front passenger seat. This could cause the front airbag, the knee airbag or the head-thorax airbag on the front passenger side to deploy in a crash which exceeds the system's deployment threshold.

Knee airbags



Knee airbag, driver's side
 Knee airbag, passenger side

The kneebag airbags are located on the lower instrument panel. They are designed to operate together with the front airbags in certain frontal impacts exceeding a preset threshold. The knee airbags operate best in conjunction with a properly positioned and fastened seat belts and when the footwell is kept clear of objects.

Occupant safety

Head/thorax airbags



1 Head/thorax airbag

The head-thorax airbags are deployed:

- on the impacted side of the vehicle
- in impacts exceeding a preset deployment threshold
- independently of the front airbags

The head-thorax airbags are not deployed in impacts which do not exceed the system's deployment threshold.

The passenger head-thorax airbag will only deploy if the system senses that the passenger seat is occupied.

Seat belts

When the engine is started, the seat belt telltale is illuminates to remind you and your passenger to fasten your seat belts. If the driver's seat belt is not fastened before the engine is started, the seat belt telltale is illuminates and a warning chime sounds for approximately 6 seconds when the engine is started.

Always wear your seat belt. All vehicle occupants always need to have their seat belts fastened and wear them properly.

In addition, applicable motor vehicle safety laws require you to wear seat belts. Even where this is not the case, we strongly recommend that all vehicle occupants have their seat belts fastened and wear them properly.

For information on fastening seat belts, see "Fastening the seat belts" (▷ page 46).

1

For information on infants and children traveling with you in the vehicle and restraint systems for infants and children, see "Children in the vehicle" (\triangleright page 72).

Occupant safety

Warning!

 \triangle

Always fasten your seat belt before driving off. Always make sure your passenger is properly restrained, even pregnant women.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident. You and your passenger should always wear seat belts.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are wearing your seat belt. The airbags can only provide the protection they were designed to afford if the occupants are using their seat belts (\triangleright page 69).

Warning!

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a nearly upright position and the belt is properly positioned on the body.

Warning!



/!\

Never let more people ride in the vehicle than there are seat belts available. Be sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

Warning!

 \wedge

Damaged seat belts or belts that were highly stressed in an accident must be replaced and their anchoring points must also be checked.

Only use seat belts which have been approved by Mercedes-Benz.

Do not make any modifications to the seat belts. This can lead to failure of the seat belts.

Do not bleach or dye seat belts as this may severely weaken them. In a crash, they may not be able to provide adequate protection.

Have all work carried out only by qualified technicians. Contact an authorized Mercedes-Benz Center.

Occupant safety

Warning!

USE SEAT BELTS PROPERLY

- Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in case of an accident.
- Each occupant should wear their seat ٠ belt at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver airbag, passenger airbag, knee airbags, head-thorax airbags) and ETD (seat belt emergency tensioning device). The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front airbags, knee airbags and ETD) and side (head-thorax airbags and ETD) impacts which exceed preset deployment thresholds.
- Never wear the shoulder belt under your arm, against your neck or off your shoulder. In a crash, your body would move too far forward. That would increase the chance of head and neck injuries. The belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.
- Never wear belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys, etc., as these might cause injuries.
- Position the lap belt as low as possible on your hips and not across the abdomen. If the belt is positioned across your abdomen, it could cause serious injuries in a crash.

- Never use a seat belt for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects.
- Belts should not be worn twisted. In a crash, you wouldn't have the full width of the belt to manage impact forces. The twisted belt against your body could cause injuries.
- Pregnant women should also use a lap-shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Never place your feet on the instrument panel, dashboard or on the seat. Always keep both feet on the floor in front of the seat.

Occupant safety

Emergency tensioning device (ETD), seat belt force limiter

The seat belts are equipped with emergency tensioning devices and belt force limiters.

The ETD is designed to activate in the following cases when the seat belts are fastened:

- in frontal or rear-end impacts exceeding a preset severity level
- if the restraint systems are operational and functioning correctly, see sns indicator lamp (▷ page 62)

In an impact, emergency tensioning devices remove slack from the belts in such a way that the seat belts fit more snugly against the body. Belt force limiters reduce the force exerted by the seat belts on occupants during a crash.

Warning!

An emergency tensioning device (ETD) that was activated must be replaced.

 \wedge

When disposing of the emergency tensioning device, our safety instructions must be followed. These are available at your authorized Mercedes-Benz Center.

!

Do not place objects heavier than 20 lbs (9 kg) on the front passenger seat. This could cause the front or side impact airbag on the passenger side and, with the seat belt fastened to secure the object, the ETD to deploy in a crash which exceeds the system's deployment threshold.

Children in the vehicle

If an infant or child is traveling with you in the vehicle:

- Secure the child using an infant or child restraint appropriate to the age and size of the child.
- Make sure the infant or child is properly secured at all times while the vehicle is in motion.

Infant and child restraint seats and information on choosing an appropriate restraint system can be obtained from any Mercedes-Benz Center.

Occupant safety

Infant and child restraint systems

Only use a BabySmart[™] compatible child restraint for the front passenger seat in this vehicle.

We recommend all infants and children be properly restrained at all times while the vehicle is in motion.

The passenger lap-shoulder belt has a special seat belt retractor for the secure fastening of child restraints.

To fasten a child restraint follow child restraint instructions for mounting. Then pull the shoulder belt out completely and let it retract. During the seat belt retraction a ratcheting sound can be heard to indicate that the special seat belt retractor is activated. The belt is now locked. Push down on child restraint to take up any slack. To deactivate, release seat belt buckle and let seat belt retract completely. The seat belt can again be used in the usual manner.

Warning!

Never release the seat belt buckle while the vehicle is in motion, since the special seat belt retractor will be deactivated.

!

∕∖∖

The use of infant or child restraints is required by law in all 50 states, the District of Columbia, the U.S. territories, and all Canadian provinces.

Infants and small children should be seated in an appropriate infant or child restraint system which is properly secured by a lap-shoulder belt and top tether strap that complies with U.S. Federal Motor Vehicle Safety Standard 213 and Canadian Motor Vehicle Safety Standard 213.

A statement by the child restraint manufacturer of compliance with this standard can be found on the instruction label on the restraint and in the instruction manual provided with the restraint.

Occupant safety

When using any infant or child restraint system, be sure to carefully read and follow all manufacturer's instructions for installation and use.

Please read and observe warning labels affixed to inside of vehicle and to infant or child restraints.

Warning!

 \wedge

Children 12 years old and under must never ride in this vehicle, except in a Mercedes-Benz authorized BabySmart[™] compatible child seat, which operates with the BabySmart[™] system installed in the vehicle to deactivate the passenger front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury will result. Infants and small children must be seated in an appropriate BabySmartTM compatible infant or child restraint system, which is properly secured with the vehicle's seat belt and top tether strap, fully in accordance with the child seat manufacturer's instructions.

Infants and small children should never share a seat belt with another occupant. During an accident, they could be crushed between the occupant and seat belt.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

Adjust the passenger seat as far as possible rearward from the dashboard when the seat is occupied.

Warning!

Children too big for child restraint systems should use regular seat belts. Position the shoulder belt across chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper belt positioning for children from 41 lbs until they reach a height where a lap/shoulder belt fits properly without a booster.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from becoming a projectile in the event of an accident.

Do not leave children unattended in the vehicle; even if the children are secured in a child restraint system. Unsupervised children in a child restraint system may use vehicle equipment and cause an accident and/or serious personal injury.

Occupant safety

BabySmart[™] airbag deactivation system



 PASSENGER AIRBAG OFF indicator lamp

Special BabySmart[™] compatible child seats, designed for use with the Mercedes-Benz system and available at any authorized Mercedes-Benz Center, are required for use with the BabySmart[™] airbag deactivation system. With the special child seat properly installed, the passenger front airbag and the passenger knee airbag will not deploy. The PASSENGER AIRBAG OFF indicator lamp ① located on the lower part of the center console will be illuminated, except with the SmartKey removed or in starter switch position **0**.

1

The system does not deactivate the head-thorax airbag and the emergency tensioning device.

Self-test BabySmart[™] without special child seat installed

After turning the SmartKey in the starter switch to position **1** or **2**, the PASSENGER AIRBAG OFF indicator lamp comes on for approximately 6 seconds and then goes out.

If the PASSENGER AIRBAG OFF indicator lamp should not come on or is continuously lit, the system is not functioning. You must see an authorized Mercedes-Benz Center before seating any child on the front passenger seat.

Occupant safety

Warning!



The BabySmartTM airbag deactivation system will ONLY work with a special child seat designed to operate with it. It will not work with child seats which are not BabySmartTM compatible.

Never place anything between seat cushion and child seat (e.g. pillow), since it reduces the effectiveness of the deactivation system. The bottom of the child seat must make full contact with the passenger seat cushion. An incorrectly mounted child seat could cause injuries to the child in case of an accident, instead of protecting the child.

Follow the manufacturer's instructions for installation of special child seats.

Warning!

When using a BabySmart[™] compatible child seat on the passenger seat, the passenger front airbag will not deploy only if the PAS-SENGER AIRBAG OFF indicator lamp (▷ page 75) remains illuminated.

Please be sure to check the PASSENGER AIRBAG OFF indicator lamp every time you use the special system child seat. Should the PASSENGER AIRBAG OFF indicator lamp go out while the restraint is installed, please check installation. If the PASSENGER AIR-BAG OFF indicator lamp remains out, do not use the BabySmartTM restraint to transport children on the passenger seat until the system has been repaired.

Warning!

/!\

 \wedge

Do not place powered-on laptops, cell phones, electronic tags such as those used in ski passes and like electronic devices on front passenger seat. Signals from such devices may interfere with the BabySmartTM system. Such signal interference may cause the PASSENGER AIRBAG OFF indicator lamp (\triangleright page 75) not to come on during self-test or be continuously lit, indicating that the system is not functioning.

Occupant safety

Installation of infant and child restraint systems


This vehicle is equipped with a tether anchorage for a top tether strap behind the passenger seat.

(1) Cover of anchorage ring

- ► To have better access to the anchorage ring, move the passenger seat forward (▷ page 43).
- Remove cover (1) in direction of the arrow from anchorage ring (3).

 Guide tether strap according to the child restraint manufacturer's instructions.

Make sure the tether strap is not twisted.



P91.40-2512-3

 Tighten the top tether strap according to the child restraint manufacturer's instructions.

 Reinstall cover ① after removing the tether strap.

2 Hook

③ Anchorage ring

 Securely fasten hook ②, which is part of the tether strap, to anchorage ring ③.

1

For safety, make sure the hook has attached to the ring beyond the safety catch, as illustrated. • Move the passenger seat back as far to the rear as possible.

Once the top tether anchorage hook is attached, the child restraint itself can be secured.

 Properly secure the child restraint using the passenger seat lap/shoulder

Panic alarm

An audible alarm and flashing exterior lamps will operate for approximately 3 minutes.



PANIC button

1

USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1

Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Activating

 Press and hold button ① for at least 1 second.

Deactivating

▶ Press button ① again.

or

▶ Insert the SmartKey in starter switch.

Driving safety systems

Driving safety systems

In this section you will find information on the following driving safety systems:

- ABS (Antilock Brake System)
- BAS (Brake Assist System)
- ESP[®] (Electronic Stability Program)
- Electrohydraulic brake system

1

In winter operation, the maximum effectiveness of the ABS, the BAS, the ESP[®], and the electrohydraulic brake system is only achieved with winter tires (▷ page 287) or snow chains as required.

Warning!

The following factors increase the risk of accidents:

- Excessive speed, especially in turns
- Wet and slippery road surfaces
- Following another vehicle too closely

The ABS, BAS, $\text{ESP}^{\circledast},$ and electrohydraulic brake system cannot reduce this risk.

Always adjust your driving style to the prevailing road and weather conditions.

ABS

/!\

Warning!



Do not pump the brake pedal. Use firm, steady brake pedal pressure instead. Pumping the brake pedal defeats the purpose of the ABS and significantly reduces braking effectiveness.

The Antilock Brake System (ABS) regulates the brake pressure so that the wheels do not lock during braking. This allows you to maintain the ability to steer your vehicle.

The ABS is functional above a speed of approximately 5 mph (8 km/h) independent of road surface conditions.

On slippery road surfaces, the ABS will respond even to light brake pressure.

Driving safety systems

The \bigcirc indicator lamp in the instrument cluster comes on (\triangleright page 29) when you switch on the ignition. It goes out when the engine is running.

Braking

If the ABS activates during braking, the ABS/ESP[®] warning lamp in the instrument cluster dial flashes. Because of the electrohydraulic brake system, you will not feel any pulsation in the brake pedal.

 Keep firm and steady pressure on the brake pedal.

Continuous, steady brake pedal pressure yields the advantages provided by the ABS, namely braking power and the ability to steer the vehicle. The ABS/ESP[®] warning lamp flashes whenever the ABS is activated which can be an indication of hazardous road conditions and functions as a reminder to take extra care while driving.

Emergency brake maneuver

 Keep continuous, full pressure on the brake pedal.

Warning!

The ABS cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction. The ABS cannot prevent accidents, including those resulting from excessive speed in turns, following another vehicle too closely, or hydroplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of an ABS equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

/!\

For more information, see the "Practical hints" section (▷ page 299).

Driving safety systems

BAS

The Brake Assist System (BAS) operates in emergency situations. If you apply the brakes very quickly, the BAS automatically provides full brake boost thereby potentially reducing the braking distance. Apply continuous full braking pressure until the emergency braking situation is over. The ABS will prevent the wheels from locking.

When you release the brake pedal the brakes function again as normal. The BAS is then deactivated.

Warning!

BAS cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase braking efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction. The BAS cannot prevent accidents, including those resulting from excessive speed in turns, following another vehicle too closely, or hydroplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of a BAS equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

ESP[®]

 \triangle

The Electronic Stability Program (ESP[®]) is operational as soon as the engine is running and monitors the vehicle's traction (force of adhesive friction between the tires and the road surface) and handling.

The ESP[®] recognizes when a wheel is spinning or if the vehicle starts to skid. By applying brakes to the appropriate wheel and by limiting the engine output, the ESP[®] works to stabilize the vehicle. The ESP[®] is especially useful while driving off and on wet or slippery road surfaces. The ESP[®] also stabilizes the vehicle during braking maneuvers.

The ABS/ESP[®] warning lamp in the instrument cluster (\triangleright page 29) flashes when the ESP[®] is engaged.

The ABS/ESP[®] warning lamp \bigwedge in the instrument (\triangleright page 28) cluster comes on when you switch on the ignition. It goes out when the engine is running.

Driving safety systems

Warning!



Never switch off the ESP[®] when you see the ABS/ESP[®] warning lamp flashing in the instrument cluster. In this case proceed as follows:

- While driving off, apply as little throttle as possible.
- While driving, ease up on the accelerator.
- Adapt your speed and driving style to the prevailing road conditions.

Failure to observe these guidelines could cause the vehicle to skid.

Warning!

The ESP[®] cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase the traction afforded. The ESP[®] cannot prevent accidents, including those resulting from excessive speed in turns, or hydroplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of an ESP[®] equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

!

Because of the ESP's[®] automatic operation, the engine must be shut off (SmartKey in starter switch position **0** or **1**) when

- the parking brake is being tested on a brake test dynamometer
- the vehicle is towed with the front axle raised

Active braking action through the ESP[®] may otherwise seriously damage the brake system.

The ESP[®] will only function properly if you use wheels of the recommended tire size (\triangleright page 371).

For more information, see the "Practical hints" section (▷ page 299).

Driving safety systems

Switching off the ESP®

Warning!

The ESP[®] should not be switched off during normal driving other than in the circumstances described below. Disabling of the system will reduce vehicle stability in standard driving maneuvers.

To improve the vehicle's traction, turn off the ESP[®] in driving situations where it would be advantageous to have the drive wheels spin and thus cut into surfaces for better grip such as:

- when driving with snow chains
- in deep snow
- in sand or gravel

When you switch off the ESP®

- the ESP[®] does not stabilize the vehicle
- the engine output is not limited, which allows the drive wheels to spin and thus cut into surfaces for better grip
- the traction control will still brake a spinning wheel
- the ESP[®] continues to operate when you are braking

1

When the ESP[®] is switched off and one or more drive wheels are spinning, the ABS/ESP[®] warning lamp in the instrument cluster flashes. However, the ESP[®] will then not stabilize the vehicle.

Turn on the ESP[®] immediately if the aforementioned circumstances do not apply anymore. The switch is located on the lower part of the center console.



- (1) ESP[®] switch (off/on)
- ▶ Press switch ①.

The ABS/ESP[®] warning lamp in the instrument cluster comes on.

The ESP[®] is deactivated.

Driving safety systems

Warning!



When the ABS/ESP[®] warning lamp is illuminated continuously, the ESP[®] is switched off.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP^{\circledast} .

!

Avoid spinning of a drive wheel for an extended period with the ESP[®] switched off. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Switching on the ESP®

Press switch (1) again.

The ESP[®] warning lamp in the speedometer goes out.

You are now again in normal driving mode with the ESP[®] switched on.

Electrohydraulic brake system

The electrohydraulic brake system combines a hydraulic brake circuit with electronically controlled brake servo assistance. You have increased braking safety and improved braking comfort.

Warning!



Never ignore a brake malfunction indicated in the speedometer display, for example by the **DRAKE** (USA only) or (()) (Canada only) indicator lamp. Refer to the "Practical hints" section (\triangleright page 300). Also read and observe the messages in the instrument cluster multifunction display (\triangleright page 319).

Warning!

The electrohydraulic brake system requires electrical power to operate.

A malfunction in the vehicle's power supply or electrical system may impair brake system operation and switch it into its emergency operation mode. In such a case, the red brake warning lamp (▷ page 300) comes on and warning messages (▷ page 319) appear in the multifunction display while driving. To brake, the driver must then apply significantly greater brake pedal pressure and depress the pedal much further to obtain the expected braking effect. If necessary, apply full pressure to the brake pedal. Stopping distance is increased!

If there is a malfunction in the electrohydraulic brake system, we recommend that the vehicle be transported with all wheels off the ground using flatbed or appropriate wheel lift/dolly equipment.

Driving safety systems

A tow bar must be used if circumstances do not permit the use of the recommended towing methods and the vehicle requires towing with all four wheels on the ground. Towing the vehicle with all four wheels on the ground is only permissible for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h). For more information, see "Towing the vehicle" (\triangleright page 360).

The electrohydraulic brake system is automatically activated when you

- unlock the vehicle with the SmartKey
- open the driver's or passenger door
- turn the SmartKey in the starter switch to position 1
- depress the brake pedal
- release the parking brake

1

If the electrohydraulic brake system is activated as the brake pedal is first depressed, you may feel a reduced pedal resistance and longer pedal travel than normal. When releasing the pedal, you may also feel the brake pedal pulsate and you may hear a sound which is caused by the activation of the electrohydraulic brake system pump. This is normal and not an indication of a malfunction. Pedal travel returns to normal when you release the brake pedal and the sound soon ceases.

If you experience the above while driving and the red brake warning lamp (\triangleright page 300) illuminates and/or warning messages appear in the multifunction display (\triangleright page 319), the brake system is malfunctioning. Follow the instructions of the warning message(s) and have the brake system checked immediately.

Warning!

 \wedge

Have brake pad replacement and other work on the electrohydraulic brake system carried out by qualified technicians only. Contact your Mercedes-Benz Center for further information. The electrohydraulic brake system must be deactivated prior to working on the system. High pressure is intermittently built up in the system as part of its automatic self-test. In addition, the system is automatically activated when the vehicle is unlocked by remote control, when the driver or passenger door is opened, when the SmartKey in the starter switch is turned to position 1, when the brake pedal is depressed or when the parking brake is released. Failure to deactivate the system prior to maintenance will cause brake pistons to extend and brake fluid to leak, which may result in injuries (contusions and acid burns). Extended brake pistons may also cause injury.

Driving safety systems

The electrohydraulic brake servo assistance switches off automatically

- approximately 2 minutes after you turned the SmartKey in the starter switch to position **0** or removed the SmartKey
- approximately 20 seconds after you locked the vehicle from outside

Note on driving with the electrohydraulic brake system

- Following extended periods of only minor loads to your brake system, you should occasionally apply the brakes when traveling at high speeds. This improves the grip of the brake pads and prevents possible brake noise.
- After driving on wet or snow-covered roads, you should apply your brakes firmly before parking your vehicle. This produces heat which serves to dry the brake disks.
 - Warning!



Make sure not to endanger any other road users when carrying out these braking maneuvers.

- On long and steep grades, shift to a lower gear (gear range 1, 2, or 3) to prevent the brakes from overheating and to reduce brake wear.
- After hard braking, it is advisable to drive on for some time so that the air stream will cool down the brakes faster.
- Only Mercedes-Benz approved components (e.g. brake pads) should be installed on your vehicle. Brake pads not approved by Mercedes-Benz may impair the safety of your vehicle.

Performance enhancement system

Performance enhancement system

Airbrake

The Airbrake enhances the vehicle's driving stability. It adapts the aerodynamics of the vehicle to the driving conditions according to the speed and the mode set.

This is achieved using a moveable spoiler.

The Airbrake is located at the rear edge of the trunk lid.

/!\

Warning!

When operating the Airbrake, make sure there is no danger of anyone being harmed by the Airbrake operation (i.e. raising and lowering of flap). Be especially careful when small children are around.

Warning!

The following factors increase the risk of accidents:

- Excessive speed, especially in turns
- Wet and slippery road surfaces
- Following another vehicle too closely

The Airbrake cannot reduce this risk.

Always adjust your driving style to the prevailing road and weather conditions.

1


If the ESP^\circledast is active, the Airbrake is automatically deactivated.

1

In winter operation, the maximum effectiveness of the Airbrake is only achieved with winter tires (M+S tires) or snow chains as required.

Performance enhancement system

The Airbrake switch is on the upper part of the center console.



Airbrake modes

- 1 Manual
- 2 Automatic
- ③ Test
- (4) Airbrake switch
- ▶ Switch on the ignition (▷ page 40).

The system runs a self-test to ensure correct operation of the Airbrake.

Test mode

The test mode allows you to check that the Airbrake is functioning correctly.

This mode can only be activated when the vehicle is at standstill.

► Slide Airbrake switch ④ to position ③.

The Airbrake swings upwards to an angle of 62° .

• Release the Airbrake switch.

The Airbrake returns to its initial position.

Manual mode

In this mode, the Airbrake is set to an angle of 30°. The driver downforce mode enhances handling in all conditions.

► Slide the Airbrake switch ④ to position ①.

The Airbrake swings upwards to an angle of 30° and stays in this position.

1

In manual mode, the Airbrake automatic function is activated in an emergency braking situation, see "Automatic mode" (> page 89).

!

Before deactivating manual mode, check the Airbrake for any objects which may have become lodged, e.g. branches or leaves, and remove them.

Otherwise the Airbrake can no longer function correctly.

Performance enhancement system

Automatic mode

This mode should be used for normal driving conditions.

 Slide the Airbrake switch (4) to position (2).

With the ignition on, the Airbrake swings upwards to an angle of 5° and then returns to its initial position.

When the vehicle exceeds a speed of 60 mph (95 km/h), the Airbrake swings up to an angle of 10° .

Rapid braking

If you need to brake in an emergency from a speed of more than 60 mph (95 km/h), the Airbrake automatically swings upwards to an angle of 62° .

This allows you to achieve the best possible braking performance in an emergency.

Warning!



Hard braking activates the Airbrake which may block the view through the interior rear view mirror. In this case, monitor the traffic behind you through the exterior rear view mirrors.

Anti-theft systems

Immobilizer

The immobilizer prevents unauthorized persons from starting your vehicle.

Activating

Removing the SmartKey from the starter switch activates the immobilizer.

Deactivating

Inserting the SmartKey in the starter switch deactivates the immobilizer.

6

In case the engine cannot be started (yet the vehicle's battery is charged), the system is not operational. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in the USA), or 1-888-881-6611 (in Canada).

Anti-theft alarm system

Once the alarm system has been armed, a visual and audible alarm is triggered when someone opens

- a door
- the trunk
- the hood
- a storage compartment in the rear
- the storage compartment under the armrest.

The alarm system will also be triggered when

- someone attempts to raise the vehicle
- someone opens a door from the inside if the vehicle was locked with the SmartKey
- someone opens the trunk with the emergency release button

1

The alarm will stay on, even if the activating element (a door, for example) is immediately closed.

If the alarm stays on for more than 30 seconds, a call to the Response Center is initiated automatically by the Tele Aid system (▷ page 215) provided Tele Aid service was subscribed to and properly activated, and that necessary cellular service and GPS coverage are available.

Anti-theft systems

Arming the alarm system

► Lock the vehicle with the SmartKey.

The turn signal lamps flash three times to indicate that the alarm system is activated. The indicator lamp in the central locking switch (▷ page 104) begins to flash after arming the alarm system.

1

If the turn signal lamps do not flash three times, one of the following elements may not be properly closed:

- a door
- the trunk
- the hood

Close the respective element and lock the vehicle again.

Disarming the alarm system

► Unlock your vehicle with the SmartKey.

The turn signal lamps flash once to indicate that the alarm system is disarmed.

1

The alarm system will rearm automatically after approximately 40 seconds if neither a door nor the trunk lid was opened.

Canceling the alarm

To cancel the alarm:

 Press button or on the SmartKey.

or

 Insert the SmartKey in the starter switch.

Anti-theft systems

Tow-away alarm

Once the tow-away alarm is armed, a visual and audible alarm will be triggered when someone attempts to raise the vehicle.

1

The tow-away protection alarm is triggered, for example, if the vehicle is lifted on one side.

If the alarm stays on for more than 30 seconds, a call to the Response Center is initiated automatically by the Tele Aid system (▷ page 215) provided Tele Aid service was subscribed to and properly activated, and that necessary cellular service and GPS coverage are available.

Arming tow-away alarm

► Lock your vehicle with the SmartKey.

The tow-away alarm is automatically armed after about 30 seconds.


1

When you unlock your vehicle, the tow-away protection disarms automatically. The tow-away alarm remains disarmed until you lock the vehicle again.

Disarming tow-away alarm

To prevent triggering the tow-away alarm, switch off the tow-away alarm feature before towing the vehicle, or when parking on a surface subject to movement, such as a ferry or auto train.

The button is located on the lower part of the center console.



Tow-away alarm off button
 Indicator lamp

Anti-theft systems

 Switch off the ignition and remove the SmartKey.

1

You cannot disarm the tow-away alarm while the ignition is switched on.

▶ Press button ①.

Indicator lamp (2) in button (1) comes on briefly.

 Exit and lock your vehicle with the SmartKey.

The tow-away alarm remains disarmed until you lock your vehicle again.

Canceling the alarm

To cancel the alarm:

 Press button or for on the SmartKey.

or

 Insert the SmartKey in the starter switch.

Locking and unlocking

Lighting

Instrument cluster

Control system

Audio system

Automatic transmission

Good visibility

Automatic climate control

Power windows

Driving systems

Useful features



Locking and unlocking

In the "Controls in detail" section you will find detailed information on how to operate the equipment installed on your vehicle. If you are already familiar with the basic functions of your vehicle, this section will be of particular interest to you.

To quickly familiarize yourself with the basic functions of the vehicle, refer to the "Getting started" section of this manual. The corresponding page numbers are given at the beginning of each segment.


SmartKey

Your vehicle comes supplied with two SmartKeys, each with remote control and a removable mechanical key.

The SmartKey provides an extended operating range. To prevent theft, however, it is advisable to only unlock the vehicle when you are in close proximity to it.

The SmartKey centrally locks and unlocks:

- the doors
- the trunk
- the fuel filler flap



SmartKey with remote control

-) 🔒 Lock button
-) 🔰 Unlock button for trunk
- (3) Mechanical key locking tab
- (4) Unlock button
- (5) Battery check lamp
- 6 PANIC Panic button

Locking and unlocking

Warning!

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. It is possible for children to open a locked door from the inside, which could result in an accident and/or serious injury.

!

To prevent possible malfunction, avoid exposing the SmartKey to high levels of electromagnetic radiation.

0

USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

0

Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1

You can also open and close the power windows using the SmartKey, see "Summer opening feature" (▷ page 195) and "Convenience closing feature" (▷ page 196).

When you unlock the vehicle, the electrohydraulic brake system is activated.

Locking and unlocking

Factory setting

Global unlocking

Press button .

All turn signal lamps flash once. The anti-theft alarm system is disarmed.

The vehicle will lock again automatically and reactivate the anti-theft alarm system within approximately 40 seconds of unlocking if:

- neither door nor trunk is opened
- the SmartKey is not inserted in the starter switch
- the central locking switch is not activated

Global locking

Press button .

With the hood, trunk and all doors closed, all turn signal lamps flash three times. The anti-theft alarm system is armed.

Selective setting

If you frequently travel alone, you may wish to reprogram the SmartKey so that pressing only unlocks the driver's door and the fuel filler flap.

Press and hold buttons and simultaneously for about 5 seconds until battery check lamp (5) flashes twice.

The SmartKey will then function as follows:

Unlocking driver's door and fuel filler flap

Press button once.

All turn signal lamps flash once. The anti-theft alarm system is disarmed.

Global unlocking

Press button twice.

All turn signal lamps flash once. The anti-theft alarm system is disarmed.

Global locking

▶ Press button 🔒.

With the hood, trunk and all doors closed, all turn signal lamps flash three times. The anti-theft alarm system is armed.

Locking and unlocking

Restoring to factory setting

► Press and hold buttons and a simultaneously for about 6 seconds until battery check lamp (5) (▷ page 96) flashes twice.

!

If you can no longer lock or unlock the vehicle with the SmartKey, then either the batteries in the SmartKey are discharged, the SmartKey is malfunctioning or the vehicle battery is drained.

- Check the batteries in the SmartKey (▷ page 99) and replace them if necessary (▷ page 346).
- Use the mechanical key to unlock the vehicle (▷ page 344).
- Have the vehicle battery and the battery connections checked. Contact an authorized Mercedes-Benz Center.

If the SmartKey is malfunctioning, contact an authorized Mercedes-Benz Center.

Checking the batteries

Press button or .

Battery check lamp (5) (▷ page 96) comes on briefly to indicate that the SmartKey batteries are in order.

!

If battery check lamp (5) does not come on briefly during check, then the SmartKey batteries are discharged.

• Replace the batteries (\triangleright page 346).

You can obtain the required batteries at any authorized Mercedes-Benz Center.

1

If the batteries are checked within signal range of the vehicle, pressing button or will lock or unlock the vehicle accordingly.

Unlocking and opening the trunk

You can unlock the trunk separately.

A minimum height clearance of 5.5 ft (1.65 m) is required to open the trunk lid.

 Press and hold button until the trunk lid unlocks and opens slightly.

Loss of SmartKey or mechanical key

If you lose a SmartKey or mechanical key, you should do the following:

- ► Have the SmartKey deactivated by an authorized Mercedes-Benz Center.
- Report the loss of the SmartKey or the mechanical key immediately to your car insurance company.
- If necessary, have the trunk lock replaced.

Your authorized Mercedes-Benz Center will be glad to supply you with a replacement.

Locking and unlocking

Opening the doors

Opening from the outside

For information on opening the doors from the outside, see "Getting started" (\triangleright page 38).

Opening from the inside

You can open a locked door from the inside. Open the door only if the vehicle is stationary and when conditions are safe to do so.



Inside door handle

Pull on door handle ①.

The door swings outwards and upwards automatically.

Ensure sufficient side- and overhead clearance prior to opening the doors, see "Main dimensions" (▷ page 375).

1

1

If the vehicle has previously been locked with the SmartKey, opening a door from the inside will trigger the anti-theft alarm system.

To cancel the alarm, do one of the following:

- Press button or or on the SmartKey.
- Insert the SmartKey in the starter switch.

Opening the trunk

Opening the trunk from the outside

A minimum height clearance of 5.5 ft (1.65 m) is required to open the trunk lid.

The handle is located above the rear license plate recess.



Trunk lock
 Handle

Locking and unlocking

The vehicle must be unlocked.

Pull on handle ② and lift the trunk lid.

Always make sure that there is sufficient overhead clearance.

The trunk can also be opened using button on the SmartKey or from its inside in an emergency, see "Trunk emergency release" (▷ page 102).

Opening the trunk from the inside

You can open the trunk from the inside if the vehicle is stationary.

A minimum height clearance of 5.5 ft (1.65 m) is required to open the trunk lid.

The switch is located on the lower part of the center console.



- (1) Remote trunk opening switch
- Press remote trunk lid release switch (1) until the trunk lid unlocks and opens slightly.
- Lift the trunk lid.

!

Always make sure that there is sufficient overhead clearance.

The trunk can also be opened using button on the SmartKey or from its inside in an emergency, see "Trunk emergency release" (▷ page 102).

Closing the trunk lid

Warning!



To prevent possible personal injury, always keep hands and fingers away from the trunk opening when closing the trunk lid. Be especially careful when small children are around.

Only drive with the trunk closed as, among other dangers such as blocked visibility, exhaust fumes may enter the vehicle interior.

Handle

Locking and unlocking

► Lower trunk lid by firmly pulling on handle ①.

!

Do not pull on the Airbrake. Otherwise the Airbrake could be damaged.

1

Do not place the SmartKey in the open trunk. You may lock yourself out.

If the vehicle was previously centrally locked, the trunk lid will lock automatically after closing it. The turn signals will flash three times to confirm locking.

Trunk emergency release

The emergency release button is located on the inside of the trunk lid.

With the emergency release button, the trunk can be opened from inside the trunk.



Emergency release button

 Briefly press emergency release button.

The trunk unlocks and the trunk lid opens slightly.

Push up the trunk lid to fully open.

1

The emergency release button unlocks the trunk while the vehicle is standing still or in motion.

Illumination of the emergency release button:

- The button will flash for 30 minutes after opening the trunk.
- The button will flash for 60 minutes after closing the trunk.

Locking and unlocking

1

The emergency release button does not open the trunk lid if the vehicle battery is discharged or disconnected.

If the vehicle has previously been locked from the outside with the SmartKey, opening the trunk from the inside using the emergency release button will trigger the anti-theft alarm system.

To cancel the alarm, do one of the following:

- Press button or or on the SmartKey.
- Insert the SmartKey in the starter switch.

Automatic locking

The doors and the trunk lock automatically when the vehicle is set into motion.

You can open a locked door from the inside. Open door only when conditions are safe to do so.

1

The doors unlock automatically after an accident if the force of the impact exceeds a preset threshold.

The vehicle locks automatically when the ignition is switched on and the wheels are turning at vehicle speeds of approximately 9 mph (15 km/h) or more. You could therefore lock yourself out when the vehicle

- is pushed
- is on a test stand

You can deactivate the automatic locking using the control system (\triangleright page 137).

Locking and unlocking from the inside

You can lock or unlock the vehicle from inside using the central locking switches. This can be useful, for example, if you want to unlock the passenger door from the inside or want to lock the vehicle before starting to drive.

The central locking switch does not lock or unlock the fuel filler flap.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

Locking and unlocking

Warning!



You can open a locked door from inside at any time. Open door only when conditions are safe to do so.

The switches are located on the upper part of the center console.



Central locking switches

Locking
 Unlocking

Locking

▶ Press central locking switch ①.

If all the doors are closed, the vehicle locks.

Unlocking

Press central locking switch (2).
 The vehicle unlocks.

1

If the vehicle was previously centrally locked using the SmartKey, it will not unlock using the central locking switch.

If the vehicle was previously locked with the central locking switch

- while in the global remote control mode, the complete vehicle is unlocked when a door is opened from the inside
- while in the selective remote control mode, only the door opened from the inside is unlocked

Lighting

Lighting

For information on how to switch on the headlamps and use the turn signals, see "Switching on headlamps" (\triangleright page 52) and (\triangleright page 53).

Ð

If you drive in countries where vehicles drive on the other side of the road than the country where the vehicle is registered, you must have the headlamps modified for symmetrical low beams. Relevant information can be obtained at your authorized Mercedes-Benz Center.

Exterior lamp switch

The exterior lamp switch is located on the dashboard to the left of the steering wheel.



- 0 Off
- Automatic headlamp mode
- Parking lamps (also tail lamps, license plate lamps, side marker lamps, instrument panel lamps)
- Low beam headlamps (or high beam headlamps when the combination switch is pushed forward) and parking lamps

- P≤→ Standing lamps, right (turn left one stop)
- ►P≤ Standing lamps, left (turn left two stops)

1

If you remove the SmartKey from the starter switch and open the driver's door while the parking lamps or low beam headlamps are switched on, then

- a warning sounds
- appears in the left multifunction display
- the message Turn off lamps appears in right multifunction display

Lighting

Manual headlamp mode

The low beam headlamps and the parking lamps can be switched on and off with the exterior lamp switch.

Automatic headlamp mode

The following lamps switch on and off automatically depending on the brightness of the ambient light:

- Low beam headlamps
- Tail and parking lamps
- License plate lamps
- Side marker lamps

Warning!

If the exterior lamp switch is set to AUTO,

• the headlamps may switch off unexpectedly when the system senses bright ambient light, for example light from oncoming traffic.

/!\

• the headlamps will not be automatically switched on under foggy conditions.

To minimize risk to you and to others, activate headlamps by turning exterior lamp switch to D when driving or when traffic and/or ambient lighting conditions require you to do so.

In low ambient lighting conditions, only switch from position Auro to D with the vehicle at a standstill in a safe location. Switching from Auro to D will briefly switch off the headlamps. Doing so while driving in low ambient lighting conditions may result in an accident. The automatic headlamp feature is only an aid to the driver. The driver is responsible for the operation of the vehicle's lights at all times.

 Turn the exterior lamp switch to position Auto.

With the SmartKey in starter switch position **1**, only the parking lamps will switch on and off automatically.

When the engine is running, the low beam headlamps, the tail and parking lamps, the license plate lamps, and the side marker lamps will switch on and off automatically.

1

Fog lamps cannot be switched on with the exterior lamp switch in position Auro. For switching on the fog lamps, turn the exterior lamp switch to position D first.

Lighting

Daytime running lamp mode

 Turn the exterior lamp switch to position 0 or AUTO.

When the engine is running, the low beam headlamps are switched on.

In low ambient light conditions, the following lamps will switch on additionally:

- Tail and parking lamps
- License plate lamps
- Side marker lamps

For nighttime driving you should turn the exterior lamp switch to position **D** to permit activation of the high beam head-lamps.

0

With the daytime running lamp mode activated and the exterior lamp switch in position **o**, the high beam headlamps cannot be switched on.

The high beam flasher is available at all times.

Canada only:

The daytime running lamp mode is mandatory and therefore in a constant mode.

When the engine is running, and you shift from a driving position to position \mathbf{N} or \mathbf{P} , the low beam headlamps will switch off with a three-minute delay.

When the engine is running, and you

- turn the exterior lamp switch to position switch on additionally.
- turn the exterior lamp switch to position ID, the manual headlamp mode has priority over the daytime running lamp mode.

The corresponding exterior lamps switch on (\triangleright page 105).

USA only:

By default, the daytime running lamp mode is deactivated. Activate the daytime running lamp mode using the control system, see "Setting daytime running lamp mode (USA only)" (▷ page 132).

When the engine is running, and you turn the exterior lamp switch to position 100%or 100%, the manual headlamp mode has priority over the daytime running lamp mode.

The corresponding exterior lamps switch on (\triangleright page 105).

Lighting

Locator lighting and night security illumination

The locator lighting and the night security illumination are described in the "Control system" section, see "Setting locator lighting" (▷ page 133) and "Setting night security illumination" (▷ page 134).

Fog lamps

Warning!

 \wedge

In low ambient lighting or foggy conditions, only switch from position Auro to D with the vehicle at a standstill in a safe location. Switching from Auro to D will briefly switch off the headlamps. Doing so while driving in low ambient lighting conditions may result in an accident.

1

Fog lamps will operate with the parking lamps and/or the low beam headlamps on. Fog lamps should only be used in conjunction with low beam headlamps. Consult your State or Province Motor Vehicle Regulations regarding permissible lamp operation.

0

Fog lamps cannot be switched on with the exterior lamp switch in position Auro. For switching on the fog lamps, turn the exterior lamp switch to position FD first.

Front fog lamps

- Switch on the low beam headlamps (▷ page 105).
- Pull out the exterior lamp switch to first stop.

The front fog lamps switch on.

The green indicator lamp in the exterior lamp switch comes on.

• Push in the exterior lamp switch.

The front fog lamps switch off.

The green indicator lamp in the exterior lamp switch goes out.

Lighting

Rear fog lamp (driver's side only)

- Switch on the front fog lamps (▷ page 108).
- Pull out the exterior lamp switch to second stop.

The rear fog lamp switches on.

The yellow indicator lamp **O**# in the exterior lamp switch comes on.

 Push in the exterior lamp switch to first stop.


The rear fog lamp switches off.

The yellow indicator lamp **O**[‡] in the exterior lamp switch goes out.

The front fog lamps remain lit.

Combination switch

The combination switch is located on the left of the steering column.



- **Combination switch**
- High beam
 High beam flasher

High beam

- Push the combination switch in direction of arrow (1) to switch on the high beam.

The high beam headlamp indicator lamp \blacksquare in the instrument cluster comes on (\triangleright page 29).

 Pull the combination switch in direction of arrow (2) to its original position to switch off the high beam.

The high beam headlamp indicator lamp **D** in the instrument cluster goes out.

High beam flasher

 Pull the combination switch briefly in direction of arrow 2.

Lighting

Hazard warning flasher

The hazard warning flasher can be switched on at all times, even with the SmartKey removed from the starter switch.

The hazard warning flasher switches on automatically when an airbag deploys.

The hazard warning flasher switch is located on the upper part of the center console.



(1) Hazard warning flasher switch

Switching on hazard warning flasher

 Press hazard warning flasher switch ①.

All turn signals are flashing.

1

With the hazard warning flasher activated and the combination switch set for either left or right turn, only the respective turn signals will operate when the ignition is switched on.

Switching off hazard warning flasher

Press hazard warning flasher switch (1) again.


1

If the hazard warning flasher has been activated automatically, press hazard warning flasher switch ① once to switch it off.

Lighting

Interior lighting

The controls are located in the overhead control panel.



- 1) Left-hand reading lamp on/off
- (2) Right-hand reading lamp on/off
- ③ Interior lighting on/off
- ④ Automatic control on/off

Automatic control

Activating

- Slide switch ④ to the left.
 Interior lamps switches on in darkness when you
 - unlock the vehicle
 - open a door
 - remove the SmartKey from the starter switch

In addition, the entry/exit lamps in the door come on when you open a door.

The interior lamps are switched off after a preset time, see "Interior lighting delayed switch-off" (\triangleright page 135).

1

If a door remains open, the interior lamps switch off automatically after approximately 5 minutes.

Deactivating

▶ Slide switch ④ to the right.

The interior lighting and the entry/exit lamps remain switched off in darkness, even when you

- unlock the vehicle
- open a door
- remove the SmartKey from the starter switch

Lighting

Manual control

Switching interior lighting on

▶ Press switch ③.

The interior lighting switches on.

!

Make sure the interior lighting is switched off when leaving the vehicle.

Switching interior lighting off

▶ Press switch ③ again.

The interior lighting switches off.

Reading lamps

The reading lamps are integrated into the interior rear view mirror.

- Press reading lamp switch (1) or (2) to switch on the desired reading lamp.
- Press reading lamp switch ① or ② again to switch off the respective reading lamp.

Trunk lamp

The trunk lamp switches on if the trunk is opened.

If you leave the trunk open for an extended period of time, the trunk lamp will switch off automatically after approximately 10 minutes.

The setting selected for the interior lighting is used for the trunk lighting as well.

Courtesy lighting

For better orientation in the dark, courtesy lamps will illuminate the interior of your vehicle.

When you open a door:

• the driver's and passenger's footwells

If the SmartKey is in starter switch position **1**:

• the center console

1

The center console is lit from the interior rear view mirror.

Instrument cluster

Instrument cluster

For a full view illustration of the instrument cluster, see (\triangleright page 28).



1 Reset button

The instrument cluster is activated when you

- open a door
- switch on the ignition
- press the reset button ①
- switch on exterior lamps

Opening a door will activate the instrument cluster only for about 30 seconds.

You can change the instrument cluster settings in the Instrument cluster submenu of the control system (\triangleright page 129).

Instrument cluster illumination

Use the reset button (1) to adjust the illumination brightness for the instrument cluster and the switches on the center console.

The instrument cluster illumination is dimmed or brightened to suit ambient light conditions.

To brighten illumination

► Turn the reset button ① clockwise.

The instrument cluster illumination will brighten.

To dim illumination

 Turn the reset button ① counterclockwise.

The instrument cluster illumination will dim.

Instrument cluster

Coolant temperature gauge

Warning!



- Driving when your engine is badly overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.
- Steam from an overheated engine can cause serious burns an can occur just by opening the hood. Stay away from the engine if you see or hear steam coming from it.

Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

!

Excessive coolant temperature triggers the coolant temperature warning lamp (\triangleright page 302) and a warning in the multifunction display (\triangleright page 323).

During severe operating conditions, e.g. stop-and-go traffic, the coolant temperature may rise close to 248°F (120°C).

The engine should not be operated with the coolant temperature above 248°F (120°C). Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

Instrument cluster

Resetting the trip odometer

- Make sure you are viewing the trip odometer in the right multifunction display (▷ page 117).
- If it is not displayed, press button or on the multifunction steering wheel until the trip odometer appears in the right multifunction display.
- Press and hold the reset button ①
 (▷ page 113) until the trip odometer is reset.

Tachometer

The red marking on the tachometer $(\triangleright$ page 29) denotes excessive engine speed.

!

Avoid driving at excessive engine speeds, as it may result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

To help protect the engine, the fuel supply is interrupted if the engine is operated within the red marking.

Outside temperature indicator

Warning!



The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose.

Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.

The outside temperature is displayed in the left multifunction display (\triangleright page 117). For information on how to select the unit of the displayed temperature, i.e. degrees Celsius (°C) or degrees Fahrenheit (°F), see "Selecting temperature display mode" (\triangleright page 129).

Instrument cluster

The temperature sensor is located in the front bumper area. Due to its location, the sensor can be affected by road or engine heat during idling or slow driving. Therefore, the accuracy of the displayed temperature can only be verified by comparison to a thermometer placed next the sensor, not by comparison to external displays, e.g. bank signs, etc.

When moving the vehicle into colder ambient temperatures (e.g. when leaving your garage), you will notice a delay before the lower temperature is displayed.

A delay also occurs when ambient temperatures rise. This prevents inaccurate temperature indications caused by heat radiated from the engine during idling or slow driving.

Control system

Control system

The control system is activated as soon as the SmartKey in the starter switch is turned to position **1**. The control system enables you to

- call up information about your vehicle
- change vehicle settings

For example, you can use the control system to find out when your vehicle is next due for service, to set the language for messages in the instrument cluster display, and much more.

Warning!

A driver's attention to the road and traffic conditions must always be his/her primary focus when driving.

/!\


For your safety and the safety of others, selecting features through the multifunction steering wheel should only be done by the driver when traffic and road conditions permit it to be done safely.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximate-ly 14 m) every second.

The control system relays information to the multifunction display.

Multifunction display

The multifunction display consists of the display fields in the speedometer and the tachometer. In its default state, the left display field shows the outside temperature and main odometer, while the trip odometer and the clock appears in the right display field. This default setting is referred to as the standard display.




Standard display

- (1) Main odometer
- (2) Outside temperature
- (3) Current gear selector lever posi
 - tion/gear range
- (4) Trip odometer
- (5) Automatic transmission shift program
 - mode
- 6 Clock

Control system

Multifunction steering wheel


The displays in the multifunction display and the settings in the control system are controlled by the buttons on the multifunction steering wheel (\triangleright page 30).



- (1) Left multifunction display in the speedometer
- (2) Right multifunction display in the tachometer

Operating the control system

- (3) Selecting the submenu or setting the volume: Press button
 - up/to increase
 - down/to decrease
- (4) Telephone: Press button



lo end a call

- (5) Menu systems: Press button
 - for next menu F
 - for previous menu 一一间
- 6 Moving within a menu: Press button
 - for next display \bigtriangleup
 - for previous display

Pressing any of the buttons on the multifunction steering wheel will alter what is shown in the multifunction display.

The information available in the multifunction display is arranged in menus, each containing a number of functions or submenus.

Control system

The individual functions are then found within the relevant menu (radio or CD operations under AUDIO, for example). These functions serve to call up relevant information or to customize the settings for your vehicle. It is helpful to think of the menus, and the functions within each menu, as being arranged in a circular pattern.

- If you press button are or repeatedly, you will pass through each menu one after the other.
- If you press button I or repeatedly, you will pass through each function display, one after the other, in the current menu.

In the Settings menu, instead of functions you will find a number of submenus for calling up and changing settings. For instructions on using these submenus, see "Settings menu" (▷ page 126).

The number of menus available in the system depends on which optional equipment is installed in your vehicle.


The menus are described on the following pages.

Control system

Menus

This is what you will see when you scroll through the menus.

The table on the next page provides an overview of the individual menus.



Control system

Menus, submenus and functions

	Menu (1)	Menu (2)	Menu ③	Menu ④	Menu (5)	Menu 6
	Standard display	AUDIO	Vehicle status message memory ¹	Settings	Trip computer	Telephone
	(⊳ page 122)	(⊳ page 123)	(⊳ page 124)	(⊳ page 126)	(⊳ page 137)	(⊳ page 139)
submenus	Digital speedometer	Selecting radio station	Calling up vehicle malfunction, warn- ing and system sta- tus messages stored in memory	Resetting to factory settings	Fuel consumption statistics after start	Loading phone book
	Calling up mainte- nance service dis- play	Operating the CD player		Instrument cluster submenu	Fuel consumption statistics since the last reset	Searching for name in phone book
Commands/	Checking tire infla- tion pressure			Time submenu	Calling up range	
				Lighting submenu		
				Vehicle submenu		

¹ The Vehicle status message memory menu is only displayed if there is a message stored.

Control system

1

The headings used in the menus table are designed to facilitate navigation within the system and are not necessarily identical to those shown in the control system displays.


The first function displayed in each menu will automatically show you which part of the system you are in.

Standard display menu

A

The left display field shows the outside temperature and main odometer, while the trip odometer and the clock appears in the right display field. This is the standard display.

You can have the outside temperature displayed instead of the digital speedometer. You can select the setting in the submenu Inst. cluster via the function Select display (> page 130).



Standard display

- (1) Main odometer
- (2) Outside temperature
- (3) Current gear selector lever position/gear range
- (4) Trip odometer
- (5) Automatic transmission shift program mode
- 6 Clock
- If you see another display, press button or repeatedly until the standard display appears.
- Press button results or to select the functions in the standard display menu.

Control system

The following functions are available:

Function	Page
Calling up digital speedometer	123
Calling up maintenance service display	289
Checking tire inflation pressure	266

Display digital speedometer

▶ Press button 🛆 once.

The current vehicle speed is shown in the multifunction display.

AUDIO menu

The functions in the AUDIO menu operate the audio equipment which you currently have turned on.


If no audio equipment is currently turned on, the message AUDIO OFF appears in the multifunction display.

The following functions are available:

Function	Page
Selecting radio station	123
Operating CD player	124

Selecting radio station

- ► Turn on the radio (▷ page 146).
- Press button or repeatedly until you see the currently tuned station in the right display.



③ Setting for station selection using memory

 $\triangleright \triangleright$

Control system

▷▷► Press button ♥ or ▶ repeatedly until the desired station is found.

The type of search depends on the setting for the station tuning $(\triangleright$ page 136):

- Memory: the next stored station is selected (SP)
- Station search


1

You can only store new stations using the corresponding feature on the radio (\triangleright page 151).

You can also operate the radio in the usual manner.

Operating the CD player

- ► Turn on the radio and select the CD player (▷ page 156).
- Press button or repeatedly until the settings for the CD currently being played are shown in the right display.





(2) Current CD (for CD changer)

Press button repeatedly until the desired track is selected.

Vehicle status message memory menu

Use the vehicle status message memory menu to scan malfunction and warning messages that may be stored in the system. Such messages appear in the multifunction display and are based on conditions or system status the vehicle's system has recorded.

The vehicle status message memory menu only appears if there are any messages stored.

Control system

Warning!

Malfunction and warning messages are only indicated for certain systems and are intentionally not very detailed. The malfunction and warning messages are simply a reminder with respect to the operation of certain systems and do not replace the owner's and/or driver's responsibility to maintain the vehicle's operating safety by having all required maintenance and safety checks performed on the vehicle and by bringing the vehicle to an authorized Mercedes-Benz Center to address the malfunction and warning messages (> page 307).

/N

 Press button a repeatedly until the vehicle status message memory appears in the right display.

If the vehicle status message memory menu does not appear, then there are no messages stored.

Vehicle status messages have been recorded

If conditions have occurred causing status messages to be recorded, the number of messages appears in the right display:



- (1) Number of messages
- ▶ Press button or ∴.

The stored messages will now be displayed in the order in which they have occurred.

For malfunction and warning messages, see "Vehicle status messages in the multifunction display" (▷ page 307). Should the vehicle's system record any conditions while driving, the number of messages will reappear in the multifunction display when the SmartKey in the starter switch is turned to position **0** or removed from the starter switch.

1

The vehicle status message memory will be cleared when you turn the SmartKey in the starter switch to position 1 or 2. You will then only see high-priority messages (\triangleright page 307).


Control system

Settings menu

In the Settings menu there are two functions:

- The To reset: Press reset button for 3 seconds function with which you can reset all the settings to those set at the factory.
- A collection of submenus with which you can make individual settings for your vehicle.

 Press button or repeatedly until the Settings... menu appears in the left display.



The following settings and submenus are available:

Function	Page
Resetting all settings	126
Submenus in the Settings menu	127
Resetting the functions of a sub- menu	127
Instrument cluster submenu	129
Time submenu	131
Lighting submenu	132
Vehicle submenu	136

Resetting all settings

You can reset all the functions of all submenus to the factory settings.

► Press the reset button in the instrument cluster (▷ page 113) for approximately 3 seconds.

In the right display you will see the request to press the reset button again to confirm.

▶ Press the reset button again.

The functions of all the submenus will reset to factory settings.

1

The settings you have changed will not be reset unless you confirm the action by pressing the reset button a second time. After approximately 5 seconds, the Settings... menu reappears in the multifunction display.


For safety reasons, the Light circuit Headlamp mode in the Lighting submenu is not reset while driving.

Control system

Submenus in the Settings menu

► Press button ▲.

In the right display you see the collection of submenus.



The selection marker moves to the next submenu.

The submenus are arranged by hierarchy. Scroll down with button , scroll up with button .

With the selection marker on the desired submenu, use button individual functions within that submenu. Once within the submenu, you can use button is to move to the next function or button is to move to the previous function within that submenu.

The settings themselves are made with button **---** or **---**.

Resetting the functions of a submenu

For each submenu you can reset all the functions to the factory settings.

- Move to a function in the submenu.
- ► Press the reset button in the instrument cluster (▷ page 113) for approximately 3 seconds.

In the right display you will see the request to press the reset button again to confirm.

▶ Press the reset button again.

All functions of the submenu will reset to factory settings.

Control system

The table below shows what settings can be changed within the various menus. Detailed instructions on making individual settings can be found on the following pages.

Instrument cluster	Time	Lighting	Vehicle
Selecting temperature display mode	Setting time (hours)	Setting daytime running lamp mode (USA only)	Setting station selection mode (radio)
Selecting speedometer display mode	Setting time (minutes)	Setting locator lighting	Setting automatic locking
Selecting standard display	Selecting time display mode	Exterior lamps delayed switch-off	Tire inflation pressure display
Selecting language		Interior lighting delayed switch-off	

Control system

Instrument cluster submenu

Access the Inst. cluster submenu via the Settings menu. Use the Inst. cluster submenu to change the instrument cluster display settings.


The following functions are available:

Function	Page
Selecting the temperature dis- play	129
Selecting the speedometer dis- play	129
Selecting the standard display	130
Selecting the language	130

Selecting temperature display mode

- Move the selection marker with button defined or defined to the Inst. cluster submenu.
- Press button or repeatedly until you see this message in the left display: Temp. indicator.

The selection marker is on the current setting.




Press button + or to set temperature unit to degrees Celsius (°C) or degrees Fahrenheit (°F).

Selecting the speedometer display

- Move the selection marker with button
 I or is to the Inst. cluster submenu.
- Press button or repeatedly until you see this message in the left display: Speedometer.

The selection marker is on the current setting.




Press button + or to set the speedometer units to Kilometres or Miles.

Control system

Selecting the standard display

- Move the selection marker with button defined or defined to the Inst. cluster submenu.
- Press button or repeatedly until you see this message in the left display: Select display.

The selection marker is on the current setting.




Press button for a to select whether to display the outside temperature or the speed in the standard display.

Selecting the language

- Move the selection marker with button defined or defined to the Inst. cluster submenu.
- Press button or repeatedly until you see this message in the left display: Text.

The selection marker is on the current setting.



Press button for the language to be used for the multifunction display messages.

Available languages:

- German (Deutsch)
- English (English)
- French (français)
- Italian (italiano)
- Spanish (Español)
- Dutch (Nederlands)
- Danish (Dansk)
- Swedish (Svenska)
- Portuguese (Português)
- Turkish (Türkçe)

Control system

Time submenu

Access the Time submenu via the Settings menu. Use the Time submenu to change the time settings.


The following functions are available:

Function	Page
Setting time (hours)	131
Setting time (minutes)	131
Selecting time display	132

Setting time (hours)

- Move the selection marker with button
 or
 to the Time submenu.
- Press button or repeatedly until this message appears in the left display: Set time Hours.


The selection marker is on the hour setting.



Setting time (minutes)

- Move the selection marker with button
 or
 to the Time submenu.
- Press button or repeatedly until this message appears in the left display: Set time Minutes.

The selection marker is on the minute setting.




Control system

Selecting time display

- Move the selection marker with button
 or both to the Time submenu.
- Press button or repeatedly until you see this message in the left display: Clock.

The selection marker is on the current setting.



12-hour or 24-hour time display mode.

Lighting submenu

Access the Lighting submenu via the Settings menu. Use the Lighting submenu to change the lamp and lighting settings on your vehicle.

The following functions are available:

Function	Page
Setting daytime running lamp mode (USA only)	132
Setting locator lighting	133
Setting night security illumina- tion (Headlamps delayed switch-off)	134
Interior lighting delayed switch-off	135

Setting daytime running lamp mode (USA only)


1

This function is not available in countries where the daytime running lamp mode is mandatory and therefore in a constant mode.

- Move the selection marker with button
 I or is to the Lighting submenu.
- Press button or repeatedly until you see this message in the left display: Light circuit Headlamp mode.

The selection marker is on the current setting.

Control system



Press button or to select manual operation (Manual) or daytime running lamp mode (Constant) activated.

With daytime running lamp mode activated and the exterior lamp switch in position or Auro, the low beam headlamps are switched on when the

In low ambient light conditions the following lamps will switch on additionally:

• Parking lamps

engine is running.

- Tail lamps
- License plate lamps
- Side marker lamps

For more information on the daytime running lamp mode, see "Daytime running lamp mode" (⊳ page 107).

1

If you turn the exterior lamp switch to another position, the corresponding lamp(s) will switch on.

For safety reasons, resetting the Lighting submenu to factory settings (▷ page 127) will not reset the daytime running lamp mode.

The following message appears in the right display: Cannot be fully reset to factory settings when driving.

Setting locator lighting

With the locator lighting feature activated and the exterior lamp switch in position Auro, the following lamps will switch on during darkness when the vehicle is unlocked with the SmartKey:

- Parking lamps
- Tail lamps
- License plate lamps
- Side marker lamps
- Front fog lamps


The locator lighting switches off when the driver's door is opened.

If you do not open a door after unlocking the vehicle with the SmartKey the lamps will switch off automatically after approximately 40 seconds.

Control system

- Move the selection marker with button
 If or is to the Lighting submenu.
- Press button or repeatedly until you see this message in the left display: Locator lighting.

The selection marker is on the current setting.



- Press button + or to switch the locator lighting function 0n.
- Turn the exterior lamp switch to position Auro when exiting the vehicle (> page 105).

The locator lighting feature is activated.

Setting night security illumination (Headlamps delayed switch-off)

Use this function to set whether or not the exterior lamps to illuminate during darkness after exiting the vehicle and all doors closed.

With the delayed shut-off feature activated and the exterior lamp switch in position Auro before the engine is turned off, the following lamps will switch on when the engine is turned off and remain lit for approximately 15 seconds:

- Parking lamps
- Tail lamps
- License plate lamps
- Side marker lamps
- Front fog lamps


If after turning off the engine you do not open a door or do not close an opened door, the lamps will automatically switch off after 60 seconds.

1

You can reactivate this function within 10 minutes by opening a door.

- Move the selection marker with button
 or description to the Lighting submenu.
- Press button or repeatedly until you see this message in the left display: Headlamps delayed switch-off.

The selection marker is on the current setting.



Control system

► Turn the exterior lamp switch to position Auto before turning off the engine (▷ page 105).

The headlamps delayed switch-off feature is activated.

You can temporarily deactivate the delayed switch-off feature:

- Before leaving the vehicle turn the SmartKey in the starter switch to position 0.
- ► Then turn it to position 2 and back to 0.

The delayed switch-off feature is deactivated. It will reactivate as soon as you reinsert the SmartKey in the starter switch.

Interior lighting delayed switch-off

Use this function to set whether or not the interior lighting to remain lit during darkness for approximately 10 seconds after the SmartKey is removed from the starter switch.

- Move the selection marker with button
 If or to the Lighting submenu.
- Press button or repeatedly until you see this message in the left display: Int. lighting delayed switch-off.

The selection marker is on the current setting.



Press button + or - to switch the function On or Off.

Control system

Vehicle submenu

Access the Vehicle submenu via the Settings menu. Use the Vehicle submenu to make general vehicle settings.

The following functions are available:


Function	Page
Setting station selection mode (radio)	136
Setting automatic locking	136
Tire inflation pressure display	137

Setting radio station selection mode

Use the Press button in audio mode function to select the manual or memory station selection mode for the radio (\triangleright page 123).

- Move the selection marker with button
 + or to the Vehicle submenu.
- Press button or repeatedly until you see this message in the left display: Press button in audio mode.

The selection marker is on the current setting.



- Press button + or to select the desired station selection mode. You can select:
 - Memory, selects next stored station
 - Station search, selects next receivable station


Control system

Setting automatic locking

Use this function to activate or deactivate the automatic central locking. With the automatic central locking system activated, the vehicle is centrally locked at vehicle speeds of approximately 9 mph (15 km/h).

- Move the selection marker with button
 I or both to the Vehicle submenu.
- Press button or repeatedly until you see the following message in the left display: Automatic door lock.

The selection marker is on the current setting.




Tire inflation pressure display

Use this function to set the unit for the tire inflation pressure display.

- Move the selection marker with button + or to the Vehicle submenu.
- Press button or repeatedly until you see the following message in the left display: Tire pres. display.

The selection marker is on the current setting.



the desired tire inflation pressure unit.

Trip computer menu

Use the trip computer menu to call up statistical data on your vehicle.

The following information is available:

Function	Page
Fuel consumption statistics after start	138
Fuel consumption statistics since last reset	138
Calling up range (distance to emp- ty)	139


1

The last function called up will reappear the next time you enter the trip computer menu.

Control system

Fuel consumption statistics after start

- Press button or repeatedly until you see the first function of the Trip computer menu.
- Press button or repeatedly until you see the following message in the left display: From start.



- 1 Distance driven since start
- (2) Average speed since start
- (3) Time elapsed since start
- (4) Average fuel consumption since start


1

All statistics stored since the last engine start will be reset approximately four hours after the SmartKey in the starter switch is turned to position **0** or removed from the starter switch.

Resetting will not occur if you turn the SmartKey back to position **1** or **2** within this time period.

Fuel consumption since last reset

- Press button a or repeatedly until you see the first function of the Trip computer menu.
- Press button or repeatedly until you see the following message in the left display: From reset.



- (1) Distance driven since last reset
- (2) Average speed since last reset
- (3) Time elapsed since last reset
- Average fuel consumption since last reset

Resetting fuel consumption statistics


- Press button or repeatedly until you see the first function of the Trip computer menu.
- Press button or repeatedly until you see the reading that you want to reset in the left display.
- ► Press and hold the reset button in the instrument cluster (▷ page 113) until the value is reset to 0.

Control system

Calling up range (distance to empty)

- Press button or repeatedly until you see the first function of the Trip computer menu.
- Press button or repeatedly until you see this message in the left display: Range.

In the right display you will see the calculated range based on the current fuel tank level. Your driving style will affect the accuracy of the calculated range.



1

If the reserve fuel level has been reached, the range may no longer shown.

TEL menu

Warning!

A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the hands-free device and only use the telephone when weather, road, and traffic conditions permit.

Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and/or personal injury.

You can use the functions in the TEL menu to operate your telephone, provided it is connected to a hands-free system and switched on.

- Switch on the telephone and the radio.
- Press button a or on the steering wheel repeatedly until you see the TEL menu in the left display.

Which messages will appear in the right display field depends on whether your telephone is switched on or off:


• If the telephone is off, the message in the multifunction display is: TEL OFF.

Control system

• If the telephone is on:

The telephone will then search for a network. During this time the right display is empty.

As soon as the telephone has found a network, READY is indicated in the right display.



1 Signal strength

This standby message indicates that your telephone is ready for use and you can operate it using the control system.

You may carry out the following functions:

Function	Page
Rejecting a call	140
Answering a call	140
Ending a call	140
Dialling a number from the phone book	141
Redialing	142

Rejecting a call


If you do not wish to receive the call, you can choose to reject it.

Press button <a>

You have rejected the call. The caller receives a busy signal.

Answering a call

When your telephone is ready to receive calls, you can answer a call at any time. In the right display you will then see the message:



You have answered the call. In the right display you see the length of the call.

Ending a call

Press button <a>

You have ended the call. In the right display you will again see the standby message.

Control system

Dialing a number from the phone book

If your telephone is ready to receive calls, you may select and dial a number from the phone book at any time.

 Press button or repeatedly until you see the TEL menu in the left display.

In the right display you will see the standby message.

▶ Press button \triangle or \heartsuit .

The control system reads the phone book which is stored in the telephone. This may take up to 30 seconds. In the right display you will see this message Please wait.

When the message Please wait disappears, the phone book has been loaded.

 Press button or repeatedly until the desired name appears in the right display.

The stored names are displayed in ascending or descending alphabetical order.

1


If you press and hold or for longer than 1 second, the system scrolls rapidly through the list of names until you release the button again.

Cancel the quick search mode by pressing

Press button *C*.

The system dials the selected phone number.

 If the connection is successful, the name of the party you called and the duration of the call will appear in the multifunction display.



• If no connection is made, the control system stores the dialed number in the redial memory.

Control system

Redialing

The control system stores the most recently dialed phone numbers. This eliminates the need to search through your entire phone book.

Press button or repeatedly until you see the TEL menu in the left display.

In the right display you will see the standby message.

▶ Press button 📿 .

In the right display you see the first number in the redial memory.

- Press button or repeatedly until the desired name appears in the right display.

The control system dials the selected phone number.

Audio system

Audio system

Audio and telephone, operation

These instructions are intended to help you become familiar with your Mercedes-Benz audio system. They contain useful tips and a detailed description of the user functions.

Warning!

In order to avoid distraction which could lead to an accident, the driver should enter system settings with the vehicle at a standstill and operate the system only when road and traffic conditions permit. Always pay full attention to traffic conditions first before operating system controls while driving.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your car is covering a distance of 44 feet (approximately 14 m) every second.

Operating safety

Warning!

Any alterations made to electronic components can cause malfunctions.

The radio, amplifier, CD changer and telephone are interconnected. When one of the components is not operational or has not been removed/replaced properly, the function of other components may be impaired.

This condition might seriously impair the operating safety of your vehicle.

We recommend that you have any service work on electronic components carried out by an authorized Mercedes-Benz Center.

Location of the audio system

The audio system control panel is located behind a cover in the upper part of the center console.




1 Cover

 Briefly press on the lower part of cover (1).

The cover opens automatically.

Audio system

Operating and display elements



Audio system

	Item	Page
1	CD mode selector	156
2	Manual tuning (radio)	149
	Fast forward/reverse (cassette, CD)	154, 158
	Speed dialing memory (telephone)	163
3	Radio mode selector	149
4	Display panel	
	Cassette compartment be- hind display panel	

	Item	Page
5	Alpha-numeric keypad	
	Band selection, station buttons (radio)	149
	CD selection (CD)	158
	Telephone number entry, re- trieving speed dialing mem- ory (telephone)	161
6	Scanning (radio, cassette, CD)	151, 154, 158
7	Function button	150
8	Light-emitting diode	

	Item	Page
9	Function keys	
(10)	Cassette eject	153
(11)	Cassette mode selector	152
(12)	Telephone mode selector	160
(13)	Seek tuning (radio)	150
	Track search (cassette, CD)	153,
		158
	Speed dialing memory (telephone)	163
(14)	On/off	146
	Volume	146

Audio system

Button and soft key operation

In these instructions, the alpha-numeric keypad (right side of radio panel) and the function buttons (left side of radio panel) are referred to as "buttons". The four keys below the display panel are referred to as "soft keys".

!

Do not press directly on the display face. Otherwise the display will be damaged.

Operation

Switching on/off

Switching on:

 Turn SmartKey in starter switch to position 1 or 2.

or

Press control knob

1

If the radio is switched on without the SmartKey in the starter switch, it will automatically switch off again after approximately 30 minutes.

Switching off:

Remove SmartKey from starter switch.

or

Press control knob
 O

Adjusting the volume

Turn control knob

The volume will increase or decrease depending on the direction turned.

1

The volume setting can be selected separately for the telephone and audio system.


Adjusting audio functions

Press the AUD key to call up the bass, treble, balance and fader functions in the various operating modes. Settings for bass and treble are stored separately for the AM and FM frequency bands, cassette mode and CD mode.

Audio system

Bass

 Regardless of operating mode, press the AUD key repeatedly until BASS appears on the display.




 Press + or - key to increase or decrease level.

or

 Press both + and - keys simultaneously to reset the Bass to its center (flat) level.

Treble

 Regardless of operating mode, press the AUD key repeatedly until TREBLE appears on the display.



 Press + or - key to increase or decrease level.

or


 Press both + and - keys simultaneously to reset the Treble to its center (flat) level.

Fader

1

Your vehicle may or may not have the fader function, depending on the vehicle equipment and model.

 Regardless of operating mode, press the AUD key repeatedly until FADER appears on the display.



 Press F or R key to shift sound accordingly to the front or rear speakers.


or

 Press both F and R keys simultaneously to reset the Fader to its center level.

Audio system

Balance

 Regardless of operating mode, press the AUD key repeatedly until BALANCE appears on the display.



 Press L or R key to shift sound accordingly to the left or right speakers.

or

 Press both L and R keys simultaneously to reset the Balance to its center level.

Returning audio functions to factory settings

KEDEI
151 . 0 1
I Schemen Same' Lanna I

P82.60-4085-31

 Regardless of operating mode, press and hold AUD key longer than
 2 seconds. RESET will appear on the display.

All settings for bass, treble and balance are returned to the center level and the volume is set to a predefined level.

Audio system sound selection (EXT)*

 Regardless of operating mode, press the AUD key.

The sound settings menu appears on the display.

► Press the EXT key.

SOUN)		
DRIU	JER		
DRV	SP	AMB	OFF
			P82 60-4065-3

▶ Press one of the function keys.

Audio system

You can select from among the following settings:

- DRV: The tone level is set to the Driver position; sound is directed toward the passengers.
- SP: The tone level is set for Speech, optimizing the sound for the spoken word.
- AMB: The tone level is set for Ambience, producing a three-dimensional sound.
- 0FF: The audio system sound selection is turned off.

Telephone muting

The radio will switch to telephone mode when a call is incoming. The current audio source is muted.

Radio operation

Selecting radio mode

- ▶ Press RADIO button.
- You can now receive radio stations over the analog FM, AM or WB station frequencies.

Analog station frequencies

Selecting the band

You can select from among FM, AM or WB frequency bands.

Weather band (\triangleright page 152).

Image: Text of the second se

MW (medium wave) 530.....1710 KHz

 Press FM, AM or WB key repeatedly until desired band has been selected. The FM, AM and WB frequency bands are called up one after the other.

The frequency band currently selected appears in the upper left-hand corner of the display.

Selecting a station

The following options are available for selecting a station:

- Direct frequency band input (▷ page 150)
- Manual tuning (▷ page 150)
- Automatic seek tuning (▷ page 150)
- Scan tuning (▷ page 151)
- Preset buttons (▷ page 151)
- Automatic station memory (Autostore) (▷ page 151)

Audio system

Direct frequency input

► Select the desired frequency band.



- Press * button.
- Enter desired frequency using buttons 1 to 0.

1

You can only enter frequencies within the respective waveband.

If a button is not pressed within 4 seconds, the radio will return to the station last tuned to.

Manual tuning

• Select the desired frequency band.



 Press and hold either the or
 button until the desired frequency is reached.

Step-by-step station tuning takes place in ascending or descending order of frequency. The first three tuning steps will take place without muting. Afterwards, the radio will be muted and high-speed tuning will take place until the button is released.

Automatic seek tuning

► Select the desired frequency band.



▶ Press either the ▶ or ▶ button.

The radio will tune to the next higher or next lower receivable frequency.

Audio system

Scan tuning

- Starting scan tuning
 - ► Select desired frequency band.



▶ Press **SC#** button.

SC will appear on the display. The radio briefly tunes in all receivable stations on the band selected. The first scan cycle will tune in only the stations with a strong signal. The second scan cycle will tune in every receivable station.

- Ending scan tuning
 - ▶ Press **SC**# button or \triangle , ∇ , \triangleright or \triangleleft button.

SC disappears from the display.

Manual station memory (Presets)

You can store ten AM and ten FM stations.

- Storing stations
 - ► Tune in the desired station.
 - Press and hold desired station button to outil a brief signal tone is heard.



The frequency is stored on the selected station button.

The frequency band and station button number are shown in the upper left-hand corner of the display.

- Retrieving a station from memory
 - Press desired station button
 to

Automatic station memory (Autostore)

The Autostore memory function provides an additional memory level. The station memory for manually stored stations is not overwritten.

- Calling up Autostore memory level
 - ► Briefly press the AS key.

AS is highlighted in the display.

The radio finds the ten stations with the strongest signals. These stations are stored on the station buttons **1** to **0** in order of signal strength.

- Retrieving a station from memory
 - Press desired station button 1
 to 0.
- Leaving the Autostore memory level
 - ► Press the AS key.

The highlighted AS in the display disappears.

Audio system

Weather band



▶ Press the WB key.

The weather band station last selected is tuned in.

 Select the desired weather band station with buttons 1 to 7.

If a station cannot be tuned in, a scan is automatically started.

Press or button. The next receivable weather band station is tuned in.

Cassette operation

Playing cassettes

Press EJ button.

The display panel folds down and the cassette compartment becomes accessible.

 Insert cassette into the cassette compartment until it engages and tap it gently.

The cassette will be pulled in automatically. The system switches to cassette mode. Side 1 will be played and SIDE 1 appears in the display. Side 1 is the side of the cassette which is facing upward. The cassette deck will automatically detect the type of tape. Fold display panel back up and press gently on the display panel frame to lock it in place.

!

Do not press directly on the display face. Otherwise the display will be damaged.



or

► If a cassette is already in the mechanism, press TAPE button.

Audio system

0

A warning signal will sound after 20 seconds if the display panel is left in the down position. Fold display panel back up. If the display panel is not closed, a warning signal will sound and the radio will be muted.

Track selection



Press the TRK key.

The current track will be displayed as SIDE 1 or SIDE 2.

 You can switch sides at any time. The side will be changed automatically at the end of the tape.

Cassette eject

Press eject button EJ.

The display folds down and the cassette is ejected. The system will switch back to radio mode automatically.

 Fold display panel back up and press gently on the display panel frame to lock it.

Do not press directly on the display face. Otherwise the display will be damaged.

1

The cassette will not be ejected when the system is switched off or switched to another operating mode.

Track search

Track search forward



P82.60-4073-31

Press button.

SEEK FWD will appear in the display. Track search will run the tape forward to the start of the next track and switch to Play.

1

The beginning of a track can only be found if there is pause of at least 4 seconds between tracks.

Audio system

Track search backward

▶ Press 🖌 button.

SEEK RWD will appear on the display. Track search will run the tape backward to the start of the track currently playing and switch to Play.

Stopping track search

 $\blacktriangleright Press [\Delta], [\nabla], [A] or$ [A] button.

The cassette will switch over to Play.

Scanning

• Starting scan



P82.60-4074-31

Press SC# button.

SC will appear on the display.

Each track on the cassette will be played briefly in ascending order.

- Stopping scan
 - ▶ Press SC#, \triangle , \bigtriangledown , \triangleright or \bigcirc button.

The system will switch to Play.

Fast forward/reverse

• Starting cassette fast forward mode



▶ Press ▲ button.

FORWARD will appear on the display.

- Starting cassette fast reverse mode
 - ▶ Press ▼ button.

REWIND will appear on the display.

The cassette will automatically switch over to the play mode at the end or beginning of the tape.

- Stopping the cassette fast forward/reverse mode
 - ► Press △, ♥, ▷ or ↓ button.

The cassette will switch over to the play mode.

Skipping blank sections (skip blank)

Switching on the skip blank function

▶ Press the SB key.

SB is highlighted in the display.

If the system does not detect a sound signal, the cassette will automatically fast forward to the next sound signal.

Switching off the skip blank function

▶ Press the SB key.

The highlighted SB in the display disappears.

Dolby NR¹ (noise reduction system)

0

To enable optimum sound reproduction of cassettes recorded using Dolby B NR, the Dolby NR system should be switched on.

The Dolby NR function should be switched off when playing cassettes not recorded with Dolby B NR.

Switching on

▶ Press the NR key.

NR is highlighted in the display.

Switching off

Press the NR key.

The highlighted NR in the display disappears.

¹ DOLBY and the double-D symbol **1** are trademarks of Dolby Laboratories Licensing Corporation.

The Dolby noise reduction system is manufactured under license from Dolby Laboratories Licensing Corporation.

Audio system

CD changer operation

General notes

Should excessively high temperatures occur while in CD mode, CD TEMP HIGH will appear on the display and the CD will be muted. The unit will then switch back to the last operating mode used until the temperature has decreased to a safe operating level.



Should excessively low temperatures occur while in CD mode, CD TEMP LOW will appear on the display, but the CD will continue to play.

Handle CDs carefully to prevent interference during playback. Avoid fingerprints and dust on CDs. Do not write on CDs or apply any labels or other material to them. Only use original CDs. Using copied CDs may create problems during playback.

Clean CDs from time to time with a commercially available cleaning cloth. Do not use solvents, anti-static sprays, etc. for cleaning. Replace the CD in its case after use. Protect CDs from heat and direct sunlight.



61

Only use CDs, which bear the label shown and that conform to the compact disc digital audio standard (IEC 60908). You can therefore only use CDs with a maximum thickness of 1.3 mm.

Use of CDs which do not meet this standard may cause damage to the CD changer. Do not play single-CDs (80 mm) with an adapter. Your CD drive has been designed to play CDs which correspond to the IEC 60908 standard.

If you insert thicker data carriers, e.g. ones that have data on both sides (one side with DVD data, the other side with audio data), they cannot be ejected and will damage the drive.

Warning!

\land

The CD changer is a Class 1 laser product. There is a danger of invisible laser radiation if the cover is opened or damaged. Do not remove the cover. The CD changer does not contain any parts which can be serviced by the user. For safety reasons, have any service work which may be necessary performed only by qualified personnel.

Audio system

Operational readiness of CD changer

The CD changer is located in the trunk on the left side.




① CD changer

The CD changer can be operated from the front control panel of the radio. A loaded magazine must be installed to play CDs.

Loading/unloading a CD magazine

 Slide changer door to the right and press eject button



- (1) CD
- (2) CD changer
- ③ CD tray
- (4) CD magazine
- ▶ The CD magazine ④ will be ejected.
- Remove CD magazine and pull CD tray (3) fully out.
- Place CD (1) in recess of CD tray, label side up.
- Push CD tray into CD magazine in direction of arrow.

1

CDs which have been inserted improperly or are unreadable will not be played.

You do not need to place CDs in all six CD trays.

The lowest tray is magazine slot number 1 and the highest tray is magazine slot number 6.

 Push magazine into CD changer (2) in direction of arrow and close sliding door.

Playing CDs

▶ Press CD button.

CD will appear on the display.

The last CD listened to will then start playing at the point where it was switched off. After the last track on a CD has finished, the next CD is automatically played.

Audio system

Selecting CDs



P82.60-4067-31

 You can select from among the CDs in the CD magazine using buttons
 to

CD and the magazine slot number of the selected CD appear on the display. The number of the current track is displayed after TRACK.

CD :	2				
NO	CD	5			
RDM	RP1	-	AUD	-	Г

P82.60-4068-31

If there is no CD in the selected magazine slot, N0 $\,$ CD appears on the display with the corresponding slot number.

Skipping tracks forward/backward

- Skipping tracks forward
 - Press button.
 The next track will be played.
 - Skipping tracks backward
 - ▶ Press 🖌 button.

If the track has been playing for more than 10 seconds, it will revert to the start of that track. If it has been playing for less than 10 seconds, it will revert to the preceding track.

Pressing the repeatedly will result in multiple tracks being skipped.

Fast forward/reverse

- Fast forward
 - Press and hold button until desired point has been reached.

- Fast reverse
 - Press and hold velocity button until desired point has been reached.

1

The relative time of the track is shown on the display during the search.

Scanning

- Starting scan
 - ▶ Press **SC#** button.



P82.60-4069-31

SC appears in the display.

Each track on the current CD will be played for approximately 8 seconds in ascending order.

Audio system

- Ending scan
 - Press SC#, △, ▽, ▷ or ↓ button.

Random play

The random play function (RDM) plays the tracks on the current CD in random order.

• Switching on random play



► Press the RDM key.

RDM is highlighted in the display.

- Switching off random play
 - ▶ Press the RDM key.

The highlighted RDM in the display disappears.

Repeat

The repeat function (RPT) repeats the current track.

• Switching on repeat



P82.60-4067-31

- Press the RPT key.
 RPT is highlighted in the display.
- Switching off repeat
 - ▶ Press the RPT key.

The highlighted RPT in the display disappears.

1

The Random play and Repeat function cannot be used simultaneously.

Track and time display



P82.60-4070-31

• Press the \top key.

The number of the track being played and the elapsed playing time appear in the display.

• Press the \top key.

The total number of tracks and the total playing time of the CD appear in the display.

The CD main menu appears again after 8 seconds.

Audio system

Telephone operation

Warning!

 \triangle

Please do not forget that your primary responsibility is to drive the vehicle. A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call.

If you choose to use the telephone¹ while driving, please use the hands-free device and only use the telephone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Observe all legal requirements.

Various car telephone functions and operating steps for the car telephone can be performed and displayed via the audio system.

Further operating instructions not covered here can be found in the operating instructions for the multifunction steering wheel and the telephone.

Switching on the telephone

▶ Press TEL button.

If you have programmed an unlock code for the telephone, you must enter the code now.

- Enter the code using buttons 1
 to 0.
- If necessary, correct number entered with the CLR key. Press key briefly to delete the last digit entered; press key and hold to delete the complete number.

 Press the OK key after entering correct code.

The telephone is unlocked. If you have entered the wrong code, you must repeat the entering procedure with the correct code.

Switching off the telephone

Press TEL button repeatedly until PHONE OFF appears in the display.

The receiving symbol in the display disappears.

Adjusting the volume

► Turn control knob during telephone operation.

The volume increases or decreases depending on the direction in which the knob is turned.

1

The volume can be adjusted separately for the telephone and radio.

Audio system

Placing a call

Entering a telephone number and starting the dialing process



Enter the desired telephone number using buttons 1 to 0.

The number can have up to 32 digits, but only 13 of these are visible on the display.

If necessary, correct number entered with the $\ensuremath{\texttt{CLR}}$ key.

- Press key briefly to delete the last digit entered.
- Press key and hold to delete the complete number.
- After correct telephone number has been entered, press the SND key.

Phone book

The numbers stored in the phone book can be called up either by name or number.

Calling up the phone book



► Press △, ♥, ▷ or ☑ button.

Switching between name search and number search

► Press the ABC key.


The name search is called up.

or

▶ Press the NUM key.

The number search is called up.

Searching and calling up phone book entries by name



► Press the ABC key.

The current name is highlighted on the display. $\hfill \rhd \rhd$

Audio system

 $\triangleright \triangleright \triangleright$ Press either the \triangle or \bigtriangledown button.

The stored entries are selected according to the alphabetical order of the initial letter.

or

Press either the or dutton.
 The stored entries are selected in increments of four.

or

 Press the desired numerical key 2 to 9 vxxz

The stored entries are selected according to the alphabetical order of the initial letters (e.g. for B -Brown, press button $\frac{2}{36}$ twice).

1

Several characters and symbols cannot be shown on the display for technical reasons. They have been replaced with spaces.

Searching and selecting phone book entries by number



Press the NUM key.

The current number is marked in the display.

▶ Press either the \triangle or ∇ button.

The stored entries are selected according to numerical order.

or

▶ Press either the ▶ or ▶ button.

The stored entries are selected in increments of 5 (e.g. Entry M5, Entry M10, etc.)

Starting dialing process

 Once you have selected a number, press the SND key.

Repeat dialing

If the number dialed is busy, you can again place calls to the last ten telephone numbers dialed using the repeat dialing function.

Audio system

Manual repeat dialing (redial)



Press the SND key.

The last number dialed is shown in the display.

Select the desired telephone number using ▲, ▼, ▶ or
 button.

The abbreviation L and the number of the entry are shown in the top line of the display.

 When you have selected a number, press the SND key.

The call will be made.

Automatic repeat dialing (redial)

If a call cannot be connected, press the SND key.

REDIAL will appear on the display and repeated attempts to place the call will be made for the next 4 minutes.

Selecting numbers directly from the directory

- Enter previously selected 3-digit (1-999) number of the entry using number keys
 to
- ▶ Press the RCL key.

The telephone number stored under that entry will be dialed.

Press the SND key.

The call will be made.

Speed dialing

 Input desired entry number using number keys 1 to 0.

A maximum of two digits can be entered.

If necessary, correct the last number entered with the $\ensuremath{\texttt{CLR}}$ key.

▶ Press the SND key.

The telephone number stored under that entry will be dialed. The number, \lfloor and the full entry number will be shown in the display.

Audio system

Quick-dialing

 Press one of the desired number buttons 1 to 0 longer than 1 second.

The telephone number saved under that number will be dialed.

!

Please be aware that button **1** might already be reserved for an emergency call number.

Emergency calls "911"

The following describes how to dial a "911" emergency call using the audio system head unit when a Mercedes-Benz specified mobile phone is inserted in the phone cradle. Unless otherwise specified, the descriptions refer to the audio system head unit.

Consult the separate telephone operating instructions that came with your mobile phone for information on how to place a "911" emergency call on the mobile phone.

1 8 4	-			g!
vv	ы		m	22
	~	•••		b '



The "911" emergency call system is a public service. Using it without due cause is a criminal offense. The following conditions must be met for a "911" emergency call:

- Telephone must be switched on.
- The corresponding mobile communications network must be available.

0

Emergency calls may not be possible with all telephone networks or if certain network services and/or telephone functions are active. Check with your local service providers.

If you cannot make an emergency call, you will have to initiate rescue measures yourself.

165

Controls in detail

Audio system

Placing a "911" emergency call using audio head unit with the phone locked

Press TEL button to switch to telephone operation.

CODE? appears in the audio display.

Press button for the audio head unit until 911 appears in the audio display.

911 appears in the audio display while the telephone establishes the connection.

► Wait until the emergency call center answers, then describe the emergency.

Placing a "911" emergency call using audio head unit with the phone unlocked

- Press TEL button to switch to telephone operation.
- Enter 911 using the number keypad on the audio head unit.
- Press the SND key for dialing to begin.
 The telephone establishes the connection.
- ► Wait until the emergency call center answers, then describe the emergency.

Accepting an incoming call

Accepting an incoming call in telephone mode

With an incoming call, a ringing tone can be heard and the caller's telephone number, or the name under which this telephone number has been saved in the telephone book, appears on the display. If the caller's number is not transmitted, CALL will appear in the display.

▶ Press the SND key to accept call.

Audio system

Accepting an incoming call in cassette, CD or radio mode

If the telephone is activated in the background (receiving symbol S visible on display), the audio source is muted when a call is received. The ringing tone is heard and the caller's telephone number or the name under which this telephone number has been saved in the telephone book appears on the display. If the caller's number is not transmitted, CALL appears in the display.

▶ Press the SND key to accept the call.

Muting a call

It is possible to mute a call; the caller is then no longer able to hear you.

Mute on

▶ Press the MUT key.

Mute off

▶ Press the MUT key.

Terminating a call

▶ Press the END key.

The current call is terminated.

Call waiting

If you receive another call during an already active call, you can accept the second call and switch between the two.

Accepting a second call

▶ Press the SND key.

You are connected with the second caller, the first call is muted.

Switching between the calls

▶ Press the SND key.

Terminating the second call

▶ Press the END key.

The current call will be terminated. You are connected with the muted call again.

Automatic transmission

Automatic transmission

For information on driving with an automatic transmission, see the "Getting started" section (\triangleright page 49).

Your vehicle's transmission adapts its gear shifting process to your individual driving style by continually adjusting the shift points up or down. These shift point adjustments are performed based on current operating and driving conditions.

If the operating conditions change, the automatic transmission reacts by adjusting its gear shift program.

1

During the brief warm-up, transmission upshifting is delayed. This allows the catalytic converter to heat up more quickly to operating temperature.

!

Allow engine to warm up under low load use. Do not place full load on the engine until the operating temperature has been reached (\triangleright page 303).

Shift into park position **P** or reverse gear **R** only when the vehicle is stopped.

Avoid spinning of a drive wheel for an extended period when driving off on slippery road surfaces. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.



Gearshift pattern

The automatic transmission selects individual gears automatically, depending on:

- the gear selector lever position D with gear ranges 4, 3, 2 and 1 (▷ page 170)
- the selected shift program mode (C/MAN/S) (▷ page 173)
- the position of the accelerator pedal (▷ page 173)
- · the vehicle speed

The current gear selector lever position (P/R/N/D), the gear range (1/2/3/4) and the shift program (C/M/S) are shown in the standard display (\triangleright page 117).

Automatic transmission

An additional indication of the current gear selector lever position can be found on the cover of the shifting-gate.

Warning!

 \wedge

It is dangerous to shift the gear selector lever out of \mathbf{P} or \mathbf{N} if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal. When the gear selector lever is in position **D**, you can influence transmission shifting by

- limiting the shift range
- changing gears manually

One-touch gearshifting

Even with an automatic transmission you can change the gears manually when the gear selector lever is in position **D**.

Downshifting

 Briefly press the gear selector lever to the left in the D- direction.

The transmission will shift from the current gear to the next lower gear. This action simultaneously limits the gear range of the transmission (\triangleright page 170).

Automatic transmission

Warning!

 \triangle

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

1

To avoid overrevving the engine when the gear selector lever is moved to the **D**- direction, the transmission will not shift to a lower gear if the engine's max. speed would be exceeded.

Upshifting

 Briefly press the gear selector lever to the right in the D+ direction.

The transmission will shift from the current gear to the next higher gear as permitted by the shift program. This action simultaneously extends the gear range of the transmission.

Canceling gear range limit

 Press and hold the gear selector lever in the D+ direction until D reappears in the right multifunction display.

The transmission will shift from the current gear range directly to gear range **D**.

Shifting into optimal gear range

 Press and hold the gear selector lever in the D- direction.

The transmission will automatically select the gear range suited for optimal acceleration and deceleration. This may involve shifting down one or more gears.

Automatic transmission

Gear ranges

With the gear selector lever in position **D**, you can limit the transmission's gear range by pressing the gear selector lever to the left (**D**-), and reverse the gear range limit by pressing the gear selector lever to the right (**D**+).

The selected gear range appears in the right multifunction display (> page 117). If you press on the accelerator when the engine has reached its rpm limit, the transmission will upshift beyond any gear range limit selected.

0

If, when driving in shift program mode **C** and **S** the maximum engine speed for the gear range has been reached, the transmission shifts up automatically, even if the gear range is restricted. In shift program **MAN** the transmission will not shift up automatically.

Effect

- The transmission shifts through fourth gear only.
- 3 The transmission shifts through third gear only.

With this selection you can use the braking effect of the engine.

Effect

The transmission shifts through second gear only.

Allows the use of engine's braking power when driving:

- on steep downgrades
- in mountainous regions
- under extreme operating conditions
- The transmission operates in the first gear only.

For maximum use of engine's braking effect on very steep or lengthy downgrades.

Automatic transmission

Gear selector lever positions

Effect

P Park position

Gear selector lever position when the vehicle is parked. Place gear selector lever in position **P** only when vehicle is stopped. The park position is not intended to serve as a brake when the vehicle is parked. Rather, the driver should always set the parking brake in addition to placing the gear selector lever in position **P** to secure the vehicle.

Effect

The SmartKey can only be removed from the starter switch with the gear selector lever in position **P**. With the SmartKey removed, the gear selector lever is locked in position **P**.

If the vehicle's electrical system is malfunctioning, the gear selector lever could remain locked in position **P**.

R Reverse gear

Place gear selector lever in position **R** only when vehicle is stopped.

Effect

Neutral

N

No power is transmitted from the engine to the drive axle. When the brakes are released, the vehicle can be moved freely (pushed or towed).

To avoid damage to the transmission, never engage ${\bf N}$ while driving.

If the ESP[®] is deactivated or malfunctioning:

Move gear selector lever to **N** only if the vehicle is in danger of skidding, e.g. on icy roads.

D Drive

The transmission shifts automatically. All five forward gears are available.

Automatic transmission

!

Coasting the vehicle, or driving for any other reason with gear selector lever in \mathbf{N} can result in transmission damage that is not covered by the Mercedes-Benz Limited Warranty.

Warning!

Getting out of your vehicle with the gear selector lever not fully engaged in position **P** is dangerous. Also, position **P** alone is not intended to or capable of preventing your vehicle from moving, possibly hitting people or objects.

Always set the parking brake in addition to shifting to position \mathbf{P} (\triangleright page 57).

When parked on an incline, turn the front wheels towards the road curb.

Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

Warning!

/!\

 \wedge

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could move the gear selector lever from position **P**, which could result in an accident and/or serious personal injury.

Automatic transmission

Shift program mode selector switch



0	
C Comfort	For comfort driving
MAN Manual	For manual gearshift program
S Sport	For standard driving

 Turn the program selector switch to the desired setting.

Select **C** for comfort operation:

- The vehicle starts out in second gear for gentler starts. This does not apply if full throttle is applied or gear range **1** is selected.
- Traction and driving stability are improved on icy roads.
- Upshifts occur earlier even when you give more gas. The engine then operates at lower rpms and the wheels are less likely to spin.

Select **MAN** for the manual gearshift program. This program allows you to perform manual gearshifts (\triangleright page 176).

Driving tips

Accelerator position

Your driving style influences the transmission's shifting behavior:

Less throttle	Earlier upshifting
More throttle	Later upshifting

Kickdown

Use kickdown when you want maximum acceleration.

Press the accelerator past the point of resistance.

The transmission shifts into a lower gear.

► Ease on the accelerator when you have reached the desired speed.

The transmission shifts up again.

Automatic transmission

Stopping

When you stop briefly, e.g. at traffic lights:

- Leave the transmission in gear.
- ► Hold the vehicle with the brake.

When you stop longer with the engine idling and/or on a hill:

- ▶ Set the parking brake.
- Move the gear selector lever to position P.

Maneuvering

When you maneuver in tight areas, e.g. when pulling into a parking space:

- Control the vehicle speed by gradually releasing the brakes.
- ► Accelerate gently.
- ▶ Never abruptly step on the accelerator.

Working on the vehicle

Warning!


 \triangle

When working on the vehicle, set the parking brake and move gear selector lever to position **P**. Otherwise the vehicle could roll away.

Steering wheel gearshift control

You can change the gears manually on the steering wheel or by using the gear selector lever (\triangleright page 168).

The steering wheel gearshift buttons are located on the left and right side of the steering wheel.



Left button: downshift
 Right button: upshift

Automatic transmission

1

You can change gears using the steering wheel gearshift buttons independent of the currently selected gearshift program (C/MAN/S).

You cannot shift with the steering wheel gearshift buttons when the gear selector lever is in position **P**, **N** or **R**.

Downshifting

Warning!

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

 Press button (1) on the left side of the steering wheel.

The transmission shifts to the next lower gear.

The current gear selector position appears in the right multifunction display (\triangleright page 117).

The transmission will shift to the next lower gear as permitted by the shift program. This action simultaneously limits the gear range of the transmission (\triangleright page 170) when you are driving in the automatic program mode **C** or **S** (\triangleright page 173).

Upshifting

/l\

 Press button (2) on the right side of the steering wheel.

The transmission shifts to the next higher gear.

The current gear selector position appears in the right multifunction display (\triangleright page 117).

The transmission will shift to the next higher gear as permitted by the shift program. This action simultaneously extends the gear range of the transmission (\triangleright page 170) when you are driving in the automatic program mode **C** or **S** (\triangleright page 173).

Automatic transmission

Manual gearshift program

In the manual gearshift program **M** you can change the gears manually on the steering wheel (\triangleright page 174) or by using the gear selector lever (\triangleright page 168).

Activating manual gearshift program

► Turn program mode selector switch ① (▷ page 173) to the MAN setting.

The transmission switches to the manual program mode **M**. The letter M appears in the right multifunction display and the lamp in program mode selector switch (3) (\triangleright page 176) comes on. Automatic shifting is switched off. The gear range is not limited.

Selecting manual gearshift program



③ Program selector switch for the manual gearshift program

I Sport	For sporty driving
II Super Sport	For very sporty driving
III Race	For racing-like driving ¹

The individual shifting programs differ with regard to spontaneity, response time, and shifting smoothness.

Please always drive carefully and obey applicable speed limits.

 Turn program selector switch (3) to the desired setting (I, II or III).

1

The currently selected manual gearshift program (I, II or III) does not appear in the right multifunction display. The current setting is indicated only on the program mode selector switch (3).

Automatic transmission

Downshifting

Warning!



or

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control. ► Press button ① (▷ page 174) on the left side of the steering wheel.

 Briefly press the gear selector lever to the left in the D- direction.

The transmission shifts to the next lower gear.

The current gear selector position appears in the right multifunction display (\triangleright page 117).

1

When you brake or stop, the transmission shifts down to a gear from which you can easily accelerate or take off.

Upshifting

!

In the manual program mode **M**, the transmission will not upshift, even if the engine has reached its overrevving range. Shift up to the next gear before the engine has reached its overrevving range. Make absolutely certain that the engine speed does not reach the red marking on the tachometer (▷ page 28). Otherwise the engine could be damaged which is not covered by the Mercedes-Benz Limited Warranty.

Automatic transmission

► Press button ② (▷ page 174) on the right side of the steering wheel.

or

 Briefly press the gear selector lever to the right in the D+ direction.

The transmission shifts to the next higher gear.

The current gear selector position appears in the right multifunction display (\triangleright page 117).

If the red gearshift indicator lamp **Set** comes on in the speedometer display (> page 29), shift to the next higher gear. The fuel supply will otherwise be interrupted to prevent the engine from overrevving.

Deactivating manual gearshift program

► Turn program mode selector switch ① (▷ page 173) to the C or S setting.

The selected gearshift program appears in the right multifunction display.

Emergency operation (Limp Home Mode)

If vehicle acceleration worsens or the transmission no longer shifts, the transmission is most likely operating in limp home (emergency operation) mode. In this mode only second gear and reverse gear can be activated.

- ▶ Stop the vehicle in a safe location.
- ► Move gear selector lever to **P**.
- ► Turn off the engine.
- Wait at least 10 seconds before restarting.
- ▶ Restart the engine.
- Move gear selector lever to position D (for second gear) or R.
- Have the transmission checked at an authorized Mercedes-Benz Center as soon as possible.

Good visibility

Good visibility

For information on the windshield wipers, see (\triangleright page 54) and adjusting the mirrors, see (\triangleright page 44).

Headlamp cleaning system

The switch is located on the left side of the dashboard.



- ① To clean the headlamps
- ▶ Switch on the ignition (▷ page 40).
- Press switch ①.

The headlamps are cleaned with a high-pressure water jet.

For information on filling up the washer reservoir, see "Windshield washer system and headlamp cleaning system" (▷ page 252).

Rear view mirrors

For more information on setting the rear view mirrors, see "Mirrors" (▷ page 44).

Auto-dimming mirror

The reflection brightness of the interior rear view mirror will respond automatically to glare when

 the ignition is switched on and

 incoming light from headlamps falls on the sensor in the interior rear view mirror.

The rear view mirror will not react if

- reverse gear **R** is engaged
- the interior lighting is turned on

Warning!



The auto-dimming function does not react if incoming light is not aimed directly at sensors in the interior rear view mirror.

Glare can endanger you and others.

Warning!



In case of an accident, liquid electrolyte may escape from the mirror housing if the mirror glass breaks.

Electrolyte has an irritating effect. Do not allow the liquid to come into contact with eyes, skin, clothing, or respiratory system. In case it does, immediately flush affected area with water, and seek medical help if necessary.

Good visibility

!

Electrolyte drops coming into contact with the vehicle paint finish can be completely removed only while in the liquid state and by applying plenty of water.

Warning!



Exercise care when using the passenger-side exterior rear view mirror. The mirror surface is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your interior rear view mirror or glance over your shoulder before changing lanes.


Sun visors

The sun visors protect you from sun glare while driving.

Warning!

Do not use the vanity mirror while driving.

Keep the mirrors in the sun visors closed while vehicle is in motion. Reflected glare can endanger you and others.



- 1 Mirror cover
- (2) Mirror lamp
- (3) Mounting
- (4) Holder for gas cards
- Swing sun visor down when you experience glare.
- ► To use illuminated mirror, lift up mirror cover ①.

đ

If sun visor is disengaged from mounting ③ with mirror cover ① open, mirror lamp ② will switch off.

181

Good visibility

1

If sunlight enters through a side window, close mirror cover ① (if open), disengage sun visor from mounting ③ and pivot to the side.

Rear window defroster

The rear window defroster uses a large amount of power. To keep the battery drain to a minimum, switch off the defroster as soon as the rear window is clear. The defroster is automatically deactivated after approximately 6 to 17 minutes of operation depending on the outside temperature.

Warning!

Λ

Any accumulation of snow and ice should be removed from the rear window before driving. Visibility could otherwise be impaired, endangering you and others.

Activating

The indicator lamp on the button comes on.

!

If the rear window defroster switches off too soon and the indicator lamp starts flashing, this means that too many electrical consumers are operating simultaneously and there is insufficient voltage in the battery. The system responds automatically by deactivating the rear window defroster.

As soon as the battery has sufficient voltage, the rear window defroster automatically turns itself back on.

Deactivating

▶ Press button 🖽 again.

The indicator lamp on the button goes out.

Automatic climate control



Automatic climate control


Function

- () Center air vent, adjustable
- ② Air temperature controls for center and side air vents
- ③ Center air vent, adjustable
- (4) Air volume control for center and side air vents
- 5 Side air vent, adjustable
- 6 Automatic climate control panel

1

For draft-free ventilation, move the sliders for the center air vents to the middle position.

Automatic climate control



Automatic climate control panel

Function

- (1) Air distribution, left (automatic or manual operation)
- (2) Defrosting the windshield
- ③ Air recirculation
- ④ Rear window defroster (▷ page 181)
- (5) Air distribution, right (automatic or manual operation)

Function

- 6 Temperature control, right
- Automatic climate control on/off (complete system)
- (8) Residual heat/ventilation
- Air volume control (automatic or manual operation)
- (1) AC cooling on/off
- (1) Temperature control, left

Automatic climate control

The automatic climate control is operational whenever the engine is running. You can operate the climate control system in either the automatic or manual mode. The system cools or heats the interior depending on the selected interior temperature and the current outside temperature.

Warning!

When operating the automatic climate control, the air that enters the passenger compartment through the air vents can be very hot or very cold (depending on the set temperature). This may cause burns or frostbite to unprotected skin in the immediate area of the air vents. Always keep sufficient distance between unprotected parts of the body and the air vents. If necessary, use the air distribution controls (D page 187) to direct the air to air vents in the vehicle interior that are not in the immediate area of unprotected skin. Nearly all dust particles, pollutants and odors are filtered out before outside air enters the passenger compartment through the air distribution system.

Warning!

Follow the recommended settings for heating and cooling given on the following pages. Otherwise the windows could fog up, impairing visibility and endangering you and others.

1

If the vehicle interior is hot, ventilate the interior before driving off.

Keep the air intake grille in front of the windshield free of snow and debris.

Adjusting the temperature

Use temperature controls (6) and (1) to separately adjust the air temperature on each side of the passenger compartment. You should raise or lower the temperature setting in small increments, preferably starting at 72°F (22°C).

1

/!\

When operating the climate control system in automatic mode, you will only rarely need to adjust the temperature, air volume and air distribution.

Increasing

 Turn the outer adjustment ring slightly to the right.

The automatic climate control system will correspondingly adjust the interior air temperature.

Automatic climate control

Decreasing

 Turn the outer adjustment ring slightly to the left.

The automatic climate control system will correspondingly adjust the interior air temperature.

Adjusting the temperature for the center and side air vents

When outside temperatures are low, you can manually raise the air temperature for the center and side air vents. The controls (2) are located between the center air vents (\triangleright page 182).

Turning on warm air

Press the left button (red).

The indicator lamp on the button comes on. Warm air will enter from the center and side air vents.

Turning off warm air

▶ Press the left button (red).

The indicator lamp on the button goes out. The air from the outlets will return to the temperature set in the system.

Turning on cooler air

Press the right button (blue).

The indicator lamp on the button comes on. Cooler air will enter from the center and side air vents.

Turning off cooler air

Press the right button (blue).

The indicator lamp on the button goes out. The air from the outlets will return to the temperature set in the system.

Adjusting air volume

Use air volume control knob O (\vartriangleright page 184) for both automatic and manual air volume adjustment.

Adjusting manually

Press the control knob.

The Auto light on the control knob goes out. You can now select one of nine air volume settings.

Adjusting automatically

Press the control knob.

The Auro light on the control knob comes on. The airflow is adjusted automatically.

Automatic climate control

Adjusting air distribution

Use air distribution control knobs (1) and (5) (\triangleright page 184) to separately adjust the air distribution on each side of the passenger compartment. The following symbols are found on the controls:

Symbol	Function
	Directs air through the cen- ter air vents
\bigtriangleup	Directs air to the windows
Ş	Directs air into the entire vehicle interior
\bigtriangledown	Directs air to the footwells

Adjusting manually

▶ Press the control knob.

The Auto light on the control knob goes out. The air distribution can be adjusted manually.

Adjusting automatically

Press the control knob.

The Auto light on the control knob comes on. The air distribution is adjusted automatically.

Windshield fogged on the outside

- Switch the windshield wipers on.
- Turn the air distribution control to



Maximum cooling MAXCOOL

If the left and right air distribution controls as well as the airflow volume control are set to Auro and there is a high need for cooling, MAXCOOL is activated.

This provides the fastest possible cooling of the vehicle interior.

Automatic climate control

Defrosting the windshield

These settings should only be selected for a short time.

Activating

A

► Press button (▷ page 184). The indicator lamp on the button comes on.

Deactivating

▶ Press button (▷ page 184).

The indicator lamp on the button goes out. Defrosting is turned off.

Air recirculation mode

Switch to air recirculation mode to prevent unpleasant odors from entering the vehicle from the outside. This setting cuts off the intake of outside air and recirculates the air in the passenger compartment.

Warning!



When the outside temperature is below 41°F (5°C), only switch to air recirculation mode for short periods to prevent window fogging.

Activating

▶ Press button 🖘 (▷ page 184).

The indicator lamp on the button comes on.

Warning!



Never operate the windows if there is the possibility of anyone being harmed by the closing procedure.

In the event that the procedure causes potential danger, the closing of the windows can be immediately halted by releasing the

button or by pressing or pulling the respective window switch.

Automatic climate control

0

If you keep button so pressed, the windows will close.

The air recirculation mode is activated automatically

- at high outside temperatures
- if the concentration of carbon monoxide and nitrogen oxide in the outside air increases, for example in a tunnel

If you have turned off the air conditioner (\triangleright page 192) or the outside temperature is below 41°F (5°C), the air recirculation mode will not switch on automatically.

Deactivating

▶ Press button 🖘 (▷ page 184).

The indicator lamp on the button goes out.

1

If you keep button pressed, the windows will return to their previous position.

The air recirculation mode is deactivated automatically

 after 5 minutes if the outside temperature is below approximately 41°F (5°C)

- after 5 minutes if the air conditioner is turned off
- after 30 minutes if the outside temperature is above approximately 41°F (5°C)

At outside temperatures above 79°F (26°C) the system will not automatically switch back to outside air. A quantity of outside air is added after approximately 30 minutes.

Automatic climate control

Residual heat and ventilation

With the engine switched off, it is possible to continue to heat or ventilate the interior for up to 30 minutes. This feature makes use of the residual heat produced by the engine.

1

How long the system will provide heating depends on the coolant temperature and the temperature set by the operator. The blower will run at speed setting **1** regardless of the air distribution control setting.

Activating

- ► Turn the SmartKey in the starter switch to position 1 or 0 or remove it from the starter switch.
- ► Press button REST (▷ page 184). The indicator lamp on button REST comes on.

Deactivating

► Press button **REST** (▷ page 184).

The indicator lamp on button REST goes out.

The residual heat is automatically turned off:

- when the ignition is switched on
- after about 30 minutes
- if the battery voltage drops

191

Controls in detail

Automatic climate control

Deactivating the automatic climate control system

1

When the air conditioning is switched off, the outside air supply and circulation are also switched off. Only choose this setting for a short time. Otherwise the windows could fog up.

Deactivating

It is possible to completely deactivate the automatic climate control system.

▶ Press button **o** (▷ page 184).

The indicator lamp on button **o** comes on.

1

Under certain circumstances, e.g. when the fuel system is too hot and needs to be cooled, the cooling switches on again automatically. The red lamp on the Ac^{oeff} button the automatic climate control panel flashes.

After cooling the fuel system sufficiently, the air conditioning switches off again and the red lamp stops flashing.

Reactivating

There are several ways to reactivate the automatic climate control system:

► Press any button on the automatic climate control panel (▷ page 184).

The indicator lamp on button **o** switches off.

or

 Turn one of the control knobs on the automatic climate control.

The indicator lamp on button **o** switches off.

Automatic climate control

Air conditioning

The air conditioning is operational while the engine is running and cools the interior air to the temperature set by the operator.

1

Condensation may drip out from underneath the vehicle. This is normal and not an indication of a malfunction.

Deactivating

It is possible to deactivate the air conditioning (cooling) function of the automatic climate control system. The air in the vehicle will then no longer be cooled or dehumidified.

Press AC^{OFF} button (\triangleright page 184).

The indicator lamp on the AC^{OFF} button comes on.

1

Under certain circumstances, e.g. when the fuel system is too hot and needs to be cooled, the cooling switches on again automatically. The red lamp on the Ac^{ore} button the automatic climate control panel flashes.

After cooling the fuel system sufficiently, the air conditioning switches off again and the red lamp stops flashing.

Activating

Moist air can fog up the windows. You can dehumidify the air with the air conditioning.

▶ Press AC^{OFF} button again (\triangleright page 184).

The indicator lamp on the AC^{off} button goes out.

The air conditioning uses the refrigerant R134A. This refrigerant is free of CFCs which are harmful to the ozone layer.

!

If you press the Act button on the automatic climate control panel and it starts to flash, this indicates that the air conditioning is losing refrigerant. The compressor has turned off. The air conditioning cannot be turned on again.


Have the air conditioning checked at the nearest authorized Mercedes-Benz Center.

Power windows

Power windows

Opening and closing the windows

The door windows are opened and closed electrically. The switches for the windows are located on the door sill on the driver's side (\triangleright page 34). The switch for the passenger side is located on the door sill on the passenger side.



Left window
 Right window

Warning!

When closing the windows, make sure there is no danger of anyone being harmed by the closing procedure.

/!\

The closing of the windows can be immediately halted by releasing the switch or, if switch was pulled past the resistance point and released, by either pressing or pulling the respective switch.

If the window encounters an obstruction that blocks its path in a circumstance where you pulled the switch past the resistance point and released it to close the window, the automatic reversal function will stop the window and open it slightly. If the window encounters an obstruction that blocks its path in a circumstance where you are closing the window by pulling and holding the switch, or by pressing and holding button of on the SmartKey, or by pressing and holding the solution on the climate control panel, the automatic reversal function will not operate.

When leaving the vehicle, always remove the SmartKey from starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment can cause an accident and/or serious personal injury.

• Switch on the ignition (\triangleright page 40).

Power windows

1

With the SmartKey in starter switch position **0** or removed from the starter switch, the front power windows can be operated:

- until you open the driver's or passenger door
- for at least 5 minutes

Opening the windows

 Press switch ① or ② to the resistance point.

The corresponding window will move downwards until you release the switch.

Closing the windows

 Pull switch ① or ② to the resistance point.

The corresponding window will move upwards until you release the switch.

Warning!



If you pull and hold the switch up when closing the window, and upward movement of the window is blocked by some obstruction including but not limited to arms, hands, fingers, etc., the automatic reversal will not operate.

Fully opening the windows (Express-open)

Press switch ① or ② past the resistance point and release.

The corresponding window opens completely.

Fully closing the windows (Express-close)

 Pull switch (1) or (2) past the resistance point and release.

The corresponding window closes completely.

Warning!

\wedge

Driver's door only:

If within 5 seconds you again pull the switch past the resistance point and release, the automatic reversal will not function.

Power windows

!

If the upward movement of the window is blocked during the closing procedure, the window will stop and open slightly.

Remove the obstruction, pull the switch again past the resistance point and release.

If the window still does not close when there is no obstruction, then pull and hold the switch again. The window will then close without the obstruction sensor function.

Stopping the windows

Press or pull respective switch again.

Synchronizing power windows

The power windows must be resynchronized each time

- after the battery has been disconnected.
- if the power windows cannot be fully opened (Express-open) or closed (Express-close).
- Switch on the ignition (\triangleright page 40).
- Pull the power window switches until the windows are closed.

Hold the switches for approximately 1 second.

The power windows are synchronized.

Summer opening feature

If the weather is warm, you can ventilate the vehicle before driving off by opening the side windows.



 Aim transmitter eye of the SmartKey at the rear quarter window.

The SmartKey must be in close proximity to the rear quarter window.

- Press and hold button until the windows have reached the desired position.
- Release button to interrupt procedure.

Power windows

Convenience closing feature

When you lock the vehicle, you can close the side windows.

• Aim transmitter eye of the SmartKey at the rear quarter window.

The SmartKey must be in close proximity to the rear quarter window.

- Press and hold button function until the side windows are completely closed.
- Release button f to interrupt procedure.

Warning!

When closing the side windows, make sure that there is no danger of anyone being harmed by the closing procedure.

 \land

If potential danger exists, release button to stop the closing procedure. To open, press and hold button to continue the closing after making sure that there is no danger of anyone being harmed by the closing procedure, press and hold button to .

Driving systems

Driving systems

The driving system of your vehicle is described on the following pages:

• Cruise control, with which the vehicle can maintain a preset speed

For information on the BAS, ABS and ESP^{\circledast} driving systems, (\triangleright page 79).

Cruise control

Cruise control automatically maintains the speed you set for your vehicle.

Use of cruise control is recommended for driving at a constant speed for extended periods of time. You can set or resume cruise control at any speed over 20 mph (30 km/h).

The cruise control function is operated by means of the cruise control lever.

The cruise control lever is the uppermost lever on the left-hand side of the steering column (\triangleright page 30).

Warning!

 \wedge


Cruise control is a convenience system designed to assist the driver during vehicle operation. The driver is and must remain at all times responsible for the vehicle speed and for safe brake operation.

Only use cruise control if the road, traffic and weather conditions make it advisable to travel at a steady speed.

- The use of cruise control can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a steady speed.
- The use of cruise control can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.
- Deactivate cruise control when driving in fog.

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.

Driving systems



- (1) Sets current or higher speed
- (2) Sets current or lower speed
- ③ Cancels cruise control
- ④ Resumes at last set speed

Setting current speed

- Accelerate or decelerate to the desired speed.
- Briefly lift ① or depress ② the cruise control lever.

The current speed is set.

 Remove your foot from the accelerator pedal.

Cruise control is activated.

0

On uphill or downhill grades, cruise control may not be able to maintain the set speed. Once the grade eases, the set speed will be resumed.

Canceling cruise control

There are several ways to cancel cruise control:

▶ Step on the brake pedal.

Cruise control is canceled. The last speed set is stored for later use.

or

 Briefly push the cruise control lever to position (3).

Cruise control is canceled. The last speed set is stored for later use.

The cruise control is automatically cancelled, when

- the vehicle speed is below 20 mph (30 km/h)
- ESP[®] is in operation or switched off with the ESP switch (▷ page 83)
- you move the gear selector lever to position **N** while driving

!

However, the gear selector lever should not be moved to position **N** while driving, except to coast when the vehicle is in danger of skidding (e.g. on icy roads).

1

Depressing the accelerator pedal does not deactivate the cruise control. After brief acceleration (e.g. for passing), the cruise control will resume the last speed set.

The last stored speed is canceled when you turn off the engine.

Driving systems

Setting a higher speed

- Lift cruise control lever to position (1) and hold it up until the desired speed is reached.
- ► Release cruise control lever.

The new speed is set.

1

Depressing the accelerator pedal does not deactivate cruise control. After brief acceleration (e.g. for passing), cruise control will resume the last speed set.

Setting a lower speed

- Depress cruise control lever to position (2) and hold it down until the desired speed is reached.
- Release cruise control lever.

The new speed is set.

0

When you use the cruise control lever to decelerate, the transmission will automatically downshift if the engine's braking power does not brake the vehicle sufficiently.

Fine adjustment in 1 mph (Canada: 1 km/h) increments

Faster

 Briefly tip cruise control lever in direction of arrow 1.

Slower

 Briefly tip cruise control lever in direction of arrow (2).

Setting to last stored speed ("Resume" function)

Warning!



The speed stored in memory should only be set again if prevailing road conditions permit. Possible acceleration or deceleration differences arising from returning to preset speed could cause an accident and/or serious injury to you and others.

 Briefly push cruise control lever to position (4).

The cruise control resumes the last set speed.

 Remove your foot from the accelerator pedal.

Useful features

Map pocket in passenger footwell

Warning!

\triangle

Do not place heavy or fragile objects, or objects having sharp edges in the map pocket.

In an accident, during hard braking or sudden maneuvers, they could be thrown around inside the vehicle, and cause injury to vehicle occupants. Storage compartments

Warning!

To help avoid personal injury during a collision or sudden maneuver, exercise care when storing objects in the vehicle. Put luggage or cargo in the trunk. Do not pile luggage or cargo higher than the seat backs. Do not place anything on the shelf below the rear window.

∕!∖

Luggage nets cannot secure hard or heavy objects.

Keep compartment lids closed. This will help to prevent stored objects from being thrown about and injuring vehicle occupants during an accident.


Armrest storage compartment



Reach into the recess and lift armrest.
 The armrest opens automatically.

Useful features

Center storage compartment




Release button
 Cover

▶ Press release button ①.

Cover (2) opens automatically.

The telephone is installed in the cover of the storage compartment.

Rear storage compartment



- Release button
 Cover
- ▶ Press release button ①.

Cover (2) opens automatically.

Parcel net in trunk

There is a net available in the trunk to secure loads:

- Pull the trunk floor net from the trunk back wall towards the front over the luggage.
- ► Hang the hooks of the net on the eyes on the trunk floor.

Useful features

Ashtray and cigarette lighter

The ashtray and the cigarette lighter are located in the storage compartment under the armrest.



Cigarette lighter
 Ashtray insert

Ashtray

Warning!

Remove front ashtray only with vehicle standing still.

Removing ashtray insert

▶ Pull insert ② upwards.

Replacing ashtray insert

 Press the insert into the holder until you hear it click into place.

Cigarette lighter

Warning!

/!\

\wedge

Never touch the heating element or sides of the lighter; they are extremely hot. Hold the knob only.

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

- Switch on the ignition (\triangleright page 40).
- ▶ Push in cigarette lighter ①.

The cigarette lighter pops out automatically when hot.

Useful features


!

The lighter socket can accommodate 12V DC electrical accessories (up to a maximum of 85 W) designed for use with the standard "cigarette lighter" plug type. Keep in mind, however, that connecting accessories to the lighter socket (for example extensive connecting and disconnecting, or using plugs that do not fit properly) can damage the lighter socket. With the socket damaged, the lighter may no longer be able to be placed in the heating (pushed-in) position, or the lighter may pop out too early with the lighter not hot enough.

To help avoid damaging the cigarette lighter socket, we recommend connecting 12V DC electrical accessories designed for use with a standard "cigarette lighter" plug type to the 12 V power outlets in your vehicle whenever possible.

Power outlet

The power outlet is located on the left side in the trunk.



- 1 Power outlet
- Switch on the ignition (\triangleright page 40).
- Flip up cover and insert electrical plug (cigar lighter type).

1

The power outlet can be used to accommodate 12V DC electrical accessories (e.g. air pump, auxiliary lamps) up to a maximum of 180 W or as a battery charging point (▷ page 358).

Telephone

The telephone is located in the center storage compartment (\triangleright page 201).

Warning!



Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and personal injury.

Useful features

Radio transmitters, such as a portable telephone or a citizens band unit, should only be used inside the vehicle if they are connected to an antenna that is installed on the outside of the vehicle.

The external antenna must be approved by Mercedes-Benz. Please contact an authorized Mercedes-Benz Center for information on the installation of an approved external antenna. Refer to the radio transmitter operation instructions regarding use of an external antenna.

Warning!

Please do not forget that your primary responsibility is to drive the vehicle. A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call.

If you choose to use the telephone¹ while driving, please use the hands-free device and only use the telephone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Observe all legal requirements.



You can take and place telephone calls using the \bigcirc and \bigcirc buttons on the steering wheel. To carry out other telephone functions, use the control system (\triangleright page 139).

See separate instruction manual for instructions on how to operate the telephone.

1

For additional information on operating the telephone using the audio system head unit, see "Telephone operation" (▷ page 160).

1

Standard Mercedes-Benz cellular phone design shown, SLR phone design may vary.

Useful features

Removing the cellular phone from the cellular phone cradle



- 1 Release button
- (2) Remove the cellular phone
- Press the release button (1) and remove the cellular phone in direction of arrow (2) from the cellular phone cradle.

Inserting the cellular phone in the cellular phone cradle

 Remove the round aerial contact cover on the back of the cellular phone.



- (1) Insert the cellular phone
- ② Connector contact
- (3) Cellular phone cradle
- Slide the lower end of the cellular phone in direction of arrow (1) into connector contact (2) on cellular phone cradle (3).



- ④ Release button
- (5) Engage the cell phone in cellular phone cradle
- Push the top of the cellular phone in direction of arrow (5), until the lug on the cellular phone release button (4) engages.

The battery will be charged depending on its charge status and the position of the SmartKey in the starter switch. The charging process is shown in the cellular phone display.

Useful features

$\triangleright \triangleright$

A

If you insert the cellular phone in the cellular phone cradle and the SmartKey is not in the starter switch, the cellular phone will remain on for approximately 1 minute. If you make a call during this time, the cellular phone will be switched off approximately 1 minute (delayed switch-off time) after you hang up.

When you remove the SmartKey from the starter switch, the cellular phone remains on for approximately 1 minute.

Making calls in private mode



- ① Release button
- (2) Cellular phone cradle
- ▶ Press the release button ①.

The cellular phone cradle (2) folds up.



③ Holder

(4) Remove the cellular phone and cradle

(5) Cellular phone flap

- Remove the cellular phone, together with the cellular phone cradle (2) in direction of arrow (4), from the holder (3).
- ► Fold the cellular phone flap (5) up.

Useful features

Re-inserting the cellular phone



Fold the cellular phone flap down
 Insert the cellular phone and cradle

- ► Fold the cellular phone flap ① down.
- Guide the cellular phone, together with the cellular phone cradle in direction of arrow (2), into the holder.



- ③ Engage cellular phone cradle
- Push the top of the cellular phone in direction of arrow (3), until the cellular phone cradle engages in the holder.

!

To prevent any damage, the cellular phone flap must be folded down before closing the telephone compartment.

Making calls in hands-free mode

- ▶ Open the cellular phone flap.
- Either accept the call or dial the desired number.
- Close the cellular phone flap.
 Hands-free mode is selected.

If you wish to change back to private mode:

- ► Open the cellular phone flap.
- ► Remove the cellular phone from the holder (▷ page 206).

1

For additional information on operating the telephone using the audio system head unit, refer to "Telephone operation" (▷ page 160) in chapter "Audio system".

For additional information on operating the telephone using the multifunction steering wheel, refer to "Control system" (\triangleright page 139).

Useful features

Tele Aid

!

If you have any questions regarding activation, please call the Response Center at 1-800-756-9018 (in the USA) or 1-888-881-6611 (in Canada).

Shortly after the completion of your Tele Aid acquaintance call, you will receive a user ID and password. By visiting www.mbusa.com and selecting "Tele Aid" (USA only), you will have access to account information, remote door unlock, and more.

The Tele Aid system

(<u>Tele</u>matic <u>A</u>larm <u>I</u>dentification on <u>D</u>emand)

The Tele Aid system consists of three types of response:

- automatic and manual emergency
- Roadside Assistance
- information

The Tele Aid system is operational providing that the vehicle's battery is charged, properly connected, not damaged and cellular and GPS coverage is available.

The speaker volume of a Tele Aid call can be adjusted when using the volume control on the audio system or on the multifunction steering wheel. To raise, turn the rotary volume control on the audio system clockwise or press button \blacksquare on the multifunction steering wheel. To lower, turn the rotary volume control on the audio system control counterclockwise or press button — on the multifunction steering wheel.

To activate, press the SOS button, the Roadside Assistance button or the Information button or ing on the type of response required.

1

The SOS button is located above the inside rear view mirror.

The Roadside Assistance button \square and the Information button \square are located in the center storage compartment (\triangleright page 201).

!

The Tele Aid system utilizes the cellular network for communication and the GPS (<u>Global Positioning System</u>) satellites for vehicle location. If either of these signals are unavailable, the Tele Aid system may not function and if this occurs, assistance must be summoned by other means.

Useful features

1

When a Tele Aid call has been initiated, the audio system is muted and the selected mode (radio or CD) pauses. The cellular phone (if installed) switches off. If you must use this phone, we recommend that you use it only with the vehicle at a standstill in a safe location. Remove the phone from the cradle and place the call. The multifunction display in the instrument cluster is available for use. After the Tele Aid call has ended, the optional cellular phone switches on again. A PIN entry might be necessary.

System self-check

Initially, after switching on the ignition, malfunctions are detected and indicated (the indicator lamps in the SOS button, the Roadside Assistance button and the Information button a stay on longer than 10 seconds or do not come on). The message Tele Aid - Drive to workshop appears for approximately 10 seconds in the multifunction display.

Warning!

If the indicator lamps in the SOS button, in the Roadside Assistance button, and/or in the Information button do not come on during the system self-check, or if any of these indicators remain illuminated continuously in red and/or the message Tele Aid -Drive to workshop is displayed in the multifunction display after the system self-check, a malfunction in the system has been detected.

If a malfunction is indicated as outlined above, the system may not operate as expected. Have the system checked at the nearest Mercedes-Benz Center as soon as possible.

Emergency calls

∕!∖

An emergency call is initiated automatically following an accident in which the emergency tensioning devices (ETDs) or airbags have deployed.

An emergency call can also be initiated manually by opening the cover next to the inside rear view mirror labeled SOS, then briefly pressing the button located under the cover.

For more information, see "Initiating an emergency call manually" (▷ page 211).

Useful features

Once the emergency call is in progress, the indicator lamp in the SOS button will begin to flash. The message Connecting call appears in the multifunction display. When the connection is established, the message Call connected appears in the multifunction display. All information relevant to the emergency, such as the location of the vehicle (determined by the GPS satellite location system), vehicle model, identification number and color are generated.

A voice connection between the Response Center and the occupants of the vehicle will be established automatically soon after the emergency call has been initiated. The Response Center will attempt to determine more precisely the nature of the accident provided they can speak to an occupant of the vehicle. The Tele Aid system is available if

- it has been activated and is operational. Activation requires a subscription for monitoring services, connection and cellular air time
- the relevant cellular phone network and GPS signals are available and pass the information on to the Response Center

1

Location of the vehicle on a map is only possible if the vehicle is able to receive signals from the GPS satellite network and pass the information on to the Response Center.

Warning!

 \land

If the indicator lamp in the SOS button is flashing continuously and there was no voice connection to the Response Center established, then the Tele Aid system could not initiate an emergency call (e.g. the relevant cellular phone network is not available). The message Call failed! appears in the multifunction display for approximately 10 seconds.

Should this occur, assistance must be summoned by other means.

Useful features

Initiating an emergency call manually



Cover SOS button

Briefly press on cover ①.
 The cover will open.

Press SOS button (2) briefly.

The indicator lamp in SOS button (2) will flash until the emergency call is concluded.

- Wait for a voice connection to the Response Center.
- Close cover ① after the emergency call is concluded.

Warning!

If you feel at any way in jeopardy when in the vehicle (e.g. smoke or fire in the vehicle, vehicle in a dangerous road location), please do not wait for voice contact after you have pressed the emergency button. Carefully leave the vehicle and move to a safe location. The Response Center will automatically contact local emergency officials with the vehicle's approximate location if they receive an automatic SOS signal and cannot make voice contact with the vehicle occupants.

Roads



The Roadside Assistance button **see** is located in the center armrest cover.



Roadside Assistance button

- Open the center storage compartment (▷ page 201).
- Press and hold the button ① (for longer than 2 seconds)

A call to a Mercedes-Benz Roadside Assistance dispatcher will be initiated. The button will flash while the call is in progress. The message Connecting call will appear in the multifunction display.

Useful features

When the connection is established, the message Call connected appears in the multifunction display. The Tele Aid system will transmit data generating the vehicle identification number, model, color and location (subject to availability of cellular and GPS signals).

A voice connection between the Roadside Assistance dispatcher and the occupants of the vehicle will be established.

 Describe the nature of the need for assistance.

The Mercedes-Benz Roadside Assistance dispatcher will either dispatch a qualified Mercedes-Benz technician or arrange to tow your vehicle to the nearest authorized Mercedes-Benz Center. For services such as labor and/or towing, charges may apply. Refer to the Roadside Assistance Manual for more information. These programs are only available in the USA:

 Sign and Drive services: Services such as jump start, a few gallons of fuel or the replacement of a flat tire are obtainable.

1

The indicator lamp in the Roadside Assistance button remains illuminated in red for approximately 10 seconds during the system self-check after switching on the ignition (together with the SOS button and the Information button **ref**).

See system self-check (> page 209) if the indicator lamp does not come on in red or stays on longer than approximately 10 seconds. If the indicator lamp in the Roadside Assistance button is illuminated continuously and there was no voice connection to the Response Center established, then the Tele Aid system could not initiate a Roadside Assistance call (e.g. the relevant cellular phone network is not available). The message Call failed! appears in the multifunction display.

Roadside Assistance calls can be terminated using the solution on the multifunction steering wheel.

Useful features

Information button

The Information button • is located in the center armrest cover.



- (1) Information button
- ► Open the center storage compartment (▷ page 201).
- Press and hold the button (1) (for longer than 2 seconds).

A call to the Customer Assistance Center will be initiated. The button will flash while the call is in progress. The message Connecting call will appear in the multifunction display. When the connection is established, the message Call connected appears in the multifunction display. The Tele Aid system will transmit data generating the vehicle identification number, model, color and location (subject to availability of cellular and GPS signals).

A voice connection between the Customer Assistance Center representative and the occupants of the vehicle will be established. Information regarding the operation of your vehicle, the nearest Mercedes-Benz Center or Mercedes-Benz USA products and services is available to you.

For more details concerning the Tele Aid system, please visit www.mbusa.com and use your ID and password (sent to you separately) to learn more (USA only).

1

The indicator lamp in the Information button remains illuminated in red for approximately 10 seconds during the system self-check after switching on the ignition (together with the SOS button and the Roadside Assistance button SC).

See system self-check (\triangleright page 209) if the indicator lamp does not come on in red or stays on longer than approximately 10 seconds.

If the indicator lamp in the Information button **red** is illuminated continuously and no voice connection to the Response Center was established, then the Tele Aid system could not initiate an Information call (e.g. the relevant cellular phone network is not available). The message Call failed! appears in the multifunction display.

Information calls can be terminated using the solution on the multifunction steering wheel.

Useful features

!

If the indicator lamps do not start flashing after pressing one of the buttons or remain illuminated (in red) at any time, the Tele Aid system has detected a malfunction or the service is currently not active, and may not initiate a call. Visit your Mercedes-Benz Center and have the system checked or contact the Response Center at 1-800-756-9018 (in the USA) or 1-888-881-6611 (in Canada) as soon as possible.

Call priority

A

If other service calls such as a Roadside Assistance call or Information call are active, an Emergency call is still possible. In this case, the Emergency call will take priority and override all other active calls.

The indicator lamp in the respective button flashes until the call is concluded. Emergency calls can only be terminated by a Response Center or Customer Assistance Center representative, whereas Roadside Assistance and Information calls can also be terminated by pressing button con the multifunction steering wheel.

!

If the indicator lamp continues to flash or the system does not reset, contact the Response Center at 1-800-756-9018 (in the USA) or 1-888-881-6611 (in Canada), or Mercedes-Benz Customer Assistance at 1-800-FOR-MERCedes (1-800-367-6372) in the USA or Customer Service at 1-888-881-6611 in Canada.

Useful features

Remote door unlock

In case you have locked your vehicle unintentionally (e.g. SmartKey inside vehicle), and the reserve SmartKey is not handy:

 Contact the Mercedes-Benz Response Center at 1-800-756-9018 (in the USA) or 1-888-881-6611 (in Canada).

You will be asked to provide your password which you provided when you completed the subscriber agreement.

Then return to your vehicle and pull the trunk recessed handle for a minimum of 20 seconds until the SOS button is flashing.

The message Connecting call appears in the multifunction display.

As an alternative, you may unlock the vehicle via Internet using the ID and password sent to you shortly after the completion of your acquaintance call.

The Response Center will then unlock your vehicle with the remote door unlocking feature.

1

The remote door unlock feature is available if the relevant cellular phone network is available.

The SOS button will flash and the message Connecting call will appear in the multifunction display to indicate receipt of the door unlock command.

Once the vehicle is unlocked, a Response Center specialist may attempt to establish voice contact with the vehicle occupants.

If the trunk recessed handle was pulled for more than 20 seconds before door unlock authorization was received by the Response Center, you must wait 15 minutes before pulling the trunk recessed handle again.

Stolen Vehicle Recovery services

In the event your vehicle was stolen:

▶ Report the incident to the police.

The police will issue a numbered incident report.

 Pass this number on to the Mercedes-Benz Response Center along with your password issued to you when you subscribed to the service.

The Response Center will then attempt to covertly contact the vehicle's Tele Aid system. Once the vehicle is located, the Response Center will contact the local law enforcement and you. The vehicle's location will only be provided to law enforcement.

1


When the anti-theft alarm or the tow-away alarm stays on for more than 30 seconds, a call is initiated automatically to the Response Center. See anti-theft alarm system (\triangleright page 90) and tow-away alarm (\triangleright page 92).

Useful features

Garage door opener

The integrated remote control is capable of operating up to three separately controlled devices. It provides a convenient way to replace up to three hand-held remote controls used to operate devices such as garage door openers, gate openers, or other devices compatible with HomeLink[®] or some other systems.

Before the integrated remote control can be used, it must be programmed to the garage door opener, gate operator or other device you wish to operate. See the following instructions for programming information.



Interior rear view mirror with integrated remote control

- (1) Indicator lamp
- (2) (3) (4) Signal transmitter button

Needed for programming (not part of vehicle equipment):

- Hand-held remote control of garage door opener, gate operator or other device
- Hand-held remote control button

Warning!

 \wedge

Before programming the integrated remote control to a garage door opener or gate operator, make sure people and objects are out of the way of the device to prevent potential harm or damage. When programming a garage door opener, the door moves up or down. When programming a gate operator, the gate opens or closes.

Do not use the integrated remote control with any garage door opener that lacks safety stop and reverse features as required by U.S. federal safety standards (this includes any garage door opener model manufactured before April 1, 1982). A garage door that cannot detect an object - signaling the door to stop and reverse does not meet current U.S. federal safety standards.

Useful features

When programming a garage door opener, it is advised to park outside the garage.

Do not run the engine while programming the integrated remote control. Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide, and inhaling it can cause unconsciousness and possible death.

Programming the integrated remote control

Step 1:

▶ Switch on the ignition (▷ page 40).

Step 2:

 If you have previously programmed an signal transmitter button and wish to retain its programming, proceed to step 3.

If you are programming the integrated remote control for the first time, press and hold the two outer signal transmitter buttons (2) and (4) and release them only when the indicator lamp (1) begins to flash after approximately 20 seconds (do not hold the button for longer than 30 seconds). This procedure erases any previous settings for all three channels and initializes the memory.

If you later wish to program a second and/or third hand-held transmitter to the remaining two signal transmitter buttons, do not repeat this step and begin directly with step 3. Step 3:

Hold the end of the hand-held remote control (5) of the device you wish to train approximately 2 to 5 in (5 to 12 cm) away from the signal transmitter button ((2), (3) or (4)) to be programmed, while keeping the indicator lamp (1) in view.

Step 4:

Using both hands, simultaneously press the hand-held remote control button (a) and the desired signal transmitter button ((2), (3) or (4)). Do not release the buttons until step 5 is completed.

The indicator lamp (1) will flash, first slowly and then rapidly. $\triangleright \triangleright$

Useful features

$\triangleright \triangleright$

The indicator lamp ① flashes immediately the first time the signal transmitter button is programmed. If this button has already been programmed, the indicator lamp will only start flashing after 20 seconds.

Step 5:

A

After the indicator lamp (1) changes from a slow to a rapidly flashing light, release the hand-held remote control button and the signal transmitter button.

Step 6:

Press and hold the just-trained signal transmitter button (2), (3) or (4) and observe the indicator lamp (1).

If the indicator lamp (1) stays on constantly, programming is complete and your device should activate when the respective signal transmitter button ((2), (3) or (4)) is pressed and released.

1

If the indicator lamp ① flashes rapidly for about 2 seconds and then turns to a constant light, continue with programming steps 8 through 12 as your garage door opener may be equipped with the "rolling code" feature.

Step 7:

► To program the remaining two signal transmitter buttons, repeat the steps above starting with step 3.

Rolling code programming

To train a garage door opener (or other rolling code devices) with the rolling code feature, follow these instructions after completing the "Programming" portion (steps 1 through 6) of this text. (A second person may make the following training procedures quicker and easier.)

Step 8:

 Locate "training" button on the garage door opener motor head unit.

Exact location and color of the button may vary by garage door opener brand. Depending on manufacturer, the "training" button may also be referred to as "learn"or "smart" button. If there is difficulty locating the transmitting button, refer to the garage door opener operator's manual.

Useful features

Step 9:

Press the "training" button on the garage door opener motor head unit.

The "training light" is activated.

You have 30 seconds to initiate the following step.

Step 10:

 Return to the vehicle and firmly press, hold for 2 seconds and release the programmed signal transmitter button (2), (3) or (4)).

Step 11:

 Press, hold for 2 seconds and release same signal transmitter button a second time to complete the training process.

1

Some garage door openers (or other rolling code equipped devices) may require you to press, hold for 2 seconds and release the same signal transmitter button a third time to complete the training process.

Step 12:

► Confirm the garage door operation by pressing the programmed signal transmitter button (②, ③ or ④).

Step 13:

► To program the remaining two signal transmitter buttons, repeat the steps above starting with step 3.

Gate operator/Canadian programming

Canadian radio-frequency laws require transmitter signals to "time-out" (or quit) after several seconds of transmission which may not be long enough for the integrated signal transmitter to pick up the signal during programming. Similar to this Canadian law, some U.S. gate operators are designed to "time-out" in the same manner.

If you live in Canada or if you are having difficulties programming a gate operator (regardless of where you live) by using the programming procedures, replace step 4 with the following:

Step 4:

 Press and hold the signal transmitter button (2), 3 or 4). Do not release this button until it has been successfully trained.

Useful features

- ▷▷▶ While still holding down the signal transmitter button (2), ③ or ④), "cycle" your hand-held remote control button ⑥ as follows: Press and hold button ⑥ for 2 seconds, then release it for 2 seconds, and again press and hold it for 2 seconds. Repeat this sequence on the hand-held remote control until the frequency signal has been learned. Upon successful training, the indicator lamp ① will flash slowly and then rapidly after several seconds.
 - Proceed with programming step 5 and step 6 to complete.

1

Upon completion of programming the integrated remote control, make sure you retain the hand-held remote control that came with the garage door opener, gate operator or other device. You may need it for use in other vehicles, for future programming of an integrated remote control, or simply for continued use as a hand-held remote control to operate the respective device in other situations.

Reprogramming a single signal transmitter button

To program a device using a signal transmitter button previously trained, follow these steps:

- Switch on the ignition (\triangleright page 40).
- Press and hold the desired signal transmitter button (2), (3) or (4).
 Do not release the button.
- The indicator lamp ① will begin to flash after 20 seconds. Without releasing the signal transmitter button, proceed with programming starting with step 3.

Useful features

Operation of integrated remote control

- Switch on the ignition (\triangleright page 40).
- Select and press the appropriate integrated signal transmitter button (2),
 (3) or (4) to activate the remote controlled device.

The integrated remote control transmitter continues to send the signal as long as the button is pressed – up to 20 seconds.

Erasing the integrated remote control memory

- Switch on the ignition (\triangleright page 40).
- Simultaneously press and hold down the outer signal transmitter buttons (2) and (4), for approximately 20 seconds, until the indicator lamp (1) flashes rapidly. Do not hold for longer than 30 seconds.

The codes of all three channels are erased.

1

If you sell your vehicle, erase the codes of all three channels.

Programming tips

If you are having difficulty programming the integrated remote control, here are some helpful tips:

- Check the frequency of the hand-held remote control (5) (typically located on the reverse side of the remote). The integrated remote control is compatible with radio-frequency devices operating between 288-399 MHz.
- Put a new battery in the hand-held remote control (5). This will increase the likelihood of the hand-held remote control sending a faster and more accurate signal to the integrated remote control.
- While performing step 3, hold the hand-held remote control (5) at different lengths and angles from the signal transmitter button ((2), (3) or (4)) you are programming. Attempt varying angles at the distance of 2 to 5 inches (5 to 12 cm) away or the same angle at varying distances.

Useful features

- If another hand-held remote control is available for the same device, try the programming steps again using that other hand-held remote control. Make sure new batteries are in the hand-held remote control before beginning the procedure.
- Straighten the antenna wire from the garage door opener assembly. This may help improve transmitting and/or receiving signals.

1

Certain types of garage door openers are incompatible with the integrated remote control. If you should experience further difficulties with programming the integrated remote control, contact an authorized Mercedes-Benz Center, or call Mercedes-Benz Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100.

1

USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

0

Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Useful features

Floormats

Warning!




When you are using floormats, make sure there is enough clearance and that the floormats are securely fastened.

Floormats must always be securely fastened using eyelets (1) and retainer pins (2).

Before driving off, check that the floormats are securely in place and adjust them if necessary. A loose floormat could slip and hinder proper functioning of the pedals.

Do not place two or more floormats on top of each other.

Installing



- Eyelet
 Retainer pins
- ► Lay down the floormat.
- Press eyelets (1) onto retainers pins (2) in direction of arrow.

Removing



- ▶ Pull the floormats off retainers pins.
- Remove the floormat.

Useful features

Dust cover

Warning!



Allow the engine to cool down completely before slipping the dust cover on your vehicle. Otherwise you could be seriously burned when coming into contact with the hot exhaust system.

!

To avoid damage to the vehicle and the dust cover, observe the following:

- Use the dust cover only when the vehicle is garaged.
- Cover the vehicle only when the engine has cooled down completely.

- The vehicle as well as the dust cover must be dry before slipping the dust cover on the vehicle.
- Remove the padlock that serves as an anti-theft device before slipping the dust cover on or off (▷ page 226).
- To avoid scratches, make sure the zip fastener and the steel cable do not come into contact with the vehicle (> page 226).
- Make sure the dust cover is clean and dry before inserting it in the bag provided with the dust cover.

1

Clean the dust cover according to the care label on the inside of the dust cover.

Useful features

Slipping dust cover on/off

 Place the rolled-up dust cover with its dark grey side facing downwards on the vehicle roof.

Make sure the FRONT label is facing towards the front of the vehicle.

- Roll the side that is labelled FRONT over the hood.
- Roll the rear part over the tail end of the vehicle.
- ► Unfold the dust cover.



- On the rear right, pull down the dust cover below the bumper.
- Pull down the dust cover on the right side of the vehicle.
- On the front right, pull down the dust cover below the bumper.

- On the rear left, pull down the dust cover below the bumper.
- Pull down the dust cover on the left side of the vehicle.
- On the front left, pull down the dust cover below the bumper.

1

You can now apply the anti-theft device, see "Anti-theft device for dust cover" (▷ page 226).

 $\triangleright \triangleright$


Useful features



 To remove the dust cover, follow the above steps in reverse order.

Anti-theft device for dust cover

The anti-theft device is located on the lower edge of the dust cover on the left side of the vehicle.



- Hook and loop fastener with fabric border
- (2) Zip fastener
- (3) Elastic band and steel cable
- ④ Eyes
- 5 Padlock¹

- ▶ Open hook and loop fastener ①.
- ▶ Open zip fastener ②.
- ► Tighten the steel cable by pulling elastic band ③.
- Secure both eyes (4) of the steel cable with a padlock (5).
- ► Close zip fastener ②.
- Close fabric border using hook and loop fastener 1.

Useful features

!

To avoid damage to the vehicle and the dust cover, observe the following:

- Once you have secured the dust cover with the anti-theft device, the dust cover can be removed only by using force. This can cause damage to the dust cover (tearing) or to the paintwork.
- The dust cover anti-theft device will not prevent burglary or vehicle theft.

Roof and trunk lid racks

Warning!

This vehicle has not been designed to accommodate any type of roof or trunk lid rack. Therefore do not fit such accessories. Otherwise the rack could fall off and cause serious personal injury.

!

Do not use any type of roof or trunk lid rack. Otherwise you will damage the bodywork or paintwork of your SLR. The first 1000 miles (1500 km)

Driving instructions

At the gas station

Engine compartment

Trunk

Tires and wheels

Winter driving

Maintenance

Vehicle care



The first 1000 miles (1500 km)

In the "Operation" section you will find detailed information on operating, maintaining and caring for your vehicle. The more cautiously you treat your vehicle during the break-in period, the more satisfied you will be with its performance later on. You should therefore observe the following for the first 1000 miles (1500 km):

- Drive at varying but moderate road and engine speeds.
- Do not drive faster than 150 mph (240 km/h).
- Break in new tires for the first 100 miles (160 km), therefore avoid high-speed cornering. Do not exceed a speed of 125 mph (200 km/h).
- Do not drive at engine speeds above 4500 rpm.
- Try to avoid heavy load on the engine (driving at full throttle) and driving at high engine speeds (maximum of ²/₃ of top speed of each gear) during this break-in period.
- Avoid accelerating by kick-down.
- Change gears in good time.

- Do not attempt to slow the vehicle down by shifting to a lower gear using the gear selector lever.
- Select positions **3**, **2** or **1** only when driving at moderate speeds (for hill driving).
- Select C as the preferred shift program (▷ page 173) for the first 1000 miles 1500 km).

After 1000 miles (1500 km), you may gradually bring the vehicle up to full road and engine speed.

All of the above instructions also apply when driving the first 1000 miles (1500 km) after the engine or the rear differential has been replaced.

1

Always obey applicable speed limits.

Driving instructions

Driving instructions

Drive sensibly – save fuel

Fuel consumption, to a great extent, depends on driving habits and operating conditions.

To save fuel you should:

- Keep tires at the recommended tire inflation pressures.
- Remove unnecessary loads.
- Allow engine to warm up under low load use.
- Avoid frequent acceleration and deceleration.
- Have all maintenance work performed at the intervals specified in the Maintenance Booklet and as required by the maintenance service display. Contact an authorized Mercedes-Benz Center.

Fuel consumption is also increased by driving in cold weather, in stop-and-go traffic, on short trips and in hilly area.

Drinking and driving

Warning!

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident are greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

Pedals

Warning!

 \wedge

Keep driver's foot area clear at all times. Objects stored in this area may impair pedal movement.

Driving instructions

Power assistance

Warning!

 \triangle

The brake system requires electrical energy for operation.

A malfunction in the vehicle's power supply or electrical system may impair brake system operation and switch it into its emergency operation mode. In such a case, the red brake warning lamp (\triangleright page 300) and warning messages (\triangleright page 307) in the instrument cluster come on while driving. To brake, the driver must then apply significantly greater brake pedal pressure and depress the pedal much further to obtain the expected braking effect. If necessary, apply full pressure to the brake pedal. Brakes are only applied to the front wheels. Stopping distance is increased! If there is a malfunction in the electrohydraulic brake system, we recommend that the vehicle be transported with all wheels off the ground using flatbed or appropriate wheel lift/dolly equipment.

A tow bar must be used if circumstances do not permit the use of the recommended towing methods and the vehicle requires towing with all four wheels on the ground. Towing the vehicle with all four wheels on the ground is only permissible for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h). For more information, see "Towing the vehicle" (\triangleright page 360).

With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.

Brakes

Warning!

 \wedge

After driving in heavy rain for some time without applying the brakes or through water deep enough to wet brake components, the first braking action may be somewhat reduced and increased pedal pressure may be necessary to obtain expected braking effect. Maintain a safe distance from vehicles in front.

Resting your foot on the brake pedal will cause excessive and premature wear of the brake pads.

It can also result in the brakes overheating thereby significantly reducing their effectiveness. It may not be possible to stop the vehicle in sufficient time to avoid an accident.

Driving instructions

After driving on wet or snow-covered roads, you should apply your brakes firmly before parking your vehicle. This produces heat which serves to dry the brake disks.

1

The brake system is designed to decelerate your SLR from high speeds at the best possible rate. Depending on the applied brake force, speed, and ambient conditions, the brake system may produce a squeak-type noise when you apply the brakes at a moderate rate, e.g. at city traffic. If you experience this noise, you should occasionally test the effectiveness of the brakes by applying above-normal braking pressure at high speeds. Please perform this braking procedure three times. This will also enhance the grip of the brake pads. If the noise continuous, contact an authorized Mercedes-Benz Center.

Warning!

Make sure not to endanger any other road users when carrying out these braking maneuvers.

!

Refer to the description of the Brake Assist System (BAS) (▷ page 81).

If the parking brake is released and the red brake warning lamp in the instrument cluster stays on, there is a malfunction in the electrohydraulic brake system (\triangleright page 300) or the brake fluid level in the reservoir is too low.

Brake pad wear or a leak in the system may be the reason for low brake fluid in the reservoir.

Have the brake system inspected immediately.

All checks and service work on the brake system should be carried out by qualified technicians only. Contact an authorized Mercedes-Benz Center.

Only install brake pads and brake fluid recommended by Mercedes-Benz.

Warning!

∕!∖

If other than recommended brake pads are installed, or other than recommended brake fluid is used, the braking properties of the vehicle can be degraded to an extent that safe braking is substantially impaired. This could result in an accident.

Be certain to read and observe the warning notices on brake pad replacement (▷ page 85).

Driving instructions

!

When driving down long and steep grades, relieve the load on the brakes by shifting into a lower gear to use the engine's braking power. This helps prevent overheating of the brakes and reduces brake pad wear.

After hard braking, it is advisable to drive on for some time, rather than immediately park, so the air stream will cool down the brakes faster.

Driving off

Apply the brakes to test them briefly after driving off. Perform this procedure only when the road is clear of other traffic.

Warm up the engine smoothly. Do not place full load on the engine until the operating temperature has been reached (\triangleright page 303).

When starting off on a slippery surface, do not allow a drive wheel to spin for an extended period with the ESP[®] switched off. Doing so may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Simultaneously depressing the accelerator pedal and applying the brake reduces engine performance and causes premature brake and drivetrain wear.

Parking

Ц

!

Set the parking brake whenever parking or leaving the vehicle. In addition, move gear selector lever to position **P**.

When parking on hills, always turn front wheels towards the road curb.

Warning!

Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

To reduce the risk of personal injury as a result of vehicle movement, before turning off the engine and leaving the vehicle always:

- Keep right foot on brake pedal.
- Pull the parking brake lever up as many notches as possible.
- Move the gear selector lever to position **P**.
- Slowly release brake pedal.
- When parked on an incline, turn front wheels towards the road curb.
- Turn the SmartKey in the starter switch to position **0** and remove the SmartKey from the starter switch.
- Take the SmartKey with you and lock the vehicle when leaving.

Driving instructions

Tires

Warning!

 \triangle

If you feel a sudden significant vibration or ride disturbance, or you suspect that possible damage to your vehicle has occurred, you should turn on the hazard warning flashers, carefully slow down, and drive with caution to an area which is a safe distance from the road.

Inspect the tires and the vehicle underbody for possible damage. If the vehicle or tires appear unsafe, have the vehicle towed to the nearest Mercedes-Benz Center or tire dealer for repairs.

Treadwear indicators (TWI) are required by law. These indicators are located in six places on the tread circumference and become visible at a tread depth of approximately $1/_{16}$ in (1.6 mm), at which point the tire is considered worn and should be replaced. The treadwear indicator appears as a solid band across the tread.

Warning!

Although the applicable federal motor vehicle safety laws consider a tire to be worn when the treadwear indicators (TWI) become visible at approximately $1/_{16}$ in (1.6 mm), we recommend that you do not allow your tires to wear down to that level. As tread depth approaches $1/_{8}$ in (3 mm), the adhesion properties on a wet road are sharply reduced.

Depending upon the weather and/or road surface (conditions), the tire traction varies widely.

Have worn tires replaced in pairs (front pair or rear pair). Otherwise the driving stability of the vehicle will be adversely affected. Specified tire inflation pressures must be maintained. This applies particularly if the tires are subjected to high loads (e.g. high speeds, heavy loads, high ambient temperatures).

Warning!



Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire or driving at high speed with a flat tire will cause excessive heat build-up and possibly a fire.

!

A wheel change should only be carried out at an authorized Mercedes-Benz Center. Otherwise there is a danger of damaging the vehicle by jacking it up incorrectly.

Driving instructions

Hydroplaning

Depending on the depth of the water layer on the road, hydroplaning may occur, even at low speeds and with new tires. Reduce vehicle speed, avoid track grooves in the road and apply brakes cautiously in the rain.

Tire traction

The safe speed on a wet, snow covered or icy road is always lower than on a dry road.

You should pay particular attention to the condition of the road whenever the outside temperatures are close to the freezing point.

Warning!



If ice has formed on the road, tire traction will be substantially reduced. Under such weather conditions, drive, steer and brake with extreme caution. Mercedes-Benz recommends winter tires (\triangleright page 287) with a minimum tread depth of approximately 1/6 in (4 mm) on all four wheels for the winter season to ensure normal balanced handling characteristics. On packed snow, they can reduce your stopping distance compared to summer tires. Stopping distance, however, is still considerably greater than when the road is not covered with snow or ice. Exercise appropriate caution.

!

Avoid spinning of a drive wheel. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Tire speed rating

Regardless of the tire speed rating, local speed limits should be obeyed. Use prudent driving speeds appropriate to prevailing conditions.

Warning!

 \wedge

Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure, causing loss of vehicle control and possibly resulting in an accident and/or personal injury and possible death, for you and for others.

Your vehicle is factory equipped with "(Y)"-rated tires, which have a speed rating of over 186 mph (300 km/h).

đ

For information on tire speed rating for winter tires, see "Winter tires*" (▷ page 287).

For additional general information on tire speed markings on tire sidewall, see "Tire speed rating" (\triangleright page 274).

Driving instructions

Winter driving instructions

The most important rule for slippery or icy roads is to drive sensibly and to avoid abrupt acceleration, braking and steering maneuvers. Do not use the cruise control system under such conditions.

When the vehicle is in danger of skidding, move gear selector lever to position **N**. Try to keep the vehicle under control by corrective steering action.

6

For information on driving with snow chains, see "Snow chains" (> page 288).

Warning!



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of control loss. Road salts and chemicals can adversely affect braking efficiency. Increased pedal force may become necessary to produce the normal braking effect.

Depressing the brake pedal periodically when traveling at length on salt-strewn roads can bring road-salt-impaired braking efficiency back to normal.

If the vehicle is parked after being driven on salt-treated roads, the braking efficiency should be tested as soon as possible after driving is resumed.

Warning!

Make sure not to endanger any other road users when carrying out these braking maneuvers.

Warning!



If the vehicle becomes stuck in snow, make sure snow is kept clear of the exhaust pipe and from around the vehicle with the engine running. Otherwise deadly carbon monoxide (CO) gases may enter vehicle interior resulting in unconsciousness and death.

To assure sufficient fresh air ventilation, open a window slightly on the side of the vehicle not facing the wind.

Warning!

/!\

\wedge

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice.

For more information, see "Winter driving" (▷ page 287).

Driving instructions

Standing water

!

Do not drive through flooded areas or water of unknown depth. Before driving through water, determine its depth. Never accelerate before driving into water. The bow wave could force water into the engine and auxiliary equipment, thus damaging them.

If you must drive through standing water, drive slowly to prevent water from entering the passenger compartment or the engine compartment. Water in these areas could cause damage to electrical components or wiring of the engine or transmission, or could result in water being ingested by the engine through the air intake causing severe internal engine damage. Any such damage is not covered by the Mercedes-Benz Limited Warranty.

Passenger compartment

Warning!

Always fasten items being carried as securely as possible.

In an accident, during hard braking or sudden maneuvers, loose items will be thrown around inside the vehicle, and cause injury to vehicle occupants unless the items are securely fastened in the vehicle.

The trunk is the preferred place to carry objects.

Driving abroad

Abroad, there is an extensive Mercedes-Benz service network at your disposal. If you plan to drive into areas which are not listed in the index of your Mercedes-Benz Center directory, you should request pertinent information from an authorized Mercedes-Benz Center.

Control and operation of radio transmitters

Radio and telephone

Warning!



Please do not forget that your primary responsibility is to drive the vehicle safely. Only operate the radio or telephone¹ if road, weather and traffic conditions permit.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Observe all legal requirements.

Driving instructions

Telephones and two-way radios

Warning!



Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and personal injury.

Radio transmitters, such as a portable telephone or a citizens band unit should only be used inside the vehicle if they are connected to an antenna that is installed on the outside of the vehicle.

Refer to the radio transmitter operation instructions regarding use of an external antenna.

Catalytic converter

Your Mercedes-Benz is equipped with monolithic-type catalytic converters, an important element in conjunction with the oxygen sensors to achieve substantial control of the pollutants in the exhaust emissions. Keep your vehicle in proper operating condition by following our recommended maintenance instructions as outlined in your Maintenance Booklet.

!

To prevent damage to the catalytic converters, only use premium unleaded gasoline in this vehicle.

Any noticeable irregularities in engine operation should be repaired promptly. Otherwise excessive unburned fuel may reach the catalytic converter, causing it to overheat and potentially start a fire.

Warning!

 \wedge

As with any vehicle, do not idle, park or operate this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

Warning!



The exhaust areas on the engine hood and between the doors and front wheels get very hot. Avoid contact with them, otherwise there is the risk of severe burns.

Driving instructions

Emission control

Certain systems of the engine serve to keep the toxic components of the exhaust gases within permissible limits required by law.

These systems, of course, will function properly only when maintained strictly according to factory specifications. Any adjustments on the engine should, therefore, be carried out only by qualified Mercedes-Benz Center authorized technicians. Engine adjustments should not be altered in any way. Moreover, the specified service jobs must be carried out regularly according to Mercedes-Benz servicing requirements. For details refer to the Maintenance Booklet.

Warning!

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide, and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open at all times.

Coolant temperature

During severe operating conditions and stop-and-go city traffic, the coolant temperature may rise close to approximately 248°F (120°C). The engine should not be operated with the coolant temperature over 248°F (120°C). Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

Warning!

 \wedge



- Driving when your engine is badly overheated can cause some fluids, which may have leaked into the engine compartment, to catch fire. You could be seriously burned.
- Steam from an overheated engine can cause serious burns and can occur just by opening the hood. Stay away from the engine if you see or hear steam coming from it.

Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

At the gas station

At the gas station

Refueling

Warning!



Gasoline is highly flammable and poisonous. It burns violently and can cause serious injury. Whenever you are around gasoline, avoid inhaling fumes and skin contact, extinguish all smoking materials. Never allow sparks, flame or smoking materials near gasoline!

The fuel filler flap is located on the right-hand side of the vehicle towards the rear. Locking/unlocking the vehicle with the SmartKey automatically locks/unlocks the fuel filler flap.



- Remove the SmartKey from the starter switch.
- Open the fuel filler flap by pushing at the point indicated by arrow.

The fuel filler flap opens.

 Turn fuel cap counterclockwise and hold on to it until possible pressure is released. Take off cap and set it in the recess on the fuel filler flap.

To prevent fuel vapors from escaping into open air, fully insert filler nozzle unit.

1

Only use premium unleaded gasoline with a minimum Posted Octane Rating of 91 (average of 96 RON/86 MON). Information on gasoline quality can normally be found on the fuel pump.

 Only fill your tank until the filler nozzle unit cuts out - do not top up or overfill.

Warning!



Overfilling of the fuel tank may create pressure in the system which could cause a gas discharge. This could cause the gas to spray back out when removing the fuel pump nozzle, which could cause personal injury.

 $\triangleright \triangleright$

At the gas station

- ▷▷► Replace fuel cap by turning it clockwise until it audibly engages.
 - Close the fuel filler flap until you hear the latch close shut.


1

More information on gasoline can be found in the Factory Approved Service Products pamphlet.

Leaving the engine running and the fuel cap open can cause the malfunction indicator lamp (USA only) or the malfunction indicator lamp (Canada only) to illuminate.

For more information, see "Practical hints" (\triangleright page 301).

Check regularly and before a long trip



Coolant
 Engine oil
 Brake fluid

Opening the hood, see (\triangleright page 244).

Coolant

For normal replenishing, use water (potable water quality). For more information, see "Coolant" (\triangleright page 250) and see "Fuels, coolants, lubricants, etc." (\triangleright page 377).

Engine oil level

For more information on engine oil level, see "Engine oil" (▷ page 247).

Brake fluid

!

If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks immediately. Notify an authorized Mercedes-Benz Center immediately. Do not add brake fluid as this will not solve the problem. For more information, see "Practical hints" (▷ page 300).

At the gas station

Windshield washer and headlamp cleaning system

For more information on filling up the washer reservoir, see "Windshield washer system and headlamp cleaning system" (> page 252).

Vehicle lighting

Check function and cleanliness. For more information on replacing light bulbs, see "Replacing bulbs" (▷ page 348).

Exterior lamp switch (\triangleright page 105).

Tire inflation pressure

For more information on tire inflation pressure, see "Checking tire inflation pressure manually" (\triangleright page 266).

Engine compartment

Hood

Warning!

 \wedge

Do not pull the release lever while the vehicle is in motion. Otherwise the hood could be forced open by passing air flow.

Warning!

The exhaust areas on the engine hood and between the doors and front wheels get very hot. Avoid contact with them, otherwise there is the risk of severe burns.

Opening

Warning!

 \wedge

To help prevent personal injury, stay clear of moving parts when the hood is open and the engine is running. Make sure the hood is properly closed before driving. When closing the hood, use extreme caution not to catch hands or fingers.

The radiator fan may also start at any time automatically, even after the SmartKey has been removed from the starter switch. Stay clear of fan blades.

Warning!



Engine components may become very hot. Avoid contact with them, otherwise there is the risk of severe burns.

Warning!

The engine is equipped with a transistorized ignition system. Because of the high voltage it is dangerous to touch any components (ignition coils, spark plug sockets, diagnostic socket) of the ignition system

- with the engine running
- while starting the engine
- if ignition is "on" and the engine is turned manually

Engine compartment

The release lever is located in the driver's footwell.



1 Release lever

!

Make sure the windshield wipers are not folded away from the windshield. Otherwise the windshield wipers or the hood could be damaged.

Make sure there is sufficient clearance before opening the hood. A minimum clearance in front of the vehicle of ${}^{3}/_{4}$ ft (25 cm) is required.

The hood folding mechanism is disengaged in two stages.


► Pull release lever ① downwards.


This completes the first stage.


1

If it was not possible to release the hood, pull the release lever downwards more firmly.

Engine compartment







P88.40-2378-31

▶ Pull the hood towards you to the stop.

P88.40-2380-31

Hood latch

The hood latches are located in the upper air intake next to the headlamp units.

▶ Pull the hood latches ②.

This completes the second stage.

▶ Press the front part of the hood.

The hood opens and will automatically be held in position by gas-filled spring struts.

!

P88.40-2379-31

Make sure there is sufficient clearance before opening the hood. A minimum overhead clearance of 6.6 ft (2.0 m) is required.


Engine compartment

Closing

Warning!

 \wedge

Be careful that you do not close the hood on anyone.



P88.40-2523-31

 Pull the hood upwards in the center, against the resistance of the gas-filled spring struts.

!

Make sure the rollers at the rear of the hood are engaged and the guide pins line up with the guide holes. Otherwise the hood may be damaged.

Hold the front center part of the hood with both hands and push it backwards. After pushing the hood backwards about half-way, you will feel the hood passing a crest and the resulting force pulling the hood away from you. At that point, let go of the hood and let it fall onto the latches.

The hood should now be locked and entirely closed.

• Check that the hood is properly closed.

If the hood is not properly engaged, repeat the closing procedure.

Engine oil

The amount of oil your engine needs will depend on a number of factors, including driving style. Higher oil consumption can occur when

- · the vehicle is new
- the vehicle is driven frequently at higher engine speeds

Engine oil consumption checks should only be made after the vehicle break-in period.

Oil consumption of the SLR is slightly higher than other vehicles. Please check the engine oil level frequently.

!

Do not use any special lubricant additives, as these may damage the drive assemblies. Using special additives not approved by Mercedes-Benz may cause damage not covered by the Mercedes-Benz Limited Warranty.


Engine compartment

Checking the engine oil level

When checking the oil level,


- the vehicle must be parked on level ground
- the engine must be at normal operating temperature (min. 80°C)
- Wait for at least 30 seconds with engine still at idle.
- Measure engine oil level with engine still at idle.

The dipstick and the cap are located on the passenger side in the engine compartment.



Dipstick
 Filler cap

- ▶ Pull out dipstick ① and wipe it off.
- Reinsert the dipstick fully into the guide.
- Pull out the dipstick again after 3 seconds.



Dipstick

The engine oil level must be between the lower (min) and upper (max) marks.

► Top up the engine oil if necessary.

1

The difference in level between the upper and lower marks represents a volume of about 2.1 US qt (2.0 l).

Engine compartment

Adding engine oil

Warning!

 \wedge

The filler cap on the filler neck could be hot. Use a rag when you unscrew the filler cap. Otherwise you could burn yourself.

!

Only use approved engine oils and oil filters required for vehicles with Maintenance System. For a listing of approved engine oils and oil filters, refer to the Factory Approved Service Products pamphlet in your vehicle literature portfolio, or contact an authorized Mercedes-Benz Center.

Using engine oils and oil filters of specification other than those expressly required for the Maintenance System, or changing of oil and oil filter at change intervals longer than those called for by the Maintenance System will result in engine damage not covered by the Mercedes-Benz Limited Warranty.

- Using a rag, unscrew filler cap (2) from filler neck.
- Add engine oil as required. Be careful not to overfill with oil.

Be careful not to spill any oil when adding. Avoid environmental damage caused by oil entering the ground or water.

!

Excess oil must be siphoned or drained off. It could cause damage to the engine and catalytic converter not covered by the Mercedes-Benz Limited Warranty.

▶ Screw the filler cap back on filler neck.

You will find further information about engine oil in the "Technical data" section (\triangleright page 378) and (\triangleright page 377).

Transmission fluid level

The transmission fluid level does not need to be checked. If you notice transmission fluid loss or gear shifting malfunctions, have an authorized Mercedes-Benz Center check the transmission.

Engine compartment

Coolant

The engine coolant is a mixture of water and anticorrosion/antifreeze. To check the coolant level, the vehicle must be parked on level ground and the engine must be cool.

The coolant expansion tank is located on the passenger side of the engine compartment.


- Using a rag, slowly open the cap approximately 1/2 turn to relieve excess pressure. If opened immediately, scalding hot fluid and steam will be blown out under pressure.
- Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts.

Warning!

\triangle

In order to avoid any possibly serious burns:

- Use extreme caution when opening the hood if there are any signs of steam or coolant leaking from the cooling system, or if the coolant temperature gauge indicates that the coolant is overheated.
- Do not remove pressure cap on coolant reservoir if coolant temperature is above 194°F (90°C). Allow engine to cool down before removing cap. The coolant reservoir contains hot fluid and is under pressure.



1 Expansion tank

Using a rag, turn cap slowly approximately one half turn to the left to release any excess pressure.

 Continue turning the cap to the left and remove it.

The coolant level is correct if the level

- for cold coolant: reaches the upper mark on the bracing rib of the expansion tank (arrow)
- for warm coolant: is approximately 0.4 in (1 cm) higher
- ► Add coolant as required.
- ▶ Replace and tighten cap.

For more information, see "Coolants" (\triangleright page 381).

Trunk

Trunk

Batteries

Your vehicle is equipped with two batteries.

- Starter battery in the trunk •
- Consumer battery in the trunk ٠

These batteries should always be sufficiently charged in order to achieve its rated service life. A flat battery must be fully recharged. Refer to Maintenance Booklet for battery maintenance intervals.


If you use your vehicle mostly for short-distance trips, you will need to have the battery charge checked more frequently.

When replacing batteries, always use batteries approved by Mercedes-Benz. Have this work only carried out by an authorized Mercedes-Benz Center.

If you do not intend to operate your vehicle for an extended period of time, consult an authorized Mercedes-Benz Center about steps you need to observe.



Observe all safety instructions and precautions when handling automotive batteries.





Keep flames or sparks away from battery. Do not smoke.



Battery acid is caustic. Do not allow it to come into contact with skin, eyes or clothing.

In case it does, immediately flush affected area with clean water and seek medical help if necessary.



Wear eye protection.



Keep children away.



Follow the instructions in this Operator's Manual.

I

You must not jump start the vehicle, otherwise the vehicle electrical systems could be damaged.

For more information on battery maintenance, see "Batteries" (\triangleright page 356).

Trunk

Windshield washer system and headlamp cleaning system

Fluid for the windshield washer system and the headlamp cleaning system is supplied from the windshield washer reservoir. It has a capacity of approximately 7.4 US qt (7 I).

During all seasons, add MB Windshield Washer Concentrate "S" to water. Premix the windshield washer fluid in a suitable container.

Refill the reservoir with MB Windshield Washer Concentrate and water (or commercially available premixed windshield washer solvent/antifreeze, depending on ambient temperatures).

Always use washer solvent/antifreeze where temperatures may fall below the freezing point. Failure to do so could result in damage to the washer system/reservoir.


!

Only use washer fluid which is suitable for plastic lenses. Improper washer fluid can damage the plastic lenses of the headlamps.

 \wedge

Warning!


Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned. The washer fluid reservoir is located in the trunk underneath the floor on the left hand side.



Quick-release fasteners
 Loop

- ► Lift up the interior floor panel by loop ②.
- ► Turn the quick-release fasteners counterclockwise ① and remove the cover.

Trunk



 (\certae) Cap for windshield washer reservoir

Opening washer fluid reservoir

▶ Pull up cap ③ by the tab.

Closing washer fluid reservoir

 Press cap (3) on to the filler neck until it engages fully.

For more information, see "Windshield and headlamp washer system" (> page 383).

Tires and wheels

For safety reasons, only use tires and rims which have been tested and approved by Mercedes-Benz for use on SLR vehicles.

See an authorized Mercedes-Benz Center for information on tested and recommended rims and tires for summer and winter operation. They can also offer advice concerning tire service and purchase.

Warning!

Replace rims or tires with the same designation, manufacturer and type as shown on the original part. See an authorized Mercedes-Benz Center for further information. If incorrectly sized rims and tires are mounted:

- The wheel brakes or suspension components can be damaged.
- The operating clearance of the wheels and the tires may no longer be correct.

Warning!

Worn, old tires can cause accidents. If the tire tread is badly worn, or if the tires have sustained damage, replace them.

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (▷ page 257). Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

When replacing rims, only use Genuine Mercedes-Benz wheel bolts specified for the particular rim type. Failure to do so can result in the bolts loosening and possibly an accident.

Retreaded tires are not tested or recommended by Mercedes-Benz, since previous damage cannot always be recognized on retreads. The operating safety of the vehicle cannot be assured when such tires are used.

Important guidelines

l

/!\

A wheel change should only be carried out at an authorized Mercedes-Benz Center. Otherwise there is a danger of damaging the vehicle by jacking it up incorrectly.

- For the first 100 miles (160 km) avoid high-speed cornering. Do not exceed a speed of 125 mph (200 km/h).¹
- Only use sets of tires and rims of the same type and make.
- Tires must be of the correct size for the rim.
- Regularly check the tires and rims for damage. Dented or bent rims can cause tire inflation pressure loss and damage to the tire beads.

Please always drive carefully and obey applicable speed limits.

Tires and wheels

- If vehicle is heavily loaded, check tire inflation pressure and correct as required.
- Do not allow your tires to wear down too far. Adhesion properties on wet roads are sharply reduced at tread depths under ¹/₈ in (3 mm).
- When replacing individual tires, you should mount new tires on the front wheels first (on vehicles with same-sized wheels all around).

Tire care and maintenance

Warning!

Regularly check the tires for damage. Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle.

Worn, old tires can cause accidents. If the tire tread is badly worn, or if the tires have sustained damage, replace them.

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (\triangleright page 257). Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

Regularly check your tire inflation pressure at least once a month. For more information on checking tire inflation pressure, see "Recommended tire inflation pressure" (▷ page 264).

Tire inspection

Every time you check your tire inflation pressure, you should also inspect your tires for the following:

- excessive treadwear (▷ page 256)
- cord or fabric showing through the tire's rubber
- bumps, bulges, cuts, cracks or splits in the tread or side of the tire

Replace the tire if you find any of the above conditions.

Warning!

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (\triangleright page 257). Otherwise, the driving stabili-

Life of tire


The service life of a tire is dependent upon varying factors including but not limited to:

ty of the vehicle will be adversely affected,

especially when driving at high speeds.

- Driving style
- Tire inflation pressure
- Distance driven

Warning!







Tires and wheels

Tread depth

Do not allow your tires to wear down too far. Adhesion properties on wet roads are sharply reduced at tread depths under 1/8 in (3 mm).

Treadwear indicators (TWI) are required by law. These indicators are located in six places on the tread circumference and become visible at a tread depth of approximately $1/_{16}$ in (1.6 mm), at which point the tire is considered worn and should be replaced.

Recommended minimum tire tread depth:

- Summer tires 1/8 in (3 mm)
- Winter tires $\frac{1}{6}$ in (4 mm)


Warning!

 \triangle

Although the applicable federal motor safety laws consider a tire to be worn when the treadwear indicators (TWI) become visible at approximately $1/_{16}$ in (1.6 mm), we recommend that you do not allow your tires

to wear down to that level. As tread depth approaches 1/8 in (3 mm), the adhesion properties on a wet road are sharply reduced.

Depending upon the weather and/or road surface (conditions), the tire traction varies widely.



① TWI (<u>T</u>read<u>W</u>ear <u>I</u>ndicator)

The treadwear indicator appears as a solid band across the tread.

Storing tires

!

Keep unmounted tires in a cool, dry place with as little exposure to light as possible. Protect tires from contact with oil, grease and gasoline.

Cleaning tires

ļ

Never use a round nozzle to power wash tires. The intense jet of water can result in damage to the tire.

Always replace a damaged tire.

Warning!

\wedge

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (▷ page 257). Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

Tires and wheels

Direction of rotation

Unidirectional tires offer added advantages, such as better hydroplaning performance. To benefit, however, you must make sure the tires rotate in the direction specified.

An arrow on the sidewall indicates the intended direction of rotation (spinning) of the tire.

Warning!

19" turbine-style wheels:


The wheels must be mounted corresponding to the labelling on the inside of the rim, where LEFT refers to the left-hand side of the vehicle and RIGHT to the right-hand side of the vehicle, both seen in direction of travel. When unidirectional tires are mounted, make sure that they rotate in the direction specified. Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

Loading the vehicle

Two labels on your vehicle show how much weight it may properly carry.

- The Tire and Loading Information placard (Example A) or the Vehicle Tire Information placard (Example B) can be found on the driver's door B-pillar. This placard tells you important information about the number of people that can be in the vehicle and the total weight that can be carried in the vehicle. It also contains information on the proper size and recommended tire inflation pressures for the original equipment tires on your vehicle.
- The Certification label found on the driver's door A-pillar (▷ page 368) tells you about the gross weight capacity of your vehicle, called the Gross Vehicle Weight Rating (GVWR). The GVWR includes the weight of the vehicle, all occupants, fuel and cargo. The Certification label also tells you about the front and rear axle weight capacity, called the Gross Axle Weight Rating (GAWR). The GAWR is the total allowable weight that can be carried by a single axle (front or rear). Never exceed the GVWR or GAWR for either the front axle or rear axle.

Tires and wheels



Tire and Loading Information

Warning!



Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure. Your vehicle is equipped with either the Tire and Loading Information placard (Example A) or the Vehicle Tire Information placard (Example B).

1

Data shown on placard examples are for illustration purposes only. Load limit data are specific to each vehicle and may vary from data shown in the illustrations below. Refer to placard on vehicle for actual data specific to your vehicle.

① Driver's door B-pillar

Following is a discussion on how to work with the information contained on the two placards with regards to loading your vehicle.

Tires and wheels

Placard (Example A)

	TIDE A	ND LOAD ING IN	CODMATION
*	SEATING C		FRONT 2 REAR 3
	-	upants and cargo should never	exceed XXX kg or XXX lbs.*
TIRE	SIZE	COLD TIRE PRESSURE	SEE OWNER'S
	P195/70R14	200KPA, 29PSI	MANUAL FOR
FRONT	P195/70R14	2001014,29131	MANUAL FUR
FRONT REAR	P195/70R14 P195/70R14	200KPA, 29PSI	ADDITIONAL INFORMATION

P40.00-2062-31

(1) Load limit information on the Tire and Loading Information placard

The placard showing the load limit information is located on the driver's door B-pillar. If your vehicle is equipped with the Tire and Loading Information placard (Example A), locate the statement "The combined weight of occupants and cargo should never exceed XXX kilograms or XXX lbs." on this placard. The combined weight of all occupants, cargo/luggage and trailer tongue load (if applicable) should never exceed the weight referenced in that statement.

Placard (Example B)

	INFORM	
VEHICLE CAPACITY WEIGH SEATING CAPACITY COLD TIRE PRESSURE	LBS)	
		P40.00-2055-31

(1) Load limit information on the Vehicle Tire Information placard

The placard showing the load limit information is located on the driver's door B-pillar. If your vehicle is equipped with the Vehicle Tire Information placard (Example B), locate the heading "Vehicle Capacity Weight" on this placard. The combined weight of all occupants, cargo/luggage and trailer tongue (if applicable) should never exceed the weight listed next to vehicle capacity weight.


Seating capacity

The seating capacity gives you important information on the number of occupants that can be in the vehicle. Your vehicle is equipped with either placard Example A or placard Example B located on the driver's door B-pillar (\triangleright page 258).

0

Data shown on placard examples are for illustration purposes only. Seating data are specific to each vehicle and may vary from data shown in the illustrations below. Refer to placard on vehicle for actual data specific to your vehicle.


Tires and wheels



/EHI LE CAPA	VEHICLE			
SEATING CAPA	CITY			
COLD TIRE PR	ESSURE			
			_	
-				
2 25		_		

Placard (Example A)

(1) Seating capacity



Steps for determining correct load limit

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

Step 1 (Vehicles equipped with placard Example A)

 Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.

Step 1 (Vehicles equipped with placard Example B)

 Locate the heading "Vehicle Capacity Weight" on your vehicle's placard.

Tires and wheels

Step 2

 Determine the combined weight of the driver and passengers that will be riding in your vehicle.

Step 3

 Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.

Step 4

► The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1400-750 (5×150) = 650 lbs).

Step 5

Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.

Step 6 (if applicable)

If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle (▷ page 263). The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a load limit of 1500 lbs. **This is for illustration purposes only**. Make sure you are using the actual load limit for your vehicle stated on the vehicle's placard (▷ page 259).

Tires and wheels

Example	Combined weight limit of occupants and cargo from placard	Number of occupants (driver and passengers)	Seating configura- tion	Occupants weight	Combined weight of all occupants	Available cargo/luggage and trailer tongue weight (total load limit or vehicle capacity weight from plac- ard minus combined weight of all occupants)
1	1500 lbs	2	2	Occupant 1: 150 lbs Occupant 2: 180 lbs	330 lbs	1500 lbs - 330 lbs = 1170 lbs
2	1500 lbs	1	1	Occupant 1: 200 lbs	200 lbs	1500 lbs - 200 lbs = 1300 lbs
3	1500 lbs	1	1	Occupant 1: 150 lbs	150 lbs	1500 lbs - 150 lbs = 1350 lbs

The higher the weight of all occupants, the less cargo and luggage load capacity is available.

For more information, see "Trailer tongue load" (\triangleright page 263).

Tires and wheels

Certification label

Even after careful determination of the combined weight of all occupants, cargo and the trailer tongue load (if applicable) (\triangleright page 263) as to not exceed the permissible load limit, you must make sure that your vehicle never exceeds the Gross Vehicle Weight Rating (GVWR) and the Gross Axle Weight Rating (GAWR) for either the front or rear axle. You can obtain the GVWR and GAWR from the Certification label. The Certification Label can be found on the driver's door A-pillar, see "Technical data" (\triangleright page 368).

Gross Vehicle Weight Rating (GVWR): The total weight of the vehicle, all occupants, all cargo, and the trailer tongue load (▷ page 263) must never exceed the GVWR.

Gross Axle Weight Rating (GAWR): The total allowable weight that can be carried by a single axle (front or rear).

To assure that your vehicle does not exceed the maximum permissible weight limits (GVWR and GAWR for front and rear axle), have the loaded vehicle (including driver, passengers and all cargo and, if applicable, trailer fully loaded) weighed on a suitable commercial scale.

Trailer tongue load

The tongue load of any trailer is an important weight to measure because it affects the load you can carry in your vehicle. If a trailer is towed, the tongue load must be added to the weight of all occupants riding and any cargo you are carrying in the vehicle. The tongue load typically is ten percent of the trailer weight and everything loaded in it.

Your Mercedes-Benz has been designed primarily to carry passengers and their cargo. Mercedes-Benz does not recommend trailer towing with your vehicle.

Tires and wheels

Recommended tire inflation pressure

Warning!



Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Your vehicle is equipped with either the Tire and Loading Information placard (Example A) or the Vehicle Tire Information placard (Example B) located on the driver's door B-pillar (▷ page 258). The tire inflation pressure should be checked regularly and should only be adjusted on cold tires. The tires can be considered cold if the vehicle has been parked for at least three hours or driven less than one mile (1.6 km).

Follow recommended cold tire inflation pressures listed on placard.


Keeping the tires properly inflated provides the best handling, tread life and riding comfort.

In addition to the tire placard on the driver's door B-pillar, also consult the fuel filler flap for any additional information pertaining to special driving situations. For more information, see "Important notes on tire inflation pressure" (> page 265).

6

Data shown on placard examples are for illustration purposes only. Tire data are specific to each vehicle and may vary from data shown in the illustrations below. Refer to placard on vehicle for actual data specific to your vehicle.

Placard (Example A)



P40.00-2064-31

(1) Tire and Loading Information placard with recommended cold tire inflation pressures

Placard (Example A) lists the recommended cold tire inflation pressures for maximum loaded vehicle weight. The tire inflation pressures listed apply to the tires installed as original equipment.

Tires and wheels

Placard (Example B)



 Vehicle Tire Information placard with recommended cold tire inflation pressures

Placard (Example B) lists the recommended cold tire inflation pressures for maximum loaded vehicle weight. The tire inflation pressures listed apply to the tires installed as original equipment.

0

Placard (Example B) may list recommended cold tire inflation pressures for different vehicle loads.

Important notes on tire inflation pressure

Warning!

If the tire inflation pressure repeatedly drops:

- Check the tires for punctures from foreign objects.
- Check to see whether air is leaking from the valves or from around the rim.

Tire temperature and tire inflation pressure are also increased while driving, depending on the driving speed and the tire load.

If you will be driving your vehicle at high speeds of 100 mph (160 km/h) or higher, where it is legal and conditions allow, consult the placard on the inside of the fuel filler flap on how to adjust the cold tire inflation pressure. If you do not adjust the tire inflation pressure, excessive heat can build up and result in sudden tire failure. Be sure to readjust the tire inflation pressure for normal driving speeds. You should wait until the tires are cold before adjusting the tire inflation pressure.

Some vehicles may have supplemental tire inflation pressure information for vehicle loads less than the maximum loaded vehicle condition. If such information is provided, it can be found on the placard located on the inside of the fuel filler flap.

Tire inflation pressure changes by approximately 1.5 psi (0.1 bar) per $18^{\circ}F(10^{\circ}C)$ of air temperature change. Keep this in mind when checking tire inflation pressure where the temperature is different from the outside temperature.

Tires and wheels

Checking tire inflation pressure

Regularly check your tire inflation pressure at least once a month.

Check and adjust the tire inflation pressure when the tires are cold. The tires can be considered cold if the vehicle has been parked for at least three hours or driven less than one mile (1.6 km).

If you check the tire inflation pressure when the tires are warm (the vehicle has been driven for several miles or sitting less than three hours), the reading will be approximately 4 psi (0.3 bar) higher than the cold reading. This is normal. Do not let air out to match the specified cold tire inflation pressure. Otherwise the tire will be underinflated.

Checking tire inflation pressure manually

Follow the steps below to achieve correct tire inflation pressure:

- Remove the cap from the valve on one tire.
- Firmly press a tire gauge onto the valve.
- ► Read tire inflation pressure on tire gauge and check against the recommended tire inflation pressure on the placard on the driver's door B-pillar (▷ page 264). If necessary, add air to achieve the recommended tire inflation pressure.

1

If you have overfilled the tire, release tire inflation pressure by pushing the metal stem of the valve with e.g. a tip of a pen. Then recheck the tire inflation pressure with the tire gauge.

- ▶ Install the valve cap.
- Repeat this procedure for each tire.

267

Operation

Tires and wheels

Checking tire inflation pressure electronically

The tire inflation pressure monitor only functions on wheels that are equipped with the proper electronic sensors. It monitors the tire inflation pressure, as selected by the driver, in all four tires. A warning is issued to alert you to a decrease in tire inflation pressure in one or more of the tires.

You can call up the tire inflation pressure monitoring display using the control system (\triangleright page 137).

1

After you have reactivated the tire inflation pressure monitor, the current tire inflation pressures will only be shown after a few minutes driving time. During this time you will see the following message in the multifunction display:

Tire pressure displayed only after driving a few minutes

1

Possible differences between the readings of a tire inflation pressure gauge of an air hose, e.g. gas station equipment, and the vehicle's control system can occur. The readings issued by the control system are more precise.

• Switch on the ignition (\triangleright page 40).

- Press button or on the multifunction steering wheel repeatedly until the standard display menu appears in the multifunction display (> page 117).
- Press button repeatedly until the current tire inflation pressures for each tire appear in the multifunction display.



1

You can select the unit of measure (bar/psi) used for the tire inflation pressure by changing the setting in the control system (\triangleright page 137). $\triangleright \triangleright$

Tires and wheels

$\triangleright \triangleright$

Warning!

When the tire inflation pressure monitoring system warning light is lit, one or more of your tires is significantly under-inflated. You should stop in a safe location and check your tires as soon as possible, and inflate them to the proper tire inflation pressure as indicated on the vehicle's tire information placard. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Each tire, including the spare, should be checked monthly when cold and set to the recommended tire inflation pressure as specified in the vehicle placard and owner's manual.

0

The recommended tire inflation pressures for your vehicle can be found on the tire placard located on the driver's door B-pillar. The tire inflation pressures are not listed in the owner's manual.

Warning!



The tire inflation pressure monitor does not indicate a warning for wrongly selected tire inflation pressures. Always adjust tire inflation pressure according to the placard on the driver's door B-pillar or, if available, the inside of the fuel filler flap.

The tire inflation pressure monitor is not able to issue a warning due to a sudden dramatic loss of tire inflation pressure (e.g. tire blowout caused by a foreign object). In this case bring the vehicle to a halt by carefully applying the brakes and avoiding abrupt steering maneuvers.

1

Operating radio transmission equipment (e.g. wireless headsets, two-way radios) in or near the vehicle could cause the tire inflation pressure monitor to malfunction.

Warning!

\wedge

Follow recommend tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

269

Operation

 $\triangleright \triangleright$

Tires and wheels

Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout.

Reactivating the tire inflation pressure monitor

The tire inflation pressure monitor must be reactivated in the following situations:

- If you have changed the tire inflation pressure
- If you have replaced the wheels or tires
- If you have installed new wheels or tires
- Using the tire placard on the driver's door B-pillar or, if available, the inside of the fuel filler flap, make sure the tire inflation pressure of all four tires is correct.

Press button repeatedly until you see the current tire inflation pressures for each tire appear in the multifunction display or the following message appears in the multifunction display: Tire pressure displayed only after driving a few minutes

1

If you are transporting a deflated tire and/or additional wheel sensors in the vehicle, do not activate the tire inflation pressure monitor until

- the deflated tire and/or additional wheel sensors are no longer in the vehicle
- you have inflated the tire to the correct tire inflation pressure

► Press the reset button on the instrument cluster (▷ page 29).

The following message will appear in the multifunction display: Monitor current tire pressure?

Tires and wheels

$\triangleright \triangleright \triangleright$ Press button +.

The following message will appear in the multifunction display: Tire pres. monitor

reactivated

The tire inflation pressure monitor will now monitor the tire inflation pressure values of all four tires.

The following message will appear in the multifunction display field:

Tire pressure displayed only after driving a few minutes

This display appears until the individual tire inflation pressure values are matched with the tires. The individual values are then displayed (\triangleright page 267).

If you wish to cancel activation:

Press button ____.

If one of the following messages appears in the multifunction display:

- Reactivate tire pressure monitor after rectifying pressure
- Tire pressure Please rectify
- Check the tire inflation pressures and correct them if necessary.
- Reactivate the tire inflation pressure monitor.

Potential problems associated with underinflated and overinflated tires

Underinflated tire inflation pressure

Underinflated tires can:

- cause excessive and uneven tire wear
- adversely affect fuel economy
- lead to tire failure from being overheated
- adversely affect handling characteristics

Warning!

\wedge

Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Tires and wheels

Overinflated tire inflation pressure

Overinflated tires can:

- adversely affect handling characteristics
- cause uneven tire wear
- be more prone to damage from road hazards

/!\

- adversely affect ride comfort
- increase stopping distance

Warning!


Follow recommended tire inflation pressures.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Tire labeling

Besides tire name (sales designation) and manufacturer name, a number of markings can be found on a tire.

Following are some explanations for the markings on your vehicle's tires:



- Uniform Quality Grading Standards
 (▷ page 279)
- ② DOT, Tire Identification Number (TIN) (▷ page 276)
- ③ Maximum tire load (▷ page 277)
- ④ Maximum tire inflation pressure (▷ page 278)
- (5) Manufacturer
- (6) Tire ply material (\triangleright page 281)
- ⑦ Tire size designation, load and speed rating (▷ page 272)
- (8) Load identification (▷ page 275)

⑦ Tire name

1

For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

For more information, see "Rims and tires" (\triangleright page 371).

Tires and wheels

Tire size designation, load and speed rating



- (1) Tire width
- (2) Aspect ratio in %
- (3) Radial tire code
- (4) Rim diameter
- (5) Tire load rating
- 6 Tire speed rating

1

For illustration purposes only. Actual data on tires is specific to each vehicle and may vary from data shown in above illustration.

General:

Depending on the design standards used, the tire size molded into the sidewall may have no letter or a letter preceding the tire size designation.

No letter preceding the size designation (as illustrated above): Passenger car tire based on European design standards.

Letter "P" preceding the size designation: Passenger car tire based on U.S. design standards.

Letter "LT" preceding the size designation: Light Truck tire based on U.S. design standards.

Letter "T" preceding the size designation: Temporary spare tires which are high pressure compact spares designed for temporary emergency use only.

Tire width

The tire width (1) (\triangleright page 272) indicates the nominal tire width in mm.

Aspect ratio

The aspect ratio (2) (\triangleright page 272) is the dimensional relationship between tire section height and section width and is expressed in percentage. The aspect ratio is arrived at by dividing section height by section width.

Tire code

The tire code ③ (▷ page 272) indicates the tire construction type. The "R" stands for radial tire type. Letter "D" means diagonal or bias ply construction; letter "B" means belted-bias ply construction.

At the tire manufacturer's option, any tire with a speed capability above 149 mph (240 km/h) can include a "ZR" in the size designation (for example: 245/40 ZR 18). For additional information, see "Tire speed rating" (\triangleright page 274).

Tires and wheels

Rim diameter

The rim diameter (4) (\triangleright page 272) is the diameter of the bead seat, not the diameter of the rim edge. Rim diameter is indicated in inches (in).

Tire load rating

The tire load rating (5) (\triangleright page 272) is a numerical code associated with the maximum load a tire can support.

For example, a load rating of 91 corresponds to a maximum load of 1356 lbs (615 kg) the tire is designed to support. See also "Maximum tire load" (▷ page 277) where the maximum load associated with the load index is indicated in kilograms and lbs.

Warning!

The tire load rating must always be at least half of the GAWR (\triangleright page 282) of your vehicle. Otherwise tire failure may be the result which may cause an accident and/or serious personal injury to you or others.

/!\

/!\

Always replace rims and tires with the same designation, manufacturer and type as shown on the original part.

Warning!

Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard located on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure. For additional information on tire load rating, see "Load identification" (> page 275).

() Tire load rating (5) (▷ page 272) and tire speed rating (6) (▷ page 272) are also referred to as "service description".

Tires and wheels

Tire speed rating

The tire speed rating b (\vartriangleright page 272) indicates the approved maximum speed for the tire.

Warning!

 $\underline{\wedge}$

Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure, causing loss of vehicle control and possibly resulting in an accident and/or personal injury and possible death, for you and for others.

0

Tire load rating (5) (\triangleright page 272) and tire speed rating (6) (\triangleright page 272) are also referred to as "service description".

Summer tires

Index	Speed rating
Q	up to 100 mph (160 km/h)
R	up to 106 mph (170 km/h)
S	up to 112 mph (180 km/h)
Т	up to 118 mph (190 km/h)
Н	up to 130 mph (210 km/h)
V	up to 149 mph (240 km/h)
W	up to 168 mph (270 km/h)
Y	up to 186 mph (300 km/h)
(Y)	above 186 mph (300 km/h)
ZR	above 149 mph (240 km/h)

 At the tire manufacturer's option, any tire with a speed capability above 149 mph (240 km/h) can include a "ZR" in the size designation (for example: 245/40 ZR18). To determine the maximum speed capability of the tire, the service description for the tire must be referred to. The service description is comprised of the tire load rating (5) (\triangleright page 272) and the tire speed rating (6) (\triangleright page 272).

If your tire includes "ZR" in the size designation and no service description (5) and (6) (▷ page 272) is given, the tire manufacturer must be consulted for the maximum speed capability.

If a service description (5) and (6) (\triangleright page 272) is given, the speed capability is limited by the speed symbol in the service description. Example: 245/40 ZR18 97Y. In this example, "97Y" is the service description. The letter "Y" designates the speed rating and the speed capability of the tire is limited to 186 mph (300 km/h).

Tires and wheels

 Any tire with a speed capability above 186 mph (300 km/h) must include a "ZR" in the size designation AND the service description must be placed in parenthesis. Example: 275/40 ZR 18 (99Y). The "(Y)" speed rating in parenthesis designates the maximum speed capability of the tire as being above 186 mph (300 km/h). Consult the tire manufacturer for the actual maximum permissible speed of the tire.

All-season and winter tires

Index		Speed rating			
Q	M+S ¹	up to 100 mph (160 km/h)			
Т	M+S ¹	up to 118 mph (190 km/h)			
Н	M+S ¹	up to 130 mph (210 km/h)			
V	M+S ¹	up to 149 mph (240 km/h)			

¹ or M+S 🛕 for winter tires

Ð

Not all M+S rated tires provide special winter performance. Make sure the tires you use show M+S and the mountain/snowflake A marking on the tire sidewall. These tires meet specific snow traction performance requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) and have been designed specifically for use in snow conditions.

Load identification



1 Load identification

1

For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

Tires and wheels

In addition to tire load rating, special load information may be molded into the tire sidewall following the letter designating the tire speed rating (1) (\triangleright page 275).

No specification given: absence of any text (like in above example) indicates a standard load (SL) tire.

XL (Extra Load): designates an extra load (or reinforced) tire.

Light Load: designates a light load tire.


C, D, E: designates load range associated with the maximum load a tire can carry at a specified pressure.

DOT, Tire Identification Number (TIN)

U.S. tire regulations require each new tire manufacturer or tire retreader to mold a TIN into or onto a sidewall of each tire produced.

The TIN is a unique identifier which facilitates efforts by tire manufactures to notify purchasers in recall situations or other safety matters concerning tires and gives purchasers the means to easily identify such tires.

The TIN is comprised of "Manufacturer's identification mark", "Tire size", "Tire type code" and "Date of manufacture".



1 DOT

- (2) Manufacturer's identification mark
- ③ Tire size
- (4) Tire type code (at the option of the tire manufacturer)
- (5) Date of manufacture

1

For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

Tires and wheels

DOT (Department of Transportation)

A tire branding symbol (1) (\triangleright page 276) which denotes the tire meets requirements of the U.S. Department of Transportation.

Manufacturer's identification mark

The manufacturer's identification mark (2) $(\triangleright$ page 276) denotes the tire manufacturer.

New tires have a mark with two symbols.

Retreaded tires have a mark with four symbols. For more information on retreaded tires, see (\triangleright page 254).

Tire size

The code (3) (\triangleright page 276) indicates the tire size.

Tire type code

The code ($(\triangleright$) page 276) may, at the option of the manufacturer, be used as a descriptive code for identifying significant characteristics of the tire.

Date of manufacture

The date of manufacture (5) (\triangleright page 276) identifies the week and year of manufacture.

The first two figures identify the week, starting with "01" to represent the first full week of the calendar year. The second two figures represent the year.

For example, "3202" represents the 32nd week of 2002.

Maximum tire load



(1) Maximum tire load rating

1

For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

The maximum tire load is the maximum weight the tires are designed to support.

Tires and wheels

Warning!



Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard located on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

For more information on tire load rating (\triangleright page 273).

For information on calculating total and cargo load capacities (\triangleright page 260).

Maximum tire inflation pressure



 Maximum permissible tire inflation pressure

1

For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

This is the maximum permissible tire inflation pressure for the tire.

Always follow the recommended tire inflation pressure (\triangleright page 264) for proper tire inflation.

Warning!



Never exceed the max. tire inflation pressure. Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Tires and wheels

Uniform Tire Quality Grading Standards (U.S. vehicles)

Tire manufacturers are required to grade tires based on three performance factors: treadwear, traction and temperature resistance.



1 Treadwear

- Traction
- Temperature resistance

1

For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration. Quality grades can be found, where applicable, on the tire sidewall between tread shoulder and maximum section width. For example:

Treadwear	Traction	Temperature
200	AA	А

All passenger car tires must conform to federal safety requirements in addition to these grades.

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half $(1^{1}/_{2})$ times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Tires and wheels

Traction

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

Warning!

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Temperature

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning!

 \wedge

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

Tires and wheels

Tire ply material



Plies in sidewall
 Plies under tread

Ð

For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

This marking tells you about the type of cord and number of plies in the sidewall and under the tread.

Tire and loading terminology

Accessory weight

The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio, and heater, to the extent that these items are available as factory-installed equipment (whether installed or not).

Air pressure

The amount of air inside the tire pressing outward on each square inch of the tire. Air pressure is expressed in pounds per square inch (psi), or kilopascal (kPa) or bars.

Aspect ratio

Dimensional relationship between tire section height and section width expressed in percentage.

Bar

Another metric unit for air pressure. There are 14.5038 pounds per square inch (psi) to 1 bar; there are 100 kilopascals (kPa) to 1 bar.

Bead

The tire bead contains steel wires wrapped by steel cords that hold the tire onto the rim.

Cold tire inflation pressure

Tire inflation pressure when your vehicle has been sitting for at least three hours or driven no more than one mile (1.6 km).

Curb weight

The weight of a motor vehicle with standard equipment including the maximum capacity of fuel, oil, and coolant, and, if so equipped, air conditioning and additional optional equipment, but without passengers and cargo.

Tires and wheels

DOT (Department of Transportation)

A tire branding symbol which denotes the tire meets requirements of the U.S. Department of Transportation.

GAWR (Gross Axle Weight Rating)

The GAWR is the maximum permissible axle weight. The gross vehicle weight on each axle must never exceed the GAWR for the front and rear axle indicated on the Certification label located on the driver's door A-pillar.

GVW (Gross Vehicle Weight)

The GVW comprises the weight of the vehicle including fuel, tools, spare wheel, installed accessories, passengers and cargo and, if applicable, trailer tongue load. The GWV must never exceed the GWVR indicated on the Certification label located on the driver's door A-pillar.

GVWR (Gross Vehicle Weight Rating)

This is the maximum permissible vehicle weight of the fully loaded vehicle (weight of the vehicle including all options, passengers, fuel, and cargo and, if applicable, trailer tongue load). It is indicated on Certification label located on the driver's door A-pillar.

Kilopascal (kPa)

The metric unit for air pressure. There are 6.9 kPa to 1 psi; another metric unit for air pressure is bars. There are 100 kilopascals (kPa) to 1 bar.

Maximum load rating

The maximum load in kilograms and pounds that can be carried by the tire.

Maximum loaded vehicle weight

The sum of curb weight, accessory weight, vehicle capacity weight and production options weight.

Maximum tire inflation pressure

This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions.

Normal occupant weight

The number of occupants the vehicle is designed to seat, multiplied by 68 kilograms (150 lbs).

Occupant distribution

The distribution of occupants in a vehicle at their designated seating positions.

Production options weight

The combined weight of those installed regular production options weighing over 5 lbs (2.3 kilograms) in excess of those standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim.

Tires and wheels

PSI (Pounds per square inch)

A standard unit of measure for air pressure -> bar, kilopascal (kPa).

Recommended tire inflation pressure

Recommended tire inflation pressure listed on placard located on driver's door B-pillar for normal driving conditions. Provides best handling, tread life and riding comfort.

Rim

A metal support for a tire or a tire and tube assembly upon which the tire beads are seated.

Sidewall

The portion of a tire between the tread and the bead.

TIN (<u>Tire Identification Number</u>)

Unique identifier which facilitates efforts by tire manufacturers to notify purchasers in recall situations or other safety matters concerning tires and gives purchases the means to easily identify such tires. The TIN is comprised of "Manufacturer's identification mark", "Tire size", "Tire type code" and "Date of manufacture".

Tire load rating

Numerical code associated with the maximum load a tire can support.

Tire ply composition and material used

This indicates the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. Tire manufacturers also must indicate the ply materials in the tire and sidewall, which include steel, nylon, polyester, and others.

Tire speed rating

Part of tire designation; indicates the speed range for which a tire is approved.

Traction

Force exerted by the vehicle on the road via the tires. The amount of grip provided.

Tread

The portion of a tire that comes into contact with the road.

Treadwear indicators

Narrow bands, sometimes called "wear bars" that show across the tread of a tire when only $^{1}/_{16}$ in (1.6 mm) of tread remains.

Tires and wheels

Uniform Tire Quality Grading Standards

A tire information system that provides consumers with ratings for a tire's traction, temperature and treadwear. Ratings are determined by tire manufacturers using government testing procedures. The ratings are molded into the sidewall of the tire.

Vehicle capacity weight

Rated cargo and luggage load plus 68 kilograms (150 lbs) times the vehicle's designated seating capacity.

Vehicle maximum load on the tire

Load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight and dividing it by two.

Rotating tires

!

A wheel change should only be carried out at an authorized Mercedes-Benz Center. Otherwise there is a danger of damaging the vehicle by jacking it up incorrectly.

Warning!

Rotate front and rear wheels only if the tires are of the same dimension.

If your vehicle is equipped with mixed-size tires (different tire dimensions front vs. rear), tire rotation is not possible.

Tire rotation can be performed on vehicles with tires of the same dimension all around. If your vehicle is equipped with tires of the same dimension all around, tires can be rotated, observing a front-to-rear rotation pattern that will maintain the intended rotation (spinning) direction of the tire (\triangleright page 257).

In some cases, such as when your vehicle is equipped with mixed-size tires (different tire dimension front vs. rear), tire rotation is not possible.

If applicable to your vehicle's tire configuration, tires can be rotated according to the tire manufacturer's recommended intervals in the tire manufacturer's warranty pamphlet located in your vehicle literature portfolio. If none is available, tires should be rotated every 3000 to 6000 miles (5000 to 10000 km), or sooner if necessary, according to the degree of tire wear. The same rotation (spinning) direction must be maintained (\triangleright page 257).

Rotate tires before the characteristic tire wear pattern becomes visible (shoulder wear on front tires and tread center wear on rear tires).

Tires and wheels

Thoroughly clean the mounting face of wheels and brake disks, i.e. the inner side of the wheels/tires, during each rotation. Check for and ensure proper tire inflation pressure.

Warning!

Have the tightening torque checked after changing a wheel. Wheels could become loose if not tightened with a torque of 95 lb-ft (130 Nm).

Only use Genuine Mercedes-Benz wheel bolts specified for your vehicle's rims.

For information on wheel change, see the "Practical hints" section (▷ page 351).

Anti-theft wheel nuts

Your vehicle is equipped with anti-theft wheel nuts that prevent the theft of your vehicle's wheels.

Warning!

Pull the parking brake lever up as many notches as possible and move the gear selector lever to position **P**, before loosening the wheel bolts. Otherwise the vehicle may move and cause an accident and/or serious personal injury.

!

Do not use air tools, such as an impact wrench, when installing or removing the anti-theft wheel nuts. An impact wrench can damage the anti-theft wheel nuts and the wheel nut key, or cause them to malfunction.

!

/!`

Store wheel bolts and anti-theft wheel nuts not currently in use in a safe place to avoid damage to the threads.



Anti-theft wheel nut
 Wheel nut key

Tires and wheels

Removing anti-theft wheel nuts

- Unscrew anti-theft wheel nut ① using wheel nut key ②.
- ► Replace anti-theft wheel nut ① with one of the regular wheel bolts.
- Fasten the wheel bolt and tighten it with a torque wrench to a tightening torque of 95 lb-ft (130 Nm).

Warning!

The wheels could come loose if the wheel bolts are not tightened to a torque of 95 lb-ft (130 Nm). Have the tightening torque checked after changing a wheel.

Fitting anti-theft wheel nuts

- Unscrew a wheel bolt from one of the wheels.
- Replace that wheel bolt with one of the anti-theft wheel nuts (1) delivered with your vehicle.
- Fasten anti-theft wheel nut (1) using wheel nut key (2) and tighten with a torque wrench to a tightening torque of 95 lb-ft (130 Nm).

Warning!

/!\

The wheels could come loose if the wheel bolts are not tightened to a torque of 95 lb-ft (130 Nm). Have the tightening torque checked after changing a wheel.

1

Keep the anti-theft wheel nut key in a convenient place in your vehicle where you and service personnel can always find it easily when it is needed.

1

If you should lose the anti-theft wheel nut key or one of the anti-theft wheel nuts, please contact an authorized Mercedes-Benz Center for a replacement.

Winter driving

Winter driving

Before the onset of winter, have your vehicle winterized at an authorized Mercedes-Benz Center. This service includes:

- Check of anticorrosion and antifreeze concentration.
- Addition of cleaning concentrate to the water of the windshield and headlamp cleaning system. Add MB Concentrate "S" to a premixed windshield washer solvent/antifreeze which is formulated for below freezing temperatures (▷ page 383).
- Battery test. Battery capacity drops with decreasing ambient temperature. A well charged battery helps to make sure that the engine can be started, even at low ambient temperatures.
- Tire change. Mercedes-Benz recommends M+S rated radial-ply tires with a minimum tread depth of approximately ¹/₆ in (4 mm) on all four wheels for the winter season.

Winter tires*

!

A wheel change should only be carried out at an authorized Mercedes-Benz Center. Otherwise there is a danger of damaging the vehicle by jacking it up incorrectly.

Always use winter tires at temperatures below 45°F (7°C) and whenever wintry road conditions prevail. Not all M+S rated tires provide special winter performance. Make sure the tires you use show the mountain/snowflake A marking on the tire sidewall. These tires meet specific snow traction performance requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) and have been designed specifically for use in snow conditions. Use of winter tires is the only way to achieve the maximum effectiveness of the ABS and ESP[®] in winter operation. For safe handling, make sure that all mounted winter tires are of the same make and have the same tread design.

Warning!



Winter tires with a tread depth under 1/6 in (4 mm) must be replaced. They are no longer suitable for winter operation.

Always observe the speed rating of the winter tires installed on your vehicle. If the maximum speed for which your tires are rated is below the speed rating of your vehicle, you must place a notice to this effect where it will be seen by the driver. Such notices are available from your tire dealer or from any authorized Mercedes-Benz Center.

Winter driving

Snow chains

Snow chains should only be driven on snow-covered roads at speeds not to exceed 30 mph (50 km/h). Remove chains as soon as possible when driving on roads without snow.

1

When driving with snow chains, you may wish to deactivate the ESP[®] (▷ page 83) before setting the vehicle in motion. This will improve the vehicle's traction. Please observe the following guidelines when using snow chains:

- Use of snow chains is not permissible with all wheel/tire combinations.
- Snow chains should only be used on the rear wheels. Follow the manufacturer's mounting instructions.
- Only use snow chains that are approved by Mercedes-Benz. Your authorized Mercedes-Benz Center will be glad to advise you on this subject.
- Use of snow chains may be prohibited depending on location. Always check local and state laws before installing snow chains.

!

Use of snow chains is not permissible with tire sizes:

- 255/35 ZR19 (96Y) XL
- 295/30 ZR19 (100Y) XL
- 295/35 ZR18 (99Y)

Maintenance

Maintenance

In order to maintain the performance and safety of your SLR, we strongly recommend that you have your vehicle serviced by an authorized Mercedes-Benz Center, every 12 months, even if the vehicle has covered less than 10000 miles (15000 km) in that time.

The maintenance service indicator will notify you when your next maintenance service is due within the next 12 months or 10000 miles (15000 km), whichever comes sooner.

Failure to have the vehicle maintained in accordance with the Maintenance Booklet and maintenance service indicator at the designated times/mileage will result in vehicle damage not covered by the Mercedes-Benz Limited Warranty.

Before your next maintenance service is due, one of the following messages will appear in the right multifunction display while you are driving or when you switch on the ignition:

```
Service in .. days
Service in .. miles
```

When the maintenance service is due, the following message appears in the multifunction display: Carry out Service

Clearing the maintenance service indicator message

The maintenance service indicator message is automatically cleared after 30 seconds when you switch on the ignition. You can also clear it yourself.



1 Reset button

Press reset button ①.

The maintenance service indicator message is cleared and the standard display appears in the multifunction display (\triangleright page 117).

Maintenance

Maintenance service term exceeded

If you have exceeded the suggested service term, you will see the following message in the right multifunction display:

Service exceeded by .. days Service exceeded by .. miles

Any authorized Mercedes-Benz Center will reset the maintenance service indicator following a completed maintenance service.

Calling up the service due date

- Switch on the ignition (\triangleright page 40).
- Press button or on the multifunction steering wheel repeatedly until the standard display appears in the multifunction display (> page 117).
- Press button or on the multifunction steering wheel until the maintenance service indicator service symbol appears in the left multifunction display and the service dead-line appears in the right multifunction display.

0

If the vehicle is not be used for a longer period of time, do not disconnect the consumer battery. Instead, maintain the condition of the battery by using the battery charger approved by Mercedes-Benz for use on the SLR and supplied with the car (▷ page 358). This charger automatically controls the charge rate, and can be left connected to the car for long periods without damage to the battery.

If the battery supplying the vehicle's electrical consumers is disconnected, the days of disconnection will not be included in the count shown by the service indicator. To arrive at the true service deadline, you will need to sub-tract these days from the days shown in the service indicator.

Do not confuse the maintenance service indicator with the engine oil level indicator 🚉 .

Maintenance

Resetting the maintenance service indicator

In the event that the maintenance service on your vehicle is not carried out by an authorized Mercedes-Benz Center, you can have the maintenance service indicator reset. The automotive maintenance facility carrying out the maintenance service will find the information for resetting the maintenance service indicator in the maintenance-relevant information for your vehicle. Such information is available from either your authorized Mercedes-Benz Center or directly from Mercedes-Benz.

1

If the maintenance service indicator was inadvertently reset, have an authorized Mercedes-Benz Center correct it.

Only reset if the proper maintenance service has been performed. Resetting the system without performing the proper service as called for by the maintenance service indicator will result in engine damage and/or other vehicle damage not covered by the Mercedes-Benz Limited Warranty.

Vehicle care

Cleaning and care of the vehicle

Warning!

 \wedge

Many cleaning products can be hazardous. Some are poisonous, others are flammable. Always follow the instructions on the particular container. Always open your vehicle's doors or windows when cleaning the inside.

Never use fluids or solvents that are not designed for cleaning your vehicle.

If you have any questions about proper care of your SLR, please contact an authorized Mercedes-Benz Center.

0

Mercedes-Benz recommends that you use Mercedes-Benz care products. These have been specially developed to suit Mercedes-Benz vehicles and are state of the art. Mercedes-Benz care products are available from any Mercedes-Benz Center. Depending on body color the characteristic carbon structure of the body surface may become visible due to high ambient temperatures and humidity. This phenomenon is related to the technology and concept of the vehicle's body.

While in operation, even while parked, your vehicle is subjected to varying external influences which, if gone unchecked, can attack the paintwork as well as the underbody and cause lasting damage.

Such damage is caused not only by extreme and varying climatic conditions, but also by:

- Air pollution
- Road salt
- Tar
- Gravel and stone chipping

To avoid paint damage, you should immediately remove:

- Grease and oil
- Fuel

- Coolant
- Brake fluid
- Bird droppings
- Insects
- Tree resins, etc.

Frequent washing reduces and/or eliminates the aggressiveness and potency of the above adverse influences.

More frequent washings are necessary to deal with unfavorable conditions:

- near the ocean
- in industrial areas (smoke, exhaust emissions)
- during winter operation

You should check your vehicle from time to time for stone chipping or other damage. Any damage should be repaired as soon as possible to prevent corrosion.

Vehicle care

Vehicle washing

!

When washing the vehicle, fine and rigid particles in sponges or brushes could scratch or otherwise damage the paint. This applies to both, hand-wash or automatic car wash. Mercedes-Benz recommends you to have your vehicle cleaned at an automatic car wash from the start, preferably one without brushes, or to use plenty of water when hand-washing your vehicle.

Do not wash the car in direct sunlight and when the body surface is hot.

In the winter, remove salt residue quickly and thoroughly.

To wash the car, use:

- a car shampoo, which is recommended by Mercedes-Benz
- a soft sponge or a washing brush
- plenty of water
- Spray the car down thoroughly using plenty of water.
- Wash out the sponge and chamois frequently.
- Rinse off with clean water.
- Dry the car well with a chamois.

1

After running the vehicle through an automatic car wash, wipe any wax off of the windshield (▷ page 294). This will prevent smears and reduce wiping noise which can be caused by residual wax on the windshield.

Power washer



Do not use power washer to clean your vehicle or the engine.

Vehicle care

Wiper blades

!

The hood must be opened (▷ page 244) before folding the wiper arm away from the windshield. You could otherwise damage the hood and/or the wiper arms.

!

Never open or close the hood when the wiper arms are folded away from the windshield. You could otherwise damage the hood and/or the wiper arm.

Warning!

 \wedge

For safety reasons, switch off wipers and remove SmartKey from starter switch before cleaning the wiper blades. Otherwise the wiper motor could suddenly turn on and cause injury.

- Remove the SmartKey from the starter switch.
- ► Fold the wiper arm away from the windshield (▷ page 350).

You must feel the wiper arm engage in position. You can now clean the wiper blade.

- Clean the wiper blade inserts with a clean cloth and detergent solution.
- After cleaning the wiper blade, fold the windshield wipers back again before turning the SmartKey in the starter switch.

!

Fold the windshield wiper arms back onto the windshield before turning the SmartKey in the starter switch.

Hold on to the wiper when folding the wiper arm back. If released, the force of the impact from the tensioning spring could crack the windshield.

Window cleaning

ļ

The hood must be opened (▷ page 244) before folding the wiper arm away from the windshield. You could otherwise damage the hood and/or the wiper arms.

!

Never open or close the hood when the wiper arms are folded away from the windshield. You could otherwise damage the hood and/or the wiper arm.

Warning!

 \wedge

For safety reasons, switch off wipers and remove SmartKey from starter switch before cleaning the windshield. Otherwise the wiper motor could suddenly turn on and cause injury.

Vehicle care

- Remove the SmartKey from the starter switch.
- Fold the wiper arm away from the windshield (▷ page 350).

You must feel the wiper arm engage in position. You can now clean the wind-shield.

 Use a soft, clean cloth and a mild window cleaning solution on all outside and inside glass surfaces.

An automotive glass cleaner is recommended.

 After cleaning the windshield, fold the windshield wipers back again before turning the SmartKey in the starter switch.

!

Fold the windshield wiper arms back onto the windshield before turning the SmartKey in the starter switch.

Hold on to the wiper when folding the wiper arm back. If released, the force of the impact from the tensioning spring could crack the windshield.

Cleaning the headlamps

 Wipe the headlamp lens with a damp sponge.

!

Only use windshield washer fluid suitable for plastic lamp lenses. Unsuitable windshield washer fluid may cause damage to the plastic lenses of the headlamps.

Do not use

- a dry cloth
- abrasive products
- solvents
- cleaning agents containing solvents

You could otherwise scratch or damage the lens surface.

What to do if ...

Where will I find ...?

Unlocking in an emergency

Replacing SmartKey batteries

Replacing bulbs

Replacing the wiper blades

Flat tire

Batteries

Towing the vehicle

Fuses



What to do if ...

Lamps in instrument cluster

General information: If any of the following lamps in the instrument cluster fails to come on during the bulb self-check when switching on the ignition, have the respective bulb checked and replaced if necessary.

Problem		Possible cause/consequence	Suggested solutions
	The yellow ABS/ESP [®] warn- ing lamp comes on while driv- ing.	The ESP® is deactivated. Risk of accident! Adapt your speed and driving to the pre- vailing road and weather conditions.	 Switch the ESP[®] back on (▷ page 83). If the ESP[®] cannot be switched back on, have the system checked at an authorized Mercedes-Benz Center as soon as possible. Failure to follow these instructions increases the risk of an accident.
	The yellow ABS/ESP [®] warn- ing lamp flashes while driv- ing.	The ESP [®] , ABS, or traction control has come into operation because of detected traction loss in at least one tire.	 When driving off, apply as little throttle as possible. While driving, ease up on the accelerator. Adapt your speed and driving to the prevailing road and weather conditions. Do not deactivate ESP[®]. Exceptions: (> page 83). Failure to follow these instructions increases the risk of an accident.

Problem		Possible cause/consequence	Suggested solutions
	The yellow ABS indicator lamp comes on while driving. The ABS has detected a malfunction and has switched off. The BAS and the ESP® are also switched off (see messages in dis	 Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability. 	
		play). The electrohydraulic brake system is still	► Read and observe messages in the multi- function display (▷ page 307).
		functioning normally but without ABS available.	 Have the system checked at an authorized Mercedes-Benz Center immediately.
		If the ABS control unit is malfunctioning the automatic transmission may also be malfunctioning.	Failure to follow these instructions increases the risk of an accident.
		The charging voltage has fallen below 10 volts and the ABS was switched off.	When the voltage is above this value again, the ABS is operational again.
			 If necessary, have the generator and battery checked.

What to do if ...

Problem		Possible cause/consequence	Su	aggested solutions
(①)	(Canada only)	You are driving with the parking brake on.	►	Release the parking brake (\triangleright page 50).
BRAKE	(USA only)			
	The red brake warning lamp comes on while driving and you hear a warning sound.			
		There is a malfunction in the electrohy- draulic brake system.	•	Read and observe messages in the multi- function display (> page 307).
(①)	(Canada only)	There is insufficient brake fluid in the	►	Risk of accident! Carefully stop the vehicle in
BRAKE	(USA only)	reservoir.		a safe location and notify an authorized Mercedes-Benz Center. Do not add brake
	The red brake warning lamp comes on while driving.			fluid! This will not solve the problem.

Warning!

 \wedge

Driving with the brake warning lamp illuminated can result in an accident. Have your brake system checked immediately if the brake warning lamp stays on. Do not add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

!

If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks.

Problem		Possible cause/consequence	Suggested solutions
check engine	(USA only) (Canada only) The yellow engine malfunc- tion indicator lamp comes on while driving.	 There is a malfunction in: The fuel injection system The ignition system The emission control system Systems which effect emissions Such malfunctions may result in excessive 	Have the vehicle checked as soon as possible by an authorized Mercedes-Benz Center. An on-board diagnostic connector is used by the service station to link the vehicle to the shop diagnostics system. It allows the accurate identification of system malfunctions through the readout of diagnostic trouble codes. It is located in the front left area of
		emissions values and may switch the en- gine to its limp-home (emergency opera- tion) mode.	the footwell next to the parking brake.
		Your gas tank is empty.	• After refuelling, start, turn off and restart the engine three or four times in succession.
			The limp-home mode is canceled. You do not need to have your vehicle checked.
		The fuel cap is not closed tightly.	 Check the fuel cap.

What to do if ...

Problem	I	Possible cause/consequence	Suggested solution
*	The red coolant warning lamp comes on when the engine is running.	There is insufficient coolant in the reservoir.	 Immediately add coolant to prevent engine from overheating (> page 250).
		If this warning lamp comes on frequently, there is a leak in the cooling system.	 Have the cooling system checked by an authorized Mercedes-Benz Center.
		If the coolant level is correct, the electric radiator fan may be broken.	If the coolant temperature is below 248°F (120°C), you can continue driving to the nearest authorized Mercedes-Benz Center.
			 Avoid high engine loads (e.g. driving uphill) and stop-and-go driving.
***	The red coolant warning lamp comes on while driving and you hear a warning sound.	The coolant temperature has exceeded 248°F (120°C).	 Stop as soon as possible in a safe lo- cation and allow the engine and cool- ant to cool down.
Warning!		catch fire. You could be seriously burned. Steam from an overheated engine can cause serious burns and can occur just by opening	Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.
ed can cause some fluids which may have		the engine hood. Stay away from the engine	

if you see or hear steam coming from it.

leaked into the engine compartment to

Problem		Possible cause/consequence	Sı	iggested solutions
مل ا	The red Airbrake warning lamp comes on while driving and you hear a warning sound.	The Airbrake or the central locking system is malfunctioning.	•	Notify an authorized Mercedes-Benz Center immediately.
<u>1</u> =	The red gearshift indicator lamp comes on while you are driving.	You are driving with the manual shift pro- gram. The engine is in the overrevving range.	•	Shift to the next higher gear. Otherwise the fuel supply will be interrupted to prevent the engine from overrevving.
<u>a</u>	The yellow reserve fuel warn- ing lamp lights up while you are driving.	The fuel level has fallen into the reserve range.	•	Refuel at the nearest gas station (▷ page 241).
۵ ک	The engine oil temperature indicator comes on in the tachometer while you are	The engine oil has not yet reached its operating temperature.	•	Warm up the engine and do not drive at full power until the operating temperature has been reached.
	driving.			The symbol will go out as soon as the engine oil has reached its operating temperature.

What to do if ...

Problem		Possible cause/consequence	Suggested solution
*	The red seat belt telltale comes on briefly after starting the engine.	The telltale reminds you and your passenger to fasten your seat belts.	 Fasten your seat belt. The telltale goes out.
SRS	The red SRS indicator lamp comes on while driving.	There is a malfunction in the restraint sys- tems. The airbags or emergency tensioning device (ETD) could deploy unexpectedly or fail to activate in an accident.	 Drive with added caution to the nearest authorized Mercedes-Benz Center.

Warning!

 Λ

In the event that a malfunction of the SRS is indicated as outlined above, the SRS may not be operational. For your safety, we strongly recommend that you visit an authorized Mercedes-Benz Center immediately to have the system checked, otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in an accident and/or injury to you or to others.

What to do if ...

Problem		Possible cause/consequence	Suggested solution
	, , , , , , , , , , , , , , , , , , , ,	The tire pressure monitoring system detects a loss of pressure in at least one tire.	 Bring the vehicle to a halt, avoiding abrupt steering and braking maneu- vers. Observe the traffic situation around you.
			 Read and observe messages in the multifunction display.
			The warning lamp goes out once the tire inflation pressure monitor has been reac- tivated after the tire inflation pressure has been corrected.

Warning!

When the tire pressure monitoring system warning light is lit, one or more of your tires is significantly under-inflated. You should stop in a safe location and check your tires as soon as possible, and inflate them to the proper pressure as indicated on the vehicle's tire information placard. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Each tire, including the spare, should be checked monthly when cold and set to the recommended inflation pressure as specified in the vehicle placard and owner's manual.

1

The recommended tire inflation pressures for your vehicle can be found on the tire placard on the driver's door B-pillar, not in the owner's manual.

What to do if ...

Lamp in center console

Problem	Possible cause/consequence	Suggested solution
PASSENGER AIRBAG OFF The front passenger front airbag off indicator lamp comes on and remains illuminated.	A BabySmart [™] child seat is installed on the front passenger seat. Therefore the passenger front airbag is switched off.	
	The system is malfunctioning when there is no BabySmart [™] child seat installed on the front passenger seat.	 Have the system checked at an autho- rized Mercedes-Benz Center as soon as possible.
PASSENGER AIRBAG OFF The front passenger front airbag off indicator lamp does not come on or does not remain illuminat- ed with a BabySmart [™] child seat properly installed on the front passenger seat.	The system is malfunctioning.	 Make sure there is nothing between seat cushion and child seat. Check installation of the child seat. If the indicator lamp remains out: Have the system checked at an authorized Mercedes-Benz Center as soon as possible. Do not use the BabySmart[™] restraint to
		transport children on the front passenger seat until the system has been repaired.

What to do if ...

Vehicle status messages in the multifunction display

Warning and malfunction messages appear in the multifunction display located in the instrument cluster.

Certain warning and malfunction messages are accompanied by an audible signal.

Address these messages accordingly and follow the additional instructions given in this Operator's Manual.

Selecting the vehicle status message memory menu in the control system (▷ page 124) displays both cleared and uncleared messages.

High-priority messages appear in the multifunction display in red color.

Certain messages of high priority cannot be cleared from the multifunction display using the reset button (\triangleright page 29). Other messages of high priority and messages of less immediate priority can be cleared from the multifunction display using the reset button. They are then stored in the vehicle status message memory (▷ page 124). Remember that clearing a message will only make the message disappear. Clearing a message will not correct the condition that caused the message to appear.

Warning!

\wedge

All categories of messages contain important information which should be taken note of and, where a malfunction is indicated, addressed as soon as possible at an authorized Mercedes-Benz Center.

Failure to repair condition noted may cause damage not covered by the Mercedes-Benz Limited Warranty, or result in property damage or personal injury.

Warning!



No messages will be displayed if either the instrument cluster or the multifunction display is inoperative.

Contact your nearest authorized Mercedes-Benz Center.

1

Switching on the ignition causes all instrument cluster lamps (except high beam headlamp indicator lamp and turn signal indicator lamps unless activated) as well as the multifunction display to come on. Make sure the lamps and multifunction display are in working order before starting your journey.

What to do if ...

On the pages that follow, you will find a compilation of the most important warning and malfunction messages that may appear in the multifunction display. High priority messages appear in red color.

For your convenience the messages are divided into two sections:

- Text messages (▷ page 309)
- Symbol messages (▷ page 315)

What to do if ...

Text messages

Left display	Right display	Possible cause/consequence	Possible solution
ABS	Malfunction Visit workshop	The ABS has detected a malfunction and has switched off. The ESP^\circledast and the BAS are also deactivated.	 Continue driving with added caution. Wheels may lock during hard braking, re- ducing steering capability.
		The electrohydraulic brake system is still functioning normally but without	 Have the system checked at an authorized Mercedes-Benz Center immediately.
		the ABS available.	Failure to follow these instructions increases the risk of an accident.
	Display malfunction Visit workshop	The ABS or the ABS display is mal- functioning.	 Continue driving with added caution. Wheels may lock during hard braking, re- ducing steering capability.
			 Have the system checked at an authorized Mercedes-Benz Center immediately.
			Failure to follow these instructions increases the risk of an accident.
Cruise control		You attempted to resume a stored speed, but nothing is stored.	► Store a speed (▷ page 198).
		You attempted to set a speed below 20 mph (30 km/h).	► Drive faster than 20 mph (30 km/h) and set the speed (▷ page 198).

Left display	Right display	Possible cause/consequence	Possible solution
Cruise control	Drive to workshop	Cruise control is malfunctioning.	 Have the cruise control checked at an au- thorized Mercedes-Benz Center.
ESP	Malfunction Visit workshop	The ESP [®] has detected a malfunc- tion and switched off. The electrohy- draulic brake system is still functioning normally. The ABS may not be operational.	 Continue driving with added caution. Have the system checked at an authorized Mercedes-Benz Center immediately. Failure to follow these instructions increases the risk of an accident.
	Display malfunction The ESP® or the ESP® display is mal- Visit functioning. workshop	 Continue driving with added caution. Have the system checked at an authorized Mercedes-Benz Center immediately. Failure to follow these instructions increases the risk of an accident. 	

What to do if ...

Left display	Right display	Possible cause/consequence	Possible solution
ESP	Unavailable See Oper. Manual	The ESP [®] is deactivated because the power supply has been interrupted. The electrohydraulic brake system is still functioning normally but without the ESP [®] available.	 Synchronize the ESP[®]. With the vehicle stationary, turn the steering wheel completely to the left and then to the right. Ensure that you can turn the steering wheel to the stop without the wheels touching an object (e.g. the road curb).
			If the $ESP^{\texttt{®}}$ message does not go out:
			• Continue driving with added caution.
			 Have the system checked at an authorized Mercedes-Benz Center immediately.
			Failure to follow these instructions increases the risk of an accident.

!

When synchronizing the ESP[®], make sure you can turn the steering wheel in both directions as far as it will go without the wheels hitting any objects, e.g. a road curb.

Left display	Right display	Possible cause/consequence	Possible solution
Р	Selector lever to P!	You wish to start the engine and the selector lever is not in position P .	► Move the selector lever to P .
SLR	ACL malfunction Visit	The locking system is malfunctioning.	 Have the system checked at an authorized Mercedes-Benz Center immediately.
	workshop	• The transmission cooling system is malfunctioning.	
SRS	Restraint system malfunction Visit workshop	The SRS system is malfunctioning.	 Drive with added caution and have the sys- tem checked at an authorized Mercedes-Benz Center immediately.
Transmission	Visit workshop	The provided operating safety of the automatic transmission is reduced.	 Drive with added caution and have the sys- tem checked at an authorized Mercedes-Benz Center immediately.

What to do if ...

Left display	Right display	Possible cause/consequence	Possible solution
Tire pres. monitor	reactivated	The tire pressure monitoring system is using the current pressure values as the basis for monitoring.	
Tire pressure	displayed only when ignition is on	The tire inflation pressure is being checked.	► Switch on the ignition (▷ page 40).
Tire pres. monitor	temporarily unavailable	The tire inflation pressure monitor is unable to monitor the tire inflation pressure due to	 Remove any extra wheel sensors from the vehicle.
		 the presence of several wheel sensors in the vehicle. excessive wheel sensor temperatures. a nearby radio interference source. unrecognized wheel sensors mounted. 	As soon as the causes of the malfunc- tion have been removed, the tire pres- sure monitoring system automatically becomes active again.

Warning!

 \triangle

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle.

You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

What to do if ...

Left display	Right display	Possible cause/consequence	Possible solution
Reactivate tire pressure monitor	after rectifying pressure	There was a tire inflation pressure warning message. The yellow warning lamp for the tire pres- sure monitoring system comes on and you have not reactivated the system since the last tire inflation pressure warning message.	 Reactivate the tire pressure monitor- ing system after correcting the tire inflation pressure values (> page 269).
Tire pres. monitor inoperative	Drive to workshop	The tire inflation pressure monitor is mal- functioning.	 Have the tire inflation pressure monitor checked by an authorized Mercedes-Benz Center.
		A wheel without proper sensor was installed.	 Have the wheel checked.
	Tire pressure Please rectify	The tire inflation pressure is too low in one or more tires.	► Check and correct tire inflation pres- sure as required (▷ page 266).

Warning!

 \triangle

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle.

You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

What to do if ...

Symbol messages

Left display	Right display	Possible cause/ consequence	Possible solution
م ک	Airbrake malfunc	The Airbrake locking mecha- nism is malfunctioning.	 Notify an authorized Mercedes-Benz Center immediately.
	Battery/ Alternator Stop vehicle	The battery or the alternator is malfunctioning. The electrohydraulic brake sys- tem requires electrical energy and therefore has only limited operation. Considerably great- er brake pedal force is required and the pedal travel is longer. The stopping distance is in- creased.	 Stop the vehicle as soon as it is safe to do so. Adjust driving to be consistent with reduced braking responsiveness. Notify an authorized Mercedes-Benz Center immediately. Read and observe messages in the multifunction display. Failure to follow these instructions increases the risk of an accident.
	Convenience func- tions Temporarily Unavailable	The consumer battery has in- sufficient voltage and can no longer supply the convenience functions such as power win- dows.	The electrical consumers will come back online as soon as on-board voltage is sufficient.

Left display	Right display	Possible cause/ consequence	Possible solution
÷	Visit workshop	The battery is no longer charg- ing. Possible causes:	 Stop your vehicle immediately in a safe location and check the poly-V-belt.
		• alternator malfunctioning	If it is broken:
		• broken poly-V-belt Do not forget that the brake system requires electrical ener- gy and may be operating with restricted capability. Consider- ably greater brake pedal force is required and the pedal travel is longer. The stopping distance is increased.	 Do not continue to drive. Otherwise the engine will overheat due to an inoperative water pump which may result in damage to the engine. Notify an authorized Mercedes-Benz Center. If it is in order: Drive immediately to the nearest authorized Mercedes-Benz Center. Adjust driving to be consistent with reduced braking responsiveness. Read and observe messages in the multifunction display.
		There is a malfunction in the electronic system.	 Have the system checked at an authorized Mercedes-Benz Center immediately.

What to do if ...

Left disp	lay	Right display	Possible cause/ consequence	Possible solution
BRAKE	(USA only) (Canada only)	Brake fluid below min. level Visit workshop	There is insufficient brake fluid in the reservoir.	 Risk of accident! Stop the vehicle as soon as it is safe to do so and notify an authorized Mercedes-Benz Center immediately. Do not add brake fluid! This will not solve the problem.

Warning!

Driving with the message: Brake fluid below min. level Visit workshop

displayed can result in an accident. Have your brake system checked immediately. Do not add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

ļ

If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks.

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
(O);	Brake wear Visit workshop	The brake pads have reached their wear limit.	 Have the brake pads replaced immediately.

!

Brake pad thickness must be visually checked by a qualified technician at the intervals specified in the Maintenance Booklet.

Warning!

 \wedge

Have brake pad replacement and other work on the electrohydraulic brake system carried out by qualified technicians only. Contact your Mercedes-Benz Center for further information. The electrohydraulic brake system must be deactivated prior to working on the system. High pressure is intermittently built up in the system as part of its automatic self-test. In addition, the system is automatically activated when the vehicle is unlocked by remote control, when the driver or passenger door is opened, when the SmartKey in the starter switch is turned to position **1**, when the brake pedal is depressed or when the parking brake is released.

Failure to deactivate the system prior to maintenance will cause brake pistons to extend and brake fluid to leak, which may result in injuries (contusions and acid burns), see "Electrohydraulic brake system" (▷ page 84).

Left display	Right display	Possible cause/ consequence	Possible solution
	Reduced braking power Depress brake pedal fully	The electrohydraulic brake sys- tem is in emergency operation mode. Considerably greater brake pedal force is required and the pedal travel is longer. The stopping distance is in- creased. The maximum speed is limited to 55 mph (90 km/h).	 Do not drive any further. Stop the vehicle immediately in a safe location. Prevent the vehicle from rolling away by blocking the wheels with wheel chocks or other sizable heavy objects. Notify an authorized Mercedes-Benz Center. Call for Roadside Assistance. Failure to follow these instructions increases the risk of an accident.

What to do if ...

Left disp	lay	Right display	Possible cause/ consequence	Possible solution
BRAKE	(USA only) (Canada only)	Reduced brake effect Visit workshop Increased stopping distance Visit workshop	The electrohydraulic brake system is in emer- gency operation mode. Considerably greater brake pedal force is re- quired and the pedal travel is longer. The stop- ping distance is in- creased.	 Continue driving with added caution. Visit an authorized Mercedes-Benz Center immediately. Adjust driving to be consistent with reduced braking responsiveness. Failure to follow these instructions increases the risk of an accident.

Warning!

Driving while these messages are displayed can result in an accident. Have your brake system checked immediately.

/!\

If there is a malfunction in the electrohydraulic brake system, we recommend that the vehicle be transported with all wheels off the ground using flatbed or appropriate wheel lift/dolly equipment. A tow bar must be used if circumstances do not permit the use of the recommended towing methods and the vehicle requires towing with all four wheels on the ground.

Towing the vehicle with all four wheels on the ground is only permissible for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h). For more information, see "Towing the vehicle" (\triangleright page 360). If the electrohydraulic brake system enters its emergency operation mode, the driver must apply significantly greater brake pedal pressure and depress the pedal much further than normal to obtain braking effect.

If necessary, apply full pressure to the brake pedal. Stopping distance is increased!

What to do if ...

Left dis	splay	Right display	Possible cause/ consequence	Possible solution
BRAKE	(USA only) (Canada only)	Reduced brake effect Start engine	The battery has insufficient voltage and cannot supply suffi- cient power to the electrohy-	 Start the engine. As soon as the engine is running, the message disappears.
		Increased stopping distance Start engine	draulic brake system.	

Warning!

 \triangle

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide, and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated.

Left disp	lay	Right display	Possible cause/ consequence	Possible solution
BRAKE	(USA only)	Brakes overheated	The brake system is overheated	 Relieve the load on the brake system.
(①)	(Canada only)	Drive on, but with even greater care	with due to an excessive load on the care brakes.	 Drive more smoothly and think ahead to avoid unnecessary braking.
				When driving down steep grades, shift into a lower gear to use the engine's braking power (▷ page 170).
				 Cautiously continue driving so that the air stream will cool down the brakes.
		Release parking brake	You are driving with the parking brake set.	► Release the parking brake (▷ page 50).
		Service brake Visit workshop	There are malfunctions, but the electrohydraulic brake system is operating normally.	 Visit an authorized Mercedes-Benz Center im- mediately.

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
	Coolant Check level	The coolant level is too low.	 Add coolant (▷ page 250). If you have to add coolant frequently, have the cooling system checked by an authorized Mercedes-Benz Center immediately.

Warning!

Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts. You can be seriously burned. !

Do not ignore the low engine coolant level warning. Extended driving with the message and symbol displayed may cause serious engine damage not covered by the Mercedes-Benz Limited Warranty.

Do not drive without sufficient amount of coolant in the cooling system. The engine will overheat causing major engine damage.

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
	Coolant Stop, put engine	The coolant is too hot.	 Stop the vehicle in a safe location and turn off the en- gine.
	off		 Only start the engine again after the message disappears. You could otherwise damage the engine.

Warning!

 \wedge

Driving when your engine is badly overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns and can occur just by opening the hood. Stay away from the engine if you see or hear steam coming from it.

Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down. During severe operating conditions and stop-and-go city traffic, the coolant temperature may rise close to 248°F (120°C).

The engine should not be operated with the coolant temperature above 248°F (120°C). Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

Left display	Right display	Possible cause/ consequence	Possible solution
	Coolant Stop, put engine	The poly-V-belt could be broken.	 Stop the vehicle in a safe location and immediately turn off the engine.
	off		• Check the poly-V-belt.
			If it is broken:
			Do not continue to drive. Otherwise the engine will over- heat due to an inoperative water pump which may result in damage to the engine. Notify an authorized Mercedes-Benz Center.
			If it is intact:
			Do not continue to drive with this message displayed. Doing so could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.
			► Observe the coolant temperature gauge in the instrument cluster (▷ page 29).
			 Drive immediately to the nearest authorized Mercedes-Benz Center.
	Coolant Visit	The cooling fan for the coolant is malfunctioning.	► Observe the coolant temperature gauge in the instrument cluster (▷ page 29).
	workshop		• Have the fan replaced immediately.

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
	Differential overheated	The differential oil is too hot.	 Stop your vehicle immediately in a safe location. Do not drive any further. Wait until the instrument cluster display has cleared. Otherwise you could damage the rear differential.

ļ

The differential warning should not be ignored. Extended driving with the symbol displayed could result in serious rear differential damage that is not covered by the Mercedes-Benz Limited Warranty.

Left display	Right display	Possible cause/ consequence	Possible solution
ł	Display malfunc- tion Visit workshop	The displays for several sys- tems have malfunctioned. Some systems themselves may also have malfunctioned.	 Continue driving with added caution. When the display is malfunctioning, warnings and malfunction messages might not be displayed. Have the electronic systems checked by an authorized Mercedes-Benz Center immediately. Failure to follow these instructions increases the risk of an accident.
	Display malfunc- tion Visit workshop	Certain electronic systems are unable to relay information to the control system. The follow- ing systems may have failed: • Coolant temperature gauge • Tachometer • Cruise control display	 Have the electronic systems checked by an authorized Mercedes-Benz Center immediately.
Ć	Door open	You are attempting to drive with one or more doors open.	 Close the doors.

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
i	Engine Service	 There may be a malfunction in the fuel injection system ignition system exhaust system fuel system 	 Have the engine checked by an authorized Mercedes-Benz Center immediately.
	Engine oil pressure Visit workshop	There is no oil in the engine. There is a danger of engine damage.	 Stop your vehicle immediately in a safe location. Switch off the engine. Notify an authorized Mercedes-Benz Center immediately.

!

The engine oil level warning should not be ignored. Extended driving with the symbol displayed could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

Left display	Right display	Possible cause/ consequence	Possible solution
i¢;	Fuel system malfunction Visit workshop	The fuel cooling system is malfunctioning.	 Visit an authorized Mercedes-Benz Center immediately.
Ð	Reserve fuel	The fuel level has fallen into the reserve range.	► Refuel at the next gas station (▷ page 241).
	Check	A loss of pressure has been de-	► Check the fuel cap (▷ page 241).
	fuel cap See Oper. Manual	tected in the fuel system. The fuel cap may not be closed	If it is not closed properly:
		properly or the fuel system may be leaky.	 Close the fuel cap.
			If it is closed properly:
			 Have the fuel system checked by an authorized Mercedes-Benz Center.
R	Tel Enter PIN	You have not yet entered your PIN in you telephone.	 Enter the PIN for your SIM card.
<u></u>	Close hood	You are driving with the hood open.	► Close the hood (▷ page 244).
	Remove key	You have forgotten to remove the SmartKey.	 Remove the SmartKey from the starter switch.
	Replace key	No additional code available for the SmartKey.	 Have the SmartKey checked. Notify an authorized Mercedes-Benz Center.

Left display	Right display	Possible cause/ consequence	Possible solution
<u></u>	3rd brake lamp	The high mounted brake lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Brake lamp Left Substitute bulb on	The left brake lamp is malfunc- tioning. This message will only appear if a critical number of LEDs have blown.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Brake lamp Right Substitute bulb on	The right brake lamp is mal- functioning. This message will only appear if a critical number of LEDs have blown.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Brake lamp Drive to workshop	Brake lamp illumination is de- layed or lamp is permanently on.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Front foglamp Left	The left front fog lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Front foglamp Right	The right front fog lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Rear foglamp Left	The left rear fog lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.

Left display	Right display	Possible cause/ consequence	Possible solution
- @ -	High beam Left	The left high beam lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	High beam Right	The right high beam lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Left turn signal Mirror	The left turn signal in the side mirror is malfunctioning. This message will only appear if all light emitting diodes have stopped working.	 Have the LEDs replaced as soon as possible.
	License plate lamp, L	The left license plate lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	License plate lamp, R	The right license plate lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Light sensor Drive to	The light sensor is malfunction- ing. The headlamps switch on	 In the control system, set lamp operation to manual (▷ page 132).
	workshop	automatically.	 Switch on headlamps using the exterior lamp switch.
			• Visit an authorized Mercedes-Benz Center immediately.
	Low beam Left	The left low beam lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.

Left display	Right display	Possible cause/ consequence	Possible solution
<u>Å</u>	Low beam Right	The right low beam lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Marker lamp Front left	The front left side marker lamp is malfunctioning.	 Replace the bulb as soon as possible.
	Marker lamp Front right	The front right side marker lamp is malfunctioning.	 Replace the bulb as soon as possible.
	Marker lamp Rear left	The rear left side marker lamp is malfunctioning.	 Replace the bulb as soon as possible.
	Marker lamp Rear right	The rear right side marker lamp is malfunctioning.	 Replace the bulb as soon as possible.
	Parking lamp Front left	The left front parking lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Parking lamp Front right	The right front parking lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Remove key	You have forgotten to remove the SmartKey.	 Remove the SmartKey from the starter switch.
	Reverse lamp Right	The right backup lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Reverse lamp Left	The left backup lamp is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.

Left display	Right display	Possible cause/ consequence	Possible solution
	Right turn signal Mirror	The right turn signal in the side mirror is malfunctioning. This message will only appear if all light emitting diodes have stopped working.	 Have the LEDs replaced as soon as possible.
	Tail lamp Left Substitute bulb on	The left tail lamp is malfunc- tioning. This message will only appear if a critical number of LEDs have blown.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Tail lamp Right Substitute bulb on	The right tail lamp is malfunc- tioning. This message will only appear if a critical number of LEDs have blown.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Turn off lamps	You have removed the Smart- Key from the starter switch and opened the driver's door.	Turn the exterior lamp switch to
	Turn signal Front left	The left front turn signal lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Turn signal Front right	The right front turn signal lamp is malfunctioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.

Left display	Right display	Possible cause/ consequence	Possible solution
Rea Sub bu1 Tur Rea Sub	Turn signal Rear left Substitute bulb on	The left rear turn signal lamp is malfunctioning. A backup bulb has been brought into use.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Turn signal Rear right Substitute bulb on	The right rear turn signal lamp is malfunctioning. A backup bulb has been brought into use.	 Visit an authorized Mercedes-Benz Center as soon as possible.
	Visit workshop	The display for the lights is mal- functioning.	 Visit an authorized Mercedes-Benz Center as soon as possible.
*	Seat belt system Drive to workshop	The seat belt system is mal- functioning.	 Visit an authorized Mercedes-Benz Center immediately.
esos	Tele Aid Drive to workshop	One or more main functions of the Tele Aid system are mal- functioning.	 Have the Tele Aid system checked by an authorized Mercedes-Benz Center immediately.

Left display	Right display	Possible cause/ consequence	Possible solution
	Tire pressure Caution Tire defect	One or more tires is deflating.	 Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you.
			► Temporarily repair tire using TIREFIT (▷ page 351) or contact Roadside Assistance. If tire cannot be tempo- rarily repaired using TIREFIT, contact Roadside Assistance.
			 Have the damaged wheel repaired or replaced at an authorized Mercedes-Benz Center.

Warning!	Warning!	\triangle
Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.	Have worn or damaged tires replaced pairs (front pair or rear pair) an make the tires rotate in the direction specif (▷ page 257). Otherwise, the driving ty of the vehicle will be adversely affe especially when driving at high speed	e sure fied stabili- ected,

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
	Tire pressure Check tires	The tire inflation pressure in one or more tires is already below the minimum value. The tire inflation pressure in one or more tires is low.	 Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you. Check the tires. If no damage visible, check and correct tire inflation pressure as required. Temporarily repair tire using TIREFIT (▷ page 351) or contact Roadside Assistance. If tire cannot be temporarily repaired using TIREFIT, contact Roadside Assistance. Have the damaged wheel repaired or replaced at an authorized Mercedes-Benz Center.

Warning!

 \triangle

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle.

Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

Warning!

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (▷ page 257). Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

 \triangle

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
<u>(!)</u>	Tire pressure, FL Caution	The left front tire is deflating.	 Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you.
	Tire defect		► Temporarily repair tire using TIREFIT (▷ page 351) or contact Roadside Assistance. If tire cannot be temporarily repaired using TIREFIT, contact Roadside Assistance.
			 Have the damaged wheel repaired or replaced at an authorized Mercedes-Benz Center.
	Tire pressure, FL	The left front tire in-	 Carefully bring the vehicle to a halt.
	Check tires	flation pressure is low.	 Check the tires. If no damage visible, check and correct tire infla- tion pressure as required.
			 If necessary, have the wheel repaired or replaced at an authorized Mercedes-Benz Center.

Have worn or damaged tires replaced in

pairs (front pair or rear pair) an make sure the tires rotate in the direction specified

Warning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle.

Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

Warning!

(⊳ page 257).

 \wedge

 \triangle

Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

337

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
<u>(!)</u>	Tire pressure, FR Caution	The right front tire is deflating.	 Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you.
	Tire defect		► Temporarily repair tire using TIREFIT (▷ page 351) or contact Roadside Assistance. If tire cannot be temporarily repaired using TIREFIT, contact Roadside Assistance.
			 Have the damaged wheel repaired or replaced at an authorized Mercedes-Benz Center.
	Tire pressure, FR	The right front tire in-	 Carefully bring the vehicle to a halt.
	Check tires	flation pressure is low.	 Check the tires. If no damage visible, check and correct tire infla- tion pressure as required.
			 If necessary, have the wheel repaired or replaced at an authorized Mercedes-Benz Center.

Warning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle.

Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

Warning!

 \wedge

 \triangle

Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (\triangleright page 257).

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
<u>(!)</u>	Tire pressure, RL Caution	The left rear tire is deflating.	 Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you.
	Tire defect		► Temporarily repair tire using TIREFIT (▷ page 351) or contact Roadside Assistance. If tire cannot be temporarily repaired using TIREFIT, contact Roadside Assistance.
			 Have the damaged wheel repaired or replaced at an authorized Mercedes-Benz Center.
	Tire pressure, RL	The left rear tire infla-	 Carefully bring the vehicle to a halt.
	Check tires	tion pressure is low.	 Check the tires. If no damage visible, check and correct tire infla- tion pressure as required.
			 If necessary, have the wheel repaired or replaced at an authorized Mercedes-Benz Center.

Warning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle.

Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

Warning!

 \wedge

 \triangle

Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (\triangleright page 257).

What to do if ...

Left display	Right display	Possible cause/ consequence	Possible solution
<u>(!)</u>	Tire pressure, RR Caution	The right rear tire is deflating.	 Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you.
	Tire defect		► Temporarily repair tire using TIREFIT (▷ page 351) or contact Roadside Assistance. If tire cannot be temporarily repaired using TIREFIT, contact Roadside Assistance.
			 Have the damaged wheel repaired or replaced at an authorized Mercedes-Benz Center.
	Tire pressure, RR	The right rear tire in-	 Carefully bring the vehicle to a halt.
	Check tires	flation pressure is low.	 Check the tires. If no damage visible, check and correct tire infla- tion pressure as required.
			 If necessary, have the wheel repaired or replaced at an authorized Mercedes-Benz Center.

Warning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle.

Continued driving with a flat tire will cause excessive heat build-up and possibly a fire. Warning!

 \wedge

 \triangle

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (⊳ page 257).


Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

Left display	Right display	Possible cause/ consequence	Possible solution
	Close trunk lid	This message will appear when- ever the trunk lid is open.	► Close the trunk lid (▷ page 101).
æ	Washer fluid Check level	The washer fluid level has dropped to about $1/3$ of total reservoir capacity.	► Add washer fluid (▷ page 252).

Where will I find ...?

First aid kit

The first aid kit is located on the right-hand side in the trunk.



First aid kit
 Retaining strap

- ▶ Open the retaining strap ②.
- ▶ Remove the first aid kit ①.

1

Check expiration dates and contents for completeness at least once a year and replace missing/expired items.

TIREFIT kit, electric air pump, towing eye bolt and vehicle literature portfolio

The TIREFIT kit, the electric air pump, the vehicle literature portfolio and the towing eye bolt are located on the right-hand side underneath the floor in the trunk.



- (1) Vehicle literature portfolio
- (2) TIREFIT kit, electrical air pump
- ③ Towing eye bolt

1

When your SLR is delivered, you will find the vehicle literature portfolio in the rear storage compartment (\triangleright page 201). For permanent storage in the vehicle, keep the vehicle literature portfolio in the storage compartment in the trunk.

!


Your vehicle is equipped with a front towing eye bolt only.

You cannot tow other vehicles with your vehicle.

Where will I find ...?

Compact guide (Canada only)

The compact guide is located in the rear storage compartment.



(1) Storage compartment

Unlocking in an emergency

Unlocking the vehicle

Unlocking the trunk


6

If you cannot unlock the trunk with the SmartKey, open the trunk with the mechanical key.

Unlocking the trunk with the mechanical key will trigger the anti-theft alarm system when the door is opened.

To cancel the alarm, insert the SmartKey in the starter switch.

The handle is located above the rear license plate recess.



Mechanical key locking tab
 Mechanical key

 Press locking tab ① in the direction of arrow and, at the same time, remove mechanical key ② completely out of the housing.



Trunk lid lock

③ Unlocking

- ► Insert the mechanical key in the trunk lid lock.
- Perform the following two steps simultaneously:
 - Turn the mechanical key counterclockwise to the stop, to position (3).
 - Pull the trunk lid handle and lift the trunk lid.

Unlocking in an emergency

Unlocking the driver's door


If you can no longer lock or unlock the doors using the SmartKey, unlock the driver's door using the emergency release catch.

1

Unlocking the driver's door with the emergency release catch will trigger the anti-theft alarm system.

To cancel the alarm, insert the SmartKey in the starter switch.

The emergency release catch is located on the left side in the trunk.



① Emergency release catch

- Unlock the trunk (\triangleright page 344).
- Pull emergency release catch ①.
 The door is unlocked.

1

If it still is not possible to unlock the door, pull more firmly on the emergency release catch.

- Open the door in the normal way.
- Notify an authorized Mercedes-Benz Center.

Replacing SmartKey batteries

If the batteries in the SmartKey are discharged, the vehicle can no longer be locked or unlocked. It is recommended to have the batteries replaced at an authorized Mercedes-Benz Center.

Warning!



Batteries contain poisonous and corrosive substances. Therefore keep the batteries out of reach of children.

If a battery is swallowed, seek medical help immediately.

Batteries contain materials that can harm the environment if disposed of improperly. Recycling of batteries is the preferred method of disposal. Many states require sellers of batteries to accept old batteries for recycling.

Replacement batteries: Lithium, type CR 2025 or equivalent.

1

When inserting the batteries, make sure they are clean and free of lint.

1

When replacing batteries, always replace both batteries. The required replacement batteries are available at any Mercedes-Benz Center.

► Remove the mechanical key out of the SmartKey (▷ page 344).


Replacing SmartKey batteries



- (1) Mechanical key
- (2) Unlocking the battery compartment
- (3) Removing the battery compartment(4) Slide
- Insert mechanical key (1) in side opening, push gray slide (4) in direction of arrow (2).

The battery compartment is unlatched.

 Pull battery compartment (2) out of the housing in direction of arrow (3).



- (5) Battery
- 6 Contact spring
- Remove the discharged batteries.
- Using a lint-free cloth, insert new batteries (5) under the contact spring (6) with the plus (+) side facing up.
- Return battery compartment into housing until it locks into place.

- Slide mechanical key (1) back into the SmartKey.
- Check the operation of the SmartKey.

Replacing bulbs

Safe vehicle operation depends on proper exterior lighting and signaling. It is therefore essential that all bulbs and lamp assemblies are in good working order at all times.

Correct headlamp adjustment is extremely important. Have headlamps checked and readjusted at regular intervals and when a bulb has been replaced. See an authorized Mercedes-Benz Center for headlamp adjustment.

!

You must not change the bulbs or LEDs yourself, as you could damage the vehicle lighting systems.

Have blown bulbs or LEDs replaced by an authorized Mercedes-Benz Center.

1

If the headlamps are fogged up on the inside as a result of high humidity, driving the vehicle a distance should clear up the fogging.

1


Substitute bulbs will be brought into use when lamps malfunction. Observe the messages in the multifunction display (\triangleright page 330).

1

If one of the following bulbs blows, another bulb will adopt its function:

- Rear turn signals
- Brake lamps
- Side lamps
- Tail lamps

Replacing bulbs



Front lamps

	Lamp	Туре
1	Additional turn signal	LEDs
2	Turn signal	PY, 21 W
3	Side marker lamp	WY 5 W
4	Parking lamp	W 5 W
5	Low and high beam lamp	D2S, 35 W
6	High beam flasher	H7, 55 W
0	Front fog lamp	H3, 55 W

Rear lamps

	Lamp	Туре
8	Brake/parking lamp	LEDs
9	Turn signal lamp	LEDs
(10)	Side marker lamp	P 21 W
(1)	High mounted brake lamp	LEDs
(12)	License plate lamp	C 5 W
(13)	Rear fog lamp	P 21 W
(14)	Backup lamp	P 21 W
(15)	Reflector	-

Replacing the wiper blades

Removing wiper blades

Warning!



For safety reasons, remove SmartKey from starter switch before replacing a wiper blade. Otherwise the motor could suddenly turn on and cause injury.

!

The hood must be opened (▷ page 244) before folding the wiper arms away from the windshield. You could otherwise damage the hood and/or the wiper arm.

- Remove the SmartKey from starter switch.
- Fold the wiper arm forward.
 You must feel the wiper arm engage in position.
- Set the wiper blade at 90° to the wiper arm.



 Slide the wiper blade out in direction of arrow.

Installing wiper blades

- Position the wiper blade at 90° to the wiper arm.
- Slide the wiper blade onto the wiper arm.
- Fold the wiper blade parallel to the wiper arm.
- Fold the wiper arm backward to rest on the windshield. Make sure you hold on to the wiper when folding the wiper arm back.

!

Hold on to the wiper when folding the wiper arm back. If released, the force of the impact from the tensioning spring could crack the windshield.

Do not allow the wiper arms to contact the windshield glass without a wiper blade inserted.

Make sure the wiper blades are properly installed. Improperly installed wiper blades may cause windshield damage.

For your convenience, we recommend that you have this work carried out by an authorized Mercedes-Benz Center.

Flat tire

▼ Flat tire

The vehicle is equipped with the TIREFIT kit.

!

A wheel change should only be carried out at an authorized Mercedes-Benz Center. Otherwise there is a danger of damaging the vehicle by jacking it up incorrectly.

Preparing the vehicle

- Park the vehicle in a safe distance from moving traffic on a hard, flat surface when possible.
- ► Turn on the hazard warning flashers.
- Turn the steering wheel so that the front wheels are in a straight ahead position.
- Set the parking brake.
- ► Move the gear selector lever to **P**.
- ▶ Turn off the engine (\triangleright page 58).
- Remove the SmartKey from the starter switch.

• Open the driver's door.

1

Open door only when conditions are safe to do so.

 Have any passenger exit the vehicle at a safe distance from the roadway.

Sealing tires with TIREFIT kit

Warning!



Keep TIREFIT away from sparks, open flame or heat source.

Do not smoke.

Small tire punctures, particularly those in the tread, can be sealed with TIREFIT. TIREFIT can be used in ambient temperatures down to $-4^{\circ}F$ (-20°C).

Warning!

 \wedge

TIREFIT is a limited repair device. TIREFIT cannot be used for cuts or punctures larger than approximately 0.16 in (4 mm) and tire damage caused by driving with extremely low tire inflation pressure, or on a flat tire, or a damaged wheel.

Do not drive the vehicle under such circumstances.

Contact your nearest Mercedes-Benz Center for assistance or call Roadside Assistance.

!

After using TIREFIT, the tire inflation pressure sensor may have to be replaced.

- Foreign objects (e.g. screws or nails) should not be removed from the tire.
- ► Take TIREFIT, the sticker, and the electric air pump out of the trunk.

Flat tire

▷▷► Attach the sticker where it will be easily seen by the driver on the instrument cluster.

Warning!



Take care not to allow the contents of TIREFIT to come in contact with hair, eyes or clothing. TIREFIT is harmful if inhaled, swallowed or absorbed through the skin - causes skin, eye and respiratory irritation.

Any contact with eyes or skin should be flushed immediately with plenty of water.

If clothing comes in contact with TIREFIT, change clothing as soon as possible.

In case of allergic reaction or rash, consult a physician immediately.

Warning!

Keep TIREFIT out of reach of children. If swallowed, rinse mouth immediately with plenty of water and drink plenty of water.

/!\

Do not induce vomiting!

Consult a physician immediately.


Keep away from open flame or heat source.

If sealant has leaked out, let it dry. You can then peel it off.



- 1 TIREFIT container
 Flap
 Notch
 Electrical plug
 Air hose
 Flange
- ▶ Open flap ② on the electric air pump.
- ▶ Pull plug ④ and air hose ⑤ out of the pump housing.
- ► Screw the air pump's air hose (5) onto flange (6) of the TIREFIT container.
- Stick TIREFIT container ① upside down into notch ③ of the electric air pump.

Flat tire



- ⑦ Tire valve
- (8) Electric air pump switch
- Air hose with pressure gauge and vent screw
- (10) Filler hose

Warning!

Observe safety instructions on air pump label.

- ► Unscrew the valve cap from tire valve ⑦.
- ▶ Screw filler hose (1) onto tire valve (7).
- Insert electrical plug ④ into vehicle cigarette lighter socket.
- ► Turn the SmartKey in the starter switch to position 1 (▷ page 40).
- ▶ Press I on electric air pump switch ⑧.

The electric air pump should now switch on and inflate the tire.

!

Do not operate the electric air pump longer than 8 minutes without interruption. Otherwise it may overheat.

You may operate the air pump again after it has cooled off.

After 5 minutes, the pressure gauge must display at least 26 psi (1.8 bar). The air hose can become hot during inflation. Please exercise appropriate caution.

If this tire inflation pressure is not attained, turn off the electric air pump, detach the filler hose from the tire valve, and drive vehicle back and forth very slowly approximately 30 ft (10 m).

This serves to better distribute the TIREFIT sealant material inside the tire.

- Unscrew the air pump's air hose (5) from flange (6) of the TIREFIT container.
- Screw air hose (5) onto tire valve (7).
- ▶ Inflate the tire again.

 $\triangleright \triangleright$

Flat tire

$\triangleright \triangleright$

Warning!

If a tire inflation pressure of 26 psi (1.8 bar) is not attained, tire is too severely damaged for TIREFIT to provide a reliable tire repair.

Æ

In this case, TIREFIT cannot properly seal the tire.

Do not drive the vehicle.

Contact the nearest Mercedes-Benz Center or call Roadside Assistance.

 After attaining a tire inflation pressure of 26 psi (1.8 bar), press 0 on electric air pump switch (8).

The electric air pump should now be switched off.


- ► Turn the SmartKey in the ignition to position 0 (▷ page 40).
- Detach the electric air pump.

The air hose may still be hot. Please exercise appropriate caution.

- Store the electrical plug and the air hose behind the flap and place the air pump back in the trunk.
- Close the trunk lid.
- ► Drive away immediately.

The TIREFIT sealant will distribute itself evenly inside the tire.

Warning!



The sticker must be attached on the instrument cluster where it will be easily seen by the driver.

Vehicle handling characteristics may change. Adapt your driving accordingly.

 After driving vehicle for an initial 10 minutes, check tire inflation pressure using the pressure gauge on the air pump.

Warning!

 \wedge

If tire inflation pressure has fallen below 20 psi (1.3 bar), do not continue to drive the vehicle.

Park your vehicle safely away from the roadway and contact the nearest authorized Mercedes-Benz Center or Roadside Assistance.

If tire inflation pressure is at least 20 psi (1.3 bar), inflate tire to correct pressure (see placards on driver's door B-pillar or on fuel filler flap), and drive vehicle to nearest tire repair facility to have tire repaired or replaced.

Recommended duration of use: 300 miles (500 km) at 50 mph (80 km/h) with the recommended tire inflation pressure.

Flat tire

Warning!

Have worn or damaged tires replaced in pairs (front pair or rear pair) an make sure the tires rotate in the direction specified (▷ page 257). Otherwise, the driving stability of the vehicle will be adversely affected, especially when driving at high speeds.

Warning!

Follow recommend tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout.

- Visit an authorized Mercedes-Benz Center as soon as possible to obtain a new TIREFIT kit.
- Bring used TIREFIT materials to an authorized Mercedes-Benz Center for proper disposal.

Warning!

/!\



Do not exceed vehicle speed of 50 mph (80 km/h). A TIREFIT repair is not designed to operate at higher speeds.

The sticker must be attached on the instrument cluster where it will be easily seen by the driver.

Vehicle handling characteristics may change. Adapt your driving accordingly.

 Replace your TIREFIT container every 4 years. Replacement containers are available at your authorized Mercedes-Benz Center.

Batteries

Your vehicle is equipped with two batteries:

- The starter battery (located in the trunk)
- The battery for electrical consumers (located in the trunk)

Warning!

Failure to follow these instructions can result in severe injury or death.

Never lean over batteries while connecting, you might get injured.

Observe all safety instructions and precautions when handling automotive batteries (\triangleright page 251).

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking, etc.

!

/!\

You must not jump start the vehicle, otherwise the vehicle electrical systems could be damaged.

Only use the battery charge unit tested and approved by Mercedes-Benz for use on the SLR to charge the battery or maintain the battery charge. Using other battery chargers may cause damage to the vehicle and/or personal injury.

Information on charging the batteries (\triangleright page 358).

Have the batteries checked regularly by an authorized Mercedes-Benz Center. Refer to Maintenance Booklet for maintenance intervals or contact an authorized Mercedes-Benz Center for further information.

If it is necessary to replace the batteries, notify an authorized Mercedes-Benz Center.

Batteries

Warning!

Do not place metal objects on the battery as this could result in a short circuit.

Use leak-proof batteries only to avoid the risk of acid burns in the event of an accident.

Warning!

/!\

The brake system requires electrical power to operate.

A malfunction in the vehicle's power supply or electrical system may impair brake system operation and switch it into its emergency operation mode. The same applies if battery is disconnected. To brake, the driver must then apply significantly greater brake pedal pressure and depress the pedal much further to obtain the expected braking effect. If necessary, apply full pressure to the brake pedal. Brakes are only applied to the front wheels. Stopping distance is increased! Adjust your driving style accordingly. For more information, see "Electrohydraulic brake system" (\triangleright page 84).

Warning!

/!\



With a disconnected battery

- you will no longer be able to turn the SmartKey in the starter switch
- the gear selector lever will remain locked in position **P**

Batteries

Charging the batteries

Warning!

 Λ

Never charge a battery while still installed in the vehicle unless the battery charge unit approved by Mercedes-Benz (supplied with your vehicle) is being used. Gases may escape during charging and cause explosions that may result in paint damage, corrosion or personal injury.

A battery charge unit specially adapted for Mercedes-Benz vehicles and tested and approved by Mercedes-Benz is available, permitting the charging of the battery in its installed position. Contact an authorized Mercedes-Benz Center for information and availability. Charge battery in accordance with the separate operating instructions for the battery charger.


You can obtain detailed information on charging the battery from your authorized Mercedes-Benz Center.

Charging with the battery charger

Only use the battery charge unit approved by Mercedes-Benz and supplied with your vehicle. This charger is designed to automatically control the charge rate, and charge the battery or maintain the existing charge in the battery while the vehicle is parked and not being driven for long periods of time (on average approximately 3 weeks or more). Not driving the vehicle for such extended periods may cause the charge in the vehicle battery to drop.

Using the charging point

The charging point for the battery charger is located next to the CD-changer on the left-hand side in the trunk.



- Charging point
- Remove the SmartKey from the starter switch.
- Open the cover of the charging point ①.
- Connect the battery charger with the charging point ①.


Batteries

- Observe and follow the separate operating instructions for the battery charger.
- ► Charge up the battery.

The battery charger switches off automatically when the battery is sufficiently charged.

Using the charging terminals

The charging terminals for the battery charger are located in the trunk underneath the interior floor.



(1) Negative charging terminal

(2) Positive charging terminal

- Connect positive terminal (2) and negative terminal (1) with the battery charger. Start with the positive terminal (2).
- Charge up the battery. Observe and follow the separate operating instructions for the battery charger.

Practical hints

Towing the vehicle

Mercedes-Benz recommends that the vehicle be transported with all wheels off the ground using flatbed or appropriate wheel lift/dolly equipment.

!

Use flatbed or wheel lift/dolly equipment with SmartKey in starter switch turned to position **0**.

Do not tow with sling-type equipment. Towing with sling-type equipment over bumpy roads will damage radiator and supports.

To prevent damage during transport, do not tie down vehicle by its chassis or suspension parts.

Switch off the tow-away alarm and the automatic central locking.

When circumstances do not permit the recommended towing methods, the vehicle may be towed with all wheels on the ground or front wheels raised only so far as necessary to have the vehicle moved to a safe location where the recommended towing methods can be employed.

!

If the vehicle is towed with the front axle raised, the engine must be shut off (SmartKey in starter switch position $\mathbf{0}$ or $\mathbf{1}$). Otherwise the ESP[®] will immediately be engaged and will apply the rear wheel brakes.

When towing the vehicle with all wheels on the ground, the gear selector lever must be in position \mathbf{N} and the SmartKey must be in starter switch position $\mathbf{2}$.

When towing the vehicle with all wheels on the ground or the front axle raised, the vehicle may be towed only for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h).

!

To be certain to avoid a possibility of damage to the transmission, however, we recommend the drive shaft be disconnected at the rear axle drive flange for any towing beyond a short tow to a nearby garage.

Warning!



If circumstances require towing the vehicle with all wheels on the ground, always tow with a tow bar if:

- the engine will not run
- there is a malfunction in the electrohydraulic brake system
- there is a malfunction in the power supply or in the vehicle's electrical system

as that will be necessary to adequately control the towed vehicle.

361

Practical hints

Towing the vehicle

Prior to towing the vehicle with all wheels on the ground, make certain that the SmartKey is in starter switch position **2**.

If the SmartKey is left in starter switch position **0** for an extended period of time, it can no longer be turned in the switch. In this case, the steering is locked. To unlock, remove SmartKey from starter switch and reinsert.

1

To signal turns while being towed with the hazard warning flasher in use, turn SmartKey in starter switch to position **2** and activate the combination switch for the left or right turn signal in the usual manner – only the selected turn signal will operate.

Upon canceling the turn signal, the hazard warning flasher will operate again.

Warning!

The brake system requires electrical power to operate.

A malfunction in the vehicle's power supply or electrical system may impair brake system operation and switch it into its emergency operation mode. To brake, the driver must then apply significantly greater brake pedal pressure and depress the pedal much further to obtain the expected braking effect. If necessary, apply full pressure to the brake pedal. Brakes are only applied to the front wheels. Stopping distance is increased! Adapt your driving style accordingly. For more information, see "Electrohydraulic brake system" (\triangleright page 84).

With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle. Adapt your driving accordingly.

!

Towing of the vehicle should only be done using the properly installed towing eye bolt. Never attach tow cable, tow rope or tow rod to the vehicle chassis, frame or suspension parts.

1

When towing the vehicle with all wheels on the ground, please note the following:

With the automatic central locking activated and the SmartKey in starter switch position **2** the vehicle doors lock if the left front wheel as well as the right rear wheel are turning at vehicle speeds of approximately 9 mph (15 km/h) or more.

To prevent the vehicle door locks from locking, deactivate the automatic central locking (▷ page 137).

Practical hints

Towing the vehicle

1

The gear selector lever will remain locked in position **P** and the SmartKey will not turn in the starter switch if the battery is disconnected or discharged. See notes on the battery (\triangleright page 356).

Installing/reinstalling towing eye bolt

!


Only secure the tow bar to the towing eye bolt. The vehicle could otherwise be damaged.

► Take the towing eye bolt ① from its storage compartment (▷ page 342).

!

Your vehicle is equipped with a front towing eye bolt only (\triangleright page 362).

You cannot tow other vehicles with your vehicle.



- 1 Towing eye bolt
- Remove cover from the access hole.
- Screw towing eye bolt (1) in to its stop.
- Remove the towing eye bolt when you no longer need it. To do this, carry out the above steps in reverse order.

Points to bear in mind

- The vehicle must not be tow-started.
- If the vehicle is to be towed, only tow it with all wheels on the ground.

- If the vehicle has suffered transmission damage, only tow it with the propeller shaft disconnected.
- Before towing the vehicle, make sure the battery is connected and charged. Otherwise you will not be able to switch on the ignition and move the selector lever to N. There will then be no power assistance when steering and braking.

Transporting the vehicle

The towing eye bolt can be used to pull the vehicle onto a trailer or transporter for transporting purposes.

► Move the selector lever to **N**.

ļ

Due to the low clearance height of the SLR, care must be taken when loading and unloading from a transporter to avoid damaging the vehicle body work.

To secure the vehicle, only tie it down by the wheels or tires. Otherwise it could be damaged.

Practical hints

Fuses

Fuses

!

You must not change the fuses yourself, as you could damage the vehicle electrical systems.

Have fuses changed at an authorized Mercedes-Benz Center.

Technical data Spare parts service

Warranty coverage

Identification labels

Layout of poly-V-belt drive

Engine

Rims and tires


Electrical system

Main dimensions

eights

Puels, coolants, lubricants, etc.

6.



Spare parts service

The "Technical data" section provides the necessary technical data for your vehicle.

All authorized Mercedes-Benz Centers maintain a stock of Genuine Mercedes-Benz parts required for maintenance and repair work. In addition, strategically located parts distribution centers provide quick and reliable parts service.

More than 300 000 different spare parts for Mercedes-Benz models are available.

Mercedes-Benz Genuine parts are subjected to stringent quality inspections. Each part has been specifically developed, manufactured or selected for and adapted to Mercedes-Benz vehicles.

Therefore, Genuine Mercedes-Benz parts should be installed.

ļ

The use of non-genuine Mercedes-Benz parts and accessories not authorized by Mercedes-Benz could damage the vehicle, which is not covered by the Mercedes-Benz Limited Warranty, or could compromise the vehicle's durability or safety.

Warranty coverage

Warranty coverage

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet. Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:


- New Vehicle Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Maine, Massachusetts and Vermont¹ Emission Control System Warranty

At time of printing, the decision regarding compliance with Vermont certification regulations was still pending. The vehicle may not be permitted to be registered in Vermont. Check with an authorized Mercedes-Benz Center for details. Replacement parts and accessories are covered by the Mercedes-Benz Spare Parts and Accessories warranties, copies of which are available at any Mercedes-Benz Center.

Loss of Service and Warranty Information Booklet

Should you lose your Service and Warranty Information booklet, have an authorized Mercedes-Benz Center arrange for a replacement. It will be mailed to you.

Identification labels




- (1) Vehicle certification label with Vehicle Identification Number
- (2) Product option code plate with paint number

The vehicle certification plate with the Vehicle Identification Number and the vehicle identification plate (certification plate) with the paint number are located on the A-pillar on the driver's side.

The Vehicle Identification Number is located on the driver's side in the bottom corner of the windshield.



(3) Vehicle Identification Number



(4) Vacuum line routing diagram label

(5) Emission control information label, includes both federal and California certification exhaust emission standards

Engine number

A


The engine number is engraved on the underside of the engine and can only be read after removing the casing on the bottom of the engine.

There is also a plate on the left-hand side of the engine cover.

When ordering parts, please specify vehicle identification and engine numbers.

Layout of poly-V-belt drive

Layout of poly-V-belt drive



The SLR has two poly-V-belts (belt one shown in purple/belt two shown in black).

- 1 Idler pulley
- (2) Automatic belt tensioner
- ③ Power steering pump
- (4) Air conditioning compressor
- (5) Idler pulley
- 6 Crankshaft
- ⑦ Coolant pump
- (8) Generator (alternator)
- (9) Idler pulley
- (1) Automatic belt tensioner
- (1) Supercharger

Engine

Model	SLR (199.376) ¹
Engine	155
Mode of operation	4-stroke engine, gasoline injection
No. of cylinders	8
Bore	3.82 in (97.00 mm)
Stroke	3.60 in (92.00 mm)
Total piston displacement	331.8 cu in (5439 cm ³)
Compression ratio	8.8:1
Output acc. to SAE J 1349	617 hp/6500 rpm ² (460 kW/6500 rpm)
Maximum torque acc. to SAE J 1349	575 lb-ft/3250-5000 rpm (780 Nm/3250-5000 rpm)
Maximum engine speed	7000 rpm
Firing order	1-5-4-2-6-3-7-8
Poly-V-belt	2425 mm/1244 mm

¹ The quoted data apply only to the standard vehicle. See an authorized Mercedes-Benz Center for the corre-sponding data of all special bodies and special equipment.
 Premium fuel required. Performance may vary with fuel octane rating.

Rims and tires

Rims and tires

!

For safety reasons, only use tires and rims which have been tested and approved by Mercedes-Benz for use on SLR vehicles. Tires approved by Mercedes-Benz are developed to provide best possible performance in conjunction with the driving safety systems on your vehicle such as ABS or ESP[®].

!

Using tires and rims other than those approved by Mercedes-Benz can have detrimental effects, such as

- Poor handling characteristics
- Increased noise
- Increased fuel consumption

Moreover, tires and rims not approved by Mercedes-Benz may, under load, exhibit dimensional variations and different tire deformation characteristics that could cause them to come into contact with the vehicle body or axle parts. This may result in damage to the tires or the vehicle.

1

Further information on tires and rims is available at any authorized Mercedes-Benz Center. A placard with the recommended tire inflation pressures is located on the driver's door B-pillar. Some vehicles may have supplemental tire pressure information for driving at high speeds (\triangleright page 265) or for vehicle loads less than the maximum loaded vehicle condition. If such information is provided, it can be found on the placard located on the inside of the fuel filler flap. The tire pressure should be checked regularly and should only be adjusted on cold tires. Follow tire manufacturer's maintenance recommendation included with vehicle.

Rims and tires

Mixed size tires

	Turbine-style	10-spoke-style*	5-spoke-style*
Front axle:			
Rims (light alloy)	9J x 19	9J x 18	9J x 18
Wheel offset	1.83 in (46.5 mm)	1.77 in (45 mm)	1.77 in (45 mm)
Summer tires (radial-ply tires)	255/35 ZR19 (96Y) XL ¹	245/40 ZR18 (93Y)	245/40 ZR18 (93Y)
Rear axle:			
Rims (light alloy)	$11^{1}/_{2}$ J x 19	11 ¹ / ₂ J x 18	11 ¹ / ₂ J x 18
Wheel offset	1.77 in (45 mm)	1.73 in (44 mm)	1.73 in (44 mm)
Summer tires (radial-ply tires)	295/30 ZR19 (100Y) XL ¹	295/35 ZR18 (99Y) ¹	295/35 ZR18 (99Y) ¹

¹ Must not be used with snow chains.

!

Only use Michelin tires of the sizes and types noted above. They are the only tires approved for use on the SLR. Use of tires not specially approved for the SLR could result in unanticipated performance characteristics. For more information, contact an authorized Mercedes-Benz Center.

Rims and tires

Winter tires*

Front axle:	
Rims (light alloy)	9J x 18
Wheel offset	1.77 in (45 mm)
Tires (radial-ply tires)	245/40 R18 97V XL M+S 🖽
Rear axle:	
Rims (light alloy)	9J x 18
Wheel offset	1.77 in (45 mm)
Tires (radial-ply tires)	245/40 R18 97V XL M+S 🖽

!

Only use Michelin tires of the sizes and types noted above. They are the only tires approved for use on the SLR. Use of tires not specially approved for the SLR could result in unanticipated performance characteristics. For more information, contact an authorized Mercedes-Benz Center.

Electrical system

Generator (alternator)	14 V/150 A
Starter motor	12 V/1.7 kW
Battery	
Starter battery	12 V/35 Ah
Battery for electrical consumers	12 V/70 Ah
Spark plugs	NGK ILFR6A
Electrode gap	0.031 in (0.8 mm)
Tightening torque	18 - 22 lb-ft (25 - 30 Nm)

Main dimensions

Main dimensions

Overall vehicle length	183.3 in (4656 mm)
Overall vehicle width	75.1 in (1908 mm)
Overall vehicle width (doors open - widest point)	111.7 in (2838 mm)
Overall vehicle height	49.6 in (1261 mm)
Overall vehicle height (doors open)	80.5 in (2045 mm)
Wheelbase	106.3 in (2700 mm)
Track, front	64.5 in (1638 mm)
Track, rear	61.8 in (1569 mm)

Weights

Trunk load max. 220 lb (100 kg)

Fuels, coolants, lubricants, etc.

V Fuels, coolants, lubricants, etc.

Capacities

Vehicle components and their respective lubricants must match. Therefore use only products tested and approved by Mercedes-Benz. Please refer to the Factory Approved Service Products pamphlet, or inquire at your Mercedes-Benz Center.

	Capacity	Fuels, coolants, lubricants, etc.
Engine with oil filter	9.5 US qt (9.0 l)	Approved engine oils
Automatic transmission	9.1 US qt (8.6 l)	MB Automatic Transmission Fluid
Rear axle	1.9 US qt (1.8 l)	Hypoid gear oil SAE 75 W 85
Power steering	approximately 1.15 US qt (1.1 l)	MB Power Steering Fluid (Pentosin CHF 11S)
Front wheel hubs	approximately 3.0 oz (85 g) each	High temperature roller bearing grease
Brake system	1.6 US qt (1.5 l)	MB Brake Fluid (DOT 4+)
Cooling system	approximately 10.6 US qt (10.0 l)	MB 325.0 Anticorrosion/Antifreeze
Low temperature cooling system	approximately 5.3 US qt (5.0 l)	MB 325.0 Anticorrosion/Antifreeze
Fuel tank including a reserve of	25.6 US gal (97.0 l) 3.2 US gal (12.0 l)	Premium unleaded gasoline: Minimum Posted Octane 91 (Avg. of 96 RON/86 MON)
Air conditioning system		R-134a refrigerant and special PAG lubricant oil (never R-12)
Windshield washer and headlamp cleaning system	7.4 US qt (7 l)	MB Windshield Washer Concentrate ¹

¹ Use MB Windshield Washer Concentrate "S" and water for temperatures above freezing or MB Windshield Washer Concentrate "S" and commercially available premixed windshield washer solvent/antifreeze for temperatures below freezing. Follow suggested mixing ratios (> page 383).

Fuels, coolants, lubricants, etc.

Engine oils

Engine oils are specifically tested for their suitability in our engines and durability for our service intervals. Therefore, only use approved engine oils and oil filters required for vehicles with Maintenance System. For a listing of approved engine oils and oil filters, refer to the Factory Approved Service Products pamphlet, or contact an authorized Mercedes-Benz Center.

!

Using engine oils and oil filters of specification other than those expressly required for the Maintenance System, or changing of oil and oil filter at change intervals longer than those called for by the Maintenance System will result in engine damage not covered by the Mercedes-Benz Limited Warranty.

Please follow Maintenance System recommendations for scheduled oil changes. Failure to do so will result in engine damage not covered by the Mercedes-Benz Limited Warranty.

Engine oil additives

Do not blend oil additives with engine oil. They may damage the engine.

Damage or malfunctions resulting from blending oil additives are not covered by the Mercedes-Benz Limited Warranty.

Air conditioning refrigerant

R-134a (HFC) refrigerant and special PAG lubricating oil are used in the air conditioner system.

Never use R-12 (CFC) or mineral-based lubricating oil. Otherwise damage to the system will occur.

Fuels, coolants, lubricants, etc.

Brake fluid

During vehicle operation, the boiling point of the brake fluid is continuously reduced through the absorption of moisture from the atmosphere.

Warning!

Under extremely strenuous operating conditions, this moisture content can lead to the formation of bubbles in the system, thus reducing the system's efficiency.

Therefore, the brake fluid must be replaced regularly. Refer to your vehicle's Maintenance Booklet for replacement interval.

Only brake fluid approved by Mercedes-Benz is recommended. Your authorized Mercedes-Benz Center will provide you with additional information.

Premium unleaded gasoline

Warning!

Gasoline is highly flammable and poisonous. It burns violently and can cause serious injury. Whenever you are around gasoline, avoid inhaling fumes and skin contact, extinguish all smoking materials. Never allow sparks, flame or smoking materials near gasoline!

!

To maintain the engine's durability and performance, premium unleaded gasoline must be used. If premium unleaded is not available and low octane fuel is used, follow these precautions:

- have the fuel tank only partially filled with unleaded regular and fill up with premium unleaded as soon as possible
- avoid full throttle driving and abrupt acceleration
- do not exceed an engine speed of 3000 rpm if the vehicle is loaded with a light load such as two persons and no luggage
- do not exceed ²/₃ of maximum accelerator pedal position if the vehicle is fully loaded or operating in mountainous terrain

Fuels, coolants, lubricants, etc.

Fuel requirements

Only use premium unleaded fuel:

 The octane number (posted at the pump) must be 91 min. It is an average of both the Research (R) octane number and the Motor (M) octane number: (R+M)/2). This is also known as the ANTI-KNOCK INDEX.

Unleaded gasoline containing oxygenates such as ethanol, IPA, IBA and TBA can be used provided the ratio of any one of these oxygenates to gasoline does not exceed 10%; MTBE must not exceed 15%.

The ratio of methanol to gasoline must not exceed 3% plus additional cosolvents.

Using mixtures of ethanol and methanol is not allowed. Gasohol, which contains 10% ethanol and 90% unleaded gasoline, can be used.

These blends must also meet all other fuel requirements, such as resistance to spark knock, boiling range, vapor pressure, etc.

Gasoline additives

A major concern among engine manufacturers is carbon build-up caused by gasoline. Mercedes-Benz recommends only the use of quality gasoline containing additives that prevent the build up of carbon deposits.

After an extended period of using fuels without such additives, carbon deposits can build up especially on the intake valves and in the combustion area, leading to engine performance problems such as:

- Warm-up hesitation
- Unstable idle
- Knocking/pinging

- Misfire
- Power loss

In areas where carbon deposits may be encountered due to lack of availability of gasolines which contain these additives, Mercedes-Benz recommends the use of additives approved by us for use on Mercedes-Benz vehicles. Refer to Factory Approved Service Products pamphlet for a listing of approved product(s). Follow directions on product label.

Do not blend other fuel additives with fuel. This only results in unnecessary cost and may be harmful to engine operation.

Damage or malfunction resulting from poor fuel quality or from blending additional fuel additives other than those tested and approved by us for use on Mercedes-Benz vehicles listed in the Factory Approved Service Products pamphlet are not covered by the Mercedes-Benz Limited Warranty.

Fuels, coolants, lubricants, etc.

Coolants

The engine coolant is a mixture of water and anticorrosion/antifreeze, which provides:

- corrosion protection
- freeze protection
- boiling protection (by increasing the boiling point)

The cooling system was filled at the factory with a coolant providing freeze protection to approximately -22°F (-30°C) and corrosion protection.

If the antifreeze mixture is effective to -22 °F (-30 °C), the boiling point of the coolant in the pressurized cooling system is reached at approximately 266 °F (130 °C).

The coolant solution must be used year round to provide the necessary corrosion protection and increase in the boil-over protection. Refer to Maintenance Booklet for replacement interval. Coolant system design and coolant used determine the replacement interval. The replacement interval published in the Maintenance Booklet is only applicable if MB 325.0 anticorrosion/antifreeze solution or other Mercedes-Benz approved products of equal specification (see Factory Approved Service Products pamphlet) are used to renew the coolant concentration or bring it back up to the proper level.

To provide important corrosion protection, the solution must be at least 45% anticorrosion/antifreeze (equivalent to freeze protection to approximately - 22°F [-30°C]). If you use a solution that is more than 55% anticorrosion/antifreeze (freeze protection to approximately - 49°F [-45°C]), the engine temperature will increase due to the lower heat transfer capability of the solution. Therefore, do not use more than this amount of anticorrosion/antifreeze. If the coolant level is low, water and MB 325.0 anticorrosion/antifreeze should be used to bring it up to the proper level (have cooling system checked for signs of leakage). Please make sure the mixture is in accordance with label instructions.

The water in the cooling system must meet minimum requirements, which are usually satisfied by normal drinking water. If you are not sure about the water quality, consult an authorized Mercedes-Benz Center.

Fuels, coolants, lubricants, etc.

Anticorrosion/antifreeze

Your vehicle contains a number of aluminum parts. The use of aluminum components in motor vehicle engines necessitates that anticorrosion/antifreeze coolant used in such engines be specifically formulated to protect the aluminum parts. (Failure to use such anticorrosion/antifreeze coolant will result in a significantly shortened service life.)

Therefore, the following product is strongly recommended for use in your vehicle: Mercedes-Benz 325.0 anticorrosion/anti-freeze agent. Before the start of the winter season (or once a year in hot southern regions), you should have the anticorrosion/antifreeze concentration checked. The coolant is also regularly checked each time you bring your vehicle to an authorized Mercedes-Benz Center for service.

Anticorrosion/antifreeze quantity

	Approximately freeze protection	
	– 35°F (– 37°C)	– 49°F (– 45°C)
Main cooling system	5.2 US qt (5.0 l)	5.8 US qt (5.5 l)
Low temperature cooling system	2.6 US qt (2.5 l)	2.9 US qt (2.75 l)

Fuels, coolants, lubricants, etc.

Windshield and headlamp washer system

Both the windshield and headlamp washer systems are supplied from the windshield washer fluid reservoir.

The windshield and headlamp washer fluid reservoir has a capacity of approximately 7.4 US qt (7 l).

Refill the reservoir with MB Windshield Washer Concentrate and water (or concentrate and commercially available premixed windshield washer solvent/antifreeze, depending on ambient temperatures).

Warning!

 \wedge

Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/antifreeze on hot engine parts because it may ignite and burn. You could be seriously burned.

Windshield and headlamp washer fluid mixing ratio

For temperatures above "freezing point", use MB Windshield Washer Concentrate "S" and water:

• 1 part "S" to 100 parts water

(1.34 floz [40 ml] "S" to 1 gallon [4.0 l] water).

For temperatures below "freezing point" use MB Windshield Washer Concentrate "S" and commercially available premixed windshield washer solvent/antifreeze:

• 1 part "S" to 100 parts solvent

(1.34 floz [40 ml "S" to 1 gallon [4.0 l] solvent).

Technical terms

ABS

(<u>Anti-lock Braking System</u>) Prevents the wheels from locking up during braking so that the vehicle can continue to be steered.

Accessory weight

(⊳ page 281)

ACL

(<u>Airbrake/Central Locking</u>) Controls the locking mechanism of the Airbrake and the central locking system.

Air pressure

(⊳ page 281)

Aspect ratio

(⊳ page 281)

BabySmart[™] airbag deactivation system

This system detects if a special system compatible child restraint seat is installed on the front passenger seat. The system will automatically deactivate the passenger front airbag when such a seat is properly installed (PASSENGER AIRBAG OFF indicator lamp on the lower center console illuminates and remains illuminated).

BabySmart[™] compatible child seats

Special restraint system for children. The sensor system for the passenger seat prevents deployment of the passenger front airbag if a BabySmart[™] compatible child seat is installed. See an authorized Mercedes-Benz Center for availability.

Bar

(⊳ page 281)

BAS

(Brake Assist System)

System for potentially reducing braking distances in emergency braking situations. The system is activated when it senses an emergency based on how fast the brake is applied.

Bead

(⊳ page 281)

Bi-Xenon headlamps

Headlamps which use an electric arc as the light source and produce a more intense light than filament headlamps. Bi-Xenon headlamps produce low beam and high beam.

CAC

(<u>C</u>ustomer <u>Assistance C</u>enter) Mercedes-Benz customer service center, which can help you with any questions about your vehicle and provide assistance in the event of a breakdown.

CAN system

(<u>C</u>ontroller <u>Area Network</u>) Data bus network serving to control vehicle functions such as door locking or windshield wiping depending on vehicle settings and/or ambient conditions.

Cockpit

All instruments, switches, buttons and indicator/warning lamps in the passenger compartment needed for vehicle operation and monitoring.

Cold tire inflation pressure

(⊳ page 281)

Control system

The control system is used to call up vehicle information and to change component settings. Information and messages appear in the multifunction display. The driver uses the buttons on the multifunction steering wheel to navigate through the system and to adjust settings.

Cruise control

Driving convenience system for automatically maintaining the vehicle speed set by the driver.

Curb weight

(⊳ page 281)

DOT

(<u>D</u>epartment <u>of</u> <u>T</u>ransportation) (▷ page 282)

Engine number

The number set by the manufacturer and placed on the cylinder block to uniquely identify each engine produced.

Engine oil viscosity

Measure of the internal oil friction (viscosity) at different temperatures. The higher the temperature the oil can tolerate without thinning too much, or the lower the temperature it can tolerate without thickening too much, the better the viscosity characteristics of the oil.

ESP[®]

(Eectronic Stability Program) Improves vehicle handling and directional stability.

ETD

(Emergency Tensioning Device) Device which deploys in certain frontal and rear collisions exceeding the system's threshold to tighten the seat belts.

->SRS

GAWR

(<u>G</u>ross <u>A</u>xle <u>W</u>eight <u>R</u>ating) (▷ page 282)

Gear range

Number of gears which are available to the automatic transmission for shifting. The automatic gear shifting process can be adapted to specific operating conditions using the gear selector lever or the steering wheel gearshift control buttons.

GPS

(<u>G</u>lobal <u>Positioning System</u>) Satellite-based system for relaying geographic location information to and from vehicles equipped with special receivers. Employs CD digital maps for navigation.

GVW

(<u>G</u>ross <u>V</u>ehicle <u>W</u>eight) (▷ page 282)

GVWR

(<u>Gross Vehicle Weight Rating</u>) (▷ page 282)

Head-thorax airbag

Installed in the doors, these airbags protect occupants during side impact collisions exceeding a preset threshold. Unlike normal side airbags, head-thorax airbags are also designed to provide protection for the head area.

Instrument cluster

The displays and indicator/warning lamps in the driver's field of vision, including the tachometer, speedometer, engine temperature and fuel gauge.

Kickdown

Depressing the accelerator past the point of resistance shifts the transmission down to the lowest possible. This very quickly accelerates the vehicle and should not be used for normal acceleration needs.

Kilopascal (kPa)

(⊳ page 282)

Maximum load rating

(⊳ page 282)

Maximum loaded vehicle weight (▷ page 282)

Maximum tire inflation pressure

(⊳ page 282)

MON

(<u>Motor Octane Number</u>) The Motor Octane Number for gasoline as determined by a standardized method. It is an indication of a gasoline's ability to resist undesired detonation (knocking). The average of both the MON (Motor Octane Number) and RON (Research Octane Number) is posted at the pump, also known as ANTI-KNOCK INDEX.

Multifunction display

Two display fields in the instrument cluster used to present information provided by the control system.

Multifunction steering wheel

Steering wheel with buttons for operating the control system.

Normal occupant weight

(⊳ page 282)

Technical terms

Overspeed range

Engine speeds within the red marking on the tachometer dial. Avoid this engine speed range, as it may result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

Poly-V-belt drive

Drives engine-components (alternator, AC compressor, etc.) from the engine.

Power train

Collective term designating all components used to generate and transmit motive power to the drive axles, including

- engine
- clutch/torque converter
- transmission
- transfer case
- drive shaft
- differential
- axle shafts/axles

Production options weight

(⊳ page 282)

Program mode selector switch

Used to switch the automatic transmission between sport operation (**S**), comfort operation (**C**) and manual operation (**MAN**).

PSI

(<u>P</u>ounds per <u>s</u>quare <u>i</u>nch) (⊳ page 283)

Recommended tire inflation pressure (▷ page 283)

REST

(Residual Engine Heat Utilization) Feature that uses the engine heat stored in the coolant to heat the vehicle interior for a short time after the engine has been turned off.

Rim

(⊳ page 283)

RON

(Research Octane Number) The Research Octane Number for gasoline as determined by a standardized method. It is an indication of a gasoline's ability to resist undesired detonation (knocking). The average of both the MON (Motor Octane Number) and RON (Research Octane Number) is posted at the pump, also known as ANTI-KNOCK INDEX.

Electrohydraulic brake system

Electronically controlled hydraulic braking system for increased braking safety and comfort.

Shift lock

When the vehicle is parked, this lock prevents the gear selector lever from being inadvertently moved out of position **P** without SmartKey turned and brake pedal depressed.

Sidewall

(⊳ page 283)

SRS

(Supplemental Restraint System) Seat belts, emergency tensioning device and airbags. Though independent systems, they are closely interfaced to provide effective occupant protection.

Tele Aid

(<u>Tele</u>matic <u>A</u>larm <u>I</u>dentification on <u>D</u>emand)

The Tele Aid system consists of three types of response: automatic and manual emergency, roadside assistance and information. Tele Aid is initially activated by completing a subscriber agreement and placing an acquaintance call.

The Tele Aid system is operational provided that the vehicle's battery is charged, properly connected, not damaged and cellular and GPS coverage is available.

Tightening torque

Force times lever arm (e.g. a lug wrench) with which threaded fasteners such as wheel bolts are tightened.

TIN

(<u>Tire Identification N</u>umber) (⊳ page 283)

Tire load rating

(⊳ page 283)

Tire ply composition and material used (▷ page 283)

Tire speed rating

(⊳ page 283)

TIREFIT kit

Accessory for emergency and temporary tire repair. The TIREFIT kit consists of a container with sealant material, a filler hose and an air compressor.

Traction

(⊳ page 283)

Tread

(⊳ page 283)

Treadwear indicators

(⊳ page 283)

Uniform Tire Quality Grading Standards (▷ page 284)

Vehicle capacity weight

(⊳ page 284)

Vehicle maximum load on the tire

(⊳ page 284)

VIN

(Vehicle Identification Number) The number set by the manufacturer and placed on the body to uniquely identify each vehicle produced. Index

Α

ABS 79,385 Indicator lamp 29, 299 Messages in the multifunction display 309 ABS/ESP® Warning lamp 29, 298 Accelerator position, automatic transmission 173 Accessory weight 281 Accident 56 ACL 385 Messages in the multifunction display 312 Additional turn signals, Exterior mirror 349 Air conditioning system see Automatic climate control Air distribution 187 Air pressure 281 Air pressure see Tire inflation pressure Air recirculation mode 188 Air vents 183 Air volume 186

Airbags 63 Children 64 Front, Driver 68 Front, Passenger 68 Head-thorax 68, 69 Knee 68 Safety guidelines 67 Airbrake 31,87 Automatic mode 89 Emergency braking 89 Manual mode 88 Message in the multifunction display 315 Test Mode 88 Warning lamp 29, 303 Alarm system see Anti-theft systems Anticorrosion/antifreeze 377, 382 Antiglare, Interior rear view mirror 179 Antilock Brake System see ABS Anti-theft systems Anti-theft alarm system 90 Immobilizer 90 Tow-away alarm 92

Anti-theft wheel nuts 285 Aquaplaning see Hydroplaning Armrest 200 Ashtray 202 Aspect ratio 281 AUDIO menu 123 Audio system 31, 143 Button and soft key operation 146 Cassette operation 152 CD operation 156 Location 143 Operating and display elements 144 Operating safety 143 Operation 146 Radio operation 149 Switching on/off 146 Telephone operation 160, 204 Auto-dimming, Interior rear view mirror 179 Automatic car wash 293 Automatic central locking, Control system 103, 137

Automatic climate control 182 Adjusting air volume 186 Air conditioning refrigerant 378 Air conditioning, Cooling 192 Air distribution 187 Air recirculation mode 188 Air vents 183 Control panel 184 Deactivating system 191 Defrosting 181, 188 MAXCOOL 187 Residual heat utilization 190 Side air vents 31 Temperature 185 Temperature sensor 33 Automatic headlamp mode 106 Automatic lighting control, Interior lighting 111

Automatic transmission 167 Accelerator position 173 Damage 362 Driving tips 173 Emergency operation (Limp Home Mode) 178 Gear ranges 170 Gear selector lever 32, 167 Gear selector lever position 167, 171 Gear shifting malfunctions 178 Kickdown 173 Manual gearshift program 176 Manual shifting 168 One-touch gearshifting 168 Shift program mode selector switch 173 Starting the engine 49 Steering wheel gearshift control 174 Towing 362 Transmission fluid level 249 Automatic transmission fluid 249

В

BabySmartTM Airbag deactivation system 75, 385 Compatible child seats 385 Self-test 75 Backup lamp 349 Messages in the multifunction display 332 Bar 281 BAS 81, 385 Batteries, SmartKey Checking battery condition 99 Replacing 346 Batteries, Vehicle 251 Charging 358 Consumer battery 356 Jump starting 356 Maintenance 356 Messages in the multifunction display 315 Starter battery 251 Batteries, vehicle Consumer battery 251 Battery charger 358 Bead 281 Bi-Xenon headlamps 385

Body surface 292 Brake Electrohydraulic brake system 84 Brake Assist System see BAS Brake fluid 377, 379 Checking 242 Messages in the multifunction display 300, 317 Brake lamps 349 High mounted 349 Messages in the multifunction display 330 Brake pads Messages in the multifunction display 318 Brakes 232 Warning lamp 29, 300 Break-in the vehicle 230 Bulbs Messages in the multifunction display 330 Replacing 348

С

CAC 385 California retail buyers and lessees, important notice for 15 Call priority, Tele Aid 214 CAN system 386 Capacities and recommended fuel/lubricants 377 Cargo area see Trunk Cassette player 152 Catalytic converter 239 CD changer 156 Location 157 CD player 124 Cellular phone Delayed switch-off time 206 Inserting the cradle 205 Making calls in hands-free mode 207 Making calls in private mode 206 Re-inserting 207 Removing the cradle 205 Center console Lower part 32 Upper part 31 Center storage compartment 201

Central locking Automatic 103, 137 Central locking switch 31 Locking/unlocking from inside 103 Central locking switch 103 Children in the vehicle 72 Airbags 64 Indicator lamp, front passenger front airbag 75 Infant and child restraint systems 62, 75,77 Cigarette lighter 202 Clock 29, 131 Setting time 131 Cockpit 26, 386 Cold tire inflation pressure 281 Combination switch 27, 53, 109 Compact guide 343 Control and operation of radio transmitters 238 Control system 117, 386 Multifunction display 117 Multifunction steering wheel 118 Resetting to factory default 127

Index

Control system menus 120 AUDIO menu 123 Settings 126 Standard display menu 122 TEL 139 Trip computer 137 Vehicle status message memory 124 Control system submenus 121, 127 Instrument cluster 129 Lighting 132 Time 131 Vehicle 136 Controller Area Network see CAN Coolant 242, 250, 381 Anticorrosion/antifreeze mixing ratio and quantity 382 Capacities 377 Checking coolant level 242, 250 Messages in the multifunction display 323 Temperature 240 Temperature gauge 114 Warning lamp 29, 302 Courtesy lighting 112

Cruise control 27, 197, 386 Messages in the multifunction display 309 Curb weight 281 Customer Assistance Center see CAC

D

Daytime running lamp mode 107 Setting 132 Deep water see Standing water Defogging windshield 188 Defrosting, Front 188 Defrosting, Rear 181 Delayed switch-off Exterior lamps 134 Interior lighting 135 Department of Transportation see DOT Differential Message in the multifunction display 326 Difficulties While driving 56 With starting 50 Digital clock see Clock Digital speedometer 123 Dimensions, Vehicle 375 Direction of rotation, Tires 257

Display elements, Audio system 144 Displays Digital speedometer 123 Maintenance service indicator 289 Multifunction display 117 Outside temperature 115, 129 Showing vehicle status messages 125 Symbol messages 315 Text messages 309 Vehicle status messages 124, 307 Distance to empty (Range) 139 Door Control panel 34 Entry lamps 111 Handle, Inside 34 Handle, Outside 38 38,96 Locking/unlocking, SmartKey Message in the multifunction display 327 Opening from inside/outside 38. 100 Remote door unlock, Tele Aid 215 Unlocking in an emergency 345 DOT 282 Drinking and driving 231

Driving 46,51 Abroad 238 Hints, Electrohydraulic brake system 86 Hydroplaning 236 In winter 237 Instructions 46, 231 Problems 56 Safety systems 79 Systems 197 Through standing water 238 Tips, Automatic transmission 173 Driving safety systems 79 ABS 79 BAS 81 Electrohydraulic brake system 84 ESP[®] 81 Driving systems Cruise control 197 Dust cover 224

Е

Electric air pump 342 Electrical fuses 363 Electrical outlet see Power outlet Electrical system, Technical data 374 Electrohydraulic brake system 79, 84, 388 Activation 85 Deactivation 86 Driving hints 86 Emergency operating mode 84 Messages in the multifunction display 319 Self-check 85, 318 Warning lamp 84 Electronic Stability Program see ESP® Emergency calls 911 164 Tele Aid 209 Emergency operations Automatic transmission (Limp Home Mode) 178 Remote door unlock, Tele Aid 215 Trunk lid, Releasing from inside 102 Unlocking the vehicle 344 Emergency Tensioning Device see ETD

Emergency, In case of First aid kit 342 Flat tire 351 Hazard warning flasher 110 Instrument cluster, Indicator lamps 298 Roadside Assistance 16, 211 Towing the vehicle 360 Emission control 240 Information label 368 System warranties 14 Vacuum line routing diagram label 368 Engine Break-in recommendations 230 Cleaning 293 Compartment 244 Malfunction indicator lamp 29, 301 Number 368, 386 Poly-V-belt layout 369 Starting 49 Tachometer 29 Technical data 370 Turning off 58 Engine coolant see Coolant

Engine oil 247, 378 Adding 249, 377 Additives 247, 378 Checking level 248 Consumption 247 Filler neck 248 Message in the multifunction display 328 Recommended engine oils and oil filter 378 Temperature 29 Oil temperature indicator 303 Viscosity 386 ESP[®] 79, 81, 386 Resetting 311 Warning lamp 81, 298 Messages in the multifunction display 310 ETD 72, 386 Safety guidelines 67 Exterior lamp switch 52, 105 Exterior rear view mirrors 44

F

Filler neck, Engine oil 248 First aid kit 342 Flat tire 351 Preparing the vehicle 351 TIREFIT kit 351 Floormats 223 Fluids Automatic transmission fluid 249. 377 Brake fluid 242, 377, 379 Capacities 377 Engine coolant 250, 377, 381 Engine oil 247, 377, 378 Power steering fluid 377 Windshield washer and headlamp cleaning system 252, 377 Fog lamps 108, 349 Message in the multifunction display 330 Front airbags 68 Front lamps see Headlamps

Fuel 241 Additives 380 Capacity, Fuel tank 377 Consumption statistics 138 Filler flap 241 Filling the tank 241 Fuel reserve warning lamp 29, 303 Gauge 29 Premium unleaded gasoline 241, 379 Requirements, Octane rating 377, 380 Fuel cap Messages in the multifunction display 301, 329 Fuel filler flap Locking/unlocking 241 Fuel reserve Message in the multifunction display 329 Fuel reserve warning lamp 29 Fuel system Message in the multifunction display 329

Fuel tank

Capacity 377 Filler flap 241 Fuels, coolants, lubricants etc. 377 Fuses 363

G

Garage door opener 216 Gasoline see Fuel **GAWR** 282 Gear range Automatic transmission 170 Canceling limit 169 Limiting 170 Shifting into optimal 169 Gear selector lever 32, 167 Lock 49, 51, 388 Position 167, 171 Position indicator 167 Gearshift Indicator lamp 29 Program, Manual 173, 176 Global locking/unlocking see Key Good visibility 179

GPS 387 Gross Axle Weight Rating see GAWR Gross Vehicle Weight Rating see GVWR Gross Vehicle Weight see GVW GVW 282 GVWR 282

Н

Hands-free microphone 33 Hazard warning flasher 110 Head/thorax airbag 69 Headlamp switch-off delay see Delayed switch-off, exterior lamps Headlamps Automatic headlamp mode 106 Cleaning lenses 295 Cleaning system 179, 252, 383 Manual headlamp mode 106 Messages in the multifunction display 331 Replacing bulbs 348 Switch 52, 105 Head-thorax airbag 75, 387 High beam flasher 53, 109 Replacing bulbs 348

High beam headlamps Indicator lamp 29 Messages in the multifunction display 331 Replacing bulbs 348 Switching on 109 High mounted brake lamp 349 High-pressure cleaners 293 Hood 244 Messages in the multifunction display 329 Horn 27 HVAC see Automatic climate control Hydroplaning 236

I

Identification labels 368 Identification Number, Vehicle (VIN) 368 Ignition 40 Immobilizer 90 Indicator lamps see Lamps, Indicator and warning Infant and child restraint systems see Children in the vehicle Inflation pressure see Tires, Inflation pressure Inside door handle 34

Instrument cluster 28, 113, 387 Illumination brightness 113 Lamps 298 Messages in display see Multifunction display messages Multifunction display 117 Instrument lighting 113 Instrument panel see Instrument cluster Instruments and controls see Cockpit Interior lighting 111 Delayed switch-off 135 Interior rear view mirror 44 Auto-dimming 179 Interior storage spaces see Storage compartments

J

Jacking up the vehicle 351 Jump starting 356

Κ

Key, Mechanical 344 Key, SmartKey Battery check lamp 98 Checking the batteries 99 Factory setting 98 Locking/unlocking 96 Locking/unlocking, Global setting 98 Locking/unlocking, Selective setting 98 Loss of 99 Messages in the multifunction display 329 Opening and closing the windows 195, 196 Positions in starter switch 40 Remote control 96 Replacing the batteries 346 Turning off the engine 58 Unlocking, Trunk 99 Kickdown 173, 387 Kilopascal 282 Knee airbags 68

L

Labels Certification 368 Emission control label 368 Vacuum line routing 368 Lamps Exterior 348 Lamps, exterior Messages in the multifunction display 330 Lamps, indicator and warning ABS 29, 299 ABS/ESP[®] 29, 298 Airbrake 29, 303 Battery, SmartKey 98 Brake 29, 300 Center console 306 Coolant 29, 302 Engine malfunction 29, 301 Engine oil temperature 29, 303 Fog lamps 108 Fuel reserve 29, 303 Gearshift 29, 303 High beam 29 Instrument cluster 298 Maintenance service indicator 289

PASSENGER AIRBAG OFF 75, 306 Seat belt telltale 29, 304 SRS 29, 63, 304 Tire pressure monitor 29, 305 Turn signals 29 Language, Setting 130 License plate lamp Messages in the multifunction display 331 Replacing bulbs 348 License plate lamps 349 Light sensor Messages in the multifunction display 331 Lighter see Cigarette lighter Lighting 105 Exterior Interior 111 Limp Home Mode, Automatic transmission 178 Loading see Vehicle loading Location Audio system 143 Compact guide (Canada only) 343 Telephone 201 Vehicle literature portfolio 342

Locator lighting 108, 133 Loss of Keys 99 Service and Warranty Information Booklet 367 Low beam headlamps 105 Messages in the multifunction display 331 Replacing bulbs 348 Switching on 52 Lubricants 377

Μ

Main odometer 29 Maintenance 289, 356 Calling up service indicator 291 Resetting service indicator 291 Service indicator 289 Service term exceeded 290 Manual gearshift program, Automatic transmission 176 Manual headlamp mode see Headlamps Map pocket in passenger footwell 200 Maximum load rating, Tires 282 Maximum loaded vehicle weight 282 Maximum tire inflation pressure 282 Mechanical key 344 Menus see Control system menus Messages in display see Multifunction display messages 307 Microphone, Hands-free 33 Mirrors 179 Adjusting 44 Auto-dimming 179 Exterior rear view mirror 44 Interior rear view mirror 44 MON 241, 387 Motor Octane Number see MON Multifunction display 117, 387 Changing settings see Control system menus and Control system submenus 117 Left 29 Right 29 Selecting language 130

Multifunction display messages ABS 309 ACL malfunction 312 Airbrake 315 Battery, Vehicle 315 Brake pads 318 Coolant 323 Cruise control 310 Differential 326 Display 327 Doors 327 Electrohydraulic brake system 319 Engine 328 Engine oil 328 ESP[®] 310 Fuel system 329 Hood 329 Lamps 330 Parking brake 322 Reserve fuel 329 Seat belt 334 Service brake 322 SmartKey 329 Telephone 329 Tires 335 Trunk lid 341

Washer fluid 341 Multifunction steering wheel 30, 118, 387 Button operation 118 Gearshift control, Automatic transmission 174

Ν

Net, parcel 201 New vehicle break-in 230 Night security illumination 108, 134 Normal occupant weight 282 Number, Vehicle Identification (VIN) 368, 389

0

Occupant distribution 282 Occupant safety Airbags 63 BabySmartTM airbag deactivation system 75 Children and airbags 64 Children in the vehicle 72 Fastening the seat belts 46 Infant and child restraint systems 73 Seat belts 69 Octane number 388 Odometer Main 117 115 Trip Oil level see Engine oil, Checking level Oil see Engine oil One-touch gearshifting, Automatic transmission 168 Operating safety Audio system 143 Vehicle 20 Operator's manual 342 Outside temperature see Displays Overdue maintenance service 290 Overhead control panel 33 Overspeed range, Engine 115, 388

Ρ

Panic alarm 78 Parcel net in trunk 201 Parking 57, 234 Parking brake 32 Engaging 57 Message in the multifunction display 322 Releasing 50 Parking lamps 105 Message in the multifunction display 332 Replacing bulbs 348 Parts service 366 PASSENGER AIRBAG OFF Indicator lamp 75, 306 Passenger compartment 238 Passenger safety see Occupant safety Pedals 231 Performance enhancement system, Airbrake 87 Phone see Telephone Poly-V-belt drive 388 Layout 369 Power assistance 232 Power outlet 203 Power train 388 Power washer 293 Power windows 193 Cleaning 294 Operating 193 Synchronizing 195 Practical hints 296 Premium unleaded gasoline 379

Problems While driving 56 With the vehicle 21 Product information 13 Production options weight 282 Program mode selector switch, Automatic transmission 173, 388 PSI 283 Push starting 356

R

Radio Operation 149 Selecting stations 123 Radio transmitters 238 Range (distance to empty) 139 Reading lamp 112 Rear fog lamp see Fog lamps Rear lamps see Tail lamps Rear view mirrors see Mirrors Rear window defroster 181 Recommended tire inflation pressure 283 Recovery services, Stolen vehicle (Tele Aid) 215 Redial memory 142 Refrigerant, Air conditioning 378 Refueling 241 Regular checks 242 Remote control, SmartKey 96 Remote door unlock, Tele Aid 215 Replacing bulbs 348 Reporting safety defects 22 Research Octane Number see RON Reset button, in Instrument cluster 113, 289 Residual heat utilization 190 Restraint systems 62 Airbags 62, 63 Children in the vehicle 72 **Emergency Tensioning Device** (ETD) 62,72 Seat belts 62, 69 Rims 283, 371 Roadside Assistance 16, 211 RON 241, 388 Roof rack 227

S

Safety Driving safety systems 79 Occupant 62 Reporting defects 22 Safety belts see Seat belts Seat belt force limiter 72 Seat belts 62 Children in the vehicle 72 Fastening seat belts 46 Message in the multifunction display 334 Proper use of 48 Safety guidelines 67 Telltale 69, 304 Seating capacity 259 Seats 42 Selector lever see Gear selector lever Self-test BabySmartTM airbag deactivation system 75 Lamps in the instrument cluster 298 Tele Aid 209 Service and warranty information 14 Service intervals see Service indicator Service life Tires 255 Vehicle batteries 251 Service see Maintenance Service, Parts 366

Settings

Control system menus 120 Control system submenus 121 Factory, SmartKey 98 Individual, Vehicle 126 Menus and submenus 119 Resetting all, Control system 126 Selective, SmartKey 98 Time 131 Shift program mode selector switch, Automatic transmission 173 Shifting, Automatic transmission 167 Side air vents 31 Side marker lamps Messages in the multifunction display 332 Replacing bulbs 349 Side windows see Power windows Sidewall 283 SmartKey see Key, SmartKey Snow chains 288 Snow tires* 287 Spare fuses 363 Spare parts service 366 Speed setting Cruise control 199

Speedometer 29 SRS 62, 389 Indicator lamp 29, 304 Messages in the multifunction display 312 Standing lamps 105 Standing water, Driving trough 238 Start button 49 Starter battery 251, 356 Starter switch 27, 40 Starting difficulties, Engine 50 Starting the engine 49 Steering wheel 43 Buttons 30 Steering wheel gearshift control Automatic transmission 174 Indicator lamp 303 Stolen Vehicle Recovery services 215 Storage compartments 200 Armrest 200 Center 201 Map pocket, Passenger footwell 200 Parcel net in trunk 201 Rear 201 Storing tires 256 Submenus see Control system submenus

Sun visors 180 Supplement Restraint System see SRS Symbols used in this Operator's Manual 19

Т

Tachometer 29 Overspeed range 115 Tail lamps Messages in the multifunction display 333 Replacing bulbs 348 Technical data 364 Air conditioning refrigerant 378 Brake fluid 379 Coolants 381 Electrical system 374 Engine 370 Engine oil additives 378 Engine oils 378 Fuel requirements 380 Fuels, coolants, lubricants etc. 377 Gasoline additives 380 Main dimensions 375 Poly-V-belt 369 Premium unleaded gasoline 379 Rims and tires 371

Weights 376 Windshield and headlamp washer system 377, 383 Tele Aid 208, 389 Call priority 214 Emergency calls 209 Hands-free microphone 33 Information 213 Initiating an emergency call manually 211 Messages in the multifunction display 334 Remote door unlock 215 Roadside Assistance 211 SOS button 211 Stolen Vehicle Recovery services 215 System self-check 209 Telephone 203 Answering a call 140 Dialing 141 Ending a call 141 Hands-free microphone 33 Loading phone book 141 Messages in the multifunction display 329

Operation 139, 160 Redialing 142 Signal strength 140 Storage location 201 Temperature Interior temperature 185 Outside temperature 115 Sensor, Interior 33 Sensor, outside 116 Setting display unit 129 Tether attachment points, see Children in the vehicle Tightening torque, Wheel bolts 285, 286, 389 Time 131 TIN 276, 283 Tire and Loading Information 258 Placard 258 Terminology 281 Tire Identification Number see TIN Tire inflation pressure Checking Checking electronically 267 Checking manually 266 Setting units 137

TIREFIT kit 342, 351, 389 Tire inflation pressure 353 Using 351 Tires 254, 371 Air pressure 281 Care and maintenance 255 Cleaning 256 Direction of rotation, Spinning 257 Driving instructions 235 Hydroplaning 236 Important guidelines 254 Important notes, Tire inflation pressure 265 Inflation pressure 243, 264, 266, 278 Information placards 258 Inspection 255 Load rating 272, 277, 283 Loading terminology 281 Messages in the multifunction display 313, 335 Ply composition and material used 281, 283 Problems under-/overinflation 270 Retreads 254 Rims and tires 371

Rotation 284 Service life 255 Size designation 272 Sizes 372 288 Snow chains Speed rating 236, 272, 274, 283 Storing 256 Temperature 265, 280 Terminology 281 TIN 276 Tire pressure monitor warning lamp 29, 305 TIREFIT kit 351 Traction 236, 280 Tread depth 256, 287 Treadwear indicators 256 Vehicle maximum load on 284 Wear pattern 284 Winter* 287 Top tether, see Children in the vehicle Tow-away alarm 92 Towing 360 Transmission damage 362 Towing eye bolt 342 Installing/reinstalling 362 Traction 173, 236, 283

Transmission gear selector lever see Gear selector lever Transmission see Automatic transmission Transporting the vehicle 362 Traveling abroad 238 Tread 283 Tread depth 256, 287 Treadwear indicators 283 Trip computer 137 Trip odometer 115, 117 Trunk Closing 101 Emergency release 102 Lamp 112 Lock 100 Message in the multifunction display 341 Opening 99, 100 Opening in an emergency 344 Parcel net 201 Trunk lid rack 227 Turn signals 53 Additional in mirrors 349 Indicator lamps 29 Messages in the multifunction display 331, 333

Replacing bulbs 348 Turning off the engine 58

U

Uniform Tire Quality Grading Standards 284 Units, Setting Speedometer 129 Temperature 129 Tire inflation pressure 137 Unleaded gasoline, Premium 241, 379 Useful features 200

۷

Vacuum line routing diagram label 368 Vehicle Batteries 251 Break-in the vehicle 230 Control system, Settings menu 126 Dimensions 375 Locking/unlocking 38, 59, 96, 103 Modifications and alterations, Operating safety 20 Towing 360 Transporting 362 Unlocking in an emergency 344 Vehicle capacity weight 284

Vehicle care 292 Vehicle Identification Number see VIN Vehicle lighting 243 Vehicle literature portfolio 342 Vehicle loading 257 Load limit 258 Roof and trunk lid racks 227 Terminology 281 Vehicle maximum load on the tire 284 Vehicle Recovery services, Stolen (Tele Aid) 215 Vehicle status message memory menu 124 Vehicle washing 293 VIN 368, 389

W

Warning lamps see Lamps, Indicator and warning Warning sounds Exterior lamps 59 Parking brake 52 Seat belt telltale 69 Warranty coverage 14, 367 Washer fluid see Windshield washer fluid Washer reservoir level 252 Washing the vehicle 292 Wear pattern, Tires 284 Wheel bolts Anti-theft wheel nuts 285 Tightening torque 285 Wheels, Sizes 372 Wheels, Tires and 254 Windows see Power windows Windshield Cleaning 294 Defrosting/Defogging 188 Windshield washer fluid 252, 383 Message in the multifunction display 341 Mixing ratio 383 Refilling 252 Wiping with 55 Windshield washer system 383 Windshield wipers 27, 54 Cleaning wiper blades 294 Replacing wiper blades 350 Single wipe 55 Winter driving 287 Instructions 237 Snow chains 288 Tires* 287 Winter tires* 287

Service and Literature

Your authorized Mercedes-Benz Center has trained technicians and original Mercedes-Benz parts to service your vehicle properly. For expert advice and quality service, contact an authorized Mercedes-Benz Center.

If you are interested in obtaining service literature for your vehicle, please contact an authorized Mercedes-Benz Center. We consider this the best way for you to obtain accurate information for your vehicle.

For further information you can find us on the Mercedes-Benz web-site www.mbusa.com or www.mercedes-benz.ca.

Warning!

 \triangle

To help avoid personal injury, be extremely careful when performing any service work or repairs. Improper or incomplete service or the use of incorrect or inappropriate parts or materials may damage the vehicle or its equipment, which may in turn result in personal injury.

If you have any questions about carrying out any type of service, turn to the advice of an authorized Mercedes-Benz Center.

We reserve the right to modify the technical details of the vehicle as given in the data and illustrations of this Operator's Manual. Reprinting, translation and copying, even of excerpts, is not permitted without our prior authorization in writing.

> Press time May 23, 2005 GSP/TIP Printed in Germany