

CLS Operator's Manual

Symbols

Trademarks:

- Bluetooth® is a registered trademark of Bluetooth SIG Inc.
- ESP® and PRE-SAFE® are registered trademarks of Daimler.
- HomeLink[®] is a registered trademark of Prince, a Johnson Controls Company.
- SIRIUS and related marks are trademarks. of SIRIUS XM Radio Inc.

The following symbols are found in this Operator's Manual:



Marning!

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

- Highlights hazards that may result in damage to your vehicle.
- 1 Helpful hints or further information you may find useful.
- This symbol points to instructions for you to follow.
- A number of these symbols appearing in succession indicates a multiple-step procedure.
- This symbol tells you where to look page for further information on a topic.
- $\triangleright \triangleright$ This continuation symbol marks a warning or procedure which is continued on the next page.
- Display Text in displays, such as the control system, are printed in the type shown here.

Our company and staff congratulate you on the purchase of your new Mercedes-Benz.

Your selection of our product is a demonstration of your trust in our company name. Furthermore, it exemplifies your desire to own an automobile that will be as easy as possible to operate and will provide years of service.

Your Mercedes-Benz represents the efforts of many skilled engineers and craftsmen. To help assure your driving pleasure, and also the safety of you and your passengers, we ask you to make a small investment of time:

- Please read this manual carefully, then return it to your vehicle where it will be handy for your reference.
- Please follow the recommendations contained in this manual. They are designed to acquaint you with the operation of your Mercedes-Benz.
- Please pay attention to the warnings and cautions contained in this manual. They are designed to help improve the safety of the vehicle operator and occupants.

We extend our best wishes for many miles of safe, pleasurable driving.

Mercedes-Benz USA, LLC

A Daimler Company

dex 4	At a glance 25
Introduction 19	Safety and security35
	Controls in detail65
	Operation 175
	Practical hints 223
	Technical data 287

1, 2, 3	AIRMATIC DC (Dual Control)
, ,	ADS (Adaptive Damping System) 137
4-zone automatic climate control	Introduction 137
see Climate control system	Messages in the multifunction
A	display 240
A	Vehicle level control 138
ABS (Antilock Brake System) 58	Air pressure
Indicator lamp 252	see Tire inflation pressure
Messages in the multifunction	Air pressure (tires) 206
display 229, 239	Air pump (electric) 275
Accessory weight 205	Air recirculation mode 150
Accidents 100	Air volume 149
Air bags 37	Alarm system
Distance warning function 137	see Anti-theft systems
Emergency calls (Tele Aid) 165	Alignment bolt (vehicle tool
NECK-PRO active front head	kit) 224, 274
restraints 50	Alternator
Active Bi-Xenon headlamps	Messages in the multifunction
see Headlamps	display 245
Adaptive Brake 59	Alternator (Technical data)
Additives	see Vehicle specification
Engine oil 298	AMG menu 113
Gasoline	Anticorrosion/antifreeze 301
Address change 20	Antilock Brake System
Advanced Tire Pressure	see ABS
Monitoring System (Advanced	Anti-theft systems 62
TPMS)	Anti-theft alarm system 62
Messages in the multifunction	Immobilizer 62
display 236, 250	Aquaplaning
Air bags 37	see Hydroplaning
Emergency call upon deployment 165	Armrest, front
Front, driver and passenger 40	Storage compartment
Front passenger front air bag off	Armrest, rear
indicator lamp 41, 260	Storage compartment
Knee bag 40	Ashtrays
Messages in the multifunction	Aspect ratio (tires)
display 230	Audio/DVD menu
OCS (Occupant Classification	Auto-dimming rear view mirrors 84
System)	Automatic central locking 71, 123
Safety guidelines	Automatic headlamp mode 87
Side impact	Automatic interior lighting control 92
Window curtain	Automatic locking when driving 123
Air conditioning refrigerant and	Automatic shift program
lubricant	Automatic transmission
Air distribution	Automatic shift program
Air filter 246	Gear range indicator
	Gear ranges 104

Gear selector lever	102	Brakes	210
Kickdown	104	High-performance brake system	212
Kickdown (manual shift program)	108	Parking brake	100
Manual shift program	107	Warning lamp	252
One-touch gearshifting	105	Break-in period	176
Program mode indicator	105	Bulbs	
Program mode selector switch		see Replacing bulbs	
(automatic shift program)	105	·	
Program mode selector switch		С	
(manual shift program)	107		
Shifting procedure	102	CAC (Customer Assistance Center)	22
Steering wheel gearshift control	106	California retail buyers and	
Transmission position indicator	103	lessees, important notice for	
Transmission positions	103	Calls (phone)	125
AUX socket	158	Can holders	
Axle oils		see Cup holders	
		Capacities and recommended	
В		fuel/lubricants	
		Carpets, cleaning	221
Backrest		Center console	31
see Seats		Central locking	
Backup lamps		Automatic 71,	123
Messages in the multifunction		KEYLESS-GO	67
display		Locking/unlocking from inside	71
Bar (air pressure unit)	206	SmartKey	66
BAS (Brake Assist System)	. 59	Central locking/unlocking switch	71
Batteries, SmartKey		Certification label	288
Checking condition	. 69	Children in the vehicle	
Replacing	264	Air bags	. 37
Battery, Vehicle	278	Child safety locks (rear doors)	56
Charging	279	Child seat anchors - LATCH-type	
Jump starting	280	(ISOFIX)	55
Messages in the multifunction		Indicator lamp, front passenger	
display	245	front air bag off	41
Bead (tire)	206	Infant and child restraint systems	
Beverage holders		ISOFIX (Child seat anchors -	
see Cup holders		LATCH-type)	55
Brake Assist System		OCS (Occupant Classification	
see BAS		System)	41
Brake fluid		Override switch	
Checking level	182	Safety notes	
Messages in the multifunction		Tether anchorage points	
display	239	Top tether	
Brake lamps		Child safety	•
Cleaning lenses	219	see Children in the vehicle	
Brake pads	/	Child seat anchors – LATCH-type	
Messages in the multifunction		(ISOFIX)	
display	238	see Children in the vehicle	

Chrome-plated exhaust tip,		Coolant	
cleaning	221	Anticorrosion/antifreeze	301
Cigarette lighter	163	Capacities	297
Climate control system		Checking level	180
4-zone automatic climate control	143	Messages in the multifunction	
Air conditioning	146	display	243
Air conditioning refrigerant	298	Warning lamp	257
Air distribution	149	Corner-illuminating front fog	
Air recirculation mode	150	lamps	. 91
Air volume	149	Cruise control	127
Automatic mode	146	Activating	128
Deactivating system	145	Canceling	128
Front defroster	149	Changing the set speed	129
Maximum cooling MAX COOL	150	Last stored speed	129
Residual heat and ventilation	151	Lever	128
Temperature	147	Messages in the multifunction	
Clock	. 28	display	233
Cockpit	. 27	Resume function	129
Cold tire inflation pressure	206	Setting current speed	128
Collapsible tire (spare wheel)	296	Cup holders	160
Collapsible wheel chock	225	Curb weight	206
COMAND system		Customer Assistance Center (CAC)	. 22
see separate COMAND system		Customer Relations Department	. 22
operating instructions			
Combination switch	. 89	D	
Control system		Dashboard	
Multifunction display	111	see Instrument cluster	
Multifunction steering wheel	110	Data recording	22
Resetting to factory settings	118	Daytime running lamp mode	
Control system menus	112	Switching on or off	
AMG	113	Deep water	121
Audio/DVD	116	see Standing water	
Distronic	117	Defogging (windshield)	150
Navigation	117	Defroster	150
Settings	118	Front (Climate control system)	149
Standard display	112	Rear window	151
Telephone	125	Delayed shut-off	131
Trip computer	124	Exterior lamps	122
Vehicle status message memory	117	Interior lighting	
Control system submenus		Department of Transportation	123
Convenience	124	see DOT	
Instrument cluster	119	Difficulties	
Lighting	121	While driving	00
Vehicle			. 99
	123		
Convenience submenu		With starting	. 98
Convenience submenu Easy-entry/exit feature		With starting Digital speedometer	. 98
		With starting	. 98

Direction of rotation (tires)	Through standing water 213
Displays	With Distronic
Digital speedometer 113	Driving and parking
Distronic 131	Safety notes 96
Maintenance service indicator 214	Driving off 98, 212
Messages in the multifunction	Driving safety systems 57
display 228	ABS 58
Multifunction display 111	Adaptive Brake 59
Outside temperature 113, 120	BAS 59
Symbol messages	EBP 59
Text messages 229	ESP [®] 59
Trip computer 124	ETS 60
Vehicle status message memory 117	Driving systems
Vehicle system settings 118	AIRMATIC DC (Dual Control) 137
Distronic 129	Cruise control
Cleaning system sensor cover 219	Distronic
Control system 117	Parktronic system 139
Distance warning function 137	Driving tips, automatic
Distance warning lamp 131, 256	transmission 104
Driving with	107
Menu 132	E
Messages in the multifunction	E
display 233	Easy-entry/exit feature 83, 124
Resume function	EBP (Electronic Brake
Sensor cover	Proportioning) 59
Door control panel	Electrical system
Door handles	Improper work on or
Doors	modifications 21
Child safety locks 56	Power outlets 163
Locking/unlocking (KEYLESS-GO) 67	Electrical system (Technical data)
Locking/unlocking (NETLESS-GO) 67 Locking/unlocking (SmartKey) 66	see Vehicle specification
Messages in the multifunction	Electronic Stability Program
_	see ESP®
display	Emergency, in case of
Opening from inside	First aid kit 224
	Flat tire 271
Unlocking (Mechanical key)	Hazard warning flasher 90
DOT (Department of	Roadside Assistance
Transportation)	Towing the vehicle
Drinking and driving 210	Emergency calls
Driving	Tele Aid 165
Abroad	Emergency operations
Hydroplaning	Remote door unlock (Tele Aid) 168
Instructions 97, 210	Trunk lid, emergency release 74
In winter 209	
Problems	Emergency Tensioning Device
Safety systems 57	see ETD
Systems 127	

Emission control 213	F
Information label 289	Footoning the cost helps
System warranties 19	Fastening the seat belts
Engine	First aid kit
Break-in recommendations 176	Flat tire
Cleaning 217	Lowering the vehicle
Compartment 178	Mounting the spare wheel
Malfunction indicator	Preparing the vehicle 271
lamp 28, 257	Spare wheel
Messages in the multifunction	Floormats
display 243	Fluids
Number	Automatic transmission fluid 297
Starting 97	Brake fluid 297
Turning off 101	Capacities 296
Engine (Technical data)	Engine coolant 297
see Vehicle specification	Engine oil 297
Engine coolant	Power steering fluid 297
see Coolant	Washer and headlamp cleaning
Engine oil	system 297
Adding 180	Fog lamps 89
Additives	Messages in the multifunction
Checking level	display 247, 249
Consumption	Front air bags
Messages in the multifunction	see Air bags
display 246	Front lamps
Oil dipstick	see Headlamps
Recommended engine oils and oil	Front passenger front air bag 40
filter 298	Messages in the multifunction
ESP® (Electronic Stability	display 230
	Front passenger front air bag off
Program)	indicator lamp 41, 260
ETS	Fuel 176
Messages in the multifunction	Additives
display	Capacity, fuel tank 297
Warning lamp	Drive sensibly-safe fuel 210
ETD (Emergency Tensioning	Fuel consumption statistics 125
Device)	Fuel filler flap and cap 177
Safety guidelines	Fuel tank reserve warning
ETS (Electronic Traction System) 60	lamp 29, 256
Express operation	Premium unleaded gasoline 299
Power windows	Refueling 176
Tilt/sliding sunroof	Requirements
Exterior lamp switch 87	Fuel filler flap 177
Exterior rear view mirrors	Opening manually
Parking position	Fuels, coolants, lubricants etc 296
Exterior view of vehicle 26	

Fuel tank		Headlamps	
Capacity	297	Active Bi-Xenon headlamps	. 86
Fuel filler flap and cap	177	Automatic headlamp mode	. 87
Refueling		Bi-Xenon 86,	267
Fuses		Cleaning lenses	219
		Cleaning system	. 90
G		Daytime running lamp mode	
	1.00	Delayed shut-off	122
Garage door opener	169	Halogen	267
Gasoline		High-beam flasher	
see Fuel	00/	High-beam headlamps	. 90
GAWR (Gross Axle Weight Rating)		Low-beam headlamps	. 87
Gear range	104	Messages in the multifunction	
Indicator		display	247
Limiting		Replacing bulbs	
Shifting into optimal		Switch	
Gear selector lever		Headliner and shelf below rear	
Cleaning		window, cleaning and care of	221
Gearshift pattern		Head restraints	
Lock 97,	102	Adjustment 77	
Messages in the multifunction		Comfort head restraint	
display		Folding back	
Shifting procedure		NECK-PRO active front head	
Transmission position indicator		restraints	. 50
Transmission positions	103	Rear seat head restraints	. 80
Generator		Heated steering wheel	. 83
see Alternator		Height adjustment	
Global locking/unlocking		Seat belt outlet	. 48
see Key, SmartKey		Seats	
Glove box	158	Vehicle level control	
Gross Axle Weight Rating		High-beam flasher	. 90
see GAWR		High-beam headlamps 90,	
Gross Vehicle Weight		Indicator lamp	
see GVW		Replacing bulbs	
Gross Vehicle Weight Rating		High-performance brake system	
see GVWR		Hood	178
GVW (Gross Vehicle Weight)	206	Messages in the multifunction	
GVWR (Gross Vehicle Weight		display	241
Rating)	206	Horn	
		HVAC	
Н		see Climate control system	
Halogen headlamns		Hydroplaning	212
Halogen headlamps see Headlamps			- 12
Hard plastic trim items, cleaning	220		
Hazard warning flasher		•	
_		Identification labels	288
Headlamp cleaning system	. 70	Identification number, vehicle	
		(VIN)	289

Ignition 76, 97	Unlocking/locking manually 261
Immobilizer 62 Indicator lamps	Valet locking
see Lamps, indicator and warning	Battery check lamp 69
Infant and child restraint systems	Checking batteries 69
see Children in the vehicle	Factory setting 67, 69
Inflation pressure	Global locking (KEYLESS-
see Tires, Inflation pressure	GO) 69
Inside door handle 70	Global locking (SmartKey) 67
Instrument cluster	Global unlocking (KEYLESS-
Illumination 109	GO) 69
Lamps 251	Global unlocking
Multifunction display 111	(SmartKey) 67
Instrument lighting	Important notes on KEYLESS-GO 68
see Instrument cluster, Illumination	Locking/unlocking 66
Instrument panel	Loss of 70
see Instrument cluster	Messages in the multifunction
Instruments and controls	display 241
see Cockpit	Opening, trunk
Interior lighting	Opening and closing the power
Delayed shut-off 123	tilt/sliding sunroof
Front 91	Opening and closing the windows 96
Front reading lamps 92	Remote control 66
Rear 91, 92	Replacing 70
Rear reading lamps 92	Replacing batteries
Interior rear view mirror 84	Restoring to factory setting 67, 69
Auto-dimming rear view mirrors 84	Selective setting
Interior storage spaces	Starter switch positions
see Storage compartments	KEYLESS-GO
Intermittent wiping 93	Starter switch positions
Rain sensor 93	Kickdown
ISOFIX (Child seat anchors -	Kickdown (manual shift program) 108
LATCH-type)	Kilopascal (air pressure unit) 206
see Children in the vehicle	Knee bag 40
J	L
Jack	Labels
Jump starting 280	Certification 288
, and the start and	Emission control information 289
K	Tire and Loading Information
	placard 193
Key, Mechanical	Tire inflation pressure
Loss of 70	Lamps, exterior
Replacing 70	Exterior lamp switch 87
	Front 267

Messages in the multifunction	Locking the vehicle
display 247	KEYLESS-GO 67
Switching on/off 87	Manually 262
Lamps, indicator and warning	SmartKey 66
ABS 28, 252	Loss of
Brakes 252	Key 70
Coolant 257	Service and Warranty Information
Distance warning	booklet 288
lamp 131, 137, 256	Low-beam headlamps 87
Engine malfunction 28, 257	Exterior lamp switch 87
ESP [®] 28, 255	Indicator lamp 28
Fog lamps 89	Replacing bulbs 267
Front passenger front air bag	Switching on 87
off 31, 41, 260	Lubricants
Fuel tank reserve 29, 256	Luggage box
High-beam headlamps 28, 90	Lumbar support 79
Instrument cluster 251	
Low-beam headlamps 28, 87	M
Low tire pressure/TPMS	Maintenance 20
malfunction telltale 259	
Seat belt telltale 28, 48, 253	Maintenance System
SRS 36, 254	Service indicator display
Turn signals28	Service indicator message
Language, selecting 120	Manual headlamp mode (Low-
LATCH-type child seat anchors (ISOFIX)	
see Children in the vehicle	beam headlamps)
License plate lamps	Manual shift program 107
Messages in the multifunction	Maximum engine speed
display 248	see Vehicle specification Maximum loaded vehicle weight 206
Replacing bulbs 267	
Light alloy wheels, cleaning 220	Maximum load rating (tires)
Lighter	
see Cigarette lighter	inflation pressure
Lighting 86	Mechanical key
Daytime running lamp mode 88	see Key, Mechanical Media interface
Exterior 87	Memory function 85
Interior 91	-
Limp-home mode 108	Menus
Load index (tires) 202, 206	see Control system menus
Loading	Minispare wheel
see Vehicle loading	see Spare wheel
Locator lighting 121	Mirrors
Lock button	Auto-dimming rear view mirrors 84
Outside door handle (KEYLESS-	Exterior rear view mirror parking
GO) 69	position
	Exterior rear view mirrors
	ITTERIOR FEST VIEW MIRROR 9/1

Memory function	85	Reserve fuel	246
Vanity mirror	162	Reverse lamp	247
MOExtended system	277	Side marker lamps	248
MOExtended tires 27	77, 292	SmartKey	241
MON (Motor Octane Number)	299	SmartKey with KEYLESS-GO	241
Motor Octane Number		SRS	240
see MON		Tail lamps	249
Multicontour seat	80	Tele Aid	240
Multifunction display	111	Tire inflation pressure 235	, 250
Symbol messages		Tire pressure monitor	236
Text messages	229	Tires 235	, 250
Vehicle status messages		TPMS 236	, 250
Multifunction display messages		Trunk	241
ABS 22	29, 239	Turn signals	250
Active headlamps	247	Washer fluid	242
Advanced TPMS 23	36, 250	Multifunction steering wheel	
Air bags	230	Adjustment	82
Air filter		Buttons	110
AIRMATIC DC (Dual Control)	240	Cleaning	220
Alternator	245	Easy-entry/exit feature 83	, 124
Automatic transmission	235	Gearshift control	
Battery	245	Heating	83
Brake fluid	239	Memory function	
Brake pads	238	Overview	29
Check engine	243		
Coolant	243	N	
Corner-illuminating front fog		Navigation menu	117
lamps	249	Navigation system	1 17
Cruise control	233	see Separate operating instructions	
Distronic	233	NECK-PRO active front head	
Doors	241	restraints	50
EBP		Resetting	
Engine oil		Net, parcel	
Engine service		Night security illumination	
ESP [®] 22	29, 239	Normal occupant weight	
Fog lamps 24	,	Number, vehicle identification	207
Front passenger front air bag		(VIN)	289
Gas cap		(****)	207
Gear selector lever		0	
High-beam lamps	248		
Hood		Occupant Classification System	
License plate lamps		see OCS (Occupant Classification	
Light sensor		System)	
Low-beam lamps		Occupant distribution	207
Parking brake		Occupant safety	
Parking lamps		Air bags	
PRE-SAFE®	229	Children and air bags	37

Children in the vehicle 52	Minimum distance 141
Child seat anchors - LATCH-type	Sensor range 140
(ISOFIX) 55	Switching on/off 141
Fastening the seat belts 47	System sensors 140
Front passenger front air bag off	Warning indicators 27, 141
indicator lamp 41, 260	Parts service 288
Infant and child restraint systems 53	PASS AIR BAG OFF indicator lamp
Introduction 36	see Front passenger front air bag
ISOFIX (Child seat anchors -	off indicator lamp
LATCH-type) 55	Passenger safety
OCS (Occupant Classification	see Occupant safety
System) 41	Pedals 210
PRE-SAFE [®] 49	Phone
Seat belts 39, 45	see Telephone
OCS (Occupant Classification	Plastic parts, cleaning 220
System) 41	Power assistance 210
Self-test	Power outlets 163
Odometer 111	Power seats
Oil, oil level	see Seats
see Engine oil	Power tilt/sliding sunroof
On-board computer	Operation 152
see Control system	Synchronizing 154
One-touch gearshifting 105	Power washer 217
Operating safety 21	Power windows 94
Ornamental moldings, cleaning 218	Cleaning 219
Outside temperature	Operation 94
see Displays	Rear door window, override
Overhead control panel 33	switch 56
·	Synchronizing95
P	Practical hints 224
D -it	PRE-SAFE [®]
Paintwork, cleaning	Messages in the multifunction
Paintwork code	display 229
Panic alarm 57	Problems
Parcel net	While driving 99
Parking	With vehicle 22
Parktronic system	With wipers 94
Parking and standing lamp	Product information 19
Replacing bulbs	Production options weight 207
Parking brake	Program mode selector switch
Messages in the multifunction	Automatic shift program 105
display	Manual shift program 107
Parking position Exterior rear view mirrors 85	Proximity key
	see Key, SmartKey
Transmission position	PSI (air pressure unit) 207
Parktronic system	
Cleaning system sensors	
Malfunction 142	

R	Roadside Assistance 20, 16
RACETIMER 114	RON (Research Octane Number) 29
Radio	Roof rack
Selecting stations 116	Rubber parts, cleaning 22
Radio transmitters 213	Run-flat tires
Rain sensor	see MOExtended tires
see Intermittent wiping	
Rear axle oil	S
Rear door ashtray	Safety
see Ashtrays	Driving safety systems 5
Rear doors	Occupant safety 3
Child safety locks 56	Reporting defects 2
Rear door window	Safety belts
Override switch 56	see Seat belts
Rear fog lamp	Seat belt force limiter 4
see Fog lamps	Seat belts 4
Rear lamps	Automatic comfort-fit feature 4
see Tail lamps	Children in the vehicle 5
Rear seat head restraints	Cleaning 22
see Head restraints	Fastening 4
Rear window defroster 151	Height adjustment 4
Recommended tire inflation	Proper use of 4
pressure 183, 207	Safety guidelines 3
Refrigerant, air conditioning 298	Safety notes 4
Refueling	Telltale 28, 25
Regular checks 177	Seat heating 8
Reminder, Seat belt	Seating capacity 19
see Seat belts, Telltale	Seats 7
Remote control	Adjustment 7
see Key, SmartKey	Easy-entry/exit feature 8
Remote door unlock (Tele Aid) 168	Heating 8
Replacing	Memory function 8
Key 70	Multicontour seat 8
Replacing bulbs 266	Ventilation 8
Reporting safety defects 22	Securing cargo
Research Octane Number	Cargo tie-down hooks 15
see RON	Selective setting
Reserve fuel	see Key, SmartKey
Messages in the multifunction	Selector lever
display 246	see Gear selector lever
Reset button 29, 109	Self-test Self-test
Reset tool (NECK-PRO active front	OCS (Occupant Classification
head restraints) 264	System) 4
Restraint systems	Tele Aid 16
see Occupant safety	Service
Retaining hook 157	see Maintenance
Rims 207, 291	Service, parts

Service and warranty information 19	Steering column
Service intervals	see Multifunction steering wheel,
see Maintenance System, Service	Adjustment
indicator message	Steering wheel
Service life (tires)	see Multifunction steering wheel
Settings (4/5)/4/500 000	Steering wheel gearshift control 106
Factory setting (KEYLESS-GO) 69	Stolen Vehicle Recovery Services 169
Factory setting (SmartKey)	Storage compartments
Memory function 85	Storing tires
Menu 118	Sunroof
Selective setting (KEYLESS-GO) 69	see Power tilt/sliding sunroof
Selective setting (SmartKey)	Sunshade
Shelf below rear window, cleaning 221	Rear window 162
Side impact air bags 41	Sun visors 161, 162
Side marker lamps	Suspension tuning
Cleaning lenses	see AIRMATIC DC (Dual Control)
Messages in the multifunction	
display 248	Т
Sidewall (tires)	Tachometer
Ski bag 155	Overspeed range
SmartKey	Tail lamps
see Key, SmartKey	Cleaning lenses
SmartKey with KEYLESS-GO	Messages in the multifunction
see Key, SmartKey	display 249
Snow chains 208	Tar stains
Snow tires	Technical data
see Winter tires	Air conditioning refrigerant
Spare wheel	Brake fluid
Mounting 272	Capacities fuels, coolants,
Storage location 226	lubricants etc
Speedometer 28, 131	Coolant
Speed settings	Engine oil additives
Cruise control 128	Engine oils 298
Distronic	Fuel requirements 299
Resume function 129, 134	Gasoline additives
SRS	Identification labels
Indicator lamp	Premium unleaded gasoline 299
SRS (Supplemental Restraint System)	Rims and tires 291
Indicator lamp	Spare wheel 296
Messages in the multifunction	Vehicle specification CLS 550 290
display	Vehicle specification CLS 63 AMG . 290
Standing water, driving through 213	Washer and headlamp cleaning
Starter switch positions	system 297, 302
KEYLESS-GO	Technical data (dimensions)
SmartKey	see Vehicle specification
Starting difficulties (engine)	Technical data (electrical system)
Starting the engine 97	see Vehicle specification

Technical data (engine)		Tire ply composition and material	
see Vehicle specification		used	207
Technical data (weights)		Tire pressure loss warning system.	186
see Vehicle specification		Tire Pressure Monitoring System	
Tele Aid	164	(TPMS)	188
Emergency calls	165	Messages in the multifunction	
Information button	167	display 236,	
Initiating an emergency call		Tires 182,	291
manually	166	Advanced Tire Pressure	
Messages in the multifunction		Monitoring System (Advanced	
display	240	TPMS)	190
Remote door unlock	168	Air pressure	183
Roadside Assistance button	166	Care and maintenance	198
Search & Send	168	Cleaning	199
SOS button	166	Direction of rotation, spinning	197
Stolen Vehicle Recovery Services	169	Important notes on tire inflation	
System self-test		pressure	184
Telephone	. 29	Inflation pressure	185
Answering/ending a call	126	Information placard	193
Hands-free microphone	. 33	Inspection	198
Menu	125	Labeling	201
Operation	125	Load index 202,	206
Phone book	126	Load rating	206
Redialing	127	Messages in the multifunction	
Temperature		display 235,	250
Coolant	109	MOExtended	292
Interior temperature	147	Ply composition and material	
Outside 113,	120	used	207
Tether anchorage points		Problems under-/overinflation	185
see Children in the vehicle		Retreads	182
Tie-down hooks	157	Rims and tires (technical data)	291
Tightening torque		Rotation	200
Wheels	277	Service life	198
TIN (Tire Identification Number)	207	Sizes	291
Tire and Loading Information		Snow chains	208
placard	193	Speed rating 203,	207
Tire and loading terminology	205	Storing	199
Tire Identification Number		Temperature 184,	200
see TIN		Terminology	205
Tire inflation pressure		Tire Identification Number	
Checking	185	Tire pressure loss warning system.	186
Important notes on	184	Tire Pressure Monitoring System	
Label on the inside of fuel filler		(TPMS)	188
flap	185	TPMS low tire pressure/	
Placard on driver's door B-pillar	193	malfunction telltale	259
Tire labeling	201	Traction 199,	
Tire load rating	206	Tread	207
-		Tread depth 198,	208

Treadwear	199 U
Treadwear indicators 198, 2	208 Uniform Tiro Quality Grading
Vehicle maximum load on	Uniform Tire Quality Grading
Wear pattern	
Winter tires 208, 2	Colorting and adam star display
Tire speed rating 203, 2	mode 120
Top tether	Unleaded gasoline, premium
see Children in the vehicle	Unlooking the vehicle
	KEYLESS-GO 67
Towing	Manually 041
Towing eye bolt	SmartKov 66
Vehicle	201
Towing eye bolt	1/0
Traction	20/
Transmission	V
see Automatic transmission	
Transmission fluid level	
Transmission gear selector lever	Vehicle
see Gear selector lever	Battery
Transmission positions	
Traveling abroad	
Tread (tires)	, ,
Treadwear	6, 6
Treadwear indicators (tires) 198, 2	
Trip computer menu	,
Trip odometer, resetting	
Trunk	Unlocking/locking manually
Closing	
Fuse box	
Messages in the multifunction	Vehicle Identification Number
display	
Opening	· ·
Opening/closing system	
Tie-down hooks	157 Vehicle level control
Trunk lid emergency release	see AIRMATIC DC (Dual Control)
Unlocking manually	Vehicle lighting 86
Valet locking	75 Vehicle loading
Turning off the engine	
Turn signals	
Cleaning lenses	
Indicator lamps	0
Messages in the multifunction	Terminology 205
display	
Replacing bulbs	•
	CLS 550 290
	CLS 63 AMG 290

Vehicle status message memory Vehicle tool kit Vehicle washing see Vehicle care Vehicle weights see Vehicle specification		Winter driving Instructions	
W			
Warning lamps			
see Lamps, Indicator and warning			
Warning sounds			
Distance warning function	137		
Distronic			
Driver's or passenger's seat belt	. 48		
Parking brake			
Parktronic system			
Seat belt telltale			
Warranty coverage	288		
Washer and headlamp cleaning			
system	302		
Washer fluid			
Messages in the multifunction	0.40		
display			
Mixing ratio			
Refilling			
Washing the vehicle			
Wear pattern (tires) Weights (vehicle)	200		
see Vehicle specification Wheel			
Changing	271		
Removing			
Spare			
Tightening torque			
Wheels, sizes			
Wheels, Tires and			
Window curtain air bags			
Windows			
see Power windows			
Windows, cleaning	219		
Windshield			
Cleaning wiper blades	219		
Defogging			
Washer fluid			
Wipers			
Windshield wipers			
	270		

Winter driving Instructions 209 Snow chains 208 Tires 208 Winter tires 208, 291

Product Information

Please observe the following in your own best interest:

We recommend using Genuine Mercedes-Benz Parts as well as conversion parts and accessories explicitly approved by us for your vehicle model.

We have tested these parts to determine their reliability, safety and special suitability for Mercedes-Benz vehicles.

We are unable to make an assessment for other products and therefore cannot be held responsible for them, even if in individual cases an official approval or authorization by governmental or other agencies should exist. Use of such parts and accessories could adversely affect the safety, performance or reliability of your vehicle. Please do not use them.

Genuine Mercedes-Benz Parts and preapproved conversion parts and accessories are available at any authorized Mercedes-Benz Center. In addition, you will receive comprehensive information on permissible technical modifications and expert installations.

Operator's Manual

Notes

This Operator's Manual contains a great deal of useful information. We urge you to read it carefully and familiarize yourself with the vehicle before driving.

For your own safety and longer service life of the vehicle, we urge you to follow the instructions and warnings contained in this Operator's Manual. Ignoring them could result in damage to the vehicle or personal injury to you or others. Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

We continuously strive to improve our product and ask for your understanding that we reserve the right to make changes in design and equipment. Therefore, information, illustrations, and descriptions in this Operator's Manual might differ from your vehicle.

Vehicle equipment

Your vehicle may have some or all of the equipment described in this manual. Therefore, you may find explanations for optional equipment not installed in your vehicle. If you have any questions about operating particular equipment, any authorized Mercedes-Benz Center will be glad to demonstrate the proper procedures.

Optional equipment is also described in this manual, including operating instructions wherever necessary. Since they are special-order items, the descriptions and illustrations herein may vary slightly from the actual equipment of your vehicle.

If there are any equipment details that are not shown or described in this Operator's Manual, any authorized Mercedes-Benz Center will be glad to inform you of correct care and operating procedures. The Operator's Manual and Maintenance Booklet are important documents and should be kept with the vehicle.

Service and warranty information

The Service and Warranty Information booklet contains detailed information about the warranties covering your Mercedes-Benz, including:

- New Vehicle Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania,

Rhode Island, and Vermont Emission Control System Warranty

 State Warranty Enforcement Laws (Lemon Laws)

Important notice for California retail buyers and lessees of Mercedes-Benz automobiles

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if after a reasonable number of repair attempts Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty. During the period of 18 months from original delivery of the vehicle or the accumulation of 18 000 miles (approximately 29 000 km) on the odometer of the vehicle, whichever occurs first, a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- (1) the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair.
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified us in writing of the need for its repair, or
- (3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Written notification should not be sent to a dealer, it should be addressed to

Mercedes-Benz USA, LLC Customer Assistance Center One Mercedes Drive Montvale, NJ 07645-0350

Maintenance

The Maintenance Booklet describes all the necessary maintenance work which should be performed at regular intervals.

Always have the Maintenance Booklet with you when you take the vehicle to an authorized Mercedes-Benz Center for service. The service advisor will record each service in the booklet for you.

Roadside Assistance

The Mercedes-Benz Roadside Assistance Program provides factory-trained technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance number

1-800-FOR-MERCedes (1-800-367-6372) (in the USA) 1-800-387-0100 (in Canada)

will be answered by Mercedes-Benz Customer Assistance Representatives 24 hours a day, 365 days a year.

For additional information refer to the Mercedes-Benz Roadside Assistance Program brochure (in the USA) or the Roadside Assistance section of the Service and Warranty Information Booklet (in Canada) in your vehicle literature portfolio.

Change of address or ownership

If you change your address, be sure to send in the "Change of Address Notice" found in the Service and Warranty Information Booklet, or simply call the Mercedes-Benz Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes (1-800-367-6372), or Customer Service (in Canada) at 1-800-387-0100. This will assist us in

contacting you in a timely manner should the need arise.

If you sell your Mercedes, please leave all literature with the vehicle to make it available to the next operator.

If you bought this vehicle used, be sure to send in the "Notice of Purchase of Used Car" found in the Service and Warranty Information Booklet, or call the Mercedes-Benz Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100.

Operating your vehicle outside the **USA** or Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- Service facilities or replacement parts may not be readily available.
- Unleaded gasoline for vehicles with catalytic converters may not be available; the use of leaded fuels will damage the catalysts.
- Gasoline may have a considerably lower octane rating, and improper fuel can cause engine damage.

Certain Mercedes-Benz models are available for delivery in Europe under our European Delivery Program. For details, consult an authorized Mercedes-Benz Center or write to:

In the USA:

Mercedes-Benz USA, LLC **European Delivery Department** One Mercedes Drive Montvale, NJ 07645-0350

In Canada:

Mercedes-Benz Canada, Inc. **European Delivery Department** 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Operating safety

/ Warning!

Work improperly carried out on electronic components and associated software could cause them to cease functioning. Because the vehicle's electronic components are interconnected, any modifications made may produce an undesired effect on other systems. Electronic malfunctions could seriously impair the operating safety of your vehicle.

Contact an authorized Mercedes-Benz Center for repairs or modifications to electronic components.

Other improper work or modifications on the vehicle could also have a negative impact on the operating safety of the vehicle.

Some safety systems only function while the engine is running. You should therefore never turn off the engine while driving.



Marning!

Heavy blows against the vehicle underbody or tires/wheels may cause serious damage and impair the operating safety of your vehicle. Such blows can be caused, for example, by running over an obstacle, road debris or a pothole. If you feel a sudden significant vibration or ride disturbance, or you suspect that damage to your vehicle as occurred:

- turn on your hazard warning flashers
- slow down carefully
- · drive with caution to an area which is a safe distance from the road

Inspect the vehicle underbody and tires/ wheels for possible damage. If the vehicle appears unsafe, have it towed to the nearest authorized Mercedes-Benz Center or other qualified maintenance or repair facility for further inspection or repairs.

Proper use of the vehicle

Proper use of the vehicle requires that you are familiar with the following information and rules:

- the safety precautions in this manual
- the "Technical data" section in this manual
- · traffic rules and regulations
- motor vehicle laws and safety standards



/ Warning!

Various warning labels are attached to your vehicle. These warning labels are intended to make you and others aware of various risks. Do not remove any of these warning labels unless explicitly instructed to do so by information on the label itself. Removing warning labels may cause you and others to be unaware of certain risks which may result in an accident and/or personal injury.

Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to contact an authorized Mercedes-Benz Center immediately to have the problem diagnosed and corrected if required. If the matter is not handled to your satisfaction, please discuss the problem with the Mercedes-Benz Center management or, if necessary, contact us at one of the following addresses:

In the USA:

Customer Assistance Center Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350

In Canada:

Customer Relations Department Mercedes-Benz Canada, Inc. 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Reporting safety defects

For the USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to

www.safercar.gov; or write to:

Administrator, NHTSA Headquarters, 1200 New Jersey Avenue, SE, West Building, Washington, DC 20590.

You can also obtain other information about motor vehicle safety from

www.safercar.gov.

Vehicle data recording

Information regarding electronic recording devices

(Including notice pursuant to California Code § 9951)

Please note that your vehicle is equipped with devices that can record vehicle systems data and, if equipped with the Tele Aid system, may transmit some data in certain accidents.

This information helps, for example, to diagnose vehicle systems after a collision and to continuously improve vehicle safety. Daimler may access the information and share it with others


- for safety research or vehicle diagnosis purposes
- with the consent of the vehicle owner or lessee
- in response to an official request by law enforcement or other government agency
- for use in dispute resolution involving Daimler, its affiliates or sales/service organization and/or
- as otherwise required or permitted by law

Please check the Tele Aid subscription service agreement for details regarding the information that may be recorded or transmitted via that system.

Exterior view	26
Cockpit	27
Instrument cluster	28
Multifunction steering wheel	29
Center console	31
Door control panel	32
Overhead control panel	33



Exterior view




1 This Operator's Manual describes all features, standard or optional, potentially available for your vehicle at the time of purchase. Please be aware that your vehicle might not be equipped with all features described in this manual.

	Function	Page
1	Trunk: Locking and unlocking Opening and closing Valet locking	66 71, 72 75
2	Rear lamps	267
3	Rear window defroster	151
4	Fuel filler flap	176
5	Doors: Locking and unlocking	66, 261
6	Towing eyes	282
7	Tires and wheels	182

	Function	Page
	Rims and tires	291
8	Front lamps	266
9	Hood	178
10	Wipers	92
	Wiper blades, replacing	270
	Wiper blades, cleaning	219
11)	Windshield:	
	Wiping with washer fluid	92
	Cleaning	219
12	Power tilt/sliding sunroof	152
13	Exterior rear view mirrors	84

Cockpit




	Function	Page
1	Combination switch: Turn signals Wipers High beam	89 92 90
2	Cruise control lever: Cruise control Distronic	127 133
3	Steering wheel gearshift control	105
4	Multifunction steering wheel	29, 110
5	Instrument cluster	28, 108
6	Horn	
7	Lever for Voice Control System ¹	
8	Front Parktronic warning indicator	139

P68	10-3992-31
Function	Page
Climate control panel	143
Overhead control panel	33
Glove box	158
COMAND system ¹	
Center console	31
Starter switch	76
Steering wheel adjustment stalk Heated steering wheel	82 83
Parking brake pedal	100
Parking brake release	100
Exterior lamp switch	87
Door control panel	32
On-board diagnostics (OBD) socket	
Hood lock release lever	178
	Function Climate control panel Overhead control panel Glove box COMAND system¹ Center console Starter switch Steering wheel adjustment stalk Heated steering wheel Parking brake pedal Parking brake release Exterior lamp switch Door control panel On-board diagnostics (OBD) socket

¹ See separate operating instructions.

Instrument cluster




				Æ.,	

	Function	Page
1	♦ Left turn signal indicator lamp	
2	ESP® warning lamp	255
3	Speedometer	
4	Multifunction display	111
5		256
6	Right turn signal indicator lamp	
7	Coolant temperature indicator Coolant temperature warning lamp	109 257
8	Tachometer with: SRS Supplemental Restraint System (SRS) indicator lamp	254

	Function	Page
	Antilock Brake System (ABS) indicator	
	lamp	252
	🚁 Seat belt telltale	253
	High-beam headlamp indicator lamp Low-beam headlamp	89
	indicator lamp	87
9	Main odometer with: Transmission position	
	indicator	103
	Program mode	105
10	Clock with: BRAKE Brake warning lamp,	
	USA only	252
	Canada only check Engine malfunction	252
	indicator lamp, USA only	257

² Vehicles without Distronic: Warning lamp without function. It illuminates when the ignition is on. It should go out when the engine is running.

	Function	Page
	Engine malfunction indicator lamp, Canada only Combination low tire pressure/TPMS	257
	malfunction telltale, USA only	188, 259
	(!) Low tire pressure telltale, Canada only	190, 259
(11)	Fuel display with: Fuel tank reserve warning lamp	256
12	Reset button for: Resetting trip odometer Adjusting instrument	110
	cluster illumination	109



	Function	Page
1	Multifunction display	111
2	Press button :	
	to answer a call	125
	to dial ³	125
	to redial ³	125
	Press button :	
	to end a call	125
	to reject an incoming call	125
	Press button + or -:	
	to select submenus in the	
	Settings menu	119
	to set values	
	to operate the RACETIMER ⁴	114
	to set the volume	
3	Press button or to select next/previous menu	110


³ Function only available in telephone menu.

⁴ AMG vehicles only.

Function	Page
Press button or or briefly:	
to move within a menu	
to select previous or next track, scene or stored	
station within Audio/DVD menu	116
to switch to the phone book and select a name or	
number within Telephone menu	125
Press and hold button or 🔯:	
to select previous or next track with quick search or to select previous or next station in station list or	
wave band within Audio/ DVD menu	116
to start the quick search in the phone book within	
Telephone menu	125

Center console


Upper part



	Function	Page
1	Seat heating, driver's side	81
2	Rear window sunshade switch	162
3	Rear seat head restraints switch, folding down	80
4	Hazard warning flasher switch	90
5	Front passenger front air bag off indicator lamp	41
6	Central unlocking switch	71
7	Alarm system indicator lamp	62

	Function	Page
8	Electronic Stability Program (ESP®) control switch	59
9	Seat heating, front passenger side	81
10	Seat ventilation, front passenger side	81
11)	Central locking switch	71
12	Seat ventilation, driver's side	81

Lower part



	Function	Page
1	Ashtray	162
2	KEYLESS-GO start/stop button	76
3	Gear selector lever	102
4	Parktronic system deactivation switch	139
5	Adaptive Damping System (ADS) switch	137
6	Vehicle level control switch	138
7	Thumbwheel for setting distance for Distronic	135
8	Distance warning function on/off switch	135
9	Program mode selector switch	105

Door control panel



	Function	Page
1	Inside door handle	70
2	Seat adjustment	78
3	Memory function (for storing seat, exterior mirror and steering wheel settings)	85
4	Exterior rear view mirror adjustment	84
5	Switches for opening/ closing front and rear side windows	94
6	Trunk opening switch, trunk opening/closing system	71

Overhead control panel 13 12 10 23 33 30 Pe2.00-2659-31

	Function	Page
1	Rear interior lighting on/off	91
2	Automatic interior lighting	91
3	Front interior lighting on/ off	91
4	Power tilt/sliding sunroof switch	152
5	SOS button (Tele Aid system)	166
6	Right front reading lamp on/off	91
7	Interior rear view mirror	84
8	Front reading lamps	91
9	Garage door opener	169
10	Hands-free microphone for Tele Aid (emergency call system), telephone, and Voice Control System, see separate operating instructions	

	Function	Page
11)	Interior lighting	91
(12)	Left front reading lamp on/	91
(13)	Ambient lighting	122

Vehicle equipment	36
Occupant safety	36
Panic alarm	57
Driving safety systems	57
Anti-theft systems	62



Vehicle equipment

1 This Operator's Manual describes all features, standard or optional, potentially available for your vehicle at the time of purchase. Please be aware that your vehicle might not be equipped with all features described in this manual.

Occupant safety

Introduction

In this section you will learn the most important facts about the restraint system components of the vehicle.

The restraint systems are:

- · Seat belts
- · Child restraints
- Lower Anchors and Tethers for CHildren (LATCH) also known as ISOFIX

Additional protection potential is provided by:

- Supplemental Restraint System (SRS) with
 - Air bags
 - Air bag control unit (with crash sensors)
 - Emergency <u>Tensioning Device</u> (ETD) for seat belts
 - Seat belt force limiter
- NECK-PRO active front head restraints
- Preventive occupant <u>safe</u>ty (PRE-SAFE®)
- Air bag system components with
 - Front passenger front air bag off indicator lamp
 - Front passenger seat with Occupant Classification System (OCS)

Although the systems are independent, their protective functions work in conjunction with each other.

Marning!

Modifications to or work improperly conducted on restraint system components or their wiring, as well as tampering with interconnected electronic systems, can lead to the restraint systems no longer functioning as intended.

Air bags or Emergency Tensioning Devices (ETDs), for example, could deploy inadvertently or fail to deploy in accidents although the deceleration threshold for air bag deployment is exceeded. Therefore, never modify the restraint systems. Do not tamper with electronic components or their software.

- See "Children in the vehicle"(▷ page 52) for information on
 - infants and children traveling with you in the vehicle
 - restraint systems for infants and children

SRS indicator lamp

The SRS system conducts a self-test when the ignition is switched on and in regular intervals while the engine is running. This facilitates detection of system malfunctions.

The SRS indicator lamp SRS in the instrument cluster comes on when the ignition is switched on. It goes out no later than a few seconds after the engine has been started

The SRS components are in operational readiness when the SRS indicator lamp ses is not lit while the engine is running.

↑ Warning!

The SRS self-check has detected a malfunction when the SRS indicator lamp SRS

- · does not come on at all
- fails to go out after approximately 4 seconds after the engine was started
- comes on after the engine was started or while driving

For your safety, we strongly recommend that you contact an authorized Mercedes-Benz Center immediately to have the system checked. Otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury. The SRS might also deploy unexpectedly and unnecessarily which could also result in injury as well.

In addition, improper work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.

If it is necessary to modify an air bag system to accommodate a person with disabilities. contact an authorized Mercedes-Benz Center. USA only: Call our Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) for details.

Air bags



Warning!

Air bags are designed to reduce the potential of injury and fatality in certain

- frontal impacts (front air bags and driver's side knee bag)
- side impacts (side impact air bags and window curtain air bags)
- rollovers (window curtain air bags)

However, no system available today can completely eliminate injuries and fatalities.

Deployment of the air bags temporarily releases a small amount of dust from the air bags. This dust, however, is neither harmful to your health, nor does it indicate a fire in the vehicle. The dust might cause some temporary breathing difficulty for people with asthma or other breathing trouble. To avoid this, you may wish to get out of the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the air bag inflates, then get fresh air by opening a window or door.



Marning!

To reduce the risk of injury when the front air bags inflate, it is very important for the driver and front passenger to always be in a properly seated position and to wear their respective seat belt.

For maximum protection in the event of a collision always be in normal seated position with your back against the seat backrest. Fasten your seat belt and make sure it is properly positioned on your body.

Since the air bag inflates with considerable speed and force, a proper seating position and correct positioning of the hands on the steering wheel will help to keep you at a safe distance from the air bag. Occupants who are not wearing their seat belt, are not seated properly or are too close to the air bag can be seriously injured or killed by an air bag as it inflates with great force instantaneously:

- Sit with the seat belt properly fastened in a position that is as upright as possible with your back against the seat backrest.
- · Move the driver's seat as far back as possible, still permitting proper operation of vehicle controls. The distance from the center of the driver's chest to the center of the air bag cover on the steering wheel must be at least 10 inches (25 cm) or more. You should be able to accomplish this by

adjusting the seat and steering wheel. If you have any difficulties, please contact an authorized Mercedes-Benz Center.

- Do not lean your head or chest close to the steering wheel or dashboard.
- Keep hands on the outside of the steering wheel rim. Placing hands and arms inside the rim can increase the risk and potential severity of hand/arm injury when the driver front air bag inflates.
- Adjust the front passenger seat as far as possible rearward from the dashboard when the seat is occupied.
- · Occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side impact air bag inflates. This could result in serious injuries or death should the side impact air bag be deployed. Always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

Failure to follow these instructions can result in severe injuries to you or other occupants. If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

↑ Warning!

Accident research shows that the safest place for children in an automobile is in a rear seat. There is a possibility for a side impact air bagrelated injury if occupants, especially children, are not properly seated or restrained when next to a side impact air bag which needs to deploy rapidly in a side impact in order to do its job.

To help avoid the possibility of injury, please follow these guidelines:

Occupants, especially children, (1)should never place their bodies or

- lean their heads in the area of the door where the side impact air bag inflates. This could result in serious injuries or death should the side impact air bag be deployed.
- (2) Always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child. and for children 12 years old and under, use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.
- (3)Always wear seat belts properly.

If you believe that, even with the use of these guidelines, it would be safer for your rear seat occupants to have the rear mounted side impact air bags deactivated, then deactivation can be carried out upon your written request at an authorized Mercedes-Benz Center at an additional cost.

Please contact an authorized Mercedes-Benz Center or call the Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes (1-800-367-6372), or Customer Service (in Canada) at 1-800-387-0100 for details.

Air bags are designed to deploy only in certain

- frontal impacts (front air bags and driver's side knee bag)
- side impacts (side impact and window curtain air bags) if the system determines the need for air bag deployment
- rollovers (window curtain air bags)

Only in the event of such a situation will they provide their supplemental protection.

The driver and passengers should always wear their seat belts. Otherwise it is not possible for the air bags to provide their supplemental protection.

In case of other types of impacts and impacts below air bag deployment thresholds, air bags will not deploy. The driver and passengers will then be protected to the extent possible by a properly fastened seat belt. A properly fastened seat belt is also needed to provide the best possible protection in a rollover.

Air bags are not a substitute for seat belts. Always wear your seat belt, regardless of whether or not your vehicle is equipped with air bags.

It is important to your safety and that of your passengers to have deployed air bags replaced and to have any malfunctioning air bags repaired. This will help to make sure the air bags will continue to provide supplemental crash protection for occupants.

Safety guidelines for the seat belt, **Emergency Tensioning Device (ETD)** and air bag



Marning!

- · Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced. Their anchoring points must also be checked. Only use seat belts installed or supplied by an authorized Mercedes-Benz Center.
- Air bags and pyrotechnic Emergency Tensioning Devices (ETDs) contain perchlorate material, which may require special handling and regard for the environment. Check with your local government's disposal guidelines. California residents, see

www.dtsc.ca.gov/HazardousWaste/ Perchlorate/index.cfm.

- Air bags and ETDs are designed to function on a one-time-only basis. An air bag or ETD that has deployed must be replaced.
- Do not pass seat belts over sharp edges. They could tear.

- Do not make any modification that could change the effectiveness of the seat belts.
- Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.
- No modifications of any kind may be made to any components or wiring of the SRS.
- Do no change or remove any component or part of the SRS.
- · Do not install additional trim material, seat covers, badges, etc. over the steering wheel hub, front passenger front air bag cover, outboard sides of the seat backrests, door trim panels, or door frame
- Do not install additional electrical/ electronic equipment on or near SRS components and wiring.
- Keep area between air bags and occupants free of objects (e.g. packages, purses, umbrellas, etc.).
- Do not hang items such as coat hangers from the coat hooks or handles over the door. These items may be thrown around in the vehicle and cause head and other injuries when the window curtain air bag is deployed.
- · Air bag system components will be hot after an air bag has inflated. Do not touch them.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the
- Improper repair work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.
- For your protection and the protection of others, when scrapping the air bag unit or ETD, our safety instructions must be


followed. These instructions are available from any authorized Mercedes-Benz Center.

 Given the considerable deployment speed, required inflation volume, and the material of the air bags, there is the possibility of abrasions or other, potentially more serious injuries resulting from air bag deployment.

If you sell your vehicle, we strongly recommend that you inform the subsequent owner that the vehicle is equipped with SRS. Also refer them to the applicable section in the Operator's Manual.

Front air bags

♠ Observe Safety notes, see page 37.



Driver's front air bag ① and front passenger front air bag ② are designed to provide increased protection for the driver and front passenger against the risk of injuries to the head and thorax.

Driver and front passenger front air bag and driver's side knee bag are deployed

- in the event of certain frontal impacts
- if the system determines that air bag deployment can offer additional protection to that provided by the seat belt
- depending on whether the respective seat belt is in use
- independently of the side impact air bags and/or the window curtain air bags

The front air bags in this vehicle have been designed to inflate in two stages. This allows the air bags to have different rates of inflation. The rate of inflation is based on the vehicle deceleration rate as assessed by the air bag control unit.

The front passenger front air bag deployment is additionally influenced by the passenger's weight category as identified by the Occupant Classification System (OCS) (▷ page 41).

The lighter the front passenger-side occupant, the higher the vehicle deceleration rate required for second stage inflation of the front passenger front air bag.

The air bags will not deploy in impacts which do not exceed the system's preset deployment thresholds. You will then be protected by the fastened seat belts.

The front air bags will not deploy in the event of a rollover unless the vehicle's rate of longitudinal deceleration or acceleration exceeds the preset deployment threshold for the front air bags.

The front passenger front air bag will only be deployed if

- the system, based on OCS weight sensor readings, detects that the front passenger seat is occupied
- the PASS AIR BAG OFF

 → indicator lamp in the center console is not lit (> page 41)
- the impact exceeds a preset deployment threshold

Knee bag

Knee bag ③ is designed to provide increased protection for the driver against the risk of injuries to the knees, thighs and lower legs.

Knee bag ③ is located on the driver side lower instrument panel. It is designed to operate together with the driver front air bag in certain frontal impacts if the system determines that air bag deployment can offer additional protection to that provided by the seat belt. Knee bag ③ operates best in

conjunction with a properly positioned and fastened seat belt.

Side impact air bags



Front side impact air bags ① and rear side impact air bags ② are designed to provide increased protection for the thorax but not the head, neck and arms.

The side impact air bags are deployed

- on the impacted side of the vehicle
- in instances with a high rate of lateral vehicle deceleration or acceleration
- regardless of whether the seat belts on the impacted side of the vehicle are in use
- independently of the front air bags
- independently of the ETDs

The side impact air bags are not deployed in side impacts which do not exceed the system's deployment threshold.

The side impact air bags will not deploy in the event of a rollover unless the vehicle's rate of lateral deceleration or acceleration exceeds the preset deployment threshold for the side impact air bags.

↑ Warning!

Only use seat covers which have been tested and approved by Mercedes-Benz for your vehicle model. Using other seat covers may interfere with or prevent the deployment of the front side impact air bags. Contact an authorized Mercedes-Benz Center for availability.

Window curtain air bags



Window curtain air bags ① are designed to provide increased protection for the head but not the chest or arms.

Window curtain air bags (1) are deployed

- on the impacted side of the vehicle
- in instances with a high rate of lateral vehicle deceleration or acceleration
- independently of the front air bags
- regardless of whether the front passenger seat is occupied
- in certain vehicle rollovers, if the system determines that air bag deployment can offer additional protection to that provided by the seat belt

Window curtain air bags ① are not deployed in impacts which do not exceed the system's deployment threshold.

Window curtain air bags ① deploy in the area indicated by the arrows.

Occupant Classification System

The Occupant Classification System (OCS) activates or deactivates the front passenger front air bag automatically. The respective status is based on the classified occupant

weight category determined by weight sensor readings from the front passenger seat.

The system does not deactivate

- the front passenger side impact air bag
- the window curtain air bag
- the Emergency Tensioning Devices (ETDs)

To be classified correctly, the front passenger must sit

- with the seat belt properly fastened
- in a position that is as upright as possible with the back against the seat backrest
- · with the feet on the floor

If the occupant's weight is transferred to another object in the vehicle (e.g. by leaning on armrests), the OCS may not be able to properly approximate the occupant's weight category.

Furthermore, the occupant weight may appear to increase or decrease due to the following:

- objects hanging on the seat
- objects lodged underneath the seat
- objects stuffed between the seat and middle console
- objects stuffed between the seat and door
- other passengers pushing on the seat
- objects applying pressure to the back of the seat

Always make sure the seat has clearance in all directions at all times.

If your seat, including the trim cover and cushion, needs to be serviced in any way, take the vehicle to an authorized Mercedes-Benz Center.

Only seat accessories approved by Mercedes-Benz may be used.

Both the driver and the front passenger should always use the PASS AIR BAG OFF [] indicator lamp as an indication of whether or not the front passenger is properly positioned.

Marning!

If the PASS AIR BAG OFF 1 indicator lamp illuminates when an adult or someone larger than a small individual is in the front passenger seat, have the front passenger reposition himself or herself in the seat until the PASS AIR BAG OFF 2 indicator lamp goes out, or check whether objects are caught under or around the seat.

In the event of a collision, the air bag control unit will not allow front passenger front air bag deployment when the OCS has classified the front passenger seat occupant as weighting as much as or less than a typical 12-monthold child in a standard child restraint or if the front passenger seat is classified as being empty.

When the OCS senses that the front passenger seat occupant is classified as being up to or less than the weight of a typical 12-month-old child in a standard child restraint, the PASS AIR BAG OFF 2 indicator lamp will illuminate when the engine is started and remain illuminated, indicating that the front passenger front air bag is deactivated.

When the OCS senses that the front passenger seat occupant is classified as being heavier than the weight of a typical 12-month-old child seated in a standard child restraint or as being a small individual (such as a young teenager or a small adult), the PASS AIR BAG OFF 1 1 indicator lamp will illuminate for approximately 6 seconds when the engine is started and then, depending on occupant weight sensor readings from the seat, remain illuminated or go out. With the PASS AIR BAG OFF 1 2 indicator lamp illuminated, the front passenger front air bag is

deactivated. With the PASS AIR BAG OFF

indicator lamp out, the front passenger front air bag is activated.

When the OCS senses that the front passenger seat occupant is classified as an adult or someone larger than a small individual, the PASS AIR BAG OFF 2 indicator lamp will illuminate for approximately 6 seconds when the engine is started and then go out, indicating that the front passenger front air bag is activated.

If the PASS AIR BAG OFF 2 indicator lamp is illuminated, the front passenger front air bag is deactivated and will not be deployed.

If the PASS AIR BAG OFF 2 indicator lamp is not illuminated, the front passenger front air bag is activated and will be deployed

- in the event of certain frontal impacts
- if impact exceeds a preset deployment threshold
- independently of the side impact air bags

If the front passenger front air bag is deployed, the rate of inflation will be influenced by

- the rate of relevant vehicle deceleration as assessed by the air bag control unit
- the front passenger's weight category as identified by the OCS

For more information on air bag display messages in the multifunction display, see (> page 230).

Marning!

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating position. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriate infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

The infant or child restraint must be properly secured with the vehicle's seat belt, the seat belt and top tether strap, or lower anchors and top tether strap, fully in accordance with the child seat manufacturer's instructions.

Occupants, especially children, should always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

Children can be killed or seriously injured by an inflating air bag. Note the following important information when circumstances require you to place a child in the front passenger seat:

- Your vehicle is equipped with air bag technology designed to deactivate the front passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front passenger seat.
- A child in a rear-facing child restraint on the front passenger seat will be seriously injured or even killed if the front passenger front air bag inflates in a collision which could occur under some circumstances, even with the air bag technology installed in your vehicle. The only means to completely eliminate this risk is to never place a child in a rear-facing child restraint in the front seat. We therefore strongly recommend that you always place a child in a rear-facing child restraint in a backseat.

pass AIR BAG OFF 2 indicator lamp while driving to make sure the pass AIR BAG OFF 2 indicator lamp is illuminated. If the pass AIR BAG OFF 2 indicator lamp goes out or remains out, do not transport a child on the front passenger seat until the system has been repaired.

A child in a rear-facing child restraint on the front passenger seat will be seriously injured or even killed if the front passenger front air bag inflates.


• If you have to place a child in a forward-facing child restraint on the front passenger seat, move the seat as far back as possible, use the proper child restraint recommended for the age, size and weight of the child, and secure child restraint with the vehicle's seat belt according to the child seat manufacturer's instructions. For children larger than the typical 12-monthold child, the front passenger front air bag may or may not be activated.

Deployment of the driver front air bag does not mean that the front passenger front air bag also should have deployed.

The OCS may have determined

- that the seat was empty or occupied by the weight up to or less than that of a typical 12-month-old child seated in a standard child restraint – both of which are instances where the system suppresses deployment of the front passenger front air bag even though the impact met the criteria and was of sufficient severity to deploy the driver front air bag
- that the seat was occupied by a small individual (such as a young teenager or a small adult) or a child who weighs more than the weight of a typical 12-month-old child in a standard child restraint – both of which are instances where the system may suppress deployment of the front passenger front air bag even though the impact met the criteria and was of

sufficient severity to deploy the driver front air bag



PASS AIR BAG OFF [] indicator lamp ① will be illuminated, except with the SmartKey removed from the starter switch or with the starter switch in position **0**.

Marning!

If the red SRS indicator lamp sRS in the instrument cluster and the ASS AIR BAG OFF ME indicator lamp are lit at the same time, there is a malfunction in the OCS. The front passenger front air bag will be deactivated in this case. Have the system checked by qualified technicians as soon as possible. Contact an authorized Mercedes-Benz Center.

Only have the seat repaired or replaced at an authorized Mercedes-Benz Center.

In order to ensure proper operation of the air bag system and OCS:

- Do not place more than 4.4 lb (2 kg) into the storage bag on the back of the front passenger seat. Otherwise, the OCS may not be able to properly approximate the occupant weight category.
- Do not place objects under and/or around the front passenger seat.
- Do not hang anything from or attach any items to the seats.
- Do not stuff objects such as books between the front passenger seat and the center console or front passenger door.

- Do not move the front passenger seat backwards against stiff objects.
- Sit with the seat belt properly fastened in a position that is as upright as possible with your back against the seat backrest.
- · While seated, an occupant should not position him/herself in such a way as to cause the occupant's weight to be lifted from the seat bottom as this may result in the OCS being unable to correctly approximate the occupant's weight category.
- Read and observe all warnings in this chapter.

OCS Self-test

After turning the SmartKey in the starter switch to position 1 or 2 or pressing the KEYLESS-GO start/stop button once or twice, the PASS AIR BAG OFF | 2 indicator lamp illuminates. If an adult occupant is properly sitting on the front passenger seat and the system classifies the occupant as an adult, the PASS AIR BAG OFF 1 indicator lamp will illuminate and go out after approximately 6 seconds.

If the seat is not occupied and the system classifies the front passenger seat as being empty, the PASS AIR BAG OFF 1 indicator lamp will illuminate and not go out.

↑ Warning!

If the PASS AIR BAG OFF | 💥 indicator lamp does not illuminate, the system is not functioning. You must contact an authorized Mercedes-Benz Center before seating any child on the front passenger seat.

For more information, see the "Practical hints" section (⊳ page 260).



↑ Warning!

Never place anything between seat cushion and child seat (e.g. pillow), since it reduces the effectiveness of the OCS. The bottom and back of the child seat must make full contact with the passenger seat cushion and backrest.

If necessary, adjust the tilt of the passenger seat backrest.

An incorrectly mounted child seat could cause injuries to the child in case of an accident, instead of increasing protection for the child. Follow the manufacturer's instructions for installation of child seats.

Seat belts

Safety notes

The use of seat belts and infant and child restraint systems is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Even where this is not the case, all vehicle occupants should have their seat belts fastened whenever the vehicle is in motion.



See "Children in the vehicle"

- (⊳ page 52) for information on
- infants and children traveling with you in the vehicle
- restraint systems for infants and children



Always fasten your seat belt before driving off. Always make sure all of your passengers are properly restrained. You and your passengers should always wear seat belts.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are properly wearing your seat belt. The air bags can only protect as intended if the occupants are properly wearing their seat belts.



/ Warning!

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a position that is as upright as possible and the seat belt is properly positioned on the body.



Marning!

Never let more people ride in the vehicle than there are seat belts available. Make sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.



↑ Warning!

Damaged seat belts or seat belts that have been subjected to stress in an accident must be replaced. Also, the seat belt anchoring points must be checked.

Only use seat belts which have been approved by Mercedes-Benz.

Do not make any modifications to the seat belts. This can lead to unintended activation of the ETDs or to their failure to activate when necessary.

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Have all work carried out only by qualified technicians. Contact an authorized Mercedes-Benz Center.

Proper use of seat belts



↑ Warning!

USE SEAT BELTS PROPERLY

- · Seat belts can only protect when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in case of an accident.
- Each occupant should wear their seat belt at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver front air bag, driver side knee bag, front passenger front air bag, side impact air bags, window curtain air bags for door windows), Emergency Tensioning Devices (ETDs), seat belt force limiters, and front seat knee bolsters.

The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front air bags, driver's side knee bag, and ETDs) and side (side impact air bags, window curtain air bags, and ETDs) impacts which exceed preset deployment thresholds and in certain rollovers (window curtain air bags and ETDs).

• Never wear the shoulder belt under your arm, against your neck or off your shoulder. In a frontal crash, your body would move too far forward. That would increase the chance of head and neck injuries. The seat belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.

Adjust the seat belt so that the shoulder section is located as close as possible to the middle of the shoulder. It should not touch the neck. Never pass the shoulder portion of the seat belt under your arm. For this purpose, you can adjust the height of the seat belt outlet.

- Position the lap belt as low as possible on your hips and not across the abdomen. If the lap belt is positioned across your abdomen, it could cause serious injuries in a crash.
- Never wear seat belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys etc., as these might cause injuries.
- Make sure the seat belt is always fitted snugly. Take special care of this when wearing loose clothing.
- Never use a seat belt for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects at the same time.
- Seat belts should not be worn twisted. In a crash, you would not have the full width of the seat belt to distribute impact forces.
 The twisted seat belt against your body could cause injuries.
- Pregnant women should also always use a lap/shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Place the seat backrest in a position that is as upright as possible.
- Check your seat belt during travel to make sure it is properly positioned.
- Never place your feet on the instrument panel, dashboard, or on the seat. Always keep both feet on the floor in front of the seat.
- When using a seat belt to secure infant restraints, toddler restraints, or children in booster seats, always follow the child seat manufacturer's instructions.

Marning!

Do not pass seat belts over sharp edges. They could tear.

Do not allow the seat belt to get caught in the door or in the seat adjustment mechanism. This could damage the seat belt.

Never attempt to make modifications to seat belts. This could impair the effectiveness of the seat belts.

Fastening the seat belts

↑ Warning!

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating position. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child. For additional information, see "Children in the vehicle". A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child




- ▶ With a smooth motion, pull the seat belt out of seat belt outlet ①.
- ► Place the shoulder portion of the seat belt across the top of your shoulder and the lap portion across your hips.
- ▶ Push latch plate ② into buckle ③ until it clicks.
- ▶ If necessary, adjust the seat belt to the correct height (▷ page 48).
- ► If necessary, tighten the lap portion to a snug fit by pulling shoulder portion up.

All lap/shoulder belts except the driver's seat belt have special seat belt retractors to secure child restraints properly. For more information on special seat belt retractors, see "Infant and child restraint systems" (> page 53).

To release the seat belt with seat belt release button (4), see (> page 48).

Seat belt outlet height adjustment



- ➤ Raising: Slide the seat belt outlet height adjuster upward.
 - The seat belt outlet height adjuster engages in different positions.
- ► **Lowering:** Press and hold release button (1).
- ► Slide the seat belt outlet height adjuster downward.
- ► Release release button ① and make sure the seat belt outlet height adjuster engages into place.

Releasing the seat belts

- Press seat belt release button ④ (▷ page 47). Allow the retractor to completely rewind the seat belt by guiding latch plate ② (▷ page 47).
- Make sure the seat belt retracts completely. Otherwise the seat belt and/or latch plate could get caught or pinched in the door or in the seat mechanism. This can damage the seat belt and impair its effectiveness, and/or cause damage to the door and/or door trim panel. Such damage is not covered by the Mercedes-Benz Limited Warranty.

Damaged seat belts must be replaced. Contact an authorized Mercedes-Benz Center.

Enhanced seat belt reminder system

When the engine is started, the seat belt telltale 🚁 will always illuminate for 6 seconds to remind you and your passengers to fasten your seat belts.

If the driver's seat belt is not fastened when the engine is started, an additional warning chime will sound. The warning chime goes out after approximately 6 seconds or once the driver's seat belt is fastened.

If after these 6 seconds the driver's or the front passenger's seat belt (with the front passenger seat occupied) is not fastened with front doors closed,

- the seat belt telltale _____ remains illuminated for as long as either the driver's or front passenger's seat belt is not fastened.
- and if the vehicle speed once exceeds
 15 mph (25 km/h), the seat belt telltale
 starts flashing and a warning chime sounds with increasing intensity for a maximum of 60 seconds or until the driver's and front passenger's seat belt are fastened.

If you and/or your passenger release the seat belt during driving, the seat belt telltale *\frac{1}{4}* starts flashing and the warning chime sounds as described before. If the driver's or the front passenger's seat belt remains unfastened after 60 seconds, the warning chime stops sounding, the seat belt telltale *\frac{1}{4}* stops flashing but

After a vehicle standstill, the warning chime is reactivated and the seat belt telltale

is flashing again if the vehicle speed once exceeds 15 mph (25 km/h).

continues to be illuminated.

The seat belt telltale will only go out if both the driver's and the front passenger's seat belt (with the front passenger seat occupied) are fastened, or the vehicle is standing still and a front door is opened. For more information, see "Practical hints" (> page 253).

Emergency Tensioning Device (ETD), seat belt force limiter

The seat belts for the front seats and rear outer seats are equipped with ETDs and seat belt force limiters.

The ETDs are designed to activate in the following cases:

- in frontal or rear-end impacts exceeding the system's preset deployment threshold
- in side impacts exceeding the system's preset deployment threshold on the far side of the impact
- in certain vehicle rollovers
- if the restraint systems are operational and functioning correctly, see "SRS indicator lamp" (> page 36)

The ETDs for the front seats will only activate if the front seat belts are fastened (latch plate properly inserted into buckle).

The ETDs for the rear outer seats will activate with or without the respective seat belts fastened.

In an impact, the ETDs remove slack from the seat belts in such a way that the seat belts fit more snugly against the body. Seat belt force limiters, when activated, are employed to help reduce the peak force exerted by the seat belts on occupants during a crash.

The ETDs do not correct an incorrect seat position or incorrectly worn seat belts.

The ETDs do not pull occupants back toward the seat backrest.

↑ Warning!

Pyrotechnic ETDs that were activated must be replaced.

For your safety, when disposing of the pyrotechnic ETDs always follow our safety instructions. These are available at any authorized Mercedes-Benz Center.

Automatic comfort-fit feature seat belt

An automatic comfort-fit feature for the front seats reduces the retracting force of the seat belts when they are in normal use.

Preventive occupant safety (PRE-SAFE®)



The PRE-SAFE® system is intended to reduce the effects of an accident on vehicle occupants who are wearing their seat belt properly. Despite your vehicle being equipped with the PRE-SAFE® system, the possibility of personal injuries occurring as a result of an accident cannot be eliminated. Therefore, always drive carefully and adjust your driving to the prevailing road, weather, and traffic conditions.

The PRE-SAFE® system takes preventive measures to better protect the occupants from the possibility of personal injuries in the following hazardous situations:

- emergency braking situations, e.g. if the Brake Assist System (BAS) (⊳ page 59) is activated
- · critical dynamic driving situations, e.g. when the vehicle has been caused to understeer or oversteer because it has exceeded its physical limitations or in case of evasive steering maneuvers at speeds above approximately 85 mph (140 km/h)

The PRE-SAFE® system takes the following measures when it is activated:

- The front seat belts are pre-tensioned automatically.
- If the front passenger seat is in an unfavorable position, the seat will be adjusted to a position that seeks to better protect the occupant.
- If the vehicle is in a critical dynamic driving situation, the door windows and the tilt/ sliding sunroof also closes, except for a minimal gap that remains open.

If the closing procedure of any of these elements is blocked, it will stop and open slightly.

Once the hazardous situation no longer exists and an accident has been avoided, the seat belt pre-tensioning is deactivated. All of the PRE-SAFE® system settings can be readjusted following the critical driving event.

If the seat belts do not release:

▶ Adjust the seat backrest or seat slightly to the rear until the seat belt tension is reduced.

The locking mechanism releases.

When moving the seats, make sure there are no items in the footwell or behind the seats. Otherwise, you could damage the seats and/or the items.

NFCK-PRO active front head restraints

The NFCK-PRO active front head restraints are intended to offer the driver and front passenger increased protection from whiplash-type injuries. In the event of a rearend collision, the NECK-PRO active front head restraints on the front seats are designed to move forward in the direction of travel. They thus provide the head with increased support earlier on in the collision sequence. The NECK-PRO active front head restraints will move forward whether the seats are occupied or not.

/ Warning!

Do not attach any objects (e.g. hangers) to the head restraint posts. Otherwise, the NECK-PRO active front head restraints may not be able to function properly or offer the intended degree of protection they were designed for in the event of a rear-end collision.



↑ Warning!

Only use seat or head restraint covers which have been tested and approved by Mercedes-Benz for your vehicle model.

Using other seat or head restraint covers may interfere with or prevent the activation of the NECK-PRO active front head restraints and/ or the deployment of the front side impact air bags.

Contact an authorized Mercedes-Benz Center for availability.

When the NECK-PRO active front head restraints have been triggered in an accident, the NECK-PRO active front head restraints must be reset. Otherwise, the NECK-PRO active front head restraints cannot offer any additional protection in the event of another rear-end collision.

For information on resetting the activated NECK-PRO active front head restraints, see "Resetting activated head restraints" (⊳ page 264).

You cannot remove the NECK-PRO active front head restraints.



↑ Warning!

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eve level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

For information on head restraint adjustment, see "Head restraint height" (⊳ page 79), or see "Head restraint fore and aft adjustment" (⊳ page 79).

Correct driver seat adjustment



Marning!

In order to avoid possible loss of vehicle control the following must be done before the vehicle is put into motion:

- · seat adjustment
- head restraint adjustment
- · steering wheel adjustment
- · rear view mirror adjustment
- · fastening of seat belts



Steering wheel



↑ Observe Safety notes, see page 82.

► Position steering wheel (1) properly (⊳ page 82).

Make sure:

- You can reach the steering wheel with your arms slightly bent at the elbows.
- You can move your legs freely.
- All displays (including malfunction and indicator lamps) on the instrument cluster are clearly visible.

Seat belt



♠ Observe Safety notes, see page 45.

► Fasten and position your seat belt ② correctly (⊳ page 47).

Make sure:

- The seat belt is always fitted snugly.
- Adjust the seat belt so that the shoulder section is located as close as possible to the middle of the shoulder.
- Place the lap portion of the seat belt as low as possible on your hips.

Seat and head restraint



Observe Safety notes, see page 77.

▶ Position seat (3) and head restraint properly. See (⊳ page 78) for seat and head restraint adjustment.

Observe the following points:

- Always be in a properly seated position.
- The position should be as far rearward from the front air bag in the steering wheel as possible, while still permitting proper operation of vehicle controls.
- Adjust the seat to a comfortable seating position that still allows you to reach the accelerator/brake pedal safely.
- The seat must be adjusted so that you can correctly fasten and position your seat belt.
- The seat backrest must be in a position that is as nearly upright as possible.
- Adjust the seat cushion so that the front edge of the seat cushion lightly supports your legs.
- Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level.
- Never place hands under the seat or near any moving parts while the seat is being adjusted.

Children in the vehicle

Safety notes

If an infant or child is traveling with you in the vehicle:

- ► Secure the child using an infant or child restraint appropriate to the age and size of the child.
- ▶ Make sure the infant or child is properly secured at all times while the vehicle is in motion.

/ Warning!

When leaving the vehicle, always remove the SmartKey from the starter switch. Always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, even if they are secured in a child restraint system, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury. The children could

- injure themselves on parts of the vehicle
- be seriously or fatally injured through excessive exposure to extreme heat or cold
- injure themselves or cause an accident with vehicle equipment that can be operated even if the SmartKey is removed from the starter switch or removed from the vehicle. such as seat adjustment, steering wheel adjustment, or the memory function

If children open a door, they could injure other persons or get out of the vehicle and injure themselves or be injured by following traffic.

Do not expose the child restraint system to direct sunlight. The child restraint system's metal parts, for example, could become very hot, and the child could be burned by these parts.



↑ Warning!

Do not carry heavy or hard objects in the passenger compartment unless they are firmly secured in place.

Unsecured or improperly positioned cargo increases a child's risk of injury in the event of

- strong braking maneuvers
- · sudden changes of direction
- · an accident

Infant and child restraint systems



♠ Observe Safety notes, see page 52.

We recommend all infants and children be properly restrained at all times while the vehicle is in motion.

All lap/shoulder belts except the driver's seat belt have special seat belt retractors for secure fastening of child restraints.

To fasten a child restraint, follow the child restraint manufacturer's instructions for mounting.

To activate the special seat belt retractor:

▶ Pull the shoulder belt out completely and let it retract.

During seat belt retraction, a ratcheting sound can be heard to indicate that the special seat belt retractor is activated. The seat belt is now locked.

▶ Push down on child restraint to take up any slack.

To deactivate the special seat belt retractor:

▶ Release the seat belt buckle and let the seat belt retract completely. The seat belt can then again be used in the usual manner.



↑ Warning!

Never release the seat belt buckle while the vehicle is in motion, since the special seat belt retractor will be deactivated.

Information on child seats with mounting fittings for tether anchorages (⊳ page 54).

For information on LATCH-type (ISOFIX) child seat anchors (⊳ page 55).

The use of infant or child restraints is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Infants and small children should be seated in an appropriate infant or child restraint system. They must be properly secured in accordance with the manufacturer's

instructions for the child restraint. All infant or child restraint systems must comply with U.S. Federal Motor Vehicle Safety Standards 213 and 225 and Canadian Motor Vehicle Safety Standards 213 and 210.2.

A statement by the child restraint manufacturer of compliance with these standards can be found on the instruction label on the restraint and in the instruction manual provided with the restraint.

When using any infant restraint, toddler restraint, or booster seat, make sure to carefully read and follow all manufacturer's instructions for installation and use.

Please read and observe warning labels affixed to the inside of the vehicle and to infant or child restraints.



↑ Warning!

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating position. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriate infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

The infant or child restraint must be properly secured with the vehicle's seat belt, the seat belt and top tether strap, or lower anchors and top tether strap, fully in accordance with the child seat manufacturer's instructions.

Occupants, especially children, should always sit as upright as possible, wear the seat belt properly and use an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child.

Children can be killed or seriously injured by an inflating air bag. Note the following important information when circumstances require you to place a child in the front passenger seat:

- Your vehicle is equipped with air bag technology designed to deactivate the front passenger front air bag in your vehicle when the system senses the weight of a typical 12-month-old child or less along with the weight of a standard appropriate child restraint on the front passenger seat.
- A child in a rear-facing child restraint on the front passenger seat will be seriously injured or even killed if the front passenger front air bag inflates in a collision which could occur under some circumstances, even with the air bag technology installed in your vehicle. The only means to completely eliminate this risk is to never place a child in a rear-facing child restraint in the front seat. We therefore strongly recommend that you always place a child in a rear-facing child restraint in a backseat.
- · If you must install a rear-facing child restraint on the front passenger seat because circumstances require you to do so, make sure the PASS AIR BAG OFF indicator lamp is illuminated, indicating that the front passenger front air bag is deactivated. Should the PASS AIR BAG OFF indicator lamp not illuminate or go out while the restraint is installed, please check installation. Periodically check the PASS AIR BAG OFF | indicator lamp while driving to make sure the PASS AIR BAG OFF 3 indicator lamp is illuminated. If the PASS AIR BAG OFF indicator lamp goes out or remains out, do not transport a child on the front passenger seat until the system has been repaired.

A child in a rear-facing child restraint on the front passenger seat will be seriously

- injured or even killed if the front passenger front air bag inflates.
- If you have to place a child in a forwardfacing child restraint on the front passenger seat, move the seat as far back as possible, use the proper child restraint recommended for the age, size and weight of the child, and secure child restraint with the vehicle's seat belt according to the child seat manufacturer's instructions. For children larger than the typical 12-monthold child, the front passenger front air bag may or may not be activated.

↑ Warning!

Infants and small children should never share a seat belt with another occupant. During an accident, they could be crushed between the occupant and seat belt.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.

Children too big for a toddler restraint must ride in seats using regular seat belts. Position shoulder belt across chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lb (18 kg) until they reach a height where a lap/shoulder belt fits properly without a booster.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat. belt to prevent the child restraint from becoming a projectile in the event of an accident.

Installation of infant and child restraint systems




Observe Safety notes, see page 52.

This vehicle is equipped with tether anchorages for a top tether strap at each of the rear seating positions.

Top tether straps enable an additional connection to be made between child restraint systems secured with LATCH-type (ISOFIX) anchors and rear seats. This can further reduce the risk of injury.



- ▶ Remove anchorage ring cover ① from the anchorage ring of the seat on which a child seat is to be installed.
- ► Store anchorage ring cover ① in a convenient place (e.g. glove box).



- ► Guide top tether strap ④ between the head restraint and top of the seat backrest.

 The head restraint must be positioned such that top tether strap ④ can pass freely between the head restraint and top of the seat backrest.
- ► Make sure top tether strap ④ is not twisted.
- ► Securely fasten hook ③, which is part of top tether strap ④, to anchorage ring ②.
- ► For safety, make sure hook ③ is attached to anchorage ring ② beyond the safety catch, as illustrated.

Once hook ③ is attached, the child restraint itself can be secured.

► Install the child restraint system and tighten top tether strap ④ according to the child restraint manufacturer's instructions.

After removing the child restraint system and top tether strap (4):

▶ Reinstall anchorage ring cover (1).

Child seat anchors – LATCH-type (ISOFIX)

Observe Safety notes, see page 52.

↑ Warning!

Children too big for a toddler restraint must ride in seats using regular seat belts. Position shoulder belt across chest and shoulder, not face or neck.

A booster seat may be necessary to achieve proper seat belt positioning for children over 41 lb (18 kg) until they reach a height where a lap/shoulder belt fits properly without a hooster.

Install child seat according to manufacturer's instructions.

The child seat must be firmly attached to both anchors.

An incorrectly mounted child seat may come loose during an accident which could result in serious injury or death to the child.

Damaged or impact damaged child seats or child seat mounting fittings must be replaced.

Each rear seat has two LATCH-type (ISOFIX) anchors for the installation of a LATCH-type (ISOFIX) child seat with matching mounting fittings.

Non-LATCH-type (ISOFIX) child seats may also be used and can be installed using the vehicle's seat belt system. Install child seat according to the manufacturer's instructions.

The LATCH-type (ISOFIX) anchors are covered with upholstery blends.



Information sign (1) indicates the position of anchor (2).

- ► Fold the upholstery blend upward to access anchors (2).
- ▶ Install a LATCH-type (ISOFIX) child seat according to the manufacturer's instructions.

A rigid connection between the child seat and the body of the vehicle is established.

Child safety

Child safety locks



Observe Safety notes, see page 52.



/ Warning!

Children could open a rear door from the inside. This may cause serious personal injury or an accident. Therefore, secure the rear doors with the child safety locks whenever children are riding in the back seats of the vehicle.

The child safety locks on the rear doors enable you to secure each rear door individually. You cannot open a secured rear door from the inside. You can open the rear door from the outside when the vehicle is unlocked.



- ▶ **Securing:** Press the lever up in direction of arrow (1).
- Check to make sure the child safety locks are working properly.
- ▶ Releasing: Press the lever down in direction of arrow (2).

Override switch



↑ Observe Safety notes, see page 52.

You can disable the rear door window operation and the 12V power outlet in the rear center console for added safety. This can be useful, for instance, when you have children riding in the rear passenger compartment.



↑ Warning!

Activate the override switch when children are riding in the back seats of the vehicle. The children may otherwise injure themselves, e.g. by becoming trapped in the rear door window opening.



► Activating: Press override switch ①. Indicator lamp ② comes on.

The functions in the rear are disabled.

You can still operate the rear door windows using the switches located on the door control panel of the driver's door.

► **Deactivating:** Press override switch ① again.

Indicator lamp (2) goes out.

The functions in the rear are enabled again. For more information on power windows, see the "Controls in detail" section (> page 94).

Panic alarm



Example illustration: SmartKey with KEYLESS-GO

- ► Activating: Press and hold PANIC button ① for at least 1 second.

 An audible alarm and flashing exterior lamps will operate.
- ► **Deactivating:** Press PANIC button ① again. or
- ► Insert the SmartKey into the starter switch. or
- ► Press the KEYLESS-GO start/stop button.

 The SmartKey with KEYLESS-GO must be inside the vehicle.

1 USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1 Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- This device may not cause interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Driving safety systems

Introduction

This section contains information about the following driving safety systems:

- ABS (<u>A</u>ntilock <u>B</u>rake <u>S</u>ystem)
- Adaptive Brake
- BAS (Brake Assist System)
- EBP (Electronic Brake Proportioning)
- $\mathsf{ESP}^{\mathbb{R}}$ ($\underline{\mathsf{E}}$ lectronic $\underline{\mathsf{S}}$ tability $\underline{\mathsf{P}}$ rogram)
- In winter operation, the maximum effectiveness of most of the driving systems described in this section is only

achieved with winter tires, or snow chains as required.

Safety notes

↑ Warning!

The following factors increase the risk of accidents:

- · Excessive speed, especially in turns
- Wet and slippery road surfaces
- Following another vehicle too closely

The driving safety systems described in this section cannot reduce these risks or prevent the natural laws of physics from acting on the vehicle. They cannot increase braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded.

Only a safe, attentive, and skillful driver can prevent accidents.

The capabilities of a vehicle equipped with the driving safety systems described in this section must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

Always adjust your driving style to the prevailing road and weather conditions and keep a safe distance to other road users and objects on the street.

If a driving system malfunctions, other driving safety systems may also switch off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear.

ABS



↑ Observe Safety notes, see page 58.



↑ Warning!

Do not pump the brake pedal. Use firm, steady brake pedal pressure instead. Pumping the brake pedal defeats the purpose of the ABS

and significantly reduces braking effectiveness.

The Antilock Brake System (ABS) regulates the brake pressure so that the wheels do not lock during braking. This allows you to maintain the ability to steer your vehicle.

The ABS is functional above a speed of approximately 5 mph (8 km/h) independent of road surface conditions.

On slippery road surfaces, the ABS will respond even to light brake pressure.

The ABS indicator lamp in the instrument cluster comes on when you switch on the ignition. It goes out when the engine is running.

Braking

At the instant one of the wheels is about to lock up, a slight pulsation can be felt in the brake pedal. The pulsation indicates that the ABS is in the regulating mode.

► Keep firm and steady pressure on the brake pedal while you feel the pulsation.

Continuous, steady brake pedal pressure yields the advantages provided by the ABS, namely braking power and the ability to steer the vehicle.

The pulsating brake pedal can be an indication of hazardous road conditions and functions as a reminder to take extra care while driving.

Emergency brake maneuver

► Keep continuous full pressure on the brake pedal.



↑ Warning!

If the ABS malfunctions, other driving safety systems such as the BAS or the ESP® are also switched off. Observe indicator and warning lamps that may come on as well as messages in the multifunction display that may appear.

If the ABS malfunctions, the wheels may lock during hard braking, reducing steering capability and extending the braking distance.

BAS



♠ Observe Safety notes, see page 58.

The Brake Assist System (BAS) operates in emergency situations. If you apply the brakes very quickly, the BAS provides full brake boost automatically, thereby potentially reducing the braking distance.

► Apply continuous full braking pressure until the emergency braking situation is over. The ABS will prevent the wheels from locking.

When you release the brake pedal, the brakes function again as normal. The BAS is then deactivated.



↑ Warning!

If the BAS malfunctions, the brake system still functions, but without the additional brake boost available that the BAS would normally provide in an emergency braking maneuver. Therefore, the braking distance may increase.

Adaptive Brake

Adaptive Brake provides a high level of braking safety as well as increased braking comfort. Adaptive Brake takes driver and vehicle characteristics into consideration, thus achieving an optimal braking effect.

For more information on the brake system, see (⊳ page 210).

EBP



♠ Observe Safety notes, see page 58.

The Electronic Brake Proportioning (EBP) enhances braking effectiveness by allowing the rear brakes to supply a greater proportion of the braking effort in straight-line braking without a loss of vehicle stability.



Marning!

If the EBP malfunctions, the brake system will still function with full brake boost. However, the rear wheels could lock up during emergency braking situations, for example. You could lose control of the vehicle and cause an accident.

Adapt your driving style to the changed driving characteristics.

ESP®



♠ Observe Safety notes, see page 58.

The Electronic Stability Program (ESP®) is operational as soon as the engine is running. It monitors the vehicle's traction (force of adhesive friction between the tires and the road surface) and handling.

The ESP® recognizes that the vehicle deviates from the direction of travel as intended by the driver. By applying brakes to individual wheels and by limiting the engine output, the ESP® works to stabilize the vehicle. The ESP® is especially useful while driving off and on wet or slippery road surfaces. The ESP® also stabilizes the vehicle during braking and steering maneuvers.

The ESP® warning lamp in the instrument cluster comes on when you switch on the ignition. It goes out when the engine is running.

The ESP® warning lamp / in the instrument cluster flashes when the ESP® is engaged.

/ Warning!

Never switch off the ESP® when you see the ESP® warning lamp flashing in the instrument cluster. In this case proceed as follows:

- . When driving off, apply as little throttle as
- While driving, ease up on the accelerator
- · Adapt your speed and driving style to the prevailing road conditions.

Failure to observe these guidelines could cause the vehicle to skid. The ESP® cannot prevent accidents resulting from excessive speed.

Because the ESP® operates automatically, the engine and ignition must be shut off (SmartKey in starter switch position **0** or **1** or KEYLESS-GO start/stop button in position 0 or 1) when the parking brake is being tested on a brake test dynamometer or when the vehicle is being towed with the front axle raised.

Active braking action through the ESP® may otherwise seriously damage the brake system which is not covered by the Mercedes-Benz Limited Warranty.

- I The ESP® will only function properly if you use wheels of the recommended tire size as specified in the "Technical data" section of this Operator's Manual.
- 1 The Distronic system and cruise control switch off automatically when the ESP® engages.

Electronic Traction System (ETS)



↑ Observe Safety notes, see page 58.


The ETS (Electronic Traction System) is a component of the ESP®. The ETS improves the vehicle's ability to utilize available traction, especially under slippery road

conditions by applying the brakes to a spinning wheel.

Except CLS 63 AMG:

When you switch off the ESP®, the ETS is still enabled.

Switching off the ESP®



Switching off the ESP® (except CLS 63 AMG)



Marning!

The ESP® should not be switched off during normal driving other than in the circumstances described below. Disabling the system will reduce vehicle stability in driving maneuvers.

Do not switch off the ESP® when a spare wheel is mounted.

To improve the vehicle's traction, switch off the ESP®. This allows the drive wheels to spin and thus cut into surfaces for better grip, for example

- · when driving with snow chains
- in deep snow
- in sand or gravel



↑ Warning!

Switch on the ESP® immediately if the aforementioned circumstances do not apply anymore. Otherwise the ESP® will not stabilize the vehicle when it is starting to skid or a wheel is spinning.

When you switch off the ESP®,

- the ESP® does not stabilize the vehicle
- the engine output is not limited, which allows the drive wheels to spin and thus cut into surfaces for better grip
- the ETS will still apply the brakes to a spinning wheel
- the ESP® continues to operate when you are braking
- the cruise control or the Distronic system cannot be activated
- the cruise control or the Distronic system switch off if activated
- When the ESP® is switched off and one or. more drive wheels are spinning, the ESP® warning lamp in the instrument cluster flashes. However, the ESP® will then not stabilize the vehicle.
- ► With the engine running, press ESP® switch (1) until the ESP® warning lamp in the instrument cluster comes on. The ESP® is switched off.

♠ Warning!

When the ESP® warning lamp is illuminated continuously, the ESP® is switched off or is not operational due to a malfunction. Vehicle stability in standard driving maneuvers is reduced.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP®.

Avoid spinning of a drive wheel for an extended period with the ESP® switched off. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Switching off the ESP® (CLS 63 AMG only)



↑ Warning!

The ESP® should not be switched off during normal driving.

Disabling of the system will result in the following:

- no restriction to engine torque
- loss of system-supported traction control

"ESP® OFF" is designed for driving on closed tracks when the vehicle's natural oversteer and understeer characteristics are desired and requires a highly skilled and experienced driver able to handle these critical driving situations.

You could lose control of your vehicle and cause an accident.

Please be aware of these limits when you switch off the ESP®.

Do not switch off the ESP® when a spare wheel is mounted.

When you switch off the ESP®,

- the ESP® does not stabilize the vehicle
- the engine output is not limited, which allows the drive wheels to spin
- the ETS will still apply the brakes to a spinning wheel
- the ESP® operates while you are braking
- the cruise control or the Distronic system cannot be activated
- the cruise control or the Distronic system switch off if currently activated
- When the ESP® is switched off and one or. more drive wheels are spinning, the ESP® warning lamp in the instrument cluster flashes. However, the ESP® will then not stabilize the vehicle.

► With the engine running, press ESP® switch (1) until the ESP® warning lamp in the instrument cluster comes on. The ESP® is switched off.

↑ Warning!

When the ESP® warning lamp is illuminated continuously, the ESP® is switched off or is not operational due to a malfunction. Vehicle stability in standard driving maneuvers is reduced.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP®.

Avoid spinning of a drive wheel for an extended period with the ESP® switched off. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Switching on the ESP®

► Press ESP® switch (1) until the ESP® warning lamp in the instrument cluster goes out.

You are now again in normal driving mode with the ESP® switched on.

Anti-theft systems

Immobilizer

The immobilizer prevents unauthorized persons from starting your vehicle.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. The engine can be started by anyone with a valid SmartKey that is left inside the vehicle.

Activating

- ► With SmartKey: Remove the SmartKey from the starter switch.
- ▶ With KEYLESS-GO: Turn off the engine and open the driver's door.

Deactivating

- ▶ Switch on the ignition.
- **1** Starting the engine will also deactivate the immobilizer.

In the event that the engine cannot be started (yet the vehicle's battery is charged), the system is not operational. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in the USA) or 1-800-387-0100 (in Canada).

Anti-theft alarm system

Once the alarm system has been armed, a visual and audible alarm is triggered when someone opens

- · a door
- the trunk
- the hood


The alarm will stay on even if the activating element, a door, for example, is closed immediately.

The alarm system will also be triggered when

- the vehicle is opened with the mechanical kev
- a door is opened from the inside
- the trunk is opened with the emergency release button

To cancel the alarm after it has been triggered, see "Canceling the alarm" (⊳ page 63).

- 1 If the alarm stays on for more than 30 seconds, the Tele Aid system initiates a call to the Customer Assistance Center automatically. The Tele Aid system will initiate the call provided that
 - you have subscribed to the Tele Aid service
 - the Tele Aid service has been activated properly
 - the necessary mobile phone, power supply and GPS coverage are available



- ➤ Arming: Lock the vehicle with the SmartKey or with KEYLESS-GO.

 The turn signal lamps flash three times to indicate that the vehicle is locked. Indicator lamp ① flashes to indicate that the alarm system is armed.
- If the turn signal lamps do not flash three times, a door or the trunk may not be properly closed.

Close the respective element.

- ► Disarming: Unlock the vehicle with the SmartKey or with KEYLESS-GO. The turn signal lamps flash once to indicate that the alarm system is disarmed.
- 1 Unless you open a door or the trunk within approximately 40 seconds after unlocking the vehicle:
 - The vehicle will be locked again.
 - The anti-theft alarm system will be rearmed.

Canceling the alarm

To cancel the alarm, do one of the following:

- ▶ Insert the SmartKey into the starter switch.
- ▶ Press button or on the SmartKey.

In vehicles with KEYLESS-GO:

- Grasp an outside door handle. The SmartKey must be within 3 ft (1 m) of the vehicle.
- ► Press the KEYLESS-GO start/stop button. The SmartKey must be inside the vehicle.

Vehicle equipment	6
Locking and unlocking	6
Starter switch positions	70
Seats	7
Multifunction steering wheel	82
Mirrors	84
Memory function	8
Lighting	86
Wipers	92
Power windows	94
Driving and parking	96
Automatic transmission	10
Instrument cluster	108
Control system	110
Driving systems	12
Climate control system	143
Rear window defroster	15
Power tilt/sliding sunroof	152
Loading and storing	154
Useful features	160



Vehicle equipment

1 This Operator's Manual describes all features, standard or optional, potentially available for your vehicle at the time of purchase. Please be aware that your vehicle might not be equipped with all features described in this manual.

Locking and unlocking

Notes



↑ Observe Safety notes, see page 52.

When unlocking or locking the vehicle with the SmartKey an acoustic signal sounds. The acoustic signal is activated at the factory. If you wish to deactivate the feature, or adjust its signal volume, contact an authorized Mercedes-Benz Center.

When unlocking the vehicle, all turn signal lamps flash once. An acoustic signal sounds once, and the locking knobs in the doors move up. The anti-theft alarm system is disarmed.

When locking the vehicle, all turn signal lamps flash three times. An acoustic signal sounds three times, and the locking knobs in the doors move down. The anti-theft alarm system is armed.

All doors and the trunk must be closed.

If you cannot lock or unlock the vehicle with the SmartKey, the batteries in the SmartKey are discharged, the SmartKey is malfunctioning, or the vehicle battery is drained.

- ► Check the batteries in the SmartKey (⊳ page 69) and replace them if necessary.
- ▶ Use the mechanical key to unlock the driver's door and the trunk (⊳ page 261).

- ▶ Use the mechanical key to lock the vehicle (⊳ page 262).
- ▶ Have the vehicle battery and the vehicle battery connections checked at an authorized Mercedes-Benz Center.

If the SmartKey is malfunctioning, contact Roadside Assistance or an authorized Mercedes-Benz Center.

SmartKey

Your vehicle comes supplied with two SmartKeys, each with remote control and a removable mechanical key.

The SmartKey centrally locks and unlocks

- the doors
- the trunk lid
- the fuel filler flap



Example illustration: SmartKey with KEYLESS-GO

- 1 Lock button
- 2 S Unlock button for trunk lid
- (3) Unlock button

When you open a door, the door window on that side lowers slightly. Once you close the door, the door window moves up again.

A door window will not work if it is blocked with ice or if the vehicle battery is discharged. If you cannot shut a door, do not force it or you could damage the door or the door window. Fix whatever is affecting the window before trying to shut the door.

1 USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1 Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- This device may not cause interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Factory setting

► Global unlocking: Press button .

Unless you open a door or the trunk within approximately 40 seconds after unlocking the vehicle:

- The vehicle will be locked again.
- The anti-theft alarm system will be rearmed.
- ► Global locking: Press button 🕡.

Selective setting

If you frequently travel alone, you may wish to reprogramm the SmartKey. Pressing button will then only unlock the driver's

door, interior lockable storage compartments, and the fuel filler flap.

➤ Switching on/off: Press and hold buttons

on and on simultaneously for
approximately 6 seconds until the battery
check lamp (▷ page 69) flashes twice.

The SmartKey will then function as follows:

- ► Unlocking driver's door and fuel filler flap: Press button once.
- ► Global unlocking: Press button twice.
- ► Global locking: Press button 🔒 .

KEYLESS-GO

Vehicles equipped with KEYLESS-GO come with two SmartKeys with KEYLESS-GO, each with remote control and a removable mechanical key.

The KEYLESS-GO function is integrated into the SmartKey. The validity of the SmartKey is checked every time you pull an outside door handle.

When the SmartKey is valid, your vehicle unlocks

- the doors
- the trunk lid
- the fuel filler flap

When you open a door, the door window on that side lowers slightly. Once you close the door, the door window moves up again.

A door window will not work if it is blocked with ice or if the vehicle battery is discharged. If you cannot shut a door, do not force it or you could damage the door or the door window. Fix whatever is affecting the window before trying to shut the door.

1 USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1 Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- This device may not cause interference, and
- this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Important notes on using KEYLESS-GO

- You can also use the SmartKey with KEYLESS-GO like a normal SmartKey (> page 66).
- You can combine KEYLESS-GO functions with normal SmartKey functions (e.g. unlocking with KEYLESS-GO and locking with button).
- Always carry the SmartKey with you.
- Never store the SmartKey together with
 - electronic items such as a mobile phone or another SmartKey
 - metallic objects such as coins or metal foil

- Doing so could impair the function of the KEYLESS-GO system.
- To lock or unlock the vehicle, the SmartKey must be located outside the vehicle within approximately 3 ft (1 m) of a door or the trunk.
- If the SmartKey is positioned farther away from the vehicle, the system may no longer recognize the SmartKey. The vehicle cannot be locked or the engine started via the KEYLESS-GO system.
- If the SmartKey is removed from the vehicle (e.g. if a passenger exits the vehicle with the SmartKey)
 - when pressing the KEYLESS-GO start/ stop button or trying to lock the vehicle with the lock button on an outside door handle the message Key Not Detected appears in the multifunction display
 - with the engine running, the red message Key Not Detected appears in the multifunction display while driving off

Find the SmartKey or change its present location immediately (e.g. place it on the front passenger seat or insert it in shirt pocket).

- If you have started the engine with the KEYLESS-GO start/stop button, you can turn it off again by
 - pressing the KEYLESS-GO start/stop button
 - inserting the SmartKey into the starter switch when the vehicle is at a standstill and the automatic transmission is in park position P
- The vehicle could be inadvertently unlocked if the SmartKey is within 3 ft (1 m) of the vehicle and
 - an outside door handle is splashed with water

or

- you attempt to clean an outside door handle
- Remember that the engine can be started by anyone with a SmartKey that is left inside the vehicle.

Possibility 1 (One SmartKey in the vehicle, one SmartKey outside the vehicle):

If you leave the SmartKey behind when exiting and locking the vehicle, no message appears in the multifunction display.

Possibility 2 (One SmartKey in the vehicle, no SmartKey outside the vehicle):

When exiting and trying to lock the vehicle, the message Key Detected In Vehicle appears in the multifunction display. The vehicle will not be locked.

Factory setting

► Global unlocking: Pull an outside door handle.

Unless you open a door or the trunk within approximately 40 seconds after unlocking the vehicle:

- The vehicle will be locked again.
- The anti-theft alarm system will be rearmed.



► **Global locking:** Press lock button ① on an outside door handle.

Selective setting

If you frequently travel alone, you may wish to reprogram the SmartKey. Pulling the driver's outside door handle will then only unlock the driver's door and the fuel filler flap.

➤ Switching on/off: Press and hold buttons

or and or simultaneously for
approximately 6 seconds until the battery
check lamp (▷ page 69) flashes twice.

KEYLESS-GO will then function as follows:

- ► Unlocking driver's door and fuel filler flap: Pull the driver's outside door handle.
- Global unlocking: Pull any outside door handle other than the driver's outside door handle.
- ► Global locking: Press lock button ① on an outside door handle.

Checking SmartKey batteries



Example illustration: SmartKey with KEYLESS-GO

► Press button or on the SmartKey.

Battery check lamp ① comes on briefly to indicate that the SmartKey batteries are in order.

If the battery check lamp does not come on briefly during check, the SmartKey batteries are discharged.

- ▶ Replace the batteries (▷ page 264).
- 1 You can obtain the required batteries at any authorized Mercedes-Benz Center.

If the batteries are checked within signal range of the vehicle, pressing button or will lock or unlock the vehicle accordingly.

Loss of the SmartKey

If you lose your SmartKey or mechanical key, you should do the following:

- ► Have the SmartKey deactivated by an authorized Mercedes-Benz Center.
- Report the loss of the SmartKey or the mechanical key to your car insurance company immediately.
- ► Have the mechanical lock replaced if necessary.

Any authorized Mercedes-Benz Center will be glad to supply you with a replacement. For information on replacing the SmartKey, see "Replacing the SmartKey" (> page 70).

Replacing the SmartKey

Only you, or someone authorized by you can order a replacement key from any Mercedes-Benz Center. In order to do so, the Mercedes-Benz Center will require proof of identity and vehicle ownership with original documents, including the following:

If you are the current owner of the vehicle:

- the vehicle's current state registration
- a current identity card, passport, or drivers license

If you are an authorized person:

- the vehicle's current state registration
- a current identity card, passport, or drivers license for the authorized individual
- signed and dated authorization from the owner of the vehicle for which the key is being requested
- Duplicated or photocopied documentation will not be accepted.

Activating the key

Once you, or an authorized person, has provided the appropriate documents, the Mercedes-Benz Center will need to synchronize the key to your vehicle before it can be used. In order to do so, the Mercedes-Benz Center need access to your vehicle.

Opening the doors from the inside

You can open a door from the inside even when it is locked unless it is secured with the child safety lock (▷ page 56).

Open door only when conditions are safe to do so.



Example illustration driver's door

If the vehicle has previously been locked with the SmartKey or with KEYLESS-GO, opening a door from the inside will trigger the antitheft alarm system.

To cancel the alarm, see (▷ page 63).

- ► Front doors: Pull on inside door handle ② on the respective front door. If the door was locked, locking knob ① will move up.
 - When you open a door, the door window on that side lowers slightly. Once you close the door, the door window moves up again.
- A door window will not work if it is blocked with ice or if the vehicle battery is discharged. If you cannot shut a door, do not force it or you could damage the door or the door window. Fix whatever is

affecting the window before trying to shut the door.

- ▶ Rear doors: Pull up locking knob on the respective rear door to unlock door.
- ▶ Pull on the inside door handle on the respective rear door.

Automatic central locking

You can switch the automatic central locking on or off using the control system (⊳ page 123).

The doors and the trunk lock automatically when the vehicle is set into motion.

You can open a locked front door from the inside. Open door only when conditions are safe to do so.

The doors are designed to unlock automatically after an accident if the force of the impact exceeds a preset threshold.

The vehicle locks automatically when the ignition is switched on and the wheels are turning at a vehicle speed of above 9 mph (15 km/h). You could therefore lock yourself out when the vehicle is pushed or towed or is on a test stand.


Locking and unlocking from the inside



↑ Observe Safety notes, see page 52.

You can lock or unlock the vehicle from the inside using the central locking or unlocking switch. This can be useful, for example, if you want to lock the vehicle before starting to

The central locking or unlocking switch does not lock or unlock the fuel filler flap.



- ▶ Locking: Press central locking switch (2). When all doors are closed, the vehicle locks.
- ► Unlocking: Press central unlocking switch (1).

You can open a locked front door from the inside. Open door only when conditions are safe to do so.

If the vehicle was previously locked with the central locking switch

- and the SmartKey is set to factory settings, the complete vehicle is unlocked when a front door is opened from the inside
- and the SmartKey is set to selective settings, only the front door opened from the inside is unlocked

If the vehicle has been locked centrally with the SmartKey or with KEYLESS-GO, it will not unlock using the central unlocking switch.

Opening the trunk



↑ Warning!


Make sure the trunk is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO) gases may enter vehicle interior resulting in unconsciousness and death.

When you open the trunk, the trunk lid swings open upwards. Always make sure there is sufficient overhead clearance.

You can open the trunk when the vehicle is stationary.

A minimum height clearance of 5.9 ft (1.80 m) is required to open the trunk lid.

Opening the trunk from the outside



▶ Press and hold button (▷ page 66) on the SmartKey until the trunk unlocks and begins to open.

or

▶ Pull on handle (1). In vehicles without KEYLESS-GO: The vehicle must be unlocked.

If the trunk does not open, it is still locked separately (⊳ page 75).

Vehicles with trunk opening/closing system:

▶ Stopping the opening procedure: Press button \supset on the SmartKey.

Opening the trunk from the inside



Example illustration: Vehicles with trunk opening/ closing system

▶ Pull remote trunk opening switch (1) until the trunk begins to open.

If the trunk does not open, it is still locked separately (⊳ page 75).

Vehicles with trunk opening/closing system:

► To interrupt the opening procedure: Release remote trunk opening switch (1).

Closing the trunk



/ Warning!

Make sure the trunk is closed when the engine is running and while driving. Among other dangers, deadly carbon monoxide (CO) gases may enter vehicle interior resulting in unconsciousness and death.

To prevent possible personal injury, always keep hands and fingers away from the trunk opening when closing the trunk lid. Be especially careful when small children are around.



↑ Observe Safety notes, see page 52.

Do not leave the SmartKey in the open trunk. You may lock yourself out.

If the vehicle was previously locked centrally with the SmartKey or KEYLESS-GO, the trunk lid will lock automatically when closed. All turn signal lamps flash three times to confirm locking.

Closing the trunk from the outside manually



- ► Lower trunk lid by pulling firmly on handle (1).
- ► Close trunk with hands placed flat on trunk lid.

Closing the trunk from the inside automatically



Warning!

Maintain sight of the area around the rear of the vehicle while operating the trunk lid with the door mounted switch. Monitor the closing procedure carefully to make sure no one is in danger of being injured.

To interrupt the closing procedure, press or pull the door mounted remote trunk opening/ closing switch.

Even with the SmartKey removed from the starter switch or the SmartKey with KEYLESS-GO removed from the vehicle, the remote trunk opening/closing switch can be operated. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

In vehicles with trunk opening/closing system you can close the trunk from the inside using the remote trunk opening/ closing switch.

If the trunk lid comes into contact with an object while closing, the closing procedure is stopped and the trunk lid reopens slightly. This will happen only while the trunk is in its upper motion sequence. Check if luggage has been piled too high, for example.



- Press and hold remote trunk opening/ closing switch (1) until the trunk is closed.
- ▶ To interrupt the closing procedure: Release remote trunk opening/closing switch (1).

Closing the trunk from the outside automatically



Monitor the closing procedure carefully to make sure no one is in danger of being injured. To prevent possible personal injury, always keep hands and fingers away from the trunk opening when closing the trunk lid. Be especially careful when small children are around. To stop the closing procedure, do one of the following:

- Press button \supset on the SmartKey.
- Press or pull the remote trunk opening/ closing switch (on the driver's door).
- · Press the trunk closing switch.
- Press the KEYLESS-GO locking/closing switch.
- · Pull the trunk lid handle.

Even with the SmartKey removed from the starter switch or the SmartKey with KEYLESS-GO removed from the vehicle, the remote

trunk opening/closing switch can be operated. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

In vehicles with trunk opening/closing system you can close the trunk separately from the outside using the trunk closing switch.



Vehicles without KEYLESS-GO



Vehicles with KEYLESS-GO

▶ Press trunk closing switch ① briefly. If the trunk lid comes into contact with an object while closing, the closing procedure is stopped and the trunk lid reopens slightly. This will happen only while the trunk is in its upper motion sequence. Check if luggage has been piled too high, for example.

Closing the trunk and locking vehicle from outside

In vehicles with trunk opening/closing system and KEYLESS-GO, you can close the

trunk and lock the vehicle simultaneously from the outside using the KEYLESS-GO locking/closing switch.



- ► Make sure you have the SmartKey with KEYLESS-GO with you.
- Press KEYLESS-GO locking/closing switch ① briefly.
 With all doors closed:
 - The locking knobs in the doors move down.
 - The trunk lid starts to close automatically.
 - All turn signal lamps flash three times to confirm locking once the trunk has closed completely.
 - An acoustic signal sounds three times.
 - The anti-theft alarm system is armed.

If the trunk lid comes into contact with an object while closing, the closing procedure is stopped and the trunk lid reopens slightly. This will happen only while the trunk is in its upper motion sequence. Check if luggage has been piled too high, for example.

Trunk lid emergency release

The trunk lid can be opened from inside the trunk with the emergency release button.



► Briefly press emergency release button (1).

The emergency release button unlocks and opens the trunk while the vehicle is standing still or in motion.

Illumination of the emergency release button:

- The button flashes for 30 minutes after opening the trunk.
- The button flashes for 60 minutes after closing the trunk.

The emergency release button does not open the trunk, if the vehicle battery is discharged or disconnected.

If the vehicle has previously been locked centrally with the SmartKey or KEYLESS-GO, opening the trunk from the inside using the emergency release button will trigger the anti-theft alarm system.

To cancel the alarm, see (⊳ page 63).

Valet locking

You can lock the trunk separately with the mechanical key. This denies unauthorized access to the trunk, e.g. when you valet park the vehicle.

► Leave only the SmartKey less its mechanical key with the vehicle.



- ▶ Valet locking: Close the trunk.
- ► Remove the mechanical key from the SmartKey (▷ page 261).
- ► Insert the mechanical key in the trunk lid lock.
- ► Turn the mechanical key clockwise to position 2 and remove the mechanical key in that position to lock the trunk.

The trunk remains locked even when the vehicle is centrally unlocked.

You can then only open the trunk with the mechanical key.

- ► Canceling: Insert the mechanical key in the trunk lid lock.
- ➤ Turn the mechanical key counterclockwise to neutral position 1 and remove the mechanical key in that position to unlock the trunk.


You can now open the trunk.

Starter switch positions

SmartKey



Observe Safety notes, see page 52.



Starter switch

- o For removing SmartKey (gear selector lever must be in park position **P**)
- 1 Power supply for some electrical consumers, e.g. wipers
- 2 Ignition (power supply for all electrical consumers) and driving position
- 3 Starting position

When you switch on the ignition, all lamps in the instrument cluster come on. The low-beam headlamp indicator lamp, high-beam headlamp indicator lamp, and turn signal indicator lamps will only come on if activated. If a lamp in the instrument cluster fails to come on when the ignition is switched on, have it checked and replaced if necessary. If a lamp in the instrument cluster remains on after starting the engine or comes on while driving, refer to "Lamps in instrument cluster" (> page 251).

If the SmartKey is left in starter switch position **0** for an extended period of time, it can no longer be turned in the starter switch. In this case, the steering is locked. To unlock, remove SmartKey from the starter switch and reinsert.

The steering is locked when the SmartKey is removed from the starter switch.

Always remove the SmartKey from the starter switch when the engine is not in operation.

This will help to prevent accelerated vehicle battery discharge or a completely discharged vehicle battery.

If the SmartKey cannot be turned in the starter switch, the vehicle battery may not be sufficiently charged.

► Check the vehicle battery and charge it if necessary (> page 279).

or

► Get a jump start (> page 280).

KEYLESS-GO



Observe Safety notes, see page 52.


Vehicles equipped with the KEYLESS-GO feature are supplied with a SmartKey with integrated KEYLESS-GO function.

The SmartKey must be present in the vehicle. Pressing the KEYLESS-GO start/stop button without depressing the brake pedal corresponds to the various starter switch positions (> page 76).

Pressing the KEYLESS-GO start/stop button with the brake pedal firmly depressed will start the engine (> page 97).

The function of the SmartKey overrules the KEYLESS-GO function.

- ► Make sure the automatic transmission is in park position **P**.
- ▶ Do not depress the brake pedal.



KEYLESS-GO start/stop button

- ① USA only
- ② Canada only

Position 0

Before you press the KEYLESS-GO start/stop button, the vehicle's on-board electronics have status **0** (as with SmartKey removed).

Position 1

- ► Press the KEYLESS-GO start/stop button once.
 - This supplies power for some electrical consumers, e.g. wipers.
- When you now press the KEYLESS-GO start/stop button
 - once more, the ignition (position **2**) is switched on
 - twice more the power supply is again switched off

Ignition (or position 2)

► Press the KEYLESS-GO start/stop button twice.

This supplies power for all electrical consumers.

When you switch on the ignition, all lamps in the instrument cluster come on. The low-beam headlamp indicator lamp, high-beam headlamp indicator lamp, and turn signal indicator lamps will only come on if activated. If a lamp in the instrument cluster fails to come on when the ignition

is switched on, have it checked and replaced if necessary. If a lamp in the instrument cluster remains on after starting the engine or comes on while driving, refer to "Lamps in instrument cluster" (> page 251).

When you now press the KEYLESS-GO start/stop button once, the power supply is again switched off.

Seats

Safety notes

↑ Warning!

In order to avoid possible loss of vehicle control the following must be done before the vehicle is put into motion:

- seat adjustment
- head restraint adjustment
- steering wheel adjustment
- rear view mirror adjustment
- fastening of seat belts

Do not adjust the driver's seat while driving. Adjusting the seat while driving could cause the driver to lose control of the vehicle.

Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the seat belt would apply force at the abdomen or neck. That could cause serious or fatal injuries. The seat backrest and seat belts provide the best restraint when the wearer is in a position that is as upright as possible and seat belts are properly positioned on the body.

↑ Warning!

Your seat must be adjusted so that you can correctly fasten your seat belt.

Observe the following points:

- · Adjust the seat backrest until your arms are slightly angled when holding the steering wheel.
- · Adjust the seat to a comfortable seating position that still allows you to reach the accelerator/brake pedal safely. The position should be as far back as possible with the driver still able to operate the controls properly.
- Adjust the head restraint so that it is as close to the head as possible. The center of the head restraint must support the back of the head at eye level.
- Never place hands under the seat or near any moving parts while a seat is being adjusted.

Failure to do so could result in an accident and/or serious personal injury.



The power seats can be operated at any time. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.



Marning!

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating position. Thus, we strongly recommend that children be placed in the rear seats whenever possible. Regardless of seating position, children 12 years old and under must be seated and properly secured in an appropriately sized infant restraint, toddler restraint, or booster seat recommended for the size and weight of the child. For additional information, see "Children in the vehicle". A child's risk of serious or fatal injuries is

significantly increased if the child restraints are not properly secured in the vehicle and/ or the child is not properly secured in the child restraint.



↑ Warning!

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint so that it is as close to the head as possible and the center of the head restraint supports the back of the head at eye level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

Do not drive the vehicle without the seat head restraints. Head restraints are intended to help reduce injuries during an accident.

Seat adjustment

When moving the seats, make sure there are no items in the footwell or behind the seats. Otherwise, you could damage the seats and/or the items.

Power seats

① The memory function (▷ page 85) lets you store the settings for the seat position together with the settings for the steering wheel and the exterior rear view mirrors.



- ► Seat fore and aft adjustment: Press the switch forward or backward in direction of arrow ④.
- 1 When moving the seat fore or aft, the head restraints may readjust automatically.
- Seat backrest tilt: Press the switch forward or backward in direction of arrow
 (5).
- ► **Seat height:** Press the switch up or down in direction of arrow (3).
- ➤ Seat cushion tilt: Press the switch up or down in direction of arrow ② until your upper legs are lightly supported.
- ► **Head restraint height:** Press the switch up or down in direction of arrow (1).

Head restraint fore and aft adjustment



- While seated, reach behind you with both hands and find upper edge of the head restraint.
- ▶ Push or pull on the upper edge of the head restraint cushion to the desired position.

Comfort head restraint

When folding back the side cushions, never reach between the side cushion and the mounting post. You could otherwise be trapped.




You can adjust the side cushions of the head restraints individually.

- ► Adjusting side cushions: Pull or push side cushions ① into desired position.
- ► Adjusting forward or backward: Pull or push head restraint in direction of arrow (2).

Lumbar support

You can adjust the contour of the front seat's lumbar support to help enhance support to your spine.



Move adjustment lever ① in direction of the arrows until you have reached a comfortable seating position.

Rear seat head restraints



For safety reasons, always drive with the rear head restraints in the upright position when the rear seats are occupied.

Keep the area around head restraints clear of articles (e.g. clothing) to not obstruct the folding operation of the head restraints.



↑ Warning!

For your protection, drive only with properly positioned head restraints.

Adjust the head restraint in such a way that it is as close to the head as possible and the center of the head restraint supports the back of the head at eve level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

With a rear seat occupied, make sure to move the respective head restraint up from the lowest non-use position and have the occupant adjust the head restraint properly. Do not drive the vehicle without the seat head restraints installed when the rear seats are occupied. Head restraints are intended to help reduce injuries during an accident.




/ Warning!

Make sure the rear seat head restraints engage when placing them upright manually. Otherwise their protective function cannot be ensured.

The back of the head will not be supported in the event of a collision. That could cause serious or even fatal injuries. Rear seat occupants can be seriously injured or killed.

Folding rear seat head restraints back


The rear seat head restraints can be folded backward for increased visibility.



- ▶ Switch on the ignition.
- ▶ Press the symbol-side on head restraint release switch (1) to release the head restraints.

The head restraints will fold backward.


Placing rear seat head restraints upright



▶ Pull the head restraint forward until it locks into position.


Multicontour seat

The multicontour seat has a movable seat cushion and inflatable air cushions built into the seat backrest to provide additional lumbar and side support.



- ► Switch on the ignition.
- ➤ Seat cushion depth: Adjust the seat cushion depth to the length of your upper leg using switch ④.
- ► Seat backrest contour: Adjust the contour of the seat backrest to the desired position using + or -.
- ► Move the seat backrest support cushion to the bottom with button ③ or to the center with button ②.
- ➤ Seat backrest side bolsters: Adjust the side bolsters so that they provide good lateral support using switch ①.
- 1 If, after a period of time, the seat no longer provides the desired contour, then repeat the adjustment procedure.

Seat ventilation




The blue indicator lamps in seat ventilation switch (1) come on to show which ventilation level you have selected.

- **1** The seat ventilation for the driver's seat can be activated using the summer opening feature (▷ page 96).
- Switch on the ignition.
- ► **Switching on:** Press seat ventilation switch (1).
 - Three blue indicator lamps in seat ventilation switch (1) come on.
- Press seat ventilation switch ① repeatedly until the desired ventilation level is set.
- Switching off: Press seat ventilation switch ① repeatedly until all indicator lamps go out.


If one or more of the indicator lamps in the seat ventilation switch ① are flashing, there is insufficient voltage available since too many electrical consumers are turned on. The seat ventilation switches off automatically.

The seat ventilation will switch back on again automatically as soon as sufficient voltage is available.

Seat heating



Front seat heating switches



Rear seat heating switch (Canada only)

The red indicator lamps in seat heating switch (1) come on to show which heating level you have selected.

The seat heating switches from level 3 (high) to level 2 after approximately 5 minutes.

The seat heating switches from level 2 to level 1 (low) after approximately 10 minutes.

After approximately 20 minutes in level 1, the seat heating switches off automatically.

- ▶ Switch on the ignition.
- ▶ Switching on: Press seat heating switch (1).

Three red indicator lamps in seat heating switch (1) come on.

- ▶ Press seat heating switch (1) repeatedly until the desired seat heating level is set.
- Switching off: Press seat heating switch (1) repeatedly until all indicator lamps go out.

If one or more of the indicator lamps in seat heating switch (1) are flashing, there is insufficient voltage available since too many electrical consumers are turned on. The seat heating switches off automatically.

The seat heating will switch back on again automatically as soon as sufficient voltage is available.

Multifunction steering wheel

Safety notes

↑ Warning!


Do not adjust the steering wheel while driving. Adjusting the steering wheel while driving could cause the driver to lose control of the vehicle.

The electrical steering wheel adjustment feature can be operated at any time. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

Make sure

- you can reach the steering wheel with your arms slightly bent at the elbows
- you can move your legs freely
- all displays (including malfunction and indicator lamps) on the instrument cluster are clearly visible

Steering wheel adjustment



- ▶ Adjusting steering wheel in or out: Move stalk in direction of arrows (1).
- ▶ Adjusting steering wheel up or down: Move stalk in direction of arrows (2).
- The memory function (> page 85) lets you store the settings for the steering wheel together with the settings for the

seat position and the exterior rear view mirrors.

Easy-entry/exit feature

This feature allows the driver an easier entry into and exit from the vehicle. When entering and exiting the vehicle, the steering wheel is in its uppermost position.

The easy-entry/exit feature can be activated or deactivated in the Convenience submenu of the control system (⊳ page 124).



Marning!

You must make sure no one can become trapped or injured by the moving steering wheel when the easy-entry/exit feature is activated.

To stop steering wheel movement, move steering wheel adjustment stalk or press one of the memory position buttons.

Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could open the driver's door and unintentionally activate the easy-entry/exit feature, which could result in an accident and/or serious personal injury.

With the easy-entry/exit feature activated, the steering wheel will return to its last set position when you close the driver's door with the ignition switched on. The steering wheel will also return to its last set position when you insert the SmartKey into the starter switch or press the KEYLESS-GO start/stop button once with the driver's door closed.

1 The last set steering wheel position is stored when the ignition is switched off or the position is stored in memory (⊳ page 86).

With the easy-entry/exit feature activated, the steering wheel tilts upwards when you remove the SmartKey from the starter switch. The steering wheel also tilts upwards when you open the driver's door with the SmartKey in starter switch position 0 or 1 or the KEYLESS-GO start/stop button in position 1.

When the current position for the steering wheel is in the uppermost tilt position, the steering wheel will no longer be able to move upward when the easy-entry/exit feature is activated.

The adjustment procedure is briefly interrupted when the engine is started.



Marning!

Let the system complete the adjustment procedure before setting the vehicle in motion. All steering wheel adjustment must be completed before setting the vehicle in motion. Driving off with the steering wheel still adjusting could cause the driver to lose control of the vehicle.

Crash-responsive exit aid

When you open the driver's door after an accident has occurred, the steering column moves up. The position of the SmartKey in the starter switch is insignificant. This function facilitates exiting as well as rescue of vehicle occupants.

The crash-responsive exit aid can only be triggered when the easy-entry/exit feature is activated via the control system.

Heated steering wheel

The steering wheel heating warms up the leather area of the steering wheel.



- ▶ Switch on the ignition.
- ▶ Switching on: Turn switch at the tip of the stalk in direction of arrow (1). Indicator lamp (3) comes on.
- 1 The steering wheel heating may be suspended temporarily. However, indicator lamp (3) remains on. The steering wheel heating is suspended when the temperature of the vehicle interior is above 86°F (30°C). It is also suspended when the temperature of the steering wheel is above 95°F (35°C).

When these conditions do not apply anymore, steering wheel heating continues.

- ▶ Switching off: Turn switch at the tip of stalk in direction of arrow (2). Indicator lamp (3) goes out.
- 1 Indicator lamp (3) flashes or goes out in case of power surge or undervoltage or if the steering wheel heating malfunctions.
- 1 The steering wheel heating switches off automatically when you remove the SmartKey from the starter switch or, on vehicles with KEYLESS-GO, when you switch off the ignition and open the driver's door.

For more information on the steering wheel, see "Multifunction steering wheel" (⊳ page 110).

Mirrors

Notes

Adjust the interior and exterior rear view mirrors before driving so that you have a good view of the road and traffic conditions.

Interior rear view mirror

▶ Adjust the interior rear view mirror manually.

Exterior rear view mirrors

↑ Warning!

Exercise care when using the passenger-side exterior rear view mirror. The mirror surface is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your interior rear view mirror and glance over your shoulder before changing lanes.



- 1 You can store the settings for the exterior rear view mirror position with the memory function (⊳ page 85).
- ► Switch on the ignition.
- ▶ Press button (3) for the driver's side exterior rear view mirror or button (1) for the passenger-side exterior rear view mirror.
- ▶ Press adjustment button ② up, down, left or right according to the desired setting.
- If an exterior rear view mirror was forcibly hit from the front, manually snap it back into place.
- 1 At low ambient temperatures, the exterior rear view mirrors will be heated automatically.

Auto-dimming rear view mirrors

The exterior rear view mirror on the driver's side and the interior rear view mirror will respond automatically to glare when the

ignition is switched on and incoming light from headlamps falls on the sensor in the interior rear view mirror.

The rear view mirrors will not react if the automatic transmission is set to reverse gear **R** or the interior lighting is switched on.

The auto dimming function does not react if incoming light is not aimed directly at sensors in the interior rear view mirror.


The interior rear view mirror and the exterior rear view mirror on the driver's side do not react, for example, if the rear window sunshade is in raised position.

Light hitting the mirror(s) at certain angles (incident light) could blind you. As a result, you may not be able to observe traffic conditions and could cause an accident.

Exterior rear view mirror parking position

To assist during parking maneuvers, you can set the passenger-side exterior rear view mirror so that you can see the rear wheel and the road curb.

Setting and storing the parking position



- ► Switch on the ignition.
- ▶ Press button ①, to select the passengerside exterior rear view mirror.

- ► Shift the automatic transmission into reverse gear **R**.
 - The passenger-side exterior rear view mirror moves to the preset parking position.
- ► Adjust the passenger-side exterior rear view mirror with adjustment button ② so that you see the rear wheel and the road curb.
- ▶ Press memory button **M** ④ and within 3 seconds, press one of the arrows of adjustment button ②.

The parking position is stored if the exterior rear view mirror does not move.

Calling up the parking position

- ▶ Switch on the ignition.
- ► Press button ①, to select the passengerside exterior rear view mirror.
- ► Shift the automatic transmission into reverse gear **R**.

The passenger-side exterior rear view mirror moves to the stored parking position.

The passenger-side exterior rear view mirror returns to its previously stored driving position

- 10 seconds after you have put the gear selector lever out of reverse gear R
- immediately once your vehicle exceeds a speed of approximately 6 mph (10 km/h)
- immediately when you press button 3 to select the driver's side exterior rear view mirror

Memory function

Notes

With the memory function you can store up to three different configurations per front seat.

Each memory position button on the driver's side can store all of the following settings:


- Seat position
- Multicontour seat: previously saved settings
- Steering wheel position
- Exterior rear view mirrors' position

↑ Warning!

Do not activate the memory function while driving. Activating the memory function while driving could cause the driver to lose control of the vehicle.

Each memory position button on the front passenger side can store all of the following settings:

- Seat position
- · Multicontour seat: previously saved settings



Storing positions into memory

- ► Adjust the seats.
- ▶ On the driver's side, also adjust the steering wheel and exterior rear view mirrors to the desired positions.
- ▶ Press memory button **M** once and within 3 seconds press memory position button 1, 2 or 3.

When the settings are stored to the selected position, an acknowledgement signal sounds.

Recalling positions from memory

- ▶ Press and hold desired memory position button 1, 2 or 3 until the seat has moved to the stored position completely. On the driver's side, also wait for the steering wheel and exterior rear view mirrors to move to the stored position.
- Releasing the memory position button stops movement to the stored positions immediately.


Lighting

Notes

- 1 If you drive in countries with left-hand driving, you must have the headlamps modified for symmetrical low beams. Relevant information can be obtained at any authorized Mercedes-Benz Center.
- 1 Vehicles equipped with active Bi-Xenon headlamps:

The active Bi-Xenon headlamps increase usable illumination over conventional headlamps because they follow the curvature of the road ahead. The beams of the active Bi-Xenon headlamps shift to either side according to the vehicle's steering angle and speed.

Exterior lamp switch



- 1 ←P ≤ Standing lamps, left
- 2 P∈→ Standing lamps, right
- 3 0 Off
 - Daytime running lamp mode
- 4 Automatic headlamp mode Daytime running lamp mode
- 5 Parking lamps (also tail lamps, license plate lamps, side marker lamps and instrument panel lamps)
- 6 D Low-beam headlamps or high-beam headlamps
- 7 Front fog lamps
- 1 The exterior lamps (except standing lamps or parking lamps) go out automatically when you remove the SmartKey from the starter switch or open the driver's door with the ignition switched off.

When the parking lamps or the rear fog lamp are switched on and you remove the SmartKey from the starter switch and open the driver's door, an acoustic signal sounds.

In addition the message Switch Off Lights appears in the multifunction display.

Switch off the parking lamps or the rear fog lamp manually.

Failure to switch off the parking lamps when leaving the vehicle may result in a discharged battery.

Low-beam headlamps

The low-beam headlamps can be switched on and off with the exterior lamp switch.

- Switch on the ignition.
- ▶ Switching on: Turn the exterior lamp switch to position .

The following lamps come on:

- Low-beam headlamps
- Tail lamps
- Parking lamps
- License plate lamps
- Side marker lamps
- Instrument panel lamps
- Green indicator lamp [305] in the exterior lamp switch
- instrument cluster
- ► Switching off: Turn the exterior lamp switch to position **0**.

Automatic headlamp mode

The following lamps come on and go out automatically depending on the brightness of the ambient light:

- Low-beam headlamps
- Tail lamps
- Parking lamps
- License plate lamps
- Side marker lamps



Marning!

If the exterior lamp switch is set to AUTO, the headlamps will not automatically come on under foggy conditions.

To minimize risk to you and to others, activate headlamps by turning exterior lamp switch to when driving or when traffic and/or ambient lighting conditions require you to do so.

In low ambient lighting conditions, only switch from position AUTO to D with the vehicle at a standstill in a safe location. Switching from AUTO to D will briefly switch off the headlamps. Doing so while driving in low ambient lighting conditions may result in an accident.

The automatic headlamp feature is only an aid to the driver. The driver is responsible for the operation of the vehicle's lights at all times.

► **Switching on:** Turn the exterior lamp switch to position **AUTO**.

The following lamps come on and go out depending on the brightness of the ambient light with the SmartKey in starter switch position 1 or the KEYLESS-GO start/stop button pressed once:

- Tail lamps
- Parking lamps
- · License plate lamps
- Side marker lamps

When the engine is running, the low-beam headlamps will also come on and turn off automatically.

Daytime running lamp mode

In Canada, the daytime running lamp mode is mandatory and therefore in a constant mode. In the USA, the daytime running lamp mode is deactivated by default.

Activate the daytime running lamp mode using the control system, see "Switching

- daytime running lamp mode on or off (USA only)" (⊳ page 121).
- ► Turn the exterior lamp switch to position

 1 or Auto.

When the engine is running, the low-beam headlamps come on.

In low ambient lighting conditions, the following lamps will come on additionally:

- Tail lamps
- Parking lamps
- License plate lamps
- · Side marker lamps

With the daytime running lamp mode activated and the engine running, you cannot switch off the low-beam headlamps manually.

Canada only

With the exterior lamp switch in position or or auto, you cannot switch on the high-beam headlamps.

The high-beam flasher is available at all times.

► For nighttime driving turn the exterior lamp switch to position

to permit activation of the high-beam headlamps.

When the engine is running, and you

- shift from a driving position to park position P with the vehicle at a standstill or the parking brake is engaged, the low-beam headlamps will go out with a delay of 3 minutes
- turn the exterior lamp switch to position [300], the low-beam headlamps, the tail and parking lamps, the license plate lamps and the side marker lamps come on
- turn the exterior lamp switch to position
 , the manual headlamp mode has priority over the daytime running lamp mode

The corresponding exterior lamps come on (⊳ page 87).

USA only

You can only switch on the high-beam headlamps in low ambient lighting conditions. The high-beam flasher is available at all times.

► For nighttime driving turn the exterior lamp switch to position or **AUTO** to permit activation of the high-beam headlamps.

When the engine is running, and you turn the exterior lamp switch to position 3000 or (ID), the manual headlamp mode has priority over the daytime running lamp mode. The corresponding exterior lamps come on (⊳ page 87).

Fog lamps

Fog lamps cannot be switched on with the exterior lamp switch in position AUTO.

↑ Warning!

In low ambient lighting or foggy conditions, only switch from position AUTO to D with the vehicle at a standstill in a safe location. Switching from AUTO to D will briefly switch off the headlamps. Doing so while driving in low ambient lighting conditions may result in an accident.

Fog lamps will operate with the parking lamps and/or the low-beam headlamps on. Fog lamps should only be used in conjunction with low-beam headlamps. Consult your State or Province Motor Vehicle Regulations regarding permissible lamp operation.

- ▶ Switch on the ignition.
- ► Turn the exterior lamp switch to position ⇒00€ or 🗊 (> page 87).
- ▶ Switching on front fog lamps: Pull out the exterior lamp switch to first stop. The green indicator lamp [in the exterior lamp switch comes on.

- ▶ Switching on rear fog lamp: Pull out the exterior lamp switch to second stop. The rear fog lamp, the front fog lamps, the green 10 and the yellow indicator lamp of in the exterior lamp switch come on.
- ▶ Switching off front fog lamps/rear fog lamp: Push in the exterior lamp switch to its stop.

Locator lighting and night security illumination

Locator lighting and night security illumination are described in the "Control system" section, see "Switching locator lighting on or off" (⊳ page 121) and "Switching night security illumination (Headlamps delayed shut-off feature) on or off" (> page 122).

Combination switch



Turn signals

▶ Press the combination switch in direction of arrow (2) or (4). The corresponding turn signal indicator

lamp 🗘 or 🗘 in the instrument cluster flashes.

The combination switch resets automatically after major steering wheel movements.

To signal minor directional changes:

▶ Press the combination switch only to the point of resistance in direction of arrow ② or ④ and release.

The corresponding turn signal lamps will flash three times.

High beam

- ➤ Switching on: Push the combination switch in direction of arrow ①.

 The high-beam headlamp indicator lamp

 in the instrument cluster comes on.
- ► Switching off: Pull the combination switch in direction of arrow ③ to its original position.
- i Also note the information on high-beam headlamps with activated automatic headlamp mode (▷ page 87) or the daytime running lamp mode (▷ page 88).

High-beam flasher

► **Switching on:** Pull the combination switch briefly in direction of arrow ③.

Hazard warning flasher

The hazard warning flasher can be switched on at all times, even with the SmartKey removed from the starter switch.

The hazard warning flasher comes on automatically when an air bag deploys.

The hazard warning flasher switch is located on the center console.



- ► **Switching on:** Press hazard warning flasher switch ①.

 All turn signal lamps are flashing.
- With the hazard warning flasher activated and the combination switch set for either left or right turn, only the respective left or right turn signals will operate when the ignition is switched on.
- ► **Switching off:** Press hazard warning flasher switch (1) again.
- 1 If the hazard warning flasher has been activated automatically, press hazard warning flasher switch (1) to switch it off.

Headlamp cleaning system

The headlamps will be cleaned with a highpressure water jet automatically when the engine is running and you have

- switched on the headlamps and
- the windshield wipers have wiped the windshield with washer fluid five times

The counter resets when you switch off the ignition.

For information on filling up the washer reservoir, see "Washer system and headlamp cleaning system" (> page 181).

Corner-illuminating front fog lamps

Corner-illuminating front fog lamps are not available on vehicles with AMG Sport Package and on CLS 63 AMG.

The corner-illuminating front fog lamps improve illumination of the area in the direction into which you are turning.

The corner-illuminating front fog lamps will only operate

- in low ambient lighting conditions
- at vehicle speeds below 25 mph (40 km/h)
- with the front fog lamps switched off
- when the engine is running

Switching on

or

- ► Activate the daytime running lamp mode (> page 88).
- Switch on the left or right turn signal, depending on whether you are turning left or right.

The respective front fog lamp comes on. If you have switched on the turn signal for one side but turn the steering wheel in the other direction, the corner-illuminating front fog lamp on the side of the turn signal comes on.

or

► Turn the steering wheel in the desired direction.

Driving forward: The front fog lamp on the side of your steering direction comes on.

Driving in reverse: The front fog lamp opposite to your steering direction comes on.

The corner-illuminating front fog lamps will come on automatically depending on the steering angle, even if you did not switch on either turn signal. If the corner-illuminating front fog lamps came on automatically, they

will also go out automatically depending on the steering angle and vehicle speed.

The corner-illuminating front fog lamps temporarily come on on both sides of the vehicle if you turn the steering wheel in one direction and then again in the other direction shortly thereafter.

The corner-illuminating front fog lamp remains lit for a short time only. It then goes out automatically.

Switching off

- ► Switch off the left or right turn signal. or
- ► Steer straight ahead.
- 1 There may be a brief delay before the corner-illuminating front fog lamps go out.

Interior lighting in the front



- ① 🛣 Left front reading lamp on/off
- ② 🕞 Rear interior lighting on/off
- ③ 👸 Automatic control on/off
- ④ → Front interior lighting on/off

- 6 Interior lighting
- 7 Ambient lighting
- 8 Front reading lamps

Automatic control

- ► Activating: Press switch (≦).

 The interior lighting comes on in darkness, when you
 - · unlock the vehicle
 - remove the SmartKey from the starter switch (Interior Lighting Delayed Shut-off must be switched on (▷ page 123))
 - · open a door
 - open the trunk

The interior lighting goes out after a short time.

- If a door remains open, the interior lamps go out automatically after approximately 5 minutes.
- ▶ **Deactivating:** Press switch 🚡.

Manual control

- An interior lamp switched on manually does not go out automatically.

 Leaving an interior lamp switched on for an extended period of time with the engine turned off could result in a discharged battery.
- ► Switching front interior lighting on/ off: Press switch ____.
- ► Switching rear interior lighting on/off: Press switch 🕞.
- ► Switching front reading lamps on/off: Press respective switch 一流.

Ambient lighting

The brightness of the ambient lighting ⑦ is adjusted via the "Control system" (> page 122).

Interior lighting in the rear

An interior lamp switched on manually does not go out automatically.

Leaving an interior lamp switched on for an averaged period of time with the appropriate the continuous standard period of time with the appropriate the continuous standard period of time with the appropriate the same standard period of time with the appropriate the same standard period of time with the appropriate the same standard period of time with the appropriate the same standard period of time with the same standard period of time standard period of t

Leaving an interior lamp switched on for an extended period of time with the engine turned off could result in a discharged battery.



- ① T Left rear reading lamp on/off

Wipers


Notes

Do not operate the wipers when the windshield is dry. Dust that accumulates on a windshield might scratch the glass and/ or damage the wiper blades when wiping occurs on a dry windshield. If it is necessary to operate the wipers in dry weather conditions, always operate the wipers with washer fluid.

Windshield wipers

▶ Observe notes on page (> page 92).

Switching on/off



Combination switch

- 1 Windshield wipers off
- 2 Slow intermittent wiping⁵
- 3 Fast intermittent wiping⁶
- 4 Slow continuous wiping
- 5 Fast continuous wiping
- (6) Single wipe/ (5) Wiping with washer fluid
- ► Switch on the ignition.
- ► Turn the combination switch to the desired position, depending on the intensity of the rain.

Intermittent wiping

Only switch on intermittent wiping under wet weather conditions or in the presence of precipitation.

When you select intermittent wiping, the rain sensor is activated. The rain sensor sets a suitable wiping interval depending on the wetness of the sensor surface automatically.

Do not leave windshield wipers on an intermittent setting when the vehicle is taken to an automatic car wash or during windshield cleaning. Windshield wipers will operate in the presence of water sprayed on the windshield, and windshield wipers may be damaged as a result.

- If you have set intermittent wiping, dirt on the surface of the rain sensor or optical effects may cause the windshield wipers to wipe in an undesired fashion. This could then damage the windshield wiper blades or scratch the windshield. You should therefore switch off the windshield wipers when weather conditions are dry.
- ► Turn the combination switch to position or

After the initial wipe, pauses between wipes are controlled by the rain sensor automatically.

Intermittent wiping is interrupted when the vehicle is at a standstill and a front door is opened. This protects persons getting into or out of the vehicle from being sprayed.

Intermittent wiping will be continued when all doors are closed and

- the automatic transmission is in drive position D or reverse gear R
- the wiper setting is changed using the combination switch

Single wipe

▶ Press the combination switch briefly in direction of arrow ⑥ to the resistance point.

The windshield wipers wipe one time without washer fluid.

Wiping with washer fluid

- ▶ Press the combination switch in direction of arrow ⑥ past the resistance point. The windshield wipers operate with washer fluid.
- 1 To prevent smears on the windshield or noisy/chattering wiper blades, wipe with washer fluid every now and then even when it is raining.

⁵ Rain sensor operation with low sensitivity.

⁶ Rain sensor operation with high sensitivity.

For information on filling up the washer reservoir, see "Washer system and headlamp cleaning system" (⊳ page 181).

For information on cleaning the headlamps with washer fluid, see "Headlamp cleaning system" (⊳ page 90).

Problems with wipers

If anything blocks the windshield wipers (leaves, snow, etc.), switch them off immediately.

For safety reasons, do the following before attempting to remove any blockage:

- Stop the vehicle in a safe location.
- Remove the SmartKey from the starter switch.

or

- Turn off the engine by pressing the KEYLESS-GO start/stop button and open the driver's door (with the driver's door open, starter switch is in position **0**, same as with SmartKey removed from starter switch).
- Engage the parking brake.
- · Remove blockage.
- Turn the windshield wipers on again.

If the windshield wipers fail to function at all with the combination switch in position ••• or ••••,

- set the combination switch to the next higher wiper speed
- have the windshield wipers checked at the nearest authorized Mercedes-Benz Center

Power windows

Opening and closing

The door windows are opened and closed electrically. The switches for all door windows are located on the driver's door control panel. The switches for the respective door windows are located on the front passenger door and on the rear doors.

Operating the rear door windows from the rear is not possible when you activate the override switch (\triangleright page 56).

Observe Safety notes, see page 52.

↑ Warning!

When opening or closing the door windows, make sure there is no danger of anyone being harmed by the opening/closing procedure.

The door windows are equipped with the express operation and automatic reversal function. If in express operation mode a door window encounters an obstruction that blocks its path, the automatic reversal function will stop the door window and open it slightly.

The door windows operate differently when the switch is pulled and held. See the "Closing" when a door window is blocked" section in this chapter for details.

The closing of the door windows can be immediately halted by releasing the switch or, if the switch was pulled past the resistance point and released, by either pressing or pulling the respective switch.


If a door window encounters an obstruction that blocks its path in a circumstance where you are closing the door windows by pressing and holding button 🔒 on the SmartKey or by pressing and holding the lock button (vehicles with KEYLESS-GO) on an outside door handle, the automatic reversal function will not operate.

Activate the override switch when children are riding in the back seats of the vehicle. The children may otherwise injure themselves, e.g. by becoming trapped in the door window opening.

1 You can also open or close the door windows using the SmartKey, see "Summer opening feature" (> page 96)

and "Convenience closing feature" (⊳ page 96).

1 After switching off the ignition or removing the SmartKey from the starter switch, you can operate the door windows until you open the driver's or front passenger door. If no door was opened you can operate the door windows for up to 5 minutes.



- ▶ Switch on the ignition.
- ▶ Opening/closing: Press or pull and hold switch (1) to (4) to the resistance point. The corresponding door window moves downward or upward until you release the switch.
- ► Express operation: Press or pull switch (1) to (4) past the resistance point and release.

The corresponding door window opens or closes completely.

▶ Stopping during express operation: Press or pull the respective switch again.

Closing when a door window is blocked



Marning!

Make sure that nobody can become trapped and be seriously or even fatally injured when closing a door window with greater force or without automatic reversal function.

If the upward movement of a door window is blocked during the closing procedure, the door window will stop and open slightly.

▶ Immediately after the door window has stopped because it was blocked, pull and hold the respective switch upward until the door window is fully closed.

The door window closes with greater force.

If the door window is blocked again and opens slightly:

▶ Immediately after the door window was blocked, pull and hold the respective switch upward until the door window is fully

The door window closes without automatic reversal function.



↑ Warning!

Pulling and holding the switch to close the door window immediately after it had been blocked two times will cause the door window to close without any reversal function for as long as you hold the switch.

Synchronizing door windows

The door windows must be synchronized after the battery has been disconnected or if the door windows cannot be fully closed (express operation).

Each door window must be synchronized separately.

- ► Close all doors.
- ▶ Switch on the ignition.
- ▶ Pull and hold switch (1), (2), (3) or (4) (⊳ page 95) until the respective door window is closed.

The door window opens again slightly.

- ▶ Pull and hold the respective switch once more immediately until the door window is closed completely.
- ► Hold the respective switch for approximately 1 second. The door window is synchronized.

Summer opening feature

When the weather is warm, you can ventilate the vehicle before driving off by simultaneously

- opening the door windows
- opening the tilt/sliding sunroof
- switching on the seat ventilation for the driver's seat

The summer opening feature can only be activated via the remote control of the SmartKey. The SmartKey must be in close proximity to the driver's outside door handle.

- ▶ Aim the transmitter eye of the SmartKey at the driver's outside door handle.
- ▶ Press and hold button 🕡 on the SmartKey until the door windows and the tilt/sliding sunroof have reached the desired position.

The vehicle unlocks.

▶ Release button on the SmartKey to interrupt the opening procedure.

Convenience closing feature

When locking the vehicle, you can simultaneously close the door windows and the tilt/sliding sunroof.

Marning!

When closing the door windows and the tilt/ sliding sunroof, make sure there is no danger of anyone being harmed by the closing procedure.

If potential danger exists, proceed as follows:

 Release button to stop the closing procedure. To open, press and hold button . To continue the closing procedure after making sure that there is no danger of anyone being harmed by the closing procedure, press and hold button .

Vehicles with KEYLESS-GO:

- Release the lock button on the outside door handle to stop the closing procedure.
- Immediately pull on the same outside door handle and hold firmly. The door windows and the tilt/sliding sunroof will open for as long as the door handle is held but the door not opened.

With SmartKey

The SmartKey must be in close proximity to the driver's outside door handle.

- ▶ Aim transmitter eye of the SmartKey at the driver's outside door handle.
- ▶ Press and hold button 🔒 on the SmartKey until the door windows and the tilt/sliding sunroof are closed completely.

With KEYLESS-GO

The SmartKey with KEYLESS-GO must be located outside the vehicle within approximately 3 ft (1 m) of a door.

- Close all doors.
- Press and hold the lock button on an outside door handle (⊳ page 69) until the door windows and the tilt/sliding sunroof are closed completely.
- ► Release the lock button on the outside door handle to interrupt the closing procedure.

Driving and parking

Safety notes



Make sure absolutely no objects are obstructing the pedals' range of movement. Keep the driver's footwell clear of all obstacles. If there are any floormats or

carpets in the footwell, make sure the pedals still have sufficient clearance.

During sudden driving or braking maneuvers the objects could get caught between or under the pedals. You could then no longer brake or accelerate. This could lead to accidents and injury.



↑ Warning!

With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle. Adapt your driving accordingly.

Starting the engine




Marning!

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open at all times.

Automatic transmission



Gearshift pattern for automatic transmission

- P Park position with gear selector lever lock
- R Reverse gear
- N Neutral position
- D Drive position

For more information, see "Automatic transmission" (⊳ page 101).

▶ Make sure the automatic transmission is in park position P.

With SmartKey

- ▶ Do not depress the accelerator pedal.
- ► Turn the SmartKey in the starter switch to position 3 (⊳ page 76) and release it. The engine starts automatically.

With KEYLESS-GO




Marning!

As long as the SmartKey is in your vehicle, the vehicle can be started. Therefore, never leave children unattended in the vehicle, as they could otherwise accidentally start the engine.

When leaving the vehicle, always take the SmartKey with you and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. A child's unsupervised access to a vehicle could result in an accident and/or serious personal injury.

You can start your vehicle without the SmartKey in the starter switch using the KEYLESS-GO start/stop button.

The SmartKey must be located in the vehicle.



KEYLESS-GO start/stop button

- ① USA only
- ② Canada only
- ▶ Depress the brake pedal during the starting procedure.
- ▶ Do not depress the accelerator pedal.
- ► Press the KEYLESS-GO start/stop button once.

The engine starts automatically.

Starting difficulties

Remember that extended starting attempts can drain the battery.

The engine does not start. You can hear the starter.

There could be a malfunction in the engine electronics or in the fuel supply system.

Carry out the following steps:

▶ If you are starting the engine with the SmartKey: Turn the SmartKey in the starter

- switch to position **0** and repeat the starting procedure.
- ▶ If you are starting the engine with KEYLESS-GO: Close any doors that may be open to allow for better detection of the SmartKey.

- Start the engine with the SmartKey as radio signals from another source may be interfering with the KEYLESS-GO function.
- ► Repeat the starting procedure.

If the engine does not start after several starting attempts:

► Contact an authorized Mercedes-Benz Center or call Roadside Assistance.

The engine does not start. You cannot hear the starter.

The battery may not be charged sufficiently.

► Get a jump start (> page 280).

If the engine will not start despite a jump start:

► Contact an authorized Mercedes-Benz Center or call Roadside Assistance.

The starter has been exposed to excessive temperatures.

- ▶ Let the starter cool for about 2 minutes.
- ► Repeat the starting procedure.

If the engine does not start after several starting attempts:

▶ Contact an authorized Mercedes-Benz Center or call Roadside Assistance.

Driving off



/ Warning!

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

Do not run a cold engine at high engine speeds. Running a cold engine at high engine speeds may shorten the service life of the engine. This is not covered by the Mercedes-Benz Limited Warranty.

CLS 63 AMG: At engine temperatures below 68°F (20°C), the engine's maximum speed is restricted in order to protect it from damage. Avoid driving your vehicle at full speed when the engine is cold to prevent premature engine wear and/or diminished comfort.

If an acoustic warning sounds and the message Release Parking Brake appears in the multifunction display when driving off, you have forgotten to release the parking brake.

Release the parking brake.

- Avoid spinning of a drive wheel. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.
- I Simultaneously depressing the accelerator pedal and applying the brakes reduces engine performance and causes premature brake and drivetrain wear which is not covered by the Mercedes-Benz Limited Warranty.
- 1 Once the vehicle is in motion, the automatic central locking function engages and the locking knobs in the doors move down.

The automatic central locking function can be switched off (⊳ page 123).

Automatic transmission



Marning!

It is dangerous to shift the automatic transmission out of park position P or neutral position **N** if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate

quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

- Only shift the automatic transmission into reverse gear R or park position P when the vehicle is stopped. Otherwise the automatic transmission could be damaged.
- ▶ Depress the brake pedal. The gear selector lever lock is released.
- ▶ Shift the automatic transmission into drive position **D** or reverse gear **R**.
- **1** Shifting the automatic transmission out of park position P is only possible with the brake pedal depressed.

Only depressing the brake pedal releases the gear selector lever lock.

- ▶ Wait for the gear selection process to complete before setting the vehicle in
- ▶ If engaged, release the parking brake.
- ► Release the brake pedal.
- ► Carefully depress the accelerator pedal.

After a cold start, the automatic transmission shifts at a higher engine speed. This allows the catalytic converter to reach its operating temperature earlier.

For more information on driving, see "Driving instructions" (⊳ page 210).

Problems while driving

The engine runs erratically and misfires

- An ignition cable may be damaged.
- The engine electronics may not be operating properly.
- Unburned gasoline may have entered the catalytic converter and damaged it.

- Give very little gas.
- ► Have the problem checked at an authorized Mercedes-Benz Center as soon as possible.

The coolant temperature is above 248°F (120°C)

The coolant is too hot and is no longer cooling the engine.

- ▶ Stop the vehicle in a safe location as soon as possible.
- ► Turn off the engine immediately.
- ▶ Allow the engine and coolant to cool off.
- ▶ Check the coolant level and add coolant if necessary (⊳ page 180).

In case of accident

If the vehicle is leaking fuel:

- ▶ Do not start the engine under any circumstances.
- ▶ Exit the vehicle at a safe distance from the roadway.
- ▶ Notify local fire and/or police authorities.

If the extent of the damage cannot be determined:

► Contact an authorized Mercedes-Benz Center or call Roadside Assistance.

If no damage on major assemblies, fuel system, and engine mount can be determined:

▶ Start the engine in the usual manner.

Parking



Marning!

Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system. These materials could be ignited and cause a vehicle fire.

Vehicle movement may result in serious personal injury or damage to the vehicle or vehicle drivetrain. Therefore, always do the following before turning off the engine and leaving the vehicle:

- Keep right foot on the brake pedal.
- Engage the parking brake.
- Shift the automatic transmission into park position P.
- Slowly release the brake pedal.
- When parked on an incline, always turn the front wheels towards the road curb.
- Turn the SmartKey in the starter switch to position **0** and remove the SmartKey from the starter switch, or press the KEYLESS-GO start/stop button.
- Take the SmartKey with you and lock the vehicle when leaving.



Marning!

Vehicles with AIRMATIC:

If you have selected the Comfort suspension tuning, the vehicle lowers slightly when you lock it within approximately 60 seconds after turning off the engine. You should therefore make sure that no one is standing near the wheel arches or lying underneath the vehicle when it is being locked. Otherwise, personal injury could result.

Also, make sure your vehicle cannot come into contact with objects, such as a road curb, while lowering. Your vehicle could otherwise be damaged.

Parking brake




Marning!

Engaging the parking brake while the vehicle is in motion can cause the rear wheels to lock up. You could lose control of the vehicle and cause an accident. In addition, the vehicle's brake lights do not light up when the parking brake is engaged.

/ Warning!

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake and/or shift the automatic transmission out of park position P, either of which could result in an accident and/or serious personal injury.



- ▶ Releasing: Pull on release handle (1). When the ignition is switched on or the engine is running, the brake warning lamp BRAKE (USA only) or (1) (Canada only) in the instrument cluster goes out.
- ► Engaging: Step on parking brake pedal (2) firmly. When the engine is running, the brake warning lamp BRAKE (USA only) or (1) (Canada only) in the instrument cluster comes on.

Turning off the engine



Marning!

Do not turn off the engine before the vehicle has come to a complete stop. With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.

- ► Shift the automatic transmission into park position P.
- ► Engage the parking brake.
- 1 Always engage the parking brake in addition to shifting the automatic transmission into park position P.

With SmartKey

- ▶ Turn the SmartKey in the starter switch to position 0.
- ► Remove the SmartKey from the starter switch.

The SmartKey can only be removed from the starter switch with the automatic transmission in park position P.

With KEYLESS-GO

▶ Press the KEYLESS-GO start/stop button. With the driver's door closed, the starter switch is now in position 1. With the driver's door opened, the starter switch is set to position **0**, same as the SmartKey removed from the starter switch (\triangleright page 76).

If an acoustic warning sounds, you have tried to turn off the engine with the KEYLESS-GO start/stop button while the automatic transmission was not in park position P. Read and observe messages that may appear

in the multifunction display (⊳ page 235).

Automatic transmission

Introduction

For information on driving with an automatic transmission, see "Driving and parking" (⊳ page 96).



↑ Warning!

Make sure absolutely no objects are obstructing the pedals' range of movement. Keep the driver's footwell clear of all obstacles. If there are any floormats or

carpets in the footwell, make sure the pedals still have sufficient clearance.

During sudden driving or braking maneuvers the objects could get caught between or under the pedals. You could then no longer brake or accelerate. This could lead to accidents and injury.


Allow the engine to warm up under low load use. Do not place full load on the engine until the operating temperature has been reached.

Avoid spinning of a drive wheel for an extended period when driving off on slippery road surfaces.

This may cause serious damage to the engine and the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

① During the brief warm-up, transmission upshifting is delayed. This allows the catalytic converter to heat up more quickly to operating temperature.

Gear selector lever



Gearshift pattern for automatic transmission

- P Park position with gear selector lever lock
- R Reverse gear
- N Neutral position
- D Drive position

/ Warning!

It is dangerous to shift the automatic transmission out of park position P or neutral position **N** if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

- I Only shift the automatic transmission into reverse gear R or park position P when the vehicle is stopped. Otherwise the automatic transmission could be damaged.
- 1 Shifting the automatic transmission out of park position P is only possible with the brake pedal depressed.

Only depressing the brake pedal releases the gear selector lever lock.

1 The current gear selector lever position corresponds with the current transmission position.

The current transmission position P, R, N, or **D** appears in the multifunction display (⊳ page 103).

There are additional indicators on the cover of the shifting gate showing the current gear selector lever position.

The indicators come on when you insert the SmartKey into the starter switch, and go out when you remove the SmartKey from the starter switch.

Shifting procedure

The automatic transmission selects individual gears automatically, depending on

- the selected gear range (▷ page 104)
- the selected program mode:

C/S (⊳ page 105)

or

M (CLS 63 AMG only) (> page 107)

- the position of the accelerator pedal
- · the vehicle speed

With drive position **D** selected, you can influence transmission shifting by

- · limiting the gear range
- · extending the gear range
- changing the gears manually (CLS 63 AMG only)

CLS 63 AMG:

Double-clutching is active when downshifting in all program modes. Double-clutching reduces load-alteration effects and supports sporty driving. The degree to which you perceive double-clutching acoustically varies depending on the selected program mode.

Transmission positions

The current transmission position appears in the multifunction display.



① Transmission position indicator

Effect

P Par

Park position

Shift the automatic transmission into park position **P** only when the vehicle is stopped. The park position is not intended to serve as a brake when the vehicle is parked. Rather, the driver should always engage the parking brake in addition to shifting the automatic transmission into park position **P** to secure the vehicle.

The SmartKey can only be removed from the starter switch with the gear selector lever in park position **P**. With the SmartKey removed from the starter switch, the gear selector lever is locked in park position **P**. If the vehicle's electrical system is malfunctioning, the gear selector lever could remain locked in park position **P**. To unlock the gear selector lever manually, see "Manually unlocking the gear selector lever" (> page 263).

R Reverse gear

Shift the automatic transmission into reverse gear ${\bf R}$ only when the vehicle is stopped.

Effect



Neutral position

No power is transmitted from the engine to the drive axle. When the brakes are released, the vehicle can be moved freely (pushed or towed).

To avoid damage to the transmission, never shift the automatic transmission into neutral position N while driving.

Exception: If the ESP® is switched off or malfunctioning, shift the automatic transmission into neutral position N if the vehicle is in danger of skidding.

Coasting the vehicle, or driving for any other reason with the automatic transmission in neutral position N can result in transmission damage that is not covered by the Mercedes-Benz Limited Warranty.

D Drive position

The automatic transmission shifts automatically. All forward gears are available.

Driving tips

Kickdown

Use the kickdown when you want maximum acceleration.

► U.S. vehicles except AMG vehicles:

Fully depress the accelerator pedal. Depending on the engine speed the automatic transmission shifts into a lower gear.

► Canada vehicles and AMG vehicles:

Depress the accelerator pedal past the point of resistance.

Depending on the engine speed the automatic transmission shifts into a lower gear.

Working on the vehicle



/ Warning!

When working on the vehicle, engage the parking brake and shift the automatic transmission into park position **P**. Otherwise the vehicle could roll away which could result in an accident and/or serious personal injury.

Gear ranges

With the automatic transmission in drive position **D** and driving in automatic program mode C or S, you can limit or extend the gear range, see "One-touch gearshifting" (⊳ page 105).

The current gear range appears in the multifunction display.



Gear range indicator

Effect



With this selection you can use the braking effect of the engine.



Allows the use of the engine's braking effect when driving

- on steep downgrades
- in mountainous regions
- under extreme operating conditions



For maximum use of the engine's braking effect on very steep or lengthy downgrades.

Automatic shift program



Program mode selector switch


C Comfort	For comfort driving
S Sport	For sporty driving



Program mode selector switch on CLS 63 AMG

C Comfort	For standard driving
S Sport	For sporty driving
M Manual	For manual gearshifting

The current program mode appears in the multifunction display.



(1) Program mode indicator

You should only change the program mode when the automatic transmission is in park position **P**.

Automatic program mode **S** will not be stored. When the engine is turned off with the automatic program mode **S** selected, the automatic transmission will go to the automatic program mode **C** when the engine is restarted.

▶ Press the program mode selector switch repeatedly until the letter of the desired program mode appears in the multifunction display.

Selecting program mode **C** means:

- The vehicle starts out more gentle, both forward and reverse, except when driving off with full throttle.
- Traction and driving stability are improved on icy roads.
- Upshifts occur earlier even when you give more gas. The engine then operates at lower revolutions and the wheels are less likely to spin.

Selecting program mode **S** means that upshifts occur later.

One-touch gearshifting

With the automatic transmission in drive position ${\bf D}$ and driving in automatic program

mode C or S, you can limit or extend the gear range using the gear selector lever or the steering wheel gearshift control.

Steering wheel gearshift control is available on vehicles with AMG Sport Package and on CLS 63 AMG only.

CLS 63 AMG: For information on using the gear selector lever or the steering wheel gearshift control in manual program mode M, see "Manual shift program" (⊳ page 107).



Steering wheel gearshift control (example illustration)

1 You cannot shift with the steering wheel gearshift control when the automatic transmission is in park position P, neutral position N, or reverse gear R.

Limiting gear range



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

▶ Briefly press the gear selector lever to the left in the D- direction.

or

▶ Briefly pull left gearshift control (1). The automatic transmission will shift into the next lower gear as permitted by the shift program. This action simultaneously

- limits the gear range of the automatic transmission.
- 1 To avoid overrevving the engine when downshifting, the automatic transmission will not shift into a lower gear if the engine's maximum speed would be exceeded.

Extending gear range

▶ Briefly press the gear selector lever to the right in the **D+** direction.

or

- ▶ Briefly pull right gearshift control ②. The automatic transmission will shift into the next higher gear as permitted by the shift program. This action simultaneously extends the gear range of the automatic transmission.
- f you press on the accelerator pedal when the engine has reached the revolution limit of the current gear range, the automatic transmission will upshift beyond any gear range limit selected.

Canceling gear range limit

▶ Press and hold the gear selector lever to the right in the D+ direction until D reappears in the multifunction display.

or

▶ Pull and hold right gearshift control ② until D reappears in the multifunction display. The automatic transmission will shift from the current gear range directly into drive position **D**.

Shifting into optimal gear range

▶ Press and hold the gear selector lever to the left in the D- direction.

or

▶ Pull and hold left gearshift control (1). The automatic transmission will select the gear range suited for optimal acceleration and deceleration automatically. This will involve shifting down one or more gears.

Manual shift program

The manual shift program is available on CLS 63 AMG only.

Manual program mode **M** differs with regard to spontaneity, response time, and shifting smoothness from automatic program mode **S**.

In manual program mode **M**, system-controlled automatic gearshifting is switched off. You need to change the gears by manually upshifting or downshifting using the gear selector lever or the steering wheel gearshift control.



Program mode selector switch on CLS 63 AMG

C Comfort	For standard driving
S Sport	For sporty driving
M Manual	For manual gearshifting

The current program mode appears in the multifunction display (\triangleright page 105).

For information on automatic program mode (**C** or **S**), see "Automatic shift program" (> page 105) and "One-touch gearshifting" (> page 105).

Activating manual shift program

Press the program mode selector switch repeatedly until M appears in the multifunction display.

The automatic transmission switches to manual program mode ${\bf M}$. Automatic

shifting is switched off. The gear range is not limited.

You can change the gears manually with drive position **D** selected. You can upshift or downshift through the gears in succession.

1 Manual program mode M will not be stored. When the engine is turned off with manual program mode M selected, the automatic transmission will go to automatic program mode C when the engine is restarted.

Upshifting

- In manual program mode M, the automatic transmission will not upshift, even if the engine has reached its overrevving range. Shift up into the next gear before the engine has reached its overrevving range. Make absolutely certain that the engine speed does not reach the red marking on the tachometer. Otherwise the engine could be damaged which is not covered by the Mercedes-Benz Limited Warranty.
- ► Briefly press the gear selector lever to the right in the **D+** direction.

٥r

▶ Briefly pull right gearshift control ②(▷ page 106).

The automatic transmission shifts into the next higher gear.

Upshift indicator



In manual program mode **M**, upshift indicator ② in the multifunction display advises you to upshift before the engine reaches the overspeed range. In addition, symbol ^ may appear instead of manual

program mode symbol M in the multifunction display. Thus you can drive at the maximum engine speed for each gear without overrevving the engine.

▶ Shift the automatic transmission from current gear (1) into the next higher gear. The fuel supply will otherwise be interrupted to prevent the engine from overrevving.

Downshifting

Marning!

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

▶ Briefly press the gear selector lever to the left in the **D**- direction.

or

- ▶ Briefly pull left gearshift control ① (⊳ page 106). The automatic transmission shifts into the next lower gear.
- for maximum acceleration, press and hold the gear selector lever to the left in the **D**- direction or pull and hold the left gearshift control. Depending on the engine speed the automatic transmission selects the optimal gear for maximum acceleration.
- When you brake or stop, the automatic transmission shifts down into a gear from which you can easily accelerate or take off.

Kickdown

Using the kickdown while driving in manual program mode M is not possible.

Deactivating manual shift program

▶ Press the program mode selector switch repeatedly until C or S appears in the multifunction display.

or

► Restart the engine. The automatic transmission will go to automatic program mode C.

Manual program mode **M** is not stored.

Emergency operation (limp-home mode)

If vehicle acceleration becomes less responsive or sluggish or the automatic transmission no longer shifts, the automatic transmission is most likely operating in limphome (emergency operation) mode. In this mode only second gear and reverse gear R can be selected.

- ▶ Stop the vehicle in a safe location.
- ► Shift the automatic transmission into park position **P**.
- ► Turn off the engine.
- ▶ Wait at least 10 seconds before restarting.
- ► Restart the engine.
- ▶ Shift the automatic transmission into drive position **D** (for second gear) or reverse gear R.
- ▶ Have the automatic transmission checked at an authorized Mercedes-Benz Center as soon as possible.

Instrument cluster

Introduction

For a full view illustration of the instrument cluster, see "Instrument cluster" (⊳ page 28).


No messages will be displayed if either the instrument cluster or the multifunction display is inoperative.

As a result, you will not be able to see information about your driving conditions, such as

- speed
- · outside temperature
- warning/indicator lamps
- malfunction/warning messages
- · failure of any systems

Driving characteristics may be impaired.

If you must continue to drive, do so with added caution. Contact an authorized Mercedes-Benz Center as soon as possible.



Reset button

For information on changing the instrument cluster settings, e.g. the language, see (⊳ page 119).

Activating the instrument cluster

The instrument cluster is activated when you

- open a front door
- switch on the ignition
- press reset button (1)
- switch on the exterior lamps

Adjusting the instrument cluster illumination

- ► To brighten illumination: Turn reset button (1) clockwise until the desired level of illumination is reached.
- ▶ To dim illumination: Turn reset button (1) counterclockwise until the desired level of illumination is reached.
- 1 The instrument cluster illumination is dimmed or brightened automatically to suit ambient light conditions.

The instrument cluster illumination will also be adjusted automatically when you switch on the vehicle's exterior lamps.

Coolant temperature indicator



Marning!

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

During severe operating conditions, e.g. stopand-go traffic, the coolant temperature may rise close to 248°F (120°C).

Excessive coolant temperature triggers a warning in the multifunction display and the red coolant temperature warning lamp Limit in the instrument cluster comes

The engine should not be operated with a coolant temperature above 248°F (120°C). Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

Resetting trip odometer

- ▶ Make sure you are viewing the standard display (⊳ page 112) in the multifunction display.
- ▶ Press and hold the reset button in the instrument cluster (⊳ page 108) until the trip odometer is reset.

Tachometer

The red marking on the tachometer (⊳ page 28) denotes excessive engine speed.

Avoid driving at excessive engine speeds, as it may result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

To help protect the engine, the fuel supply is interrupted if the engine is operated within the red marking.

Control system

Introduction

The control system is activated as soon as the starter switch is in position 1.

The control system enables you to call up information about your vehicle and to change vehicle settings.

For example, you can use the control system to find out when your vehicle is next due for maintenance service, to set the language for messages in the instrument cluster display, and much more.



/ Warning!

A driver's attention to the road and traffic conditions must always be his/her primary focus when driving.

For your safety and the safety of others, selecting features through the multifunction steering wheel should only be done by the


driver when traffic and road conditions permit it to be done safely.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

The control system relays information to the multifunction display.

Multifunction steering wheel

The displays in the multifunction display and the settings in the control system are controlled by using the buttons on the multifunction steering wheel.



- Multifunction display
- Press button

to select submenus in the Settings menu

to set values

to operate the RACETIMER⁷ to set the volume

Press button



to answer a call

to dial8

to redial



to end a call

to reject an incoming call



Press button



to select next or previous menu

Press button briefly



to move within a menu

Within Audio/DVD menu to select previous or next track, scene or stored station

Within **Telephone** menu to switch to the phone book and select a name or number

Press and hold button



 Within Audio / DVD menu to select previous or next track with quick search or to select previous or next station in station list or wave band Within **Telephone** menu to

start the quick search in the phone book

Depending on the selected menu, pressing the buttons on the multifunction steering wheel will alter what appears in the multifunction display.

The information available in the multifunction. display is arranged in menus and accompanying functions and submenus.

The individual functions are then found within the relevant menu (radio or CD operations under Audio/DVD menu, for example). These functions serve to call up relevant information or to customize the settings for your vehicle.

8 Function only available in telephone menu.


It is helpful to think of the menus, and the functions within each menu, as being arranged in a circular pattern.

- ▶ Press button 🗊 or 🛅 repeatedly to pass through each menu one after the other.
- ▶ Press button 🔯 or 🛆 repeatedly to pass through each function display, one after the other, in the current menu.

In the Settings menu, instead of functions, you will find a number of submenus for calling up and changing settings. For instructions on using these submenus, see "Settings menu" (⊳ page 118).

The number of menus available in the system depends on which optional equipment is installed in your vehicle.


Multifunction display



- 1) Outside temperature indicator
- (2) Trip odometer
- (3) Automatic transmission program mode indicator
- 4 Transmission position/gear range indicator
- (5) Main odometer

For more information on menus displayed in the multifunction display, see "Menus and submenus" (⊳ page 112).

Menus and submenus



i The headings used in the menus table are designed to facilitate navigation within the system and are not necessarily identical to those shown in the multifunction display. The first function displayed in each menu will automatically show you which part of the system you are in.

	Function
1	Standard display menu (> page 112)
2	AMG ⁹ menu (⊳ page 113)
3	Audio/DVD menu (⊳ page 116)
4	Navigation menu (⊳ page 117)
5	Distronic menu (⊳ page 117)
6	Vehicle status message memory ¹⁰ menu (⊳ page 117)
7	Settings menu (⊳ page 118)

Function

- Trip computer menu (⊳ page 124)
- Telephone menu (⊳ page 125)

Standard display menu

You can select whether the digital speedometer or the outside temperature appears in the standard display (> page 120).



Standard display

- ① Basic display with outside temperature
- ② Trip odometer

⁹ AMG vehicles only.

¹⁰ The vehicle status message memory menu is only displayed if there is a message stored.

- ▶ If you see another display, press button

 or repeatedly until the standard display appears.
- ▶ Press button or to select the functions in the **Standard display** menu.

The following functions are available:

- Restarting the tire pressure loss warning system (▷ page 187) (Canada only)
- Restarting the TPMS (▷ page 189) (USA only)
- Checking tire inflation pressure with the Advanced TPMS (> page 190) (Canada only)
- Calling up digital speedometer or outside temperature (▷ page 113)
- Calling up maintenance service indicator display (▷ page 215)

Calling up digital speedometer or outside temperature

Depending on the chosen setting for the standard display (> page 120) you can call up the other display here.

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.

▶ Press button or repeatedly until the digital speedometer or the outside temperature appears in the multifunction display.




- 1 Basic display with digital speedometer
- ② Status line display with outside temperature
- 3 Trip odometer

You can select whether the digital speedometer or the outside temperature appears in the status line display (> page 120).

AMG menu

This function is only available in AMG vehicles.

► Press button or repeatedly until the **AMG** menu appears in the multifunction display.



The main screen of the **AMG** menu shows you the gear currently engaged ① as well as the engine oil temperature ②.


The engine oil temperature flashes if the engine oil temperature has not yet reached 80°C. During this time, avoid driving at full engine speed.

If the engine reaches the overspeed range in the manual shift program, the menu will be shown in red. In addition, you will see UP next to gear indicator ① as a reminder to upshift. Use buttons \bigcirc or \bigcirc to select the following functions in the **AMG** menu:

- Vehicle supply voltage (> page 114)
- RACETIMER (> page 114)
- Overall analysis (> page 115)
- Lap analysis (> page 115)

Vehicle supply voltage

- ▶ Press button ☐ or ☐ repeatedly until the **AMG** menu appears in the multifunction display.
- ► Press button repeatedly until the vehicle supply voltage appears in the multifunction display.



- (1) Gear indicator
- ② Vehicle supply voltage indicator


RACETIMER

Marning!

The RACETIMER feature is only for use on roads and in conditions where high speed driving is permitted. Racing on public roads is prohibited under all circumstances. The driver is and must always remain responsible for following posted speed limits.

The RACETIMER allows you to time and save driving stretches.

- ► Press button or repeatedly until the **AMG** menu appears in the multifunction display.



- 1 Gear indicator
- ② RACETIMER
- 3 Lap number

You can start the RACETIMER when the engine is running or the starter switch is in position **2** (\triangleright page 76).

While the RACETIMER is being displayed, you cannot adjust the audio volume using buttons + or -.

- ▶ **Starting:** Press button + .
- ➤ Displaying intermediate time: Press button while the timer is running. The intermediate time is shown for 5 seconds.
- ▶ **Stopping:** Press button + .

When you stop the vehicle and turn the SmartKey to position 1 (▷ page 76) or, in vehicles with KEYLESS-GO, turn off the engine and do not open the driver's door, the RACETIMER stops timing. Timing is resumed when you press button + after switching the ignition back on or restarting the engine.

Saving lap time and starting a new lap

You can save up to nine laps.

- ► Press button while the timer is running.
 - The intermediate time will be shown for 5 seconds.
- ▶ Press button within 5 seconds. The intermediate time shown will be saved as a lap time.

The RACETIMER begins timing the new lap. The new lap begins to be timed as soon as the intermediate time is called up.



- Gear indicator
- ② RACETIMER
- 3 Best lap time
- 4 Lap number

Resetting current lap

- ► Press button + while the timer is running.
 The timer stops.
- ► Press button ___.

 The lap time is reset to "0".

Deleting all laps


It is not possible to delete a single saved lap. When you turn off the engine, the RACETIMER will be reset to "0" after 30 seconds. All laps are deleted.

- ► Press button + while the timer is running.
 The timer stops.
- ► Press the reset button in the instrument cluster twice (> page 109).
- Press button +... The timer starts. The saved laps are deleted.

Overall analysis

This function is only available if you have saved at least one lap and have stopped the RACETIMER.

- ► Press button or repeatedly until the **AMG** menu appears in the multifunction display.
- ▶ Press button repeatedly until the overall analysis appears in the multifunction display.




- ① Overall analysis of RACETIMER
- ② Overall driving time
- (3) Maximum speed
- (4) Overall distance driven
- (5) Average speed

Lap analysis

This function is only available if you have saved at least two laps and have stopped the RACETIMER.

- ► Press button or repeatedly until the **AMG** menu appears in the multifunction display.
- ▶ Press button repeatedly until the lap analysis appears in the multifunction display.

Each lap is shown in its own submenu. The fastest lap is indicated by flashing symbol ①.



- 1 Lap number
- ② Lap time
- ③ Maximum speed during lap
- 4 Lap length
- ⑤ Average speed during lap
- ▶ Press button or to see other lap analyses.

Audio/DVD menu

The functions in the **Audio/DVD** menu operate the audio or video equipment which you have currently switched on.

The following functions are available:

- Selecting radio station (⊳ page 116)
- Operating audio devices/audio media (▷ page 116)
- Operating video DVD (⊳ page 117)


If no audio equipment is currently switched on, the message ${\tt AUDIO}\ {\tt Off}$ appears in the multifunction display.

Selecting radio station

1 The SIRIUS XM Satellite Radio is treated as a radio application.

Additional optional satellite radio equipment and a subscription to a satellite radio service provider are required for satellite radio operation. Contact an authorized Mercedes-Benz Center for details and availability for your vehicle. For more information, refer to separate COMAND system operating instructions.

- ► Switch on the COMAND system and select radio. Refer to separate COMAND system operating instructions.
- ► Press button or repeatedly until the currently tuned station appears in the multifunction display.



Example illustration

- ① Wave band setting
- ② Station frequency

- ➤ Selecting next or previous stored station: Press button ☑ or ☑ briefly to select a stored station.
- ► Selecting next or previous station in the station list: Press and hold button or to select a station.
- ► Selecting next or previous station in wave band (Only if no station list is available): Press and hold button

 to select a station.

You can only store new stations using the corresponding feature on the radio. Refer to separate COMAND system operating instructions.

You can also operate the radio in the usual manner.

Operating audio devices/audio media

- Switch on the COMAND system and select the audio device or audio media. Refer to separate COMAND system operating instructions.
- ► Press button ☐ or ☐ repeatedly until the Audio/DVD menu appears in the multifunction display.



Example illustration

- 1) Disc number
- ② Current track
- ► Selecting next or previous track: Press button ♂ or △ briefly.

The current track does not appear during Audio AUX mode operation.

Operating video DVD

- Switch on the COMAND system and select DVD-Video. Refer to separate COMAND system operating instructions.
- ► Press button or repeatedly until the **Audio/DVD** menu appears in the multifunction display.



- 1) Disc number
- ② Current scene
- ▶ Press button or to select a scene.

Navigation menu

The **Navigation** menu contains the functions needed to operate your navigation system.

▶ Press button or repeatedly until the **Navigation** menu appears in the multifunction display.

The message shown in the multifunction display depends on the status of the navigation system:

- With the COMAND system switched off, the message NAVI Off appears in the multifunction display.
- With the COMAND system switched on but route guidance not activated, the direction of travel and, if applicable, the name of the street currently traveled on appear in the multifunction display.
- With the COMAND system switched on and route guidance activated, the direction of travel and maneuver instructions appear in the multifunction display.

Please refer to separate COMAND system operating instructions for instructions on how to activate the route guidance system.

Distronic menu

Use the **Distronic** menu to display the current settings for your Distronic system. The information shown in the multifunction display depends on whether the Distronic system is activated or deactivated.

Please refer to the "Driving systems" section of this manual (▷ page 129) for instructions on how to activate Distronic.

Vehicle status message memory menu

Use the **Vehicle status message memory** menu to scan malfunction and warning messages that may be stored in the memory. Such messages appear in the multifunction display and are based on conditions or system status the vehicle's system has recorded.

The **Vehicle status message memory** menu only appears if messages have been stored.

Malfunction and warning messages are only indicated for certain systems and are intentionally not very detailed. The malfunction and warning messages are simply a reminder with respect to the operation of certain systems. They do not replace the owner's and/or driver's responsibility to maintain the vehicle's operating safety. Have all required maintenance and safety checks performed on the vehicle. Bring the vehicle to an authorized Mercedes-Benz Center to address the malfunction and warning messages.

▶ Press button ☐ or ☐ repeatedly until the Vehicle status message memory menu appears in the multifunction display. If conditions have occurred causing status messages to be recorded, the number of messages appears in the multifunction display.



▶ Press button 🗘 or 🔯.

The stored messages will now be displayed in the order in which they have occurred. For malfunction and warning messages, see "Vehicle status messages in the multifunction display" (> page 228).

Should the vehicle's system record any conditions while driving, the number of messages will reappear in the multifunction display when the SmartKey in the starter switch is turned to position **0** or removed from the starter switch. With KEYLESS-GO, the number of messages will reappear when you turn off the engine by pressing the KEYLESS-GO start/stop button and open the driver's door.

Except for high-priority messages, the vehicle status message memory will be cleared when you switch off the ignition.

Settings menu

Introduction

In the Settings menu there are two functions: The function To reset, press reset button for 3 seconds., with which you can reset all the settings to the original factory settings and a collection of submenus with which you can make individual settings for your vehicle.

The following settings and submenus are available in the Settings menu:

- Resetting to factory settings (> page 118)
- Submenus in the Settings menu
 (▷ page 119)
- Instrument cluster submenu
 (▷ page 119)
- Lighting submenu (▷ page 121)
- Vehicle submenu (> page 123)
- Convenience submenu (⊳ page 124)

Resetting to factory settings

You can reset the settings of all submenus to the factory settings.

For safety reasons, the function Headlamp Mode in the Lighting submenu cannot be reset while driving.

► Press button or repeatedly until the Settings menu appears in the multifunction display.



Press the reset button in the instrument cluster (▷ page 108) for approximately 3 seconds.

The request to press the reset button once more to confirm appears in the multifunction display.

▶ Press the reset button once more.

The settings you have changed will not be reset unless you confirm the action by pressing the reset button a second time. After approximately 5 seconds, the Settings menu reappears in the multifunction display.

Submenus in the Settings menu

- ► Press button or repeatedly until the Settings menu appears in the multifunction display.



- ▶ Press button —.
 The selection marker moves to the next submenu.
- ► Scroll down with button ___, scroll up with button ___.
- ► With the selection marker on the desired submenu, use button △ to access the individual functions within that submenu.
- ► Once within the submenu, use button

 to move to the next function or button

 to move to the previous function

 within that submenu.
- ► Use button + or to change the settings of the respective function.

The following lists show what settings can be changed within the various menus. Detailed instructions on making individual settings can be found on the following pages.

Instrument cluster submenu

- Selecting speedometer display mode (▷ page 120)
- Selecting language (▷ page 120)

- Selecting display (speed or outside temperature) for status line (▷ page 120)
- Selecting display (speed or outside temperature) for standard display (> page 120)

Lighting submenu

- Switching daytime running lamp mode on or off (USA only) (▷ page 121)
- Switching locator lighting on or off (> page 121)
- Setting ambient lighting (> page 122)
- Switching night security illumination (Headlamps delayed shut-off feature) on or off (▷ page 122)
- Switching interior lighting delayed shut-off on or off (> page 123)

Vehicle submenu

 Switching automatic central locking on or off (⊳ page 123)

Convenience submenu

Activating easy-entry/exit feature
 (▷ page 124)

Instrument cluster submenu

Access the Instr. Cluster submenu via the Settings menu. Use the Instr. Cluster submenu to change the instrument cluster display settings.

The following functions are available:

- Selecting speedometer display mode (▷ page 120)
- Selecting language (> page 120)
- Selecting display (speed or outside temperature) for status line (▷ page 120)
- Selecting display (speed or outside temperature) for standard display (> page 120)

Selecting speedometer display mode

- ► Press button ☐ or ☐ repeatedly until the Settings menu appears in the multifunction display.
- ► Move the selection marker with button

 + or to the Instr. Cluster submenu.
- ► Press button or repeatedly until the message Display Unit Speed-/ Odometer appears in the multifunction display.

The selection marker is on the current setting.



► Press button + or - to set speedometer unit to Km or Miles.

Selecting language

- ► Press button or repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button 🗘.
- ► Press button or repeatedly until the message Language appears in the multifunction display.


The selection marker is on the current setting.



▶ Press button + or - to select the language to be used for the multifunction display messages.

Selecting display (speed or outside temperature) for status line

- ► Press button or repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button <a> □.
- ► Press button or repeatedly until the message Status Line Display appears in the multifunction display. The selection marker is on the current setting.



► Press button + or - to select the status line to Speed or Outside Temp.. You will see the status line display when you have called up a different display from the standard display.

Selecting display (speed or outside temperature) for standard display

- ► Press button or repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button <a> □.
- ► Move the selection marker with button

 + or to the Instr. Cluster submenu.
- ► Press button or repeatedly until the message Basic Display appears in the multifunction display. The selection marker is on the current setting.



▶ Press button + or - to select the display shown in the standard display. The other display now appears in the **Standard display** menu (▷ page 112).

Lighting submenu

Access the Lighting submenu via the Settings menu. Use the Lighting submenu to change the lamp and lighting settings on your vehicle.

The following functions are available:

- Switching daytime running lamp mode on or off (USA only) (▷ page 121)
- Switching locator lighting on or off (> page 121)
- Setting ambient lighting (▷ page 122)
- Switching night security illumination (Headlamps delayed shut-off feature) on or off (> page 122)
- Switching interior lighting delayed shut-off on or off (⊳ page 123)

Switching daytime running lamp mode on or off (USA only)

- ▶ Press button ☐ or ☐ repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button <a> □.
- ► Move the selection marker with button

 + or to the Lighting submenu.
- ► Press button or repeatedly until the message Headlamp Mode appears in the multifunction display.

The selection marker is on the current setting.



▶ Press button + or - to select manual operation (Manual) or daytime running lamp mode (Constant).

With daytime running lamp mode switched on and the exterior lamp switch in position or auto, the low-beam headlamps are switched on when the engine is running.

In low ambient light conditions the following lamps will come on additionally:

- Parking lamps
- Tail lamps
- License plate lamps
- Side marker lamps

For more information on the daytime running lamp mode, see (▷ page 88).

For safety reasons, resetting all the functions of all submenus to the factory settings while driving (▷ page 118) will not deactivate the daytime running lamp mode.

The following message appears in the multifunction display:

Lighting - Cannot be completely reset to factory settings while driving.

Switching locator lighting on or off

With the locator lighting feature activated and the exterior lamp switch in position [AUTO], the following lamps will come on during darkness when the vehicle is unlocked using button on the SmartKey:

- Parking lamps
- Tail lamps
- License plate lamps

- · Side marker lamps
- Front fog lamps

The locator lighting goes out when the driver's door is opened.

If you do not open the driver's door after unlocking the vehicle with the SmartKey, the lamps will go out automatically after approximately 40 seconds.

- ▶ Press button or repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button 🗘.
- ► Move the selection marker with button

 → or to the Lighting submenu.
- ▶ Press button or repeatedly until the message Surround Light. Function appears in the multifunction display.

The selection marker is on the current setting.



- ► Press button + or to switch the locator lighting function 0n or 0ff.
- ► Turn the exterior lamp switch to position **AUTO** when exiting the vehicle.

 The locator lighting feature is activated.

Setting ambient lighting

Use this function to adjust the brightness of the ambient lighting.

- ► Press button ☐ or ☐ repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button 🗘.

- Move the selection marker with button+ or − to the Lighting submenu.
- ► Press button or repeatedly until the message Ambient Light Level appears in the multifunction display. The selection marker is on the current setting.



▶ Press button + or - to select the desired brightness of the ambient lighting. The setting 1 represents the darkest level and setting 5 the brightest level. The ambient light is switched off at setting 0.

Switching night security illumination (Headlamps delayed shut-off feature) on or off

Use this function to set whether you would like the exterior lamps to remain on for 15 seconds during darkness after exiting the vehicle and closing all doors.

With the headlamps delayed shut-off feature activated and the exterior lamp switch in position Auto before the engine is turned off, the following lamps will come on when the engine is turned off:

- Parking lamps
- Tail lamps
- License plate lamps
- Side marker lamps
- · Front fog lamps

If, after turning off the engine, you do not open a door or do not close an opened door, the lamps will automatically go out after 60 seconds.

- ► Press button ☐ or ☐ repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button 🗘 .
- Move the selection marker with button+ or − to the Lighting submenu.
- ▶ Press button or repeatedly until the message Headlamps Delayed Shutoff appears in the multifunction display. The selection marker is on the current setting.



- ► Press button + or − to switch the headlamps delayed shut-off feature 0n or 0ff.
- ► Turn the exterior lamp switch to position

 AUTO before turning off the engine.

 The headlamps delayed shut-off feature is activated.

You can temporarily deactivate the headlamps delayed shut-off feature:

- Before exiting the vehicle, turn the SmartKey in the starter switch to position 0.
- ► Then turn it to position 2 and back to position 0.

The headlamps delayed shut-off feature is deactivated. It will reactivate as soon as you start the engine.

Switching interior lighting delayed shutoff on or off

Use this function to set whether you would like the interior lighting to remain on for 10 seconds during darkness after you have removed the SmartKey from the starter switch.

- ► Press button or repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button <a> □.
- ► Press button △ or ▽ repeatedly until the message Interior Lighting Delayed Shut-off appears in the multifunction display.

The selection marker is on the current setting.



► Press button + or - to switch the interior lighting delayed shut-off feature On or Off.

Vehicle submenu

Access the Vehicle submenu via the Settings menu. Use the Vehicle submenu to set the automatic central locking.

Switching automatic central locking on or off

Use this function to switch the automatic central locking on or off. With the automatic central locking activated, the vehicle is locked centrally at a vehicle speed of approximately 9 mph (15 km/h).

- ▶ Press button ☐ or ☐ repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button <a> □.

- ▶ Move the selection marker with button + or - to the Vehicle submenu.
- ▶ Press button 🗘 or 💎 repeatedly until the message Automatic Door Locking appears in the multifunction display. The selection marker is on the current setting.



▶ Press button 🛨 or 🛑 to switch the automatic central locking On or Off.

Convenience submenu

Access the Convenience submenu via the Settings menu. Use the Convenience submenu to activate the easy-entry/exit feature.

Activating easy-entry/exit feature

Use this function to activate and deactivate the easy-entry/exit feature (⊳ page 83).

Marning!

You must make sure no one can become trapped or injured by the moving steering wheel when the easy-entry/exit feature is activated.

To stop steering wheel movement, move steering wheel adjustment stalk or press one of the memory position buttons.

Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could open the driver's door and unintentionally activate the easy-entry/exit feature, which could result in an accident and/or serious personal injury.

- ▶ Press button or repeatedly until the Settings menu appears in the multifunction display.
- ▶ Press button <a> □.
- ▶ Move the selection marker with button + or - to the Convenience submenu.
- ▶ Press button 🗘 or 💎 repeatedly until the message Easy-entry Function appears in the multifunction display. The selection marker is on the current setting.



▶ Press button + or - to activate (0n) or deactivate (Off) the easy-entry/exit feature.

Trip computer menu


Use the **Trip computer** menu to call up statistical data on your vehicle.

The following information is available:

- Fuel consumption statistics since start (⊳ page 125)
- Fuel consumption statistics since last reset (⊳ page 125)
- Resetting fuel consumption statistics (⊳ page 125)
- Distance to empty (> page 125)

Fuel consumption statistics since start

- ► Press button or preparedly until the first function of the **Trip computer** menu appears in the multifunction display.
- ▶ Press button or repeatedly until the message From Start appears in the multifunction display.




- 1) Distance driven since start
- ② Time elapsed since start
- 3 Average speed since start
- (4) Average fuel consumption since start

All statistics stored since the last engine start will be reset approximately 4 hours after the SmartKey in the starter switch is turned to position **0** or removed from the starter switch. Resetting will not occur if you turn the SmartKey back to position **1** or **2** within this time period.

Fuel consumption statistics since last reset

- ► Press button or repeatedly until the first function of the **Trip computer** menu appears in the multifunction display.
- ▶ Press button or repeatedly until the message From Reset appears in the multifunction display.



- ① Distance driven since last reset
- 2 Time elapsed since last reset

- 3 Average speed since last reset
- 4 Average fuel consumption since last reset

Resetting fuel consumption statistics

- ► Press button or repeatedly until the first function of the **Trip computer** menu appears in the multifunction display.
- ▶ Press button or repeatedly until the reading that you want to reset appears in the multifunction display.
- ▶ Press and hold the reset button in the instrument cluster until the respective values are reset to 0.

The fuel consumption statistics reset automatically to 0 after 99 999 miles or 9 999 hours, whichever occurs first.

Distance to empty

- ▶ Press button or prepeatedly until the first function of the **Trip computer** menu appears in the multifunction display.
- ► Press button or repeatedly until the message Range: appears in the multifunction display.

The calculated remaining driving range based on the current fuel tank level appears in the multifunction display. If only very little fuel is left in the tank, a vehicle at the fuel pump papears instead of the remaining driving range.



Telephone menu

↑ Warning!

A driver's attention to the road must always be his/her primary focus when driving. For

your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the handsfree device and only use the telephone when weather, road and traffic conditions permit. Some jurisdictions prohibit the driver from using a mobile phone while driving a vehicle. Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

You can connect your telephone to the COMAND system via Bluetooth®, see separate COMAND system operating instructions.

- ► Switch on the COMAND system. Refer to separate COMAND system operating instructions.
- ► Press button ☐ or ☐ repeatedly until the message TEL appears in the multifunction display. One of the following messages will appear in the multifunction display:
 - No Service: No network is available.
 - Bluetooth Ready: The telephone has not been connected to the COMAND system via Bluetooth[®] yet.
 - ► Connect the telephone to the COMAND system via Bluetooth[®].
 - Ready or name of the network provider (if available): The telephone has found a network and is ready for use. You can operate it using the control system.

Answering a call

When your telephone is ready to receive calls, you can answer a call at any time. In the multifunction display you will then see the following message, or if available, the caller ID (number or name):



▶ Press button .
You have answered the call.

Ending a call or rejecting an incoming call


▶ Press button <a> □.

Dialing a number from the phone book

When your telephone is ready to receive calls, you may select and dial a number from the phone book at any time.

- ► Press button or repeatedly until the message TEL appears in the multifunction display.
- ▶ Press button or repeatedly until the desired name appears in the multifunction display.

If you press and hold button or or for longer than 1 second, the system scrolls rapidly through the list of names until you release the button again. The stored names are displayed in alphabetical order.



► Press button .


The control system dials the selected phone number.

If the connection is successful and this feature is supported by your network provider, the name of the party (if stored in

your phone book) you are calling will appear in the multifunction display. The control system stores the dialed number in the redial memory.

or

▶ Press button if you do not want to make the call.



Redialing

The control system stores the most recently dialed phone numbers. This eliminates the need to search through your entire phone book.

- ▶ Press button or repeatedly until the message TEL appears in the multifunction display.
- ► Press button [...].
 The first number in the redial memory appears in the multifunction display.
- ► Press button or repeatedly until the desired number or name appears in the multifunction display.
- ▶ Press button .

 The control system dials the selected phone number.

Driving systems

Introduction

This section describes the following driving systems of your vehicle:

- Cruise control
- Distronic
- Distance warning function (only available with Distronic)

- AIRMATIC DC
- · Parktronic system

The driving safety systems ABS, Adaptive Brake, BAS, EBP and ESP® are described in the "Safety and security" section (> page 57).

Cruise control

The cruise control maintains the speed you set for your vehicle automatically.

The use of the cruise control is recommended for driving at a constant speed for extended periods of time.

The currently set speed or last set speed ("Resume" function) appears in the multifunction display for approximately 5 seconds. The corresponding cruise control speed segments from the selected speed to the vehicle maximum speed in the multifunction display are illuminated.

The cruise control is a convenience system designed to assist the driver during vehicle operation. The driver is and must always remain responsible for the vehicle's speed and for safe brake operation.

Only use the cruise control if the road, traffic, and weather conditions make it advisable to travel at a constant speed.

- The use of the cruise control can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a constant speed.
- The use of the cruise control can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.
- Deactivate the cruise control when driving in fog.


The "Resume" function should only be operated if the driver is fully aware of the

previously set speed and wishes to resume this particular preset speed.



↑ Warning!

The cruise control brakes automatically so that the set speed is not exceeded.



- Setting current or higher speed
- ② Setting current or lower speed
- ③ Canceling the cruise control
- 4 Activating the cruise control or resuming to last set speed

Activating cruise control

You can activate the cruise control at a vehicle speed above 20 mph (30 km/h). You cannot activate the cruise control

- · when you brake
- · when you have engaged the parking brake
- when the automatic transmission is in park position P, reverse gear R, or neutral position N
- the ESP[®] is switched off or has switched off due to a malfunction

The vehicle speed displayed in the speedometer can briefly vary from the speed setting for the cruise control system.

Setting current speed

- Accelerate or decelerate to the desired. speed.
- ▶ Briefly lift the cruise control lever in direction of arrow (1) or press in direction of arrow (2).
- ► Remove your foot from the accelerator
- 1 On uphill grades, the cruise control may not be able to maintain the set speed. Once the grade eases, the set speed will be resumed.

On downhill grades, the cruise control maintains the set speed by braking with the vehicle's brake system. In addition, on longer downhill grades the automatic transmission will downshift automatically.

Canceling cruise control

Depress the brake pedal.

▶ Briefly push the cruise control lever in direction of arrow (3).

The last set speed is stored for later use.

The last stored speed is deleted from memory when the engine is turned off.

The cruise control switches off automatically when you depress the brake pedal or you engage the parking brake. In this case, the cruise control speed segments in the multifunction display will go out.

The cruise control also switches off automatically when

- the vehicle speed falls below 20 mph (30 km/h)
- the ESP® is in operation
- the ESP® is switched off with the ESP® switch
- the FSP® has switched off due to a malfunction
- you shift the automatic transmission into neutral position N while driving

The cruise control speed segments in the multifunction display goes out and an acoustic warning will sound. Observe additional messages in the multifunction display that may appear.

Depressing the accelerator pedal does not deactivate the cruise control. After a brief acceleration (e.g. for passing), the cruise control will resume the last set speed.

Changing the set speed

Marning!

Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Increase or decrease the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected acceleration or deceleration of the vehicle could cause an accident and / or serious injury to you and others.

When you use the cruise control lever to decelerate, the brake system will brake the vehicle automatically if the engine's braking power does not brake the vehicle sufficiently.

- ▶ Increasing: Lift the cruise control lever in direction of arrow (1) and hold it up until the desired speed is reached.
- ▶ **Decreasing:** Press the cruise control lever in direction of arrow (2) and hold it down until the desired speed is reached.
- ▶ Release the cruise control lever. The new speed is set and the vehicle will accelerate or decelerate.

Fine adjustment in 1 mph (Canada: 1 km/h) increments

- ▶ Increasing: Briefly tip the cruise control lever in direction of arrow (1).
- ▶ **Decreasing:** Briefly tip the cruise control lever in direction of arrow (2).

Setting stored speed (Resume function)



↑ Warning!

The set speed stored in memory should only be set again if prevailing road conditions and legal speed limits permit. Possible acceleration or deceleration differences arising from returning to the preset speed could cause an accident and/or serious injury to you and others.

- ▶ Briefly pull the cruise control lever in direction of arrow (4). If no speed is stored, the current speed is set and stored.
- ▶ Remove your foot from the accelerator pedal.

The last stored speed is deleted from memory when the engine is turned off.

Distronic

Safety notes

When activated, the Distronic adaptive cruise control increases the driving convenience afforded by the cruise control while traveling on expressways and other major roadways.

- If the Distronic distance sensor detects a slower moving vehicle directly ahead, your vehicle speed will be reduced so that you follow that vehicle at your preset following distance.
- If there is no vehicle directly ahead of you, the Distronic will function in the same way as standard cruise control (> page 127).



Marning!

The Distronic requires familiarity with its operational characteristics. We strongly recommend that you review the following information carefully before operating the system.



Marning!

The Distronic is a convenience system. Its speed adjustment reduction capability is intended to make cruise control more effective and usable when traffic speeds vary. It is not however, intended to, nor does it, replace the need for extreme care.

The responsibility for the vehicle's speed, distance to the preceding vehicle and, most importantly, brake operation to ensure a safe stopping distance, always remains with the driver.

The Distronic cannot take street and traffic conditions into account. Complex driving situations are not always fully recognized by the Distronic. This could result in wrong or missing distance warnings.



↑ Warning!

The Distronic adaptive cruise control is not a substitute for active driving involvement. It does not react to pedestrians or on stationary objects, nor does it recognize or predict the lane curvature or the movement of preceding vehicles.

The Distronic can only apply 20% of the maximum braking power of the vehicle.

It is the driver's responsibility at all times to be attentive to the road, weather and traffic conditions. Additionally, the driver must provide the steering, braking and other driving inputs necessary to remain in control of the vehicle.

High-frequency sources such as toll stations, speed measuring systems etc. can cause the Distronic system to malfunction.



The Distronic cannot take road and traffic conditions into account. Only use the Distronic if the road, weather and traffic conditions make it advisable to travel at a constant speed.



/ Warning!

Use of the Distronic can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.

The Distronic does not function in adverse sight and distance conditions. Do not use the Distronic during conditions of fog, heavy rain, snow or sleet.



↑ Warning!

The Distronic cannot take weather conditions into account. Switch off the Distronic or do not switch it on if:

- · roads are slippery or covered with snow or ice. The wheels could lose traction while braking or accelerating, and the vehicle could skid.
- the Distronic system sensor cover is dirty or visibility is diminished due to snow, rain or fog, for example. The distance control system functionality could be impaired.

Always pay attention to surrounding traffic conditions even while the Distronic is switched on. Otherwise, you may not be able to recognize dangerous situations until it is too late. This could cause an accident in which you and/or others could be injured.



↑ Warning!

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.



↑ Warning!

Close attention to road and traffic conditions is imperative at all times, regardless of whether or not the Distronic is activated.

Use of the Distronic can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a constant speed.

The Distronic will not react to stationary objects in the roadway (e.g. a stopped vehicle in a traffic jam or a disabled vehicle). The

Distronic will also not respond to oncoming vehicles.

Switch off the Distronic

- when changing from the left to the right lane if vehicles are moving more slowly in the left lane
- when entering a turn lane or highway off ramp
- in complex driving situations, such as in highway construction zones

In these situations, the Distronic will continue to maintain the set speed unless deactivated.

The Distronic is designed and intended only to maintain a set speed and keep a set distance from moving objects in front of it.

① USA only:

This device has been approved by the FCC as a "Vehicular Radar System". The radar sensor is intended for use in an automotive radar system only. Removal, tampering, or altering of the device will void any warranties, and is not permitted by the FCC. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Removal, tampering, or altering of the device will void any warranties, and is not permitted. Do not tamper with, alter, or use in any non-approved way.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Distronic displays in the speedometer



When the Distronic is activated, one or two cruise control speed segments come on around set speed (1).

The vehicle speed displayed on the speedometer can briefly vary from the speed setting on the Distronic system.



When the Distronic detects a vehicle directly ahead, the cruise control speed segments ② appear in the speedometer. These segments represent the difference between the set speed of your vehicle ① and the speed of the preceding vehicle ③.

If the Distronic calculates that there is a danger of collision, the distance warning lamp in the instrument cluster comes on and an intermittent warning sounds.

► Immediately apply the brakes to avoid a collision.

Under no circumstances should the driver await the intermittent warning sound before braking.

The intermittent warning sound ceases and the distance warning lamp goes out when the necessary distance to the vehicle ahead is established again.



↑ Warning!

An intermittent warning sounds and the distance warning lamp 🛕 in the instrument cluster is illuminated if the Distronic system calculates that the distance to the vehicle ahead and your vehicle's current speed indicate that the Distronic will not be capable of slowing the vehicle sufficiently to maintain the preset following distance, which creates a danger of a collision.

Immediately brake the vehicle to increase your distance to the preceding vehicle. The warning sound is intended as a final caution in which you should intercede with your own braking inputs to avoid a potentially dangerous situation. Do not wait for the operation of the warning signal to intercede with your own braking. This will result in potentially dangerous emergency braking which will not always result in an impact being avoided.

Tailgating increases the risk of an accident.



Marning!

The Distronic brakes your vehicle with a maximum deceleration of 6.5 ft/s^2 (2 m/s²). This corresponds to approximately 20% of the maximum deceleration of your vehicle.

The Distronic brakes the vehicle in an effort to restore the preset distance or to maintain the set speed.

Distronic menu in the control system

The information shown in the multifunction display depends on whether the Distronic

system and/or the distance warning function are activated or deactivated.


1 To activate or deactivate the Distronic system, see (⊳ page 133) or see (⊳ page 134).

To activate or deactivate the Distance warning function, see (⊳ page 137).

▶ Press button 🗊 or 🛅 repeatedly until one of the following two displays appears in the multifunction display.

Distronic deactivated


When the Distronic is deactivated, you will see the standard Distronic display in the multifunction display.



- 1) Preceding vehicle, if detected
- (2) Actual distance to the preceding vehicle
- (3) Preset distance threshold to the preceding vehicle
- (4) Your vehicle
- (5) Symbol for activated distance warning function (⊳ page 137)


Distronic activated

When the Distronic is activated (1), you will see the set speed in the multifunction display for approximately 5 seconds. The following display appears in the multifunction display.



Cruise control lever

The Distronic system is operated by means of the cruise control lever.



- 1) Setting current or higher speed
- ② Setting current or lower speed
- ③ Deactivating the Distronic
- 4 Activating the Distronic, resuming to the last set speed or increasing speed in 1 mph (Canada: 1 km/h) increments

Activating Distronic

You can activate the Distronic when the vehicle speed is between 20 mph (30 km/h) and 110 mph (180 km/h).

When the Distronic is activated, one or two cruise control speed segments around the set speed in the multifunction display are illuminated. The multifunction display will briefly show a message such as DISTRONIC 55 MPH

(Canada: DISTRONIC 90 km/h).

If the Distronic is not activated after the cruise control lever is pulled in direction of arrow ④ (▷ page 133), you will see the message – in the multifunction display. In the following cases you cannot activate the Distronic:

- up to 2 minutes after starting the engine
- · when you brake
- when you have engaged the parking brake

- when the automatic transmission is in park position P, reverse gear R, or neutral position N
- when the ESP® is switched off or has switched off due to a malfunction

The vehicle speed displayed on the speedometer can briefly vary from the speed setting on the Distronic system.

Setting the current speed

- Accelerate or decelerate to the desired speed.
- ▶ Briefly lift the cruise control lever in direction of arrow ① or depress in direction of arrow ② (▷ page 133).
- Remove your foot from the accelerator pedal.
- 1 If you do not take your foot off of the accelerator pedal and continue to accelerate past the set speed, the following message will appear in the multifunction display:

DISTRONIC Override

The distance to a slower moving vehicle in front of you will not be set. Your vehicle speed will then be determined only by the accelerator pedal position.

Setting a higher speed

Marning!

Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Increase the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected acceleration of the vehicle could cause an accident and/or serious injury to vou and others.

You can increase the set speed in 1 mph (Canada: 1 km/h) increments or in 5 mph (Canada: 10 km/h) increments.

Adjustment in 5 mph (Canada: 10 km/h) increments

▶ Briefly lift the cruise control lever up in direction of arrow (1) (⊳ page 133). The new speed is set and the vehicle will accelerate. Keep in mind that it may take a brief moment until the vehicle has reached the set speed.

Fine adjustment in 1 mph (Canada: 1 km/h) increments

▶ Briefly pull the cruise control lever in direction of arrow (4) (⊳ page 133).

Setting a lower speed



/ Warning!

Keep in mind that it may take a brief moment until the vehicle has made the necessary adjustments.

Decrease the set vehicle speed to a value that the prevailing road conditions and legal speed limits permit. Otherwise, sudden and unexpected deceleration of the vehicle could cause an accident and/or serious injury to you and others.

1 When you use the cruise control lever to decelerate, the brake system will automatically brake the vehicle if the engine's braking power does not brake the vehicle sufficiently.

Adjustment in 5 mph (Canada: 10 km/h) increments

▶ Briefly press the cruise control lever down in direction of arrow ② (⊳ page 133). The new speed is set and the vehicle will decelerate. Keep in mind that it may take a brief moment until the vehicle has reached the set speed.

Setting stored speed (Resume function)



Marning!

The set speed stored in memory should only be set again if prevailing road conditions and legal speed limits permit. Possible acceleration or deceleration differences arising from returning to the preset speed could cause an accident and/or serious injury to you and others.

- ▶ Briefly pull the cruise control lever in direction of arrow 4 (\triangleright page 133). If no speed is stored, the current speed is set and stored.
- ► Remove your foot from the accelerator pedal.

Deactivating Distronic

▶ Depress the brake pedal.

▶ Briefly push the cruise control lever in direction of arrow (3) (⊳ page 133). The cruise control speed segments in the multifunction display will go out and the following message appears briefly in the multifunction display: DISTRONIC Off

The last set speed is stored for later use.

The last stored speed is deleted from memory when the engine is turned off.

The Distronic switches off automatically when you depress the brake pedal or you engage the parking brake. In this case, the cruise control speed segments in the multifunction display will go out.

The Distronic also switches off automatically when

- the vehicle speed falls below 20 mph (30 km/h)
- the ESP® is in operation
- the ESP® is switched off with the ESP® switch

- the ESP[®] has switched off due to a malfunction
- · you shift the automatic transmission into neutral position N while driving

The cruise control speed segments in the multifunction display goes out and an acoustic warning will sound. Observe additional messages in the multifunction display that may appear.

↑ Warning!

Distronic switches off and releases the brakes when the vehicle decelerates below the minimum speed of 20 mph (30 km/h) by operation of the system. At that time the driver must apply the brakes in order to reduce vehicle speed further or bring it to a stop.

Depressing the accelerator pedal does not deactivate the Distronic. After a brief acceleration (e.g. for passing), the Distronic will resume the last set speed.

Setting the following distance in Distronic

You can set the specified following distance for Distronic by varying the time setting between 1.0 and 2.0 seconds. Using this time setting and the current speed of your vehicle, Distronic calculates and sets the required following distance to the preceding vehicle. The set distance will be shown in the multifunction display.



Marning!

It is up to the driver to exercise discretion to select the appropriate setting given road conditions, traffic, driver's preferred driving style and applicable laws and driving recommendations for safe following distance.



- ▶ Increasing distance: Turn thumbwheel (1) towards 52. Increasing the distance setting tells Distronic to maintain a greater following distance to the preceding vehicle.
- ▶ Decreasing distance: Turn thumbwheel (1) towards \textstyle Decreasing the distance setting tells Distronic to maintain a shorter following distance to the preceding vehicle.

Driving with Distronic

This section describes a number of driving situations where special precaution is required on the part of the driver. Be prepared to brake in such situations. Braking will deactivate the Distronic system.



Marning!

The Distronic works to maintain the speed selected by the driver unless a moving obstacle proceeding directly ahead of it in the same travel direction is detected (e.g. following another vehicle ahead of you at your set distance).

This means that:

- Your vehicle can pass another vehicle after you have changed lanes.
- · While in a sharp turn or if the preceding vehicle is in a sharp turn, the Distronic could lose sight of the preceding vehicle. Your vehicle could then accelerate to the previously selected speed.

The Distronic regulates only the distance between your vehicle and those directly ahead of it, but does not register stationary objects in the road, e.g.:

- a stopped vehicle in a traffic jam
- a disabled vehicle
- · an oncoming vehicle

The driver must always be alert, observe all traffic and intercede as required by means of steering or braking the vehicle.



Warning!

The Distronic should not be used in snowy or icy road conditions.


The most likely cause for a malfunctioning system is a dirty Distronic system sensor cover (located in the hood grille), especially at times of snow and ice or heavy rain.

In such a case, the Distronic will switch off, and the message DISTRONIC Currently Unavailable - See Operator's Manual appears in the multifunction display.

For cleaning and care of the Distronic system sensor cover, see (⊳ page 219).


1 If the message DISTRONIC Currently Unavailable - See Operator's Manual disappears during driving and the last set speed flashes for approximately 5 seconds, the dirt (e.g. slush) has dissolved; the Distronic works again.

Turns and bends




In turns or bends, the Distronic may not detect a moving vehicle in front, or it may detect one too soon. This may cause your vehicle to brake late or unexpectedly.

Offset driving




A vehicle traveling in your lane but offset from your direct line of travel may not be detected by the Distronic. There will be insufficient distance to the preceding vehicle.

Lane changing



The Distronic has not yet detected the vehicle changing lanes. There will be insufficient distance to the lane-changing vehicle.

Narrow vehicles



Because of their narrow profile, the vehicles traveling near the outer edges of the lane have not yet been detected by the Distronic. There will be insufficient distance to the preceding vehicles.

Distance warning function

When the Distronic is deactivated, this function will continue to warn you when recognizing a stationary obstacle or a slower vehicle moving in your vehicle's path and the danger of a collision exists:

- The distance warning lamp in the instrument cluster comes on.
- An intermittent warning will sound if necessary.

If these warnings are issued, you must apply the brakes to maintain a safe distance and avoid a collision with the preceding vehicle. When depressing the brake pedal, the warning sound ceases. The warning sound will also cease when the distance to the preceding vehicle is sufficient again without applying the brakes. In this case, the distance warning lamp A will also go out.

↑ Warning!

If the distance warning lamp (A) in the instrument cluster comes on while driving and/or an intermittent warning sounds, immediate attention on the part of the driver is required. As required by the traffic situation, apply the brakes and navigate around a possible obstacle. However, do not drive by relying on the distance warning function, as this will result in an emergency braking application. This will not always enable you to avoid a collision, especially when traveling on varying road surface conditions and with varying driver reaction. Complex driving situations are not always fully recognized by the distance warning function. This could result in wrong or missing distance warnings.



► Activating/deactivating: Press switch (1).

When the distance warning function is activated, indicator lamp ② in switch ① comes on. A loudspeaker symbol appears in the multifunction display (▷ page 132).

Airmatic DC (Dual Control)


Introduction

The AIRMATIC DC lets you select the chassis and suspension setup. The chassis and suspension setup adjusts the damping behavior and the ride height for your vehicle. The AIRMATIC DC consists of two components. The Adaptive Damping System (ADS) (▷ page 137) and the vehicle level control (▷ page 138).

Adaptive Damping System (ADS)

The fine tuning of the damping is dependent on

- your driving style
- road surface conditions
- vehicle loading
- your personal settings



The following settings are available:

- Comfort Both indicator lamps (2) are off.
- Sport 1 One indicator lamp (2) is on.
- Sport 2 Both indicator lamps (2) are on.
- ▶ Start the engine.
- ▶ Press ADS switch (1) repeatedly until the desired suspension tuning is reached.

The setting remains stored when you turn off the engine.

/ Warning!

If you have selected the Comfort suspension tuning, the vehicle lowers slightly when you lock it within approximately 60 seconds after turning off the engine. To avoid personal injury, make sure nobody is in the vicinity of the wheel housing or under the vehicle when you turn off the engine.

When parking, make sure there is sufficient clearance under the vehicle for it to lower without making contact with the road curb for example. Otherwise, the vehicle could be damaged.

Vehicle level control

↑ Warning!

To help avoid personal injury, keep hands and feet away from wheel housing area, and stay away from under the vehicle when lowering the vehicle chassis.

Your vehicle automatically adjusts its ride height to increase vehicle safety and to reduce fuel consumption.

You can choose between normal or raised level.


The vehicle chassis ride height is raised or lowered according to the selected level setting and to the vehicle speed. At a speed exceeding approximately 68 mph (110 km/h) with normal level set or exceeding 75 mph (120 km/h) with raised level set, the ride height is reduced automatically. With decreasing speed, the ride height is again raised to the normal level.

These height adjustments are so small that you may not notice any change.

Select the raised level only when required by current driving conditions. Otherwise, the handling may be impaired and the fuel consumption may increase.

The following vehicle level settings can be selected when the vehicle is stationary and the engine is running:

Vehicle level when stationary	Indicator lamp (⊳ page 139)	Suspension tuning	Use for	Ride height increase over normal	Automatic lowering
Normal	Lamp off	Comfort	For driving on normal roads	None	Max. approx. 0.4 in (10 mm)
Normal	Lamp off	Sport 1 or 2	For driving on normal roads	None	Max. approx. 0.6 in (15 mm)
Raised	Lamp on	Comfort	For driving on rough roads or with snow chains	Approx. 0.8 in (20 mm)	Max. approx. 1.2 in (30 mm)
Raised	Lamp on	Sport 1 or 2	For driving on rough roads or with snow chains	Approx. 0.8 in (20 mm)	Max. approx. 1.4 in (35 mm)



- ▶ Start the engine.
- ► Briefly press vehicle level control switch (1) to change from normal level to raised level. When the vehicle is in raised level, pressing vehicle level control switch (1) will return the vehicle to normal level.

The setting raised is canceled and the vehicle is lowered to the normal level automatically if the vehicle speed is above 75 mph (120 km/h) or if the vehicle speed stays between 50 mph (80 km/h) and 75 mph

(120 km/h) for approximately 5 minutes. Indicator lamp (2) in vehicle level control switch (1) goes out.

If you do not drive in this speed range, the

selected vehicle level setting remains stored in memory even if the SmartKey is removed from the starter switch.

Parktronic system

The Parktronic system is an electronic parking aid with ultrasonic sensors designed to assist the driver during parking maneuvers. The Parktronic system indicates the relative distance between the vehicle and an obstacle visually and audibly.

The Parktronic system is activated automatically when


- you switch on the ignition and
- you release the parking brake

and

· the automatic transmission is in drive position **D**, reverse gear **R**, or neutral position N

The Parktronic system deactivates at speeds above approximately 11 mph (18 km/h). At lower speeds, the Parktronic system activates again.

The Parktronic system also deactivates when you shift the automatic transmission into park position P or engage the parking brake. The Parktronic system monitors the surroundings of your vehicle with six sensors in the front bumper and four sensors in the rear bumper.



Example illustration, sensors in the front bumper

To function properly, sensors (1) must be free of dirt, ice, snow and slush. Clean sensors (1) regularly. Be careful not to scratch or damage sensors (1), see "Cleaning the driving systems sensors" (▷ page 219).

/ Warning!

The Parktronic is a supplemental system. It is not intended to, nor does it replace, the need for extreme care. The responsibility during parking and other critical maneuvers always remains with the driver.

/ Warning!


Make sure no persons or animals are in or near the area in which you are parking/ maneuvering. Otherwise, they could be injured.


Special attention must be paid to objects with smooth surfaces or low silhouettes (e.g. trailer couplings, painted posts, elevated crossbars or road curbs). Such objects may not be detected by the system and can damage the vehicle.

During parking maneuvers, pay special attention to objects located above or below the height of the sensors (e.g. street curbs, painted posts, or trailer hitches etc.). The Parktronic system will not detect such objects at close range and damage to your vehicle or the object may result.

Ultrasonic signals from outside sources (e.g. truck air brakes, car wash, or jackhammers) may impair the operation of the Parktronic system.

Range of the sensors





Front sensors

Center	approx. 40 in (100 cm)
Corners	approx. 24 in (60 cm)

Rear sensors

Center	approx. 48 in (120 cm)
Corners	approx. 32 in (80 cm)


Minimum distance

Center	approx. 8 in (20 cm)
Corners	approx. 6 in (15 cm)


If the Parktronic system detects an obstacle in this range, all the distance warning segments illuminate and you hear a warning signal. If the obstacle is closer than the minimum distance, the actual distance may no longer be indicated by the Parktronic system.

Warning indicators

Visual signals indicate the relative distance between the sensors and an obstacle.



Front area warning indicators



Rear area warning indicators

Each warning indicator is divided into five yellow and two red distance segments for left side ① and right side ② of the vehicle. The Parktronic system is ready to measure when the yellow readiness indicators ③ are illuminated.

The current transmission position determines which warning indicator will be activated.


Current transmission position	Warning indicator
D	Front area activated
R or N	Front and rear area activated

As your vehicle approaches an object, one or more distance segments will illuminate, depending on the distance. When the seventh distance segment illuminates, you have reached the minimum distance.

- Front area: An intermittent acoustic warning will sound as the first red distance segment illuminates and a constant acoustic warning lasting a maximum of 2 seconds will sound for the second red distance segment. The signal is canceled when the automatic transmission is shifted into park position **P** or the parking brake is engaged.
- Rear area: An intermittent acoustic warning will sound as the first red distance segment illuminates and a constant acoustic warning lasting a maximum of 2 seconds will sound for the second red distance segment. The signal is canceled when the automatic transmission is shifted into drive position **D**, or park position **P**, or the parking brake is engaged.

Switching the Parktronic system on/ off

The Parktronic system switches on automatically when the ignition is switched on.



- ➤ Switching off: Press Parktronic switch ①.
 Indicator lamp ② comes on.
- ► **Switching on:** Press Parktronic switch ① again.

Parktronic system malfunction

There is a malfunction in the Parktronic system, if only the red distance segments illuminate and an acoustic warning sounds. The Parktronic system will switch off automatically after 20 seconds and indicator lamp ② in Parktronic switch ① comes on.

► Have the Parktronic system checked at an authorized Mercedes-Benz Center as soon as possible.

If only the red distance segments illuminate and no acoustic warning sounds, the Parktronic system sensors are dirty (e.g. dirt, ice, snow and slush). Another cause could be interference from other radio or ultrasonic signals (e.g. truck air brakes, car wash, or jackhammers). The Parktronic system will switch off automatically after 20 seconds and indicator lamp ② in Parktronic switch ① comes on.

- ► Switch off the ignition.
- ► Clean the Parktronic system sensors (> page 219).
- Switch on the ignition.
- Check the Parktronic system operation at another location to rule out interference from outside radio or ultrasonic signals.

Climate control system

Control panels

4-zone automatic climate control





P83.40-4272-31

	Function	Recommendation/Notes	
	Front climate control panel		
1	Air distribution, driver's side		(⊳ page 149)
2	Front defroster	Keep this setting selected only until the windshield or the side windows are clear again.	(⊳ page 149)
3	Temperature control, driver's side, raising	1 Set the temperature to 72°F (22°C).	(⊳ page 147)
4	Display		
5	Temperature control, passenger side, raising	1 Set the temperature to 72°F (22°C).	(⊳ page 147)
6	Rear window defroster		(⊳ page 151)
7	Air distribution, passenger side		(⊳ page 149)

	Function	Recommendation/Notes	
8	Air distribution and air volume, passenger side (automatic mode)	Switch on the automatic mode. The indicator lamp in button AUTO comes on.	(⊳ page 146)
9	AC cooling on/off	1 Switch on/off the air conditioning.	(⊳ page 146)
10	Temperature control, passenger side, lowering	1 Set the temperature to 72°F (22°C).	(⊳ page 147)
11)	REAR Rear air- conditioning remote control (USA only)		(⊳ page 147)
	Rear air- conditioning remote control (Canada only)		
12	Increasing air volume		(⊳ page 149)
13	Climate control on/	Switch on/off the climate control system.	(⊳ page 145)
14)	Decreasing air volume		(⊳ page 149)
(15)	on/off (USA only)		(⊳ page 150)
	REST Residual heat/ ventilation (Canada only)	• With the engine turned off, it is possible to continue to heat or ventilate the interior.	(⊳ page 151)
16	Temperature control, driver's side, lowering	i) Set the temperature to 72°F (22°C).	(⊳ page 147)
17)	Air recirculation	Only use this function for a short time, e.g. in a tunnel. Otherwise, the windows can fog up due to lack of fresh air.	(⊳ page 150)
18	Air distribution and air volume, driver's side (automatic mode)	Switch on the automatic mode. The indicator lamp in button auto comes on.	(⊳ page 146)
	Rear climate control panel		

	Function	Recommendation/Notes	
19	Temperature control, left, raising	1 Set the temperature to 72°F (22°C).	(⊳ page 147)
20	Display		
21)	Temperature control, right, raising	1 Set the temperature to 72°F (22°C).	(⊳ page 147)
22	Temperature control, right, lowering	1 Set the temperature to 72°F (22°C).	(⊳ page 147)
23	Temperature control, left, lowering	1 Set the temperature to 72°F (22°C).	(⊳ page 147)

Notes on climate control system

The climate control system is operational whenever the engine is running. You can operate the climate control system in either the automatic or manual mode. The system cools or heats the interior depending on the selected interior temperature.

It can only function optimally when you are driving with the windows and the tilt/sliding sunroof closed.

Nearly all dust particles, pollutants and odors are filtered out before outside air enters the passenger compartment through the air distribution system.

Marning!

Severe conditions (e.g. strong air pollution) may require replacement of the filter before its scheduled replacement interval. A clogged filter will reduce the air volume to the interior and the windows could fog up, impairing visibility and endangering you and others. Have a clogged filter replaced as soon as possible at an authorized Mercedes-Benz Center.

The air conditioning will not engage (no cooling) if the A/C mode (⊳ page 146) is deactivated.

Follow the recommended settings for heating and cooling given on the following pages. Otherwise the windows could fog up, impairing visibility and endangering you and others.

► Keep the air intake grille in front of the windshield free of snow and debris.

Do not obstruct air flow by placing objects on the air flow-through exhaust slots below the rear window.

f the vehicle interior is hot, ventilate the interior before driving off, see "Summer opening feature" (> page 96). The climate control will then adjust the interior temperature to the set value much faster.

Deactivating the climate control system



Marning!

When the climate control system is deactivated, the outside air supply and circulation are also deactivated. Only choose this setting for a short time. Otherwise the windows could fog up, impairing visibility and endangering you and others.

- ▶ **Deactivating:** Press button **OFF**. 0 appears in display (4) (\triangleright page 143).
- ▶ Reactivating: Press button OFF. Display (4) comes on. The previous settings are once again in effect.

Air conditioning

The air conditioning is operational while the engine is running and cools the interior air to the temperature set by the operator. In addition, the air conditioning dehumidifies the interior air and helps prevent window fogging.



↑ Warning!

If you deactivate the air conditioning, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.

1 Condensated water may drip out from underneath the vehicle. This is normal and not an indication of a malfunction.

The air conditioning uses the refrigerant R134a. This refrigerant is free of CFCs which are harmful to the ozone layer.

Deactivating

It is possible to deactivate the air conditioning. The interior air will then no longer be cooled or dehumidified.

► Press button A/c . The indicator lamp in the button goes out. The cooling function switches off after a short delay.

Activating

Moist air can fog up the windows. You can dehumidify the interior air with the air conditioning.

► Press button A/c . The indicator lamp in the button comes on. The evaporator will be vented when the air conditioning has been in use. Approximately 1 hour after locking the vehicle, the blower switches on automatically. The blower will run for 30 minutes at its lowest level. The blower noise is normal and not an indication of a malfunction. When you unlock the vehicle in the meantime, venting will be interrupted. If the vehicle battery is low. automatic evaporator venting will not occur in order to preserve the battery.

Automatic mode

When operating the climate control system in automatic mode, the interior air temperature, air volume and air distribution are adjusted automatically.

In automatic mode, cooling with dehumidification is switched on. This function can be switched off if necessary.



↑ Warning!

If you deactivate the air conditioning, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.

- ► Set the desired temperature (⊳ page 147).
- ► Activating: Press one button AUTO. The indicator lamp in the button comes on. AUTO appears in display 4 (\triangleright page 143). The air volume and air distribution are adjusted automatically.
- ▶ **Deactivating:** Press button 😵 or 🛞. AUTO disappears in display (4). The automatic function for air volume is switched off, and air volume is controlled according to the desired setting. The

automatic air distribution remains switched on.

or

► Turn air distribution control ① or ⑦
(▷ page 143) on each side of the passenger compartment to the desired symbol.

The indicator lamp in button Auto goes out. Automatic air distribution is switched off in the corresponding zone, and air distribution is controlled according to the desired position. The automatic air volume remains switched on.

Setting the temperature

You can adjust the air temperature for each of the 4 zones separately. You should raise or lower the temperature setting in small increments, preferably starting at 72°F (22°C).



Front zones

Rear zones

- ► Press button REAR .
 Display ④ (> page 143) switches over.
- 1 You can also press button REAR once more to switch back to the standard display.

Rear climate control panel

You can adjust the air temperature on each side of the rear passenger compartment. You should raise or lower the temperature setting in small increments, preferably starting at 72°F (22°C).

Adjusting air vents




When operating the climate control, the air that enters the passenger compartment through the air vents can be very hot or very cold (depending on the set temperature). This may cause burns or frostbite to unprotected skin in the immediate area of the air vents.

Always keep sufficient distance between unprotected parts of the body and the air vents. If necessary, use the air distribution adjustment to direct the air to air vents in the vehicle interior that are not in the immediate area of unprotected skin.

For best possible performance of the climate control:


- ► Keep the air intake grille in front of the windshield free of snow, leaves, sticks, and any other debris.
- Always keep all air vents and grilles in the passenger compartment free from obstruction.
- For draft-free ventilation, move the adjustable center and side air vents to the middle position.

Center air vents



- 1 Left center air vent, adjustable
- ② Right center air vent, adjustable
- 3 Thumbwheel for air volume control for adjustable right center air vent
- 4 Thumbwheel for air volume control for adjustable left center air vent
- ▶ Opening/closing: Turn thumbwheels ③ and ④ upward or downward.

Side air vents



Example illustration driver's side

- 1 Left side defroster air vent, fixed
- ② Left side air vent, adjustable
- 3 Thumbwheel for air volume control for adjustable left side air vent
- ► Opening/closing: Turn thumbwheel ③ in the required direction.

Front armrest storage compartment ventilation


The front armrest storage compartment can be ventilated, for instance to cool its contents, when the climate control system is activated. The level of airflow to the front armrest storage compartment depends on the airflow and air distribution settings. The temperature of the air is approximately the same as that of the air flowing from the center air vents.

Close the front armrest storage compartment air vent when heating the vehicle interior. Activate the air conditioning (cooling function) when the outside temperature is high. Otherwise, temperature-sensitive items stored in the front armrest storage compartment could be damaged.



► Opening/closing air vent: Slide lever ①
up or down.

Rear center console air vents



- 1 Left rear center air vent, adjustable
- (2) Right rear center air vent, adjustable
- 3 Thumbwheel for air volume control for right rear center air vent
- 4 Rear climate control panel
- (5) Thumbwheel for air volume control for left rear center air vent
- ► Opening/closing: Turn thumbwheel ③ or ⑤ upward or downward.

Adjusting air distribution

The air distribution can be adjusted separately on each side of the passenger compartment.

The symbols on the control represent the following functions:

Symbol	Function
^	Directs air through the center, side and defroster air vents to the windshield and front door windows
₽	Directs air through the center and side air vents
į,	Directs air into the entire vehicle interior
قم ۲	Directs air through the center and side air vents and to the footwells

► Turn air distribution control ① or ⑦ (▷ page 143) to the desired symbol.

You can also turn the air distribution control to a position between two symbols.

Adjusting air volume

Front defroster

You can use this setting to defrost the windshield, for example if it is iced up.
You can also defog the windshield and the front door windows.

- Keep this setting selected only until the windshield or the front door windows are clear again.
- ► Activating: Press button (The indicator lamp in the button comes on. The climate control switches to the following functions automatically:
- cooling on to dehumidify
- most efficient blower speed and heating power, depending on outside temperature

- air flows onto the windshield and the front door windows
- the air recirculation mode is switched off
- 1 You can adjust the air volume, air distribution and interior air temperature when the front defroster is switched on.
- ▶ **Deactivating:** Press button 📦 again. The indicator lamp in the button goes out. The previous settings are once again in effect. The cooling remains switched on. The air recirculation remains switched off.

► Press button AUTO. The indicator lamp in button was goes out. Air volume and air distribution are adjusted automatically.

Windshield fogged on the outside

- ► Switch the windshield wipers on (⊳ page 92).
- ► Turn air distribution control to 🙀 or

Maximum cooling MAX COOL

MAX COOL is only available in U.S. vehicles. MAX COOL is only operational when the engine is running.

This provides the fastest possible cooling of the vehicle interior (when windows and tilt/ sliding sunroof are closed).

► Activating: Press button MAX COOL appears in display (4) (⊳ page 143).

The air conditioning switches automatically to the following functions:

- · maximum cooling
- · maximum blowing power
- the air recirculation mode is switched on
- ▶ **Deactivating:** Press button again. MAX COOL disappears in display (4). The previous settings are once again in effect.
- 1 To switch the maximum cooling function off, you can also press button OFF, AUTO, Or WEBEAR.

Air recirculation mode

Switch to air recirculation mode to prevent unpleasant odors from entering the vehicle from the outside (e.g. before driving through a tunnel). This setting cuts off the intake of outside air and recirculates the air in the passenger compartment.



Marning!

Fogged windows impair visibility, endangering you and others. If the windows begin to fog on the inside, switching off the air recirculation mode immediately should clear interior window fogging. If interior window fogging persists, make sure the air conditioning is activated, or press button WMAX .

- ▶ Activating: Press button 🖘. The indicator lamp in the button comes on.
- The air recirculation mode is activated automatically at high outside temperatures and if the concentration of carbon monoxide (CO) and nitrogen oxide in the outside air increases, for example in a tunnel.

The indicator lamp in button si is not lit when the air recirculation mode is switched on automatically.

A quantity of outside air is added after approximately 30 minutes.

- ▶ **Deactivating:** Press button again. The indicator lamp in the button goes out.
- The manually selected air recirculation mode is deactivated automatically:
 - after 5 minutes if the outside temperature is below approximately 41°F (5°C)
 - after 5 minutes if the air conditioning is turned off
 - after 30 minutes if the outside temperature is above approximately 41°F (5°C)

Residual heat and ventilation

This feature is only available in Canada vehicles.

With the engine turned off, it is possible to continue to heat or ventilate the interior for up to 30 minutes. This feature makes use of the residual heat produced by the engine.

- i If you switch on the residual heat function when outside temperatures are high, only the ventilation will be switched on.
- 1 Regardless of the selected air volume, the blower operates at low speed.
- 1 How long the system will provide heating depends on the coolant temperature and the selected temperature. The blower will run at speed setting 1 regardless of the air volume control setting.
- ► Activating: Switch off the ignition.
- ► Press button REST.

 The indicator lamp in the button comes on.

▶ Deactivating: Press button REST.

The indicator lamp in the button goes out.

The residual heat is deactivated automatically:

- when the ignition is switched on
- after approximately 30 minutes
 - · if the battery voltage drops
 - if the coolant temperature is too low

Rear window defroster

↑ Warning!

Any accumulation of snow and ice should be removed from the rear window before driving. Visibility could otherwise be impaired, endangering you and others.

The rear window defroster uses a large amount of power. To keep the battery drain to a minimum, switch off the defroster as soon as the rear window is clear. The defroster is switched off automatically after some time of operation depending on the outside temperature.

- ► Switch on the ignition.
- ► Switching on: Press button on the respective climate control panel.

 The indicator lamp in the button comes on.
- ▶ Switching off: Press button again.

The rear window defroster switches off when the battery voltage is too low. The indicator lamp in button [MBFAR] flashes. Too many electrical consumers may be operating simultaneously.

Switch off consumers that are currently not needed if required.

Power tilt/sliding sunroof

Opening and closing

Observe Safety notes, see page 52.



↑ Warning!

When opening or closing the tilt/sliding sunroof, make sure there is no danger of anyone being harmed by the opening/closing procedure.

The tilt/sliding sunroof is equipped with the express operation and automatic reversal function. If the movement of the tilt/sliding sunroof is blocked during the closing procedure, the tilt/sliding sunroof will stop and open slightly.

The tilt/sliding sunroof operates differently when the sunroof switch is pressed and held. See the "Closing when the tilt/sliding sunroof is blocked" section for details.

The opening/closing procedure of the tilt/ sliding sunroof can be immediately halted by releasing the sunroof switch or, if the sunroof switch was moved past the resistance point and released, by moving the sunroof switch in any direction.

↑ Warning!

The tilt/sliding sunroof is made out of glass. In the event of an accident, the glass may shatter. This may result in an opening in the roof.


In a vehicle rollover, occupants not wearing their seat belts or not wearing them properly may be thrown out of the opening. Such an opening also presents a potential for injury for occupants wearing their seat belts properly as entire body parts or portions of them may protrude from the passenger compartment.

I To avoid damaging the seals, do not transport any objects with sharp edges which can stick out of the tilt/sliding sunroof.

Do not open the tilt/sliding sunroof if there is snow or ice on the roof, as this could result in malfunctions.

If you cannot open or close the tilt/sliding sunroof due to a malfunction contact Roadside Assistance or an authorized Mercedes-Benz Center.

- Please keep in mind that weather conditions can sometimes change rapidly. Make sure to close the tilt/sliding sunroof when leaving the vehicle. If water enters the vehicle interior, vehicle electronics could be damaged which is not covered by the Mercedes-Benz Limited Warranty.
- 1 You can also open or close the tilt/sliding sunroof using the SmartKey or the KEYLESS-GO function, see "Summer opening feature" (⊳ page 96) and "Convenience closing feature" (⊳ page 96).
- After switching off the ignition or removing the SmartKey from the starter switch, you can operate the tilt/sliding sunroof until you open the driver's or front passenger door. If no door was opened you can operate the tilt/sliding sunroof for up to 5 minutes.



Sunroof switch

- Raising
- ② Opening
- ③ Closing

With the sunroof closed or raised, you can slide the sunroof screen forward and back.



Sunroof screen

► Switch on the ignition.

Opening

- ▶ Opening manually: Press and hold the sunroof switch to the resistance point in direction of arrow ②.
- ► Release the sunroof switch when the desired position is reached.
- ► Express operation: To open the tilt/ sliding sunroof completely, press the sunroof switch past the resistance point in direction of arrow ② and release.
- ► Stopping during express operation: Move the sunroof switch in any direction.
- Express opening is not available when the tilt/sliding sunroof is raised. The tilt/ sliding sunroof must be closed first.
- When the tilt/sliding sunroof is open, resonance noises may result in addition to the usual wind noises. They are caused by minimal pressure changes in the passenger compartment. To reduce or eliminate these noises, change the position of the tilt/sliding sunroof or open a window slightly.

Raising

- ➤ Raising manually: Press and hold the sunroof switch to the resistance point in direction of arrow (1).
- ► Release the sunroof switch when the desired position is reached.
- ▶ Express operation: To raise the tilt/ sliding sunroof completely, press the sunroof switch past the resistance point in direction of arrow ① and release.
- ► Stopping during express operation:

 Move the sunroof switch in any direction.
- 1 Express raising is not available when the tilt/sliding sunroof is open. The tilt/sliding sunroof must be closed first.

Closing

- ➤ Closing manually: Pull and hold the sunroof switch to the resistance point in direction of arrow (3).
- ► Release the sunroof switch when the desired position is reached.
- ► Express operation: To close the tilt/ sliding sunroof completely, pull the sunroof switch past the resistance point in direction of arrow (3) and release.
- ► Stopping during express operation: Move the sunroof switch in any direction.

Closing when the tilt/sliding sunroof is blocked



Make sure that nobody can become trapped and be seriously or even fatally injured when closing the tilt/sliding sunroof with greater force or without automatic reversal function.

If the movement of the tilt/sliding sunroof is blocked during the closing procedure (e.g. by ice or pollution), the tilt/sliding sunroof will stop and open slightly.

► Immediately after the tilt/sliding sunroof has stopped and opened because it was blocked, pull and hold the sunroof switch

in direction of arrow ③ until the tilt/sliding sunroof is fully closed.

The tilt/sliding sunroof closes with greater force.

If the tilt/sliding sunroof is blocked again and opens slightly:

► Immediately after the tilt/sliding sunroof was blocked and has opened, pull and hold the sunroof switch in direction of arrow (3) until the tilt/sliding sunroof is fully closed.

The tilt/sliding sunroof closes without automatic reversal function.



↑ Warning!

Pulling and holding the sunroof switch to close the tilt/sliding sunroof immediately after it had been blocked two times will cause the tilt/sliding sunroof to close without any reversal function for as long as you hold the sunroof switch.

Synchronizing

The tilt/sliding sunroof must be synchronized

- after the battery has been disconnected or discharged
- · after a malfunction
- if the tilt/sliding sunroof does not open smoothly
- If the tilt/sliding sunroof cannot be closed or synchronized, contact an authorized Mercedes-Benz Center or call Roadside Assistance
- ▶ Vehicles with SmartKey: Switch off the ignition and remove the SmartKey from the starter switch.
- ▶ Vehicles with KEYLESS-GO: Switch off the ignition and open the driver's door. This puts the starter switch in position 0, same as with the SmartKey removed from the

- starter switch. The driver's door then can be closed again.
- ► Remove the fuse for the tilt/sliding sunroof from the fuse box (⊳ page 284).
- Reinsert the fuse in the fuse box.
- ▶ Switch on the ignition.
- ▶ Press and hold the sunroof switch in direction of arrow (1) (▷ page 152) until the tilt/sliding sunroof is fully raised at the rear.
- Keep holding the sunroof switch in direction of arrow (1) for approximately 1 second.
- ► Check the express operation feature (⊳ page 153). If the tilt/sliding sunroof opens and closes completely, the roof is synchronized. Otherwise repeat the above steps.

Loading and storing

Loading instructions



Always fasten items being carried as securely as possible using cargo tie-down hooks and fastening materials appropriate for the weight and size of the load.

In an accident, during hard braking or sudden maneuvers, loose items will be thrown around inside the vehicle. This can cause injury to vehicle occupants unless the items are securely fastened in the vehicle.

To help avoid personal injury during a collision or sudden maneuver, exercise care when transporting cargo. Do not pile luggage or cargo higher than the seat backrests.

The trunk is the preferred place to carry objects. Always use cargo tie-down hooks when transporting cargo. Do not place anything on the rear-window shelf.

Never drive a vehicle with the trunk open. Deadly carbon monoxide (CO) gases may

enter vehicle interior resulting in unconsciousness and death.

Load distribution

The total load weight including vehicle occupants and luggage/cargo should not exceed the total load limit indicated on the corresponding Tire and Loading Information placard located on the driver's door B-pillar (⊳ page 194).

The handling characteristics of a fully loaded vehicle depends greatly on the load distribution. It is therefore recommended to load the vehicle accordingly with the heaviest items being placed towards the front of the vehicle.

Please pay attention to and comply with the following instructions when loading the vehicle and transporting cargo:

- Always place items being carried against front or rear seat backrests, and fasten them as securely as possible.
- The heaviest portion of the cargo should always be kept as low as possible against front or rear seat backrests.

Roof rack

For information about further roof rack equipment, contact an authorized Mercedes-Benz Center.



Warning!

Only use roof racks approved by Mercedes-Benz for your vehicle model to avoid damage to the vehicle.

Follow the manufacturer's installation instructions. Otherwise, an improperly attached roof rack system or its load could become detached from the vehicle.


Do not exceed the maximum roof load of 220 lb (100 kg).

Take into consideration that when the roof rack is loaded, the handling characteristics

are different from those when operating the vehicle without the roof rack loaded.

Make sure

- you can raise the tilt/sliding sunroof completely
- you can open the trunk completely



- ► Flip trim covers (1) open.
- ▶ Only attach the roof rack to the anchorage points under trim covers (1).
- ▶ Observe manufacturer's instructions for installation

Ski bag (Canada only)




↑ Warning!

The ski bag is designed for up to four pairs of skis. Do not load the ski bag with other objects.

Always fasten the ski bag securely. In an accident, an unfastened ski bag can cause injury to vehicle occupants.

Unfolding and loading


▶ Fold rear armrest down.



- ▶ Pull catches ② in direction of arrows.
- ▶ Open ski bag compartment cover ① downwards in direction of the arrow.




- ► Pull ski bag ③ into passenger compartment and unfold.
- ► Remove the cup holder in the rear center console (> page 161).
- ▶ Open the trunk.




► Press button ④.

The flap opens in direction of arrow.




► From trunk, slide skis into ski bag.



➤ Tighten strap ⑤ by pulling at the loose end (arrow) until the skis in the ski bag are tightly secured.



With insert or cup holder removed, fold cover (a) upward in direction of arrow.



- ► Connect hook (7) to eye (8) located in the front storage compartment in the rear center console.
- ▶ Tighten strap by pulling at the loose end (arrow).

Unloading and folding

- ► Loosen both straps.
- ▶ Disconnect hook (7) from eye (8).
- Unload skis.
- ► Close flap in trunk.
- ▶ Fold and flatten ski bag lengthwise.
- ▶ Place folded ski bag inside recess of seat backrest.
- ► Close ski bag compartment cover.

Removing the ski bag

For ski bag removal, we recommend that you contact an authorized Mercedes-Benz Center



Marning!

Never drive a vehicle with trunk open while the ski bag is removed. Deadly carbon monoxide (CO) gases may enter vehicle interior, resulting in unconsciousness and death.

To prevent unauthorized persons from access to the trunk, always close the cover.

Parcel net

↑ Warning!

Parcel nets are intended for storing lightweight items only, such as road maps, mail, etc.

Heavy objects, objects with sharp edges, or fragile objects may not be transported in the parcel nets. In an accident, during hard braking, or sudden maneuvers, they could be thrown around inside the vehicle and cause injury to vehicle occupants.

Parcel nets cannot protect transported goods in the event of an accident.

A parcel net is located in the front passenger footwell.

Hooks

A retaining hook can be used to attach cargo items such as bags.

Do not use the retaining hook to tie down cargo.



▶ Pull strap (1) of retaining hook (2) down.

Cargo tie-down hooks

Four cargo tie-down hooks are located in the trunk.

Always follow loading instructions (⊳ page 154).



Carefully secure cargo by applying even load on all cargo tie-down hooks with rope of sufficient strength to hold down the cargo.

Front storage compartments

/!\ Warning!

To help avoid personal injury during a collision or sudden maneuver, exercise care when storing objects in the vehicle. Put luggage or cargo in the trunk if possible.

Do not pile luggage or cargo higher than the seat backrests.


Do not place anything on shelf below the rear window.

Keep compartment lids closed. This will help to prevent stored objects from being thrown about and injuring vehicle occupants during

- braking
- · vehicle maneuvers
- · an accident

Glove box

Depending on vehicle equipment, an AUX socket or a media interface is located in the glove box. For information on Audio AUX mode or on media interface, see separate COMAND system operating instructions.



- ▶ Opening: Press glove box lid release (1).
- ► Closing: Push glove box lid ② upwards until it engages.


You can lock the glove box, e.g. when the vehicle is in the shop for service.

The glove box can only be locked or unlocked with the mechanical key.



- Glove box unlocked
- 2 Glove box locked

Front armrest storage compartment




1 The Roadside Assistance button (⊳ page 164) and the Information button (⊳ page 167) are located in the storage compartment.

The front armrest storage compartment can be ventilated (⊳ page 148).

▶ Opening storage compartment: Press button 1 right or left and fold cover 2 sideward.

Seat storage compartment

A storage compartment is located in the seat base of the driver's seat.



- ▶ Opening: Pull handle (1) up.
- ▶ Fold the lid forward in direction of arrow.

Rear storage compartments



To help avoid personal injury during a collision or sudden maneuver, exercise care when storing objects in the vehicle. Put luggage or cargo in the trunk if possible.


Do not pile luggage or cargo higher than the seat backrests.

Do not place anything on shelf below the rear window.

Keep compartment lids closed. This will help to prevent stored objects from being thrown about and injuring vehicle occupants during

- braking
- · vehicle maneuvers
- an accident

Rear center console storage compartment



▶ Slide cover (1) forward or rearward.

Rear armrest storage compartment

- Do not sit on or lean your body weight against the armrest when it is folded down, as you could otherwise damage it.
- Before storing the armrest in the seat backrest, close the storage compartment cover.
- ▶ Fold the rear armrest down.



▶ Opening: Press the handle upwards and fold the rear armrest lid up.

Storage bags



↑ Warning!

Do not place objects with a combined weight of more than 4.4 lb (2 kg) into the storage bag. Otherwise, the Occupant Classification System (OCS) may not be able to properly approximate the occupant weight category. The storage bag is intended for storing lightweight items only.

Heavy objects, objects with sharp edges or fragile objects may not be transported in the storage bag. In an accident, during hard braking, or sudden maneuvers, they could be thrown around inside the vehicle and cause injury to vehicle occupants.

The storage bag cannot protect transported goods in the event of an accident.

Storage bags are located on the back of the front seats.

Useful features

Cup holders



/ Warning!

In order to help prevent spilling liquids on vehicle occupants and/or vehicle equipment, only use containers that fit into the cup holder. Use lids on open containers and do not fill containers to a height where the contents, especially hot liquids, could spill during braking, vehicle maneuvers, or in an accident. Liquids spilled on vehicle occupants may cause serious personal injury. Liquids spilled on vehicle equipment may cause damage not covered by the Mercedes-Benz Limited Warranty.

The cup holder must be extended when in use with bottles.

When not in use, keep the cup holder closed. An open cup holder may cause injury to you or others when contacted during braking, vehicle maneuvers, or in an accident. Keep in mind that objects placed in the cup holder may come loose during braking, vehicle maneuvers, or in an accident and be thrown around in the vehicle interior. Objects thrown around in the vehicle interior may cause an accident and/or serious personal

Cup holder in front center console

injury.

The cup holder can be removed for cleaning purposes.



► Extending: Briefly press mark on cup holder.

The cup holder automatically extends upward.

- ▶ Removing: Extend cup holder.
- ▶ Press mark on cup holder and remove cup holder by pulling it upward.
- ▶ Reinstalling: Insert cup holder into opening.
- ▶ **Retracting:** Press mark on cup holder and push cup holder in until it engages.
- Make sure that the cup holder is correctly positioned in the guide while you are reinstalling it. Otherwise the cup holder can be damaged.
- ▶ Press mark on cup holder and press cup holder downward until it engages.

Cup holder in rear center console

The cup holder can be removed for cleaning purposes.




▶ Opening/closing: Slide cover (1) forward or rearward.



- ▶ Removing: Move pin (2) in direction of arrow to unlock cup holder (3).
- ▶ With the cup holder unlocked, take cup holder (3) out upwards.
- ▶ Reinstalling: Insert cup holder (3).
- ▶ Move pin ② against direction of arrow to lock the cup holder.

Cup holder in rear armrest




- ▶ Opening: Briefly press the front of the rear armrest.
- ► Closing: Slide cup holder back until it engages.
- Do not sit on or lean your body weight against the armrest when it is folded down, as you could otherwise damage it.
- Close the cup holder before folding the armrest upwards. Otherwise you could damage the cup holder.

Sun visors



Marning!

Do not use the vanity mirror while driving. Keep the vanity mirrors in the sun visors closed while vehicle is in motion. Reflected glare can endanger you and others.



- Vanity mirror lamp
- ② Mounting
- ③ Sun visor
- 4 Holder, e.g. for gas cards
- (5) Vanity mirror
- 6 Vanity mirror cover

Glare through the windshield

► Flip sun visor (3) down when you experience glare.

Glare through a door window

- ► Close vanity mirror cover (6) if opened.
- ▶ Disengage sun visor (3) from mounting (2).
- ▶ Pivot sun visor (3) to the side.

Vanity mirror

The vanity mirror lamp only functions when the sun visor is engaged in mounting (2).

- ► Flip sun visor (3) down.
- ► Lift up vanity mirror cover (6). Vanity mirror lamp (1) comes on.

Rear window sunshade




Marning!

When operating the rear window sunshade make sure there is no danger of anyone being harmed by the extending or retracting procedure.

The extending or retracting procedure can be immediately halted by briefly pressing rear window sunshade switch. To reverse direction of movement, press rear window sunshade switch again.


Observe Safety notes, see page 52.



- ▶ Switch on the ignition.
- ► Extending/Retracting: Press rear window sunshade switch (1) briefly.

Ashtrays


Center console ashtray



- ▶ Opening: Briefly press the marking on the bottom of cover (1).
- ▶ Removing ashtray insert: Secure vehicle from movement by engaging the parking brake.
- ▶ Shift the automatic transmission into neutral position N.
- ▶ Push sliding knob (2) to the right and hold.

- ► Grab and remove ashtray insert from ashtray frame.
- ▶ Reinstalling ashtray insert: Push the ashtray insert back into the frame until it engages.
- ▶ Closing: Push down cover (1).

Rear door ashtray



- ▶ Opening: Press the top of ashtray ② briefly.
- ▶ Removing ashtray insert: Pull ashtray release (1) in direction of arrow.
- ► Remove ashtray insert upwards from ashtray frame.
- ▶ Reinstalling ashtray insert: Push ashtray insert back into ashtray frame until it engages.
- ▶ Closing: Push the top of ashtray (2).

Cigarette lighter

♠ Observe Safety notes, see page 52.




Never touch the heating element or sides of the lighter; they are extremely hot. Hold the knob only.

Make sure any children traveling with you do not injure themselves or start a fire with the hot cigarette lighter.

If the engine is off and the cigarette lighter is being used extensively, the vehicle battery may become discharged.

▶ Open the cover (▷ page 162).



- ► Switch on the ignition.
- ▶ Push in cigarette lighter ①. Cigarette lighter (1) will pop out automatically when hot.
- ► Take out cigarette lighter ①.
- ▶ Reinsert cigarette lighter (1) in its socket after use.

Power outlets

- Make sure no fluids come into contact with the power outlet, as this could cause a short circuit.
- Make sure the override switch is not. activated. The power outlet in the rear center console will not function if the override switch is activated.

The power outlets can be used to accommodate 12V DC electrical accessories (e.g. auxiliary lamps, mobile phone chargers) up to a maximum of 15 A (180 W).

If the engine is off and the power outlets are being used extensively, the vehicle battery may become discharged.

▶ Switch on the ignition.

Power outlet in rear center console

► Open the cover in the rear center console (> page 159).



Power outlet in trunk



Tele Aid

In order to activate the Tele Aid system, a subscriber agreement must be completed. To ensure your system is activated and operational, please press Information button •— to perform the acquaintance call. Failure to complete either of these steps may result in a system that is not activated.

If you have any questions regarding activation, please call the Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) (USA only) or 1-888-923-8367 (Canada only).

Shortly after the completion of your Tele Aid acquaintance call, you will receive a user ID and password in the mail. You may use this password to access the Tele Aid section in "Owner's Online" at **www.mbusa.com** (USA only). The "My Tele Aid" section will give you access to account information, remote door unlock and more.

The Tele Aid system is available if

- it has been activated and is operational. Activation requires a subscription for monitoring services, connection and cellular air time
- vehicle battery power is available
- the relevant cellular phone network and GPS signals are available and pass the information on to the Customer Assistance Center
- 1 Location of the vehicle on a map is only possible if the vehicle is able to receive signals from the GPS satellite network and pass the information on to the Customer Assistance Center.

The Tele Aid system

(<u>Tele</u>matic <u>Alarm Identification on Demand</u>) The Tele Aid system consists of three types of response:

- Automatic and manual emergency
- Roadside Assistance
- Information

To adjust the speaker volume during a Tele Aid call do the following:

▶ Press button + or - on the multifunction steering wheel.

or

Use the adjustment button on your COMAND system.

Be sure to check "Owner's Online" at **www.mbusa.com** (USA only) for more information and a description of all available features.

System self-test

The system performs a self-test after you have switched on the ignition.

/ Warning!

A malfunction in the system has been detected if any or all of the following conditions occur:

- The indicator lamp in the SOS button does not come on during the system self-test.
- The indicator lamp in Roadside Assistance button does not come on during the system self-test.
- The indicator lamp in Information button does not come on during the system self-test.
- The indicator lamp in the SOS button, Roadside Assistance button , or Information button remains illuminated constantly in red after the system self-test.
- The message Tele Aid Inoperative appears in the multifunction display after the system self-test.

If a malfunction is indicated as outlined above, the system may not operate as expected. In case of an emergency, help will have to be summoned by other means.

Have the system checked at the nearest Mercedes-Benz Center or contact the Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) (USA only) or 1-888-923-8367 (Canada only) as soon as possible.

Emergency calls

In order to activate the Tele Aid system, a subscriber agreement must be completed. To ensure your system is activated and operational, please press Information button • to perform the acquaintance call. Failure to complete either of these steps may result in a system that is not activated.

If you have any questions regarding activation, please call the Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) (USA only) or 1-888-923-8367 (Canada only).

An emergency call is initiated automatically following an accident in which the Emergency Tensioning Devices (ETDs) or air bags have deployed.

1 An automatically initiated Tele Aid emergency call cannot be canceled.

An emergency call can also be initiated manually (⊳ page 166).

Once the emergency call is in progress, the indicator lamp in the SOS button will begin to flash. The message Connecting Call appears in the multifunction display and the COMAND system is muted. When the connection is established, the message Call Connected appears in the multifunction display.

All information relevant to the emergency, such as the location of the vehicle (determined by the GPS satellite location system), vehicle model, identification number and color are generated.

A voice connection between the Customer Assistance Center and the occupants of the vehicle will be established automatically soon after the emergency call has been initiated. The Customer Assistance Center will attempt to determine the nature of the emergency more precisely, provided they can speak to an occupant of the vehicle.

f no vehicle occupant responds, an ambulance will be sent to the vehicle immediately.



Marning!

If the indicator lamp in the SOS button is flashing continuously and there was no voice connection to the Customer Assistance Center established, then the Tele Aid system could not initiate an emergency call (e.g. the

relevant cellular phone network is not available).

The message Call Failed appears in the multifunction display for approximately 10 seconds.

Should this occur, assistance must be summoned by other means.

1 The "911" emergency call system is a public service. Using it without due cause is a criminal offense.

Initiating an emergency call manually



- ► Briefly press on cover ① to open.
- ► Press SOS button ② briefly.

 The indicator lamp in SOS button ② will flash until the emergency call is concluded.
- ► Wait for a voice connection to the Customer Assistance Center.
- Close cover ① after the emergency call is concluded.

If you feel at any way in jeopardy when in the vehicle (e.g. smoke or fire in the vehicle, vehicle in a dangerous road location), please do not wait for voice contact after you have pressed the emergency button. Carefully leave the vehicle and move to a safe location. The Customer Assistance Center will automatically contact local emergency officials with the vehicle's approximate location if they receive an automatic SOS

signal and cannot make voice contact with the vehicle occupants.

► **Terminating calls:** Press button on the multifunction steering wheel.

or

Press the respective button for ending a telephone call on the COMAND system.

Roadside Assistance button



▶ Press and hold Roadside Assistance button ① for longer than 2 seconds. A call to a Mercedes-Benz Roadside Assistance dispatcher will be initiated. The indicator lamp in Roadside Assistance button ① will flash while the call is in progress. The message Connecting Call will appear in the multifunction display and the COMAND system is muted.

When the connection is established, the message <code>Call</code> Connected appears in the multifunction display. The Tele Aid system will transmit data generating the vehicle identification number, model, color and location (subject to availability of cellular and GPS signals).

The COMAND system display indicates that a Tele Aid call is in progress. While the call is connected you can change to the navigation menu by pressing the NAVI button on the COMAND system. Spoken commands are not available. A voice connection between the Roadside Assistance dispatcher and the occupants of the vehicle will be established.

▶ Describe the nature of the need for assistance.

The Mercedes-Benz Roadside Assistance dispatcher will either dispatch a qualified Mercedes-Benz technician or arrange to tow your vehicle to the nearest authorized Mercedes-Benz Center. For services such as labor and/or towing, charges may apply. Refer to the Roadside Assistance manual for more information.

Sign and Drive services (USA only): Services such as a jump start, a few gallons of fuel or the replacement of a flat tire with the vehicle spare wheel are obtainable at no charge.

- 1 If the indicator lamp in Roadside Assistance button (1) is flashing continuously and there was no voice connection to the Customer Assistance Center established, then the Tele Aid system could not initiate a Roadside Assistance call (e.g. the relevant cellular phone network is not available). The message Call Failed appears in the multifunction display.
- ▶ Terminating calls: Press button on the multifunction steering wheel.



or

▶ Press the respective button for ending a telephone call on the COMAND system.

Information button



Press and hold Information button (1) for longer than 2 seconds.

A call to the Customer Assistance Center will be initiated. The indicator lamp in Information button (1) will flash while the call is in progress. The message Connecting Call will appear in the multifunction display and the COMAND system is muted.

When the connection is established, the message Call Connected appears in the multifunction display. The Tele Aid system will transmit data generating the vehicle identification number, model, color and location (subject to availability of cellular and GPS signals).

1 The COMAND system display indicates that a Tele Aid call is in progress. While the call is connected you can change to the navigation menu by pressing the NAVI button on the COMAND system. Spoken commands are not available.

A voice connection between the Customer Assistance Center representative and the occupants of the vehicle will be established. Information regarding the operation of your vehicle, the nearest authorized Mercedes-Benz Center or Mercedes-Benz USA products and services is available to you.

For more details concerning the Tele Aid system, please visit www.mbusa.com (USA only), log in to "Owner's Online" and visit the "My Tele Aid" section to learn more.

- 1 If the indicator lamp in Information button 1 is flashing continuously and there was no voice connection to the Customer Assistance Center established, then the Tele Aid system could not initiate an Information call (e.g. the relevant cellular phone network is not available). The message Call Failed appears in the multifunction display.
- ► **Terminating calls:** Press button on the multifunction steering wheel.

or

Press the respective button for ending a telephone call on the COMAND system.

Call priority

If other service calls such as a Roadside Assistance call or Information call are active, an emergency call is still possible. In this case, the emergency call will take priority and override all other active calls.

The indicator lamp in the respective button flashes until the call is concluded. Automatic initiated emergency calls can only be terminated by a Customer Assistance Center representative. All other calls can be terminated by pressing button on the multifunction steering wheel or the respective button for ending a telephone call on the COMAND system.

When a Tele Aid call has been initiated, the COMAND system audio is muted. The mobile phone is no longer connected to the COMAND system. If you must use this phone, we recommend that you use it only with the vehicle at a standstill in a safe location.

Destination Download to the COMAND system

The components and operating principles of the COMAND system can be found in the separate COMAND system operating instructions. Destination Download allows you access to a database of over 10 million points of interest (POIs) that can be downloaded to your vehicle's navigation system. If you know the destination, the address can be downloaded, or can be provided with points of interests near your location.

Route guidance

You will be prompted to confirm that route guidance to the entered address is to be started.

- ► Select Yes using button or on the COMAND system.
- ► Press button ox on the COMAND system to confirm.

The system calculates the route and subsequently starts the route guidance to the defined address.

- 1 If you select No, you can save the address to your address book.
- 1 The Destination Download feature is available if the relevant mobile phone network is available and data connection is possible.

Search & Send

"Search & Send" is a navigation destination address entry service. For more information on "Search & Send", refer to separate COMAND system operating instructions.

Remote door unlock

In case you have locked your vehicle unintentionally (e.g. SmartKey inside vehicle), and the reserve SmartKey is not available:

- ► Contact the Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) (USA only) or 1-888-923-8367 (Canada only). You will be asked to provide your password.
- ► Then return to your vehicle at the time arranged with the Customer Assistance Center and pull the trunk recessed handle

for a minimum of 20 seconds until the indicator lamp in the SOS button is flashing. The message Connecting Call appears in the multifunction display.

As an alternative, you may unlock the vehicle via Internet in the "My Tele Aid" section of "Owner's Online", using your ID and password (USA only).

1 The remote door unlock feature is available if the relevant cellular phone network is available.

The SOS button will flash and the message Connecting Call will appear in the multifunction display to indicate receipt of the door unlock command.

If the tailgate recessed handle was pulled for more than 20 seconds before door unlock authorization was received by the Customer Assistance Center, you must wait 15 minutes before pulling the tailgate recessed handle again.

Stolen Vehicle Recovery Services

In the event your vehicle was stolen:

- ► Report the incident to the police. The police will issue a numbered incident report.
- ▶ Pass this number on to the Customer Assistance Center along with your password.

The Customer Assistance Center will then attempt to covertly contact the vehicle's Tele Aid system. Once the vehicle is located, the Customer Assistance Center will contact the local law enforcement and you. The vehicle's location will only be provided to law enforcement.

1 If the anti-theft alarm stays on for more than 30 seconds, the Tele Aid system will notify the Customer Assistance Center automatically.

Garage door opener

The integrated remote control can operate up to three separately controlled devices compatible with HomeLink® or some other systems.


↑ Warning!

Before programming the integrated remote control to a garage door opener or gate operator, make sure people and objects are out of the way of the device to prevent potential harm or damage. When programming a garage door opener, the door moves up or down. When programming a gate operator, the gate opens or closes.

Do not use the integrated remote control with any garage door opener that lacks safety stop and reverse features as required by U.S. federal safety standards (this includes any garage door opener model manufactured before April 1, 1982). A garage door that cannot detect an object - signaling the door to stop and reverse - does not meet current U.S. federal safety standards.

When programming a garage door opener, park vehicle outside the garage.

Do not run the engine while programming the integrated remote control. Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.



Interior rear view mirror with integrated remote control

Hand-held remote control (5) is not part of the vehicle equipment.

Programming the integrated remote control

- ▶ Step 1: Switch on the ignition.
- ► Step 2: If you have previously programmed a signal transmitter button and wish to retain its programming, proceed to step 3.

or

▶ If you are programming the integrated remote control for the first time, press and hold the two outer signal transmitter buttons ② and ④ and release them when indicator lamp ① begins to flash after approximately 20 seconds.

Do not hold the buttons for longer than 30 seconds.

This procedure erases any previous settings for all three channels and initializes the memory. If you later wish to program a second and/or third hand-held transmitter to the remaining two signal transmitter buttons, do not repeat this step and begin directly with step 3.

- ▶ Step 3: Hold the end of hand-held remote control ⑤ of the device you wish to train approximately 2 to 12 in (5 to 30 cm) away from the signal transmitter button (②, ③ or ④) to be programmed, while keeping indicator lamp ① in view.
- ▶ Step 4: Using both hands, simultaneously press hand-held remote control button ⑥ and the desired signal transmitter button (②, ③ or ④). Do not release the buttons until step 5 is completed.

 Indicator lamp ① will flash, first slowly and then rapidly.
- i Indicator lamp i flashes immediately the first time the signal transmitter button is programmed. If this button has already been programmed, the indicator lamp will start flashing after 20 seconds.

- ➤ Step 5: After indicator lamp ① changes from a slow to a rapidly flashing light, release the hand-held remote control button and the signal transmitter button.
- ▶ Step 6: Press and hold the just-trained signal transmitter button (②, ③ or ④) and observe indicator lamp ①.

 If indicator lamp ① stays on constantly, programming is complete and your device should activate when the respective signal transmitter button (②, ③ or ④) is pressed and released.
- 1 If indicator lamp 1 flashes rapidly for approximately 2 seconds and then turns to a constant light, continue with programming steps 8 through 12 as your garage door opener may be equipped with the "rolling code" feature.
- ► **Step 7:** To program the remaining two signal transmitter buttons, repeat the steps above starting with step 3.

Rolling code programming

To train a garage door opener (or other rolling code devices) with the rolling code feature, follow these instructions after completing the "Programming" portion (steps 1 through 6) of this text. For your convenience and to complete the procedure faster, you might want to have someone assist you.

- ► Step 8: Locate the "training" button on the garage door opener motor head unit.
- Exact location and color of the button may vary by garage door opener brand.

 Depending on manufacturer, the "training" button may also be referred to as "learn" or "smart" button. If there is difficulty locating the transmitting button, refer to the garage door opener Operator's Manual.
- ➤ Step 9: Press the "training" button on the garage door opener motor head unit.

 The "training light" is activated.

 You have 30 seconds to initiate the following two steps.

- ▶ Step 10: Return to the vehicle and firmly press, hold for 2 seconds and release the programmed signal transmitter button (②, ③ or ④).
- ➤ Step 11: Press, hold for 2 seconds and release same signal transmitter button a second time to complete the training process.
- i) Some garage door openers (or other rolling code equipped devices) may require you to press, hold for 2 seconds and release the same signal transmitter button a third time to complete the training process.
- ► Step 12: Confirm the garage door operation by pressing the programmed signal transmitter button (②, ③ or ④).
- ➤ **Step 13:** To program the remaining two signal transmitter buttons, repeat the steps above starting with step 3.

Gate operator/Canadian programming

Canadian radio-frequency laws require transmitter signals to "time-out" (or quit) after several seconds of transmission which may not be long enough for the integrated signal transmitter to pick up the signal during programming. Similar to this Canadian law, some U.S. gate operators are designed to "time-out" in the same manner.

If you live in Canada or if you are having difficulties programming a gate operator (regardless of where you live) by using the programming procedures, replace step 4 with the following:

- ➤ Step 4: Press and hold the signal transmitter button (②, ③ or ④). Do not release this button until it has been successfully trained.
- ▶ While still holding down the signal transmitter button (②, ③ or ④), "cycle" your hand-held remote control button ⑥ as follows: Press and hold button ⑥ for 2 seconds, then release it for 2 seconds, and again press and hold it for 2 seconds.

- Repeat this sequence on the hand-held remote control until the frequency signal has been learned.
- Upon successful training, indicator lamp ① will flash slowly and then rapidly after several seconds.
- ► Proceed with programming step 5 and step 6 to complete.
- 1 Upon completion of programming the integrated remote control, make sure you retain the hand-held remote control that came with the garage door opener, gate operator or other device. You may need it for use in other vehicles, for future programming of an integrated remote control, or simply for continued use as a hand-held remote control to operate the respective device in other situations.

Reprogramming a single signal transmitter button

To program a device using a signal transmitter button previously trained, follow these steps:

- ► Switch on the ignition.
- ▶ Press and hold the desired signal transmitter button (②, ③ or ④). Do not release the button.
 Indicator lamp ① will begin to flash after 20 seconds.
- ► Without releasing the signal transmitter button, proceed with programming starting with step 3.

Operation of integrated remote control

- ► Switch on the ignition.
- Select and press the appropriate integrated signal transmitter button (2),
 3 or 4) to activate the remote controlled device.

The integrated remote control transmitter continues to send the signal as long as the button is pressed – up to 20 seconds.

Erasing the integrated remote control memory

- 1 If you sell your vehicle, erase the codes of all three channels.
- ► Switch on the ignition.
- ► Simultaneously press and hold outer signal transmitter buttons ② and ④, for approximately 20 seconds, until indicator lamp ① flashes rapidly. Do not hold for longer than 30 seconds.

The codes of all three channels are erased.

Programming tips

If you are having difficulty programming the integrated remote control, here are some helpful tips:

- Check the frequency of hand-held remote control (5) (typically located on the reverse side of the remote). The integrated remote control is compatible with radio-frequency devices operating between 280-390 MHz.
- Put a new battery in hand-held remote control ⑤. This will increase the likelihood of the hand-held remote control sending a stronger and more accurate signal to the integrated remote control.
- While performing step 3, hold hand-held remote control (5) at different lengths and angles from the signal transmitter button ((2), (3) or (4)) you are programming.
 Attempt varying angles at the distance of 2 to 12 inches (5 to 30 cm) away or the same angle at varying distances.
- If another hand-held remote control is available for the same device, try the programming steps again using that other hand-held remote control. Make sure new batteries are in the hand-held remote control before beginning the procedure.
- Straighten the antenna wire from the garage door opener assembly. This may help improve transmitting and/or receiving signals.

1 Certain types of garage door openers are incompatible with the integrated remote control. If you should experience further difficulties with programming the integrated remote control, contact an authorized Mercedes-Benz Center, or call the Mercedes-Benz Customer Assistance Center (USA only) at 1-800-FOR-MERCedes, or the HomeLink® Hotline (USA only) at 1-800-355-3515, or the Customer Service (Canada only) at 1-800-387-0100.

1 USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

1 Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- This device may not cause interference, and
- this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Floormats



Marning!


Whenever you are using floormats, make sure there is enough clearance and that the floormats are securely fastened.

Floormats should always be securely fastened using the fastening equipment.

Before driving off, check that the floormats are securely in place and adjust them if necessary. A loose floormat could slip and hinder proper functioning of the pedals.

Do not place several floormats on top of each other as this may impair pedal movement.

► Move the driver's seat or front passenger seat as far to the rear as possible.



- ▶ Removing: Pull floormat off of retainer pins (1).
- ▶ Installing: Press floormat eyelets ② onto retainer pins (1).

Vehicle equipment	••••	170
The first 1000 miles (1500 km)		170
At the gas station		170
Engine compartment		178
Tires and wheels		182
Winter driving		208
Driving instructions		210
Maintenance		214
Vehicle care		21



Vehicle equipment

1 This Operator's Manual describes all features, standard or optional, potentially available for your vehicle at the time of purchase. Please be aware that your vehicle might not be equipped with all features described in this manual.

The first 1000 miles (1500 km)

The more cautiously you treat your vehicle during the break-in period, the more satisfied you will be with its performance later on.

- Drive your vehicle during the first 1000 miles (1500 km) at varying but moderate vehicle and engine speeds.
- During this period, avoid heavy loads (full throttle driving) and excessive engine speeds (no more than 2/3 of maximum rpm in each gear).
- Select C as the preferred shift program (⊳ page 105) for the first 1000 miles (1500 km).
- · Avoid accelerating by kickdown.
- Do not attempt to slow the vehicle down by shifting to a lower gear using the gear selector lever.
- Select gear ranges **3**, **2** or **1** (▷ page 104) only when driving at moderate speeds (for hill driving).

After 1000 miles (1500 km) you may gradually increase vehicle and engine speeds to the permissible maximum.

- Additional instructions for AMG vehicles:
 - During the first 1000 miles (1500 km), do not exceed a speed of 85 mph (140 km/h).
 - During this period, avoid engine speeds above 4500 rpm in each gear.
 - Shift gears in a timely manner.

All of the above instructions, as may apply to your vehicle type, also apply when driving the first 1000 miles (1500 km) after the engine or the rear differential has been replaced.

1 Always obey applicable speed limits.

At the gas station

Refueling

↑ Warning!

Gasoline is highly flammable and poisonous. It burns violently and can cause serious personal injury.

Never allow sparks, flames or smoking materials near gasoline!

Turn off the engine before refueling.

Whenever you are around gasoline, avoid inhaling fumes and any skin or clothing contact. Extinguish all smoking materials.

Direct skin contact with fuels and the inhalation of fuel vapors are damaging your health.



Marning!

Overfilling of the fuel tank may create pressure in the system which could cause a gas discharge. This could cause the gas to spray back out when removing the fuel pump nozzle, which could cause personal injury.

- Never refuel vehicles with gasoline engine with diesel fuel. Even small amounts of diesel fuel will damage the fuel system and engine. Damage resulting from the use of non-approved fuels or fuel additives or resulting from mixing gasoline with diesel fuel is not covered by the Mercedes-Benz Limited Warranty.
- If you have accidentally filled the tank with incorrect or non-approved fuel, do not switch on the ignition. Otherwise the incorrect or non-approved fuel will get into the fuel lines. The fuel system must be drained completely. Contact an authorized


Mercedes-Benz Center to have the fuel system drained completely.

- To prevent damage to the catalytic converters, only use premium unleaded gasoline in this vehicle.
 - Any noticeable irregularities in engine operation should be repaired promptly. Otherwise, excessive unburned fuel may reach the catalytic converter, causing it to overheat and potentially start a fire.
- ① Only use premium unleaded gasoline with a minimum Posted Octane Rating of 91 (average of 96 RON/86 MON). Information on gasoline quality can normally be found on the fuel pump. Please contact gas station personnel in case labels on the pump cannot be found. For more information on gasoline, see "Premium unleaded gasoline" (▷ page 299), see "Fuel requirements" (▷ page 299), or contact an authorized Mercedes-Benz Center, or visit www.mbusa.com (USA only).

Locking/unlocking the vehicle with the SmartKey or KEYLESS-GO automatically locks/unlocks the fuel filler flap.

1 In case the central locking system does not release the fuel filler flap, see "Fuel filler flap" (▷ page 263).

The fuel filler flap is located on the right-hand side of the vehicle towards the rear.



► Turn off the engine.

- i) Leaving the engine running and the fuel filler cap open can cause the yellow fuel tank reserve warning lamp to flash and the malfunction indicator lamp [heighe] (USA only) or [Canada only) to illuminate. For more information, see also "Practical hints" (> page 257).
- ► Remove the SmartKey from the starter switch.
 - KEYLESS-GO: Open the driver's door. This puts the starter switch in position **0**, same as with the SmartKey removed from the starter switch. The driver's door then can be closed again.
- ▶ **Opening:** Press fuel filler flap ① at the point indicated by the arrow.
- ► Turn fuel filler cap ② counterclockwise.
- ► Take off fuel filler cap ②.
- ▶ Place fuel filler cap ② in direction of arrow into holder ③.
- ► Fully insert filler nozzle unit and refuel.
- ► Only fill your tank until the filler nozzle unit cuts out do not top off or overfill.
- ► Closing: Turn fuel filler cap ② clockwise until it audibly engages.
- Olose the fuel filler flap before locking the vehicle. Otherwise the flap locking pin will prevent closing the fuel filler flap.
- ► Close fuel filler flap ①.

Check regularly and before a long trip

For information on quantities and requirements of operating agents, see "Fuels, coolants, lubricants, etc." (> page 296). Check the following:

- Engine oil level (⊳ page 179)
- Tire inflation pressure (⊳ page 185)
- Coolant level (▷ page 180)
- Vehicle lighting (> page 266)

- Washer system and headlamp cleaning system (⊳ page 181)
- Brake fluid (> page 182)

Engine compartment

Hood



Marning!

Do not pull the release lever while the vehicle is in motion. Otherwise the hood could be forced open by passing air flow.

This could cause the hood to come loose and injure you and/or others.

Opening



↑ Warning!

If you see flames or smoke coming from the engine compartment, or if the coolant temperature indicator indicates that the engine is overheated, do not open the hood. Move away from vehicle and do not open the hood until the engine has cooled. If necessary, call the fire department.

Warning!

You could be injured when the hood is open even when the engine is turned off.

Parts of the engine can become very hot. To prevent burns, let the engine cool completely before touching any components on the vehicle. Comply with all relevant safety precautions.

↑ Warning!

To help prevent personal injury, stay clear of moving parts when the hood is open and the engine is running.

The radiator fan may continue to run for approximately 30 seconds or may even restart after the engine has been turned off. Stay clear of fan blades.

↑ Warning!

The engine is equipped with a transistorized ignition system. Because of the high voltage it is dangerous to touch any components (ignition coils, spark plug sockets, diagnostic socket) of the ignition system

- · with the engine running
- · while starting the engine
- when the ignition is switched on and the engine is turned manually



- ▶ Pull hood lock release lever (1). The hood is unlocked.
- Never open the hood if the wiper arms are folded forward away from the windshield. Otherwise the windshield wipers or the hood could be damaged.



- ▶ Push handle (2) under the hood upwards.
- ▶ Pull up on the hood and then release it. The hood will be held open at shoulder height by gas-filled struts automatically.

Closing

Marning!

When closing the hood, use extreme caution not to catch hands or fingers. Be careful that you do not close the hood on anyone.

Make sure the hood is securely engaged before driving off. Do not continue driving if the hood can no longer engage after an accident, for example. The hood could otherwise come loose while the vehicle is in motion and injure you and/or others.

- ► Let the hood drop from a height of approximately 8 in (20 cm).
- ► Check to make sure the hood is fully closed.

If you can raise the hood at a point above the headlamps, then it is not properly closed. Open it again and let it drop with somewhat greater force.

Engine oil

The amount of oil your engine consumes will depend on a number of factors, including driving style. Increased oil consumption can occur when the vehicle is new or the vehicle is driven frequently at higher engine speeds. Engine oil consumption checks should only be made after the vehicle break-in period.

Do not use any special lubricant additives, as these may damage the drive assemblies. Using special additives not approved by Mercedes-Benz may cause damage not covered by the Mercedes-Benz Limited Warranty.

For further information contact an authorized Mercedes-Benz Center.

Notes on checking engine oil level

When checking the oil level


- the vehicle must be parked on level ground
- with the engine at operating temperature, the vehicle must have been stationary for

at least 5 minutes with the engine turned

 with the engine not at operating temperature, the vehicle must have been stationary for at least 30 minutes with the engine turned off

Checking engine oil level

▶ Open the hood (> page 178).



- ▶ Pull out oil dipstick ①.
- ▶ Wipe oil dipstick (1) clean.
- ▶ Slowly insert oil dipstick (1) fully into the dipstick guide tube.
- ▶ Pull out oil dipstick (1) again after approximately 3 seconds to obtain accurate reading.

The oil level is correct when it is between lower (min) mark (3) and upper (max) mark (2) of oil dipstick (1).

① CLS 550:

The filling quantity between the upper and lower marks on the oil dipstick is approximately 2.1 US qt. (2.0 l).

1 CLS 63 AMG:

The filling quantity between the upper and lower marks on the oil dipstick is approximately 1.6 US qt. (1.5 l).

▶ If necessary, add engine oil. For more information on engine oil, see "Fuels, coolants, lubricants etc." (⊳ page 296).

For information on messages in the multifunction display concerning engine oil, see the "Practical hints" section (> page 246).

Adding engine oil

I Only use approved engine oils and oil filters required for vehicles with Maintenance System. For a listing of approved engine oils and oil filters, contact an authorized Mercedes-Benz Center or visit www.mbusa.com (USA only).

The following will result in engine or emission control system damage not covered by the Mercedes-Benz Limited Warranty:

- Using engine oils and oil filters of specification other than those expressly required for the Maintenance System.
- Changing of oil and oil filter at change intervals longer than those called for by the Maintenance System.
- Using any oil additives.



CLS 550



CLS 63 AMG

- ▶ Unscrew filler cap (1) from filler neck.
- Add engine oil as required. Be careful not to overfill with oil.

Be careful not to spill any oil when adding. Avoid environmental damage caused by oil entering the ground or water.

- Excess oil must be siphoned or drained off. It could cause damage to the engine and emission control system not covered by the Mercedes-Benz Limited Warranty.
- ► Screw filler cap ① back on filler neck. For more information on engine oil, see the "Technical data" section (▷ page 296) and (▷ page 298).

Transmission fluid level

The transmission fluid level does not need to be checked. If you notice transmission fluid loss or gearshifting malfunctions, have an authorized Mercedes-Benz Center check the transmission.

Coolant level


The engine coolant is a mixture of water and anticorrosion/antifreeze.

When checking the coolant level, the vehicle must be parked on level ground, and the coolant temperature must be below 158°F (70°C).

/ Warning!

In order to avoid any potentially serious burns:

- Use extreme caution when opening the hood if there are any signs of steam or coolant leaking from the cooling system, or if the coolant temperature indicator indicates that the coolant is overheated.
- Do not remove the cap on the coolant expansion tank if the coolant temperature is above 158°F (70°C). Allow the engine to cool down before removing the cap. The coolant expansion tank contains hot fluid and is under pressure.
- Using a rag, slowly open the cap approximately 1/2 turn counterclockwise to relieve excess pressure. If opened immediately, scalding hot fluid and steam will be blown out under pressure.
- Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts.



- ► Using a rag, slowly open cap (1) approximately 1/2 turn counterclockwise to relieve excess pressure.
- ► Continue turning cap (1) counterclockwise and remove it.

The coolant level is correct if the level

- for cold coolant: reaches marking bar (3) in coolant expansion tank (2)
- for warm coolant: is approximately 0.6 in (1.5 cm) higher
- ► Add coolant as required.
- ▶ Screw cap (1) back on and tighten it.

For more information on coolant, see the "Technical data" section (> page 297) and (⊳ page 300).

Washer system and headlamp cleaning system



Marning!

Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/ antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned.

- Always use washer solvent/antifreeze where temperatures may fall below freezing point. Failure to do so could result in damage to the washer system/fluid reservoir.
- I Only use washer fluid which is suitable for plastic lenses. Improper washer fluid can damage the plastic lenses of the headlamps.
- Do not use distilled or deionized water in the washer fluid reservoir. Otherwise, the washer fluid level sensor could be damaged.

Fluid for the washer system and the headlamp cleaning system is supplied from the washer fluid reservoir.

During all seasons, use MB Windshield Washer Concentrate "MB SummerFit". Mix it with water or premixed washer solvent/ antifreeze depending on the ambient temperature (⊳ page 302).




- ▶ Opening washer fluid reservoir: Pull tab of cap (1) upwards.
- ▶ Refill the washer fluid reservoir.
- ► Closing washer fluid reservoir: Press cap (1) onto filler hole until it engages.

For more information, see "Washer system and headlamp cleaning system" (⊳ page 297).

Brake fluid level

If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum. mark or below, have the brake system checked for brake pad thickness and leaks immediately. Contact an authorized Mercedes-Benz Center immediately. Do not add brake fluid as this will not solve the problem. For more information, see "Practical hints".

When checking the brake fluid level, the vehicle must be parked on level ground.



The brake fluid level is correct when it is between lower mark (MIN) (2) and upper mark (MAX) (1) of the brake fluid reservoir.

Tires and wheels

Safety notes

Contact an authorized Mercedes-Benz Center for information on tested and recommended rims and tires for summer and winter operation. They can also offer advice concerning tire service and purchase.

↑ Warning!

Replace rims or tires with the same designation, manufacturer and type as shown on the original part. For further information contact an authorized Mercedes-Benz Center. If incorrectly sized rims and tires are mounted, the wheel brakes or suspension components can be damaged. Also, the operating clearance of the wheels and the tires may no longer be correct.



/ Warning!

Worn, old tires can cause accidents. If the tire tread is worn to minimum tread depth, or if the tires have sustained damage, replace them.

When replacing rims, only use genuine Mercedes-Benz wheel bolts specified for the particular rim type. Failure to do so can result in the bolts loosening and possibly an accident.

Retreaded tires are not tested or recommended by Mercedes-Benz, since previous damage cannot always be recognized on retreads. The operating safety of the vehicle cannot be assured when such tires are used.



↑ Warning!

If you feel a sudden significant vibration or ride disturbance, or you suspect that possible damage to your vehicle has occurred, you

should turn on the hazard warning flashers, carefully slow down, and drive with caution to an area which is a safe distance from the road. Inspect the tires and the vehicle underbody for possible damage. If the vehicle or tires

appear unsafe, have the vehicle towed to the nearest authorized Mercedes-Benz Center or tire dealer for repairs.

Marning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You could lose control of the vehicle. Continued driving with a flat tire or driving at high speed with a flat tire will cause excessive heat buildup and possibly a fire.

Important guidelines

- Only use sets of tires and rims of the same type and make.
- Tires must be of the correct size for the rim.
- Break in new tires for approximately 60 miles (100 km) at moderate speeds.
- · Regularly check the tires and rims for damage. Dented or bent rims can cause tire inflation pressure loss and damage to the tire beads.
- If the vehicle is heavily loaded, check tire inflation pressure and correct as required.
- Do not allow your tires to wear down too far. Adhesion properties on wet roads are sharply reduced at tread depths of less than $\frac{1}{8}$ in (3 mm).
- · When replacing individual tires, you should mount new tires on the front wheels first (on vehicles with same-sized wheels all around).

Recommended tire inflation pressure



Marning!

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Your vehicle is equipped with the Tire and Loading Information placard located on the driver's door B-pillar (⊳ page 193).

The tire inflation pressure should be checked regularly. Only adjust the tire inflation pressure on cold tires. The tires can be considered cold if the vehicle has been parked for at least 3 hours or driven less than 1 mile (1.6 km). Depending on the ambient temperature, the driving speed and the tire load, the tire temperature changes. When the tire temperature changes by 18°F (10°C), the tire inflation pressure will change by approximately 1.5 psi (0.1 bar). Keep this in mind when checking tire inflation pressure on warm tires and adjust the tire pressure only if the tire inflation pressure is too low for the current operating conditions. If you check the tire inflation pressure when the tires are warm, the reading will be higher than the cold reading. This is normal. Do not let air out to match the specified cold tire inflation

pressure. Otherwise, the tire will be underinflated.

Follow recommended cold tire inflation pressures listed on Tire and Loading Information placard on the driver's door B-pillar.

Keeping the tires properly inflated provides the best handling, tread life and riding comfort.

In addition to the Tire and Loading Information placard on the driver's door B-pillar, also consult the tire inflation pressure label on the inside of the filler flap for any additional information pertaining to special driving situations. For more information, see "Important notes on tire inflation pressure" (⊳ page 184).

Data shown on Tire and Loading Information placard example are for illustration purposes only. Tire data are specific to each vehicle and may vary from data shown in the following illustration. Refer to Tire and Loading Information placard on vehicle for actual data specific to your vehicle.

62 I	RENECONEMENT	THE LES PHEUS	ET LE OI WASEMENT
	DATES CHARTY TO	7 7 TOUT 2	T SERVE E TRUE E
		or a should never on on or loss or dall jewels dis	contribution part to a
TRE PNEU	100E TABLE	PROTEC MESSURE PROJECT PRODUCTION	SEE CHANERS MANUAL FOR
TAGNET CANNOT	286/46/ZR:8/09/3L	2001094, 25 (FG)	ACCITIONAL INFORMATIONS
MARGIE MAN	286/36 2018 10173).	200 1014, 25 750	(a)
SAVAGE DE FREDHVINDE	17(10.010)	1271011, 10792	ETT

The Tire and Loading Information placard lists the recommended cold tire inflation pressures (1) for maximum loaded vehicle weight. The tire inflation pressures listed apply to the tires installed as original equipment.

Important notes on tire inflation pressure



Marning!

If the tire inflation pressure drops repeatedly, check the tires for punctures from foreign objects and/or whether air is leaking from the valves or from around the rim.

Tire temperature and tire inflation pressure are also increased while driving, depending on the driving speed and the tire load.

If you will be driving your vehicle at high speeds of 100 mph (160 km/h) or higher, where it is legal and conditions allow, consult the tire inflation pressure label on the inside of the fuel filler flap on how to adjust the cold tire inflation pressure. If you do not adjust the tire inflation pressure, excessive heat can build up and result in sudden tire failure.

If you are not sure about the proper tire inflation, contact an authorized Mercedes-Benz Center.

1 Driving comfort may be reduced when the tire inflation pressure is adjusted to the value for speeds above 100 mph (160 km/h) as specified on the tire inflation pressure label located on the inside of the fuel filler flap.


Make sure to readjust the tire inflation pressure for normal driving speeds. Supplemental tire inflation pressure information for different loading conditions of the vehicle can be found on the tire inflation pressure label. The tire inflation pressure label is located on the inside of the fuel filler

For the tire inflation pressure for spare wheels such as Minispare wheels or spare wheels with collapsible tire refer to

- the yellow label on the spare wheel rim
- the "Technical data" section of this Operator's Manual (⊳ page 296)
- the Tire and Loading Information placard on the driver's door B-pillar

Unless specified otherwise, the tire inflation pressures on the tire inflation pressure label are valid for all approved, factory-equipped tires. When a tire size is specified, the tire inflation pressure that follows applies to that particular tire size only.


1 Data shown on tire inflation pressure label examples are for illustration purposes only. Tire inflation pressure data are specific to each vehicle and may vary from data shown in the following illustrations. Refer to the tire inflation pressure label on vehicle for actual data specific to your vehicle.



Example illustration: Tire inflation pressures for all approved, factory equipped tires

Some tire inflation pressure labels may only show the rim diameter instead of the entire tire size, e.g. R 18 or 18".

The rim diameter is part of the tire size as specified on the tire sidewall (▷ page 202).



Example illustration: Tire inflation pressures specific to rim diameter

Potential problems associated with underinflated and overinflated tires

Underinflated tires

↑ Warning!

Follow recommended tire inflation pressures. Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Underinflated tires can

- cause excessive and uneven tire wear
- adversely affect fuel economy
- · lead to tire failure from being overheated
- adversely affect handling characteristics

Overinflated tires



↑ Warning!

Follow recommended tire inflation pressures. Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Overinflated tires can

- adversely affect handling characteristics
- · cause uneven tire wear
- be more prone to damage from road hazards
- adversely affect ride comfort
- increase stopping distance

Checking tire inflation pressure

Safety notes



↑ Warning!

Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Check the tire inflation pressure at least once a month.

Check and adjust the tire inflation pressure when the tires are cold (\triangleright page 183).

Checking tire inflation pressure manually

Follow the steps below to achieve correct tire inflation pressure:

- ▶ Remove the cap from the valve on one tire.
- Firmly press a tire gauge onto the valve.
- ▶ Read the tire inflation pressure on the tire gauge and check against the recommended tire inflation pressure on the Tire and Loading Information placard on the driver's door B-pillar (⊳ page 193). If necessary, add air to achieve the recommended tire inflation pressure.
- ▶ If you have overfilled the tire, release tire inflation pressure by pushing the metal stem of the valve with e.g. a tip of a pen. Then recheck the tire inflation pressure with the tire gauge.
- ► Install the valve cap.
- ▶ Repeat this procedure for each tire.

Tire pressure loss warning system (Canada only)

While the vehicle is being driven, the tire pressure loss warning system monitors the set tire inflation pressures by evaluating each wheel's rotational speed. This allows the system to detect a significant loss of pressure in a tire. If a wheel's rotational speed changes due to falling tire inflation pressure, you will see a corresponding warning message in the multifunction display.

The tire pressure loss warning system may function in a restricted manner or with a delay

- · when snow chains are mounted to the vehicle
- in the presence of ice and snow
- when you are driving on a loose surface (e.g. sand or gravel)
- when you are driving in a very sporty manner (involving rapid acceleration or high speeds in curves)
- · when you are driving with a loaded roof rack or heavily laden vehicle



When the multifunction display shows the message Tire Pressure Check Tires, one or more of your tires are significantly underinflated. You should stop and check your tires as soon as possible, and inflate them to the proper tire inflation pressure as indicated on the vehicle's Tire and Loading Information placard or on the tire inflation pressure label.

Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Each tire, including the spare, should be checked at least once a month when cold. Inflate the tires to the recommended tire inflation pressure as specified on

- the Tire and Loading Information placard on the driver's door B-pillar
- the tire inflation pressure label located on the inside of the fuel filler flap
- 1 The recommended tire inflation pressures for your vehicle can be found on
 - the Tire and Loading Information placard located on the driver's door B-pillar (⊳ page 193)
 - the tire inflation pressure label on the inside of the fuel filler flap

The tire inflation pressures are not listed in the Operator's Manual.

The tire pressure loss warning system does not provide a warning for wrongly selected tire inflation pressures. Always adjust tire inflation pressure according to the Tire and Loading Information placard on the driver's door B-pillar or on the tire inflation pressure label located on the inside of the fuel filler flap.

The tire pressure loss warning system does not replace regular checks of the tire inflation pressures since a gradual pressure loss in more than one tire cannot be detected by the tire pressure loss warning system.

The tire pressure loss warning system is not able to issue a warning due to a sudden dramatic loss of tire inflation pressure (e.g. tire blowout caused by a foreign object). In this case bring the vehicle to a halt by carefully applying the brakes and avoiding abrupt steering maneuvers.

Restarting the tire pressure loss warning system

The tire pressure loss warning system must be restarted in the following situations:

- after you have changed the tire inflation pressure
- after you have replaced the wheels or tires
- after you have installed new wheels or tires
- ▶ Using the Tire and Loading Information placard on the driver's door B-pillar or, if available, the tire inflation pressure label on the inside of the fuel filler flap, make sure the tire inflation pressure of all four tires is correct.



↑ Warning!

The tire pressure loss warning system can only warn you in a reliable manner if you have set the correct tire inflation pressures for each tire.

If an incorrect tire inflation pressure was set, the system will monitor the pressure according to the incorrect value.

- Switch on the ignition.
- ► Make sure the standard display appears in the multifunction display (⊳ page 112).
- ▶ Press button 🔯 or 🗘 on the multifunction steering wheel repeatedly until the following message appears in the multifunction display:

Run Flat Indicator

Active

Menu: R-Button

▶ Press the reset button (> page 109). The following message will appear in the multifunction display:

Restart.

Run Flat Indicator?

▶ If you wish to confirm: Press button

The following message will appear in the multifunction display:

Run Flat Indicator Restarted

After a certain "learning phase", the tire pressure loss warning system checks the set pressure values for all four tires.

▶ If you wish to cancel: Press button —.

Tire Pressure Monitoring System (TPMS), (USA only)

Your vehicle is equipped with a Tire Pressure Monitoring System (TPMS). It measures the tire inflation pressure in the vehicle's tires and issues warnings in case of pressure loss. The Tire Pressure Monitoring System (TPMS) is equipped with a combination low tire pressure/TPMS malfunction telltale in the instrument cluster. Depending on how the telltale illuminates, it indicates a low tire pressure condition or a malfunction in the TPMS system itself:

- If the telltale illuminates continuously, one or more of your tires are significantly underinflated. There is no malfunction in the TPMS
- · If the telltale flashes for 60 seconds and then stays illuminated, the TPMS system itself is not operating properly.

The TPMS only functions on wheels that are equipped with the proper electronic sensors. It monitors the tire inflation pressure, as selected by the driver, in all four tires. A warning is issued to alert you to a decrease in pressure in one or more of the tires.



/ Warning!

The TPMS does not indicate a warning for wrongly selected inflation pressures. Always adjust tire inflation pressure according to the Tire and Loading Information placard or the supplemental tire inflation pressure information on the inside of the fuel filler flap. The TPMS is not able to issue a warning due to a sudden dramatic loss of pressure (e.g. tire blowout caused by a foreign object). In this case bring the vehicle to a halt by carefully applying the brakes and avoiding abrupt steering maneuvers.



/ Warning!

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door Bpillar or the tire inflation pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure.

Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately 1 minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is

illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

- If a condition causing the TPMS to malfunction develops, it may take up to 10 minutes for the system to signal a malfunction using the TPMS telltale flashing and illumination sequence.

 The telltale extinguishes after a few minutes driving if the malfunction has been corrected.
- Operating radio transmission equipment (e.g. wireless headsets, two-way radios) in or near the vehicle could cause the TPMS to malfunction.
- 1 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - This device may not cause harmful interference, and
 - this device must accept any interference received, including interference that may cause undesired.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Tire inflation pressure warnings

If the system detects a significant loss of tire inflation pressure in one or more than one tire, a message appears in the multifunction display. In addition, an acoustic warning sounds and the low tire pressure telltale in the instrument cluster comes on.



Example illustration

Restarting the TPMS

↑ Warning!

It is the driver's responsibility to set the tire inflation pressure to the recommended cold tire inflation pressure. Underinflated tires affect the ability to steer or brake the vehicle. You might lose control over the vehicle.

When you restart the TPMS, the system sets new reference values for each tire.

The TPMS must be restarted when you have adjusted the tire inflation pressure to a new level (e.g. because of different load or driving conditions). The TPMS is then recalibrated to the current tire inflation pressures.

Restart the TPMS after adjusting the tire inflation pressure to the inflation pressure recommended for the vehicle operating condition. Tire inflation pressure should only be adjusted on cold tires. Observe the recommended tire inflation pressure on the Tire and Loading Information placard on the driver's door B-pillar. Some vehicles may have supplemental tire inflation pressure information for driving at high speeds or for vehicle loads less than the maximum loaded vehicle condition. If such information is provided, it can be found on the inside of the fuel filler flap.

- ▶ Using the Tire and Loading Information placard on the driver's door B-pillar (▷ page 193) or, if available, the supplemental tire inflation pressure information on the inside of the fuel filler flap, make sure the tire inflation pressure of all four tires is correct.
- Switch on the ignition.

- ▶ Press button 🗊 or 🗊 on the multifunction steering wheel repeatedly until the standard display appears in the multifunction display (▷ page 112).
- ▶ Press button 🗘 or 🔯 on the multifunction steering wheel repeatedly until the following message appears in the multifunction display:

Tire Pressure Monitor Active

Menu: R-Button

- ▶ Press the reset button (▷ page 109). The following message appears in the multifunction display: Restart tire pressure monitor?
- ▶ If you wish to confirm: Press button + .

The following message appears in the multifunction display:

Tire Pressure Monitor Restarted

After driving a few minutes the system verifies that the current tire inflation pressures are within the system's specified range. Afterwards, the current tire inflation pressures are accepted as reference values and then monitored.

▶ If you wish to cancel: Press button —.

Advanced Tire Pressure Monitoring System (Advanced TPMS), (Canada only)

Your vehicle is equipped with the Advanced Tire Pressure Monitoring System (Advanced TPMS). It measures the tire inflation pressure in the vehicle's tires and issues warnings in case of pressure loss in one or more of the tires.

The TPMS only functions on wheels that are equipped with the proper electronic sensors.

- 1 This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:
 - 1. This device may not cause interference, and
 - 2. this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

↑ Warning!

The TPMS does not indicate a warning for wrongly selected inflation pressures. Always adjust tire inflation pressure according to the Tire and Loading Information placard or the supplemental tire inflation pressure information on the inside of the fuel filler flap.

The TPMS is not able to issue a warning due to a sudden dramatic loss of pressure (e.g. tire blowout caused by a foreign object). In this case bring the vehicle to a halt by carefully applying the brakes and avoiding abrupt steering maneuvers.



/ Warning!

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door Bpillar or the tire inflation pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.


As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your

tires are significantly underinflated.
Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure.

Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

Tire pressure inquiries are made using the multifunction display. The current tire inflation pressure for each tire appears in the multifunction display after a few minutes of driving.

- 1 Possible differences between the readings of a tire pressure gauge of an air hose, e.g. gas station equipment, and the vehicle's control system can occur. The tire pressure displayed by the control system apply to sea level. In high-altitude locations, the reading on a tire pressure gauge will be higher than the reading issued by the vehicle's control system. Do not reduce the tire inflation pressure under such circumstances.
- ► Switch on the ignition.
- ▶ Press button or on the multifunction steering wheel repeatedly until the standard display appears in the multifunction display (▷ page 112).
- ► Press button or until the current inflation pressure for each tire appears in the multifunction display.




Example illustration

When the vehicle has been parked for longer than 20 minutes, the message Tire pressure is only displayed after driving for a few minutes appears in the multifunction display.

- With a spare wheel mounted, the system may still indicate the tire inflation pressure of the removed road wheel for some minutes. If this happens, keep in mind that the indicated value where the spare wheel is mounted does not reflect the actual spare tire inflation pressure.
- 1 Operating radio transmission equipment (e.g. wireless headsets, two-way radios) in or near the vehicle could cause the TPMS to malfunction.

Tire inflation pressure warnings

If the system detects a significant loss of tire inflation pressure in one or more than one tire, a message appears in the multifunction display. In addition, an acoustic warning sounds and the low tire pressure telltale in the instrument cluster comes on.



Example illustration

The respective tire is indicated by a red rectangle.

Restarting Advanced TPMS



/\ Warning!

It is the driver's responsibility to set the tire inflation pressure to the recommended cold tire inflation pressure. Underinflated tires affect the ability to steer or brake the vehicle. You might lose control over the vehicle.

When you restart the TPMS, the system sets new reference values for each tire.

The TPMS must be restarted when you have adjusted the tire inflation pressure to a new level (e.g. because of different load or driving conditions). The TPMS is then recalibrated to the current tire inflation pressures.

Restart the TPMS after adjusting the tire inflation pressure to the inflation pressure recommended for the vehicle operating condition. Tire inflation pressure should only be adjusted on cold tires. Observe the recommended tire inflation pressure on the Tire and Loading Information placard on the driver's door B-pillar. Some vehicles may have supplemental tire inflation pressure information for driving at high speeds or for vehicle loads less than the maximum loaded vehicle condition. If such information is provided, it can be found on the inside of the fuel filler flap.

Canada only:

The TPMS usually recognizes tire pressure adjustments and sets new reference values automatically. You can, however, restart the TPMS manually as described.

- ▶ Using the Tire and Loading Information placard on the driver's door B-pillar (⊳ page 193) or the supplemental tire inflation pressure information on the inside of the fuel filler flap, make sure the tire inflation pressure of all four tires is correct.
- ▶ Switch on the ignition.
- ▶ Press button 🗊 or 🛅 on the multifunction steering wheel repeatedly until the standard display appears in the multifunction display (▷ page 112).

▶ Press button or repeatedly until you see the current inflation pressures for each tire appear in the display or the following message appears in the multifunction display:

Tire pressure is only displayed after driving for a few minutes

▶ Press the reset button (▷ page 108). The following message will appear in the multifunction display: Restart

tire pressure monitor?

▶ If you wish to confirm: Press button

The following message will appear in the multifunction display:

Tire Pressure Monitor Restarted

After driving a few minutes the system verifies that the current tire inflation pressures are within the system's specified range. Afterwards the current tire inflation pressures are accepted as reference values and then monitored.

- ▶ If you wish to cancel: Press button .
- **1** When the wheel positions have been changed, the inflation pressure of a tire may be displayed for the wrong position temporarily. After driving for a few minutes, the inflation pressure will be shown for the correct position.

Maximum tire inflation pressure



↑ Warning!

Never exceed the maximum tire inflation pressure. Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort. wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.



for illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

This is the maximum permissible tire inflation pressure (1) for the tire.

Always follow the recommended tire inflation pressure (⊳ page 183) for proper tire inflation.

Loading the vehicle

Two labels on your vehicle show how much weight it may properly carry.

(1) The Tire and Loading Information placard can be found on the driver's door B-pillar. This placard tells you important information about the number of people that can be in the vehicle and the total weight that can be carried in the vehicle. It also contains information on the proper size and recommended tire inflation

- pressures for the original equipment tires on your vehicle.
- (2) The certification label, also found on the driver's door B-pillar. It tells you about the gross weight capacity of your vehicle, called the Gross Vehicle Weight Rating (GVWR). The GVWR includes the weight of the vehicle, all occupants, fuel and cargo. The certification label also tells you about the front and rear axle weight capacity, called the Gross Axle Weight Rating (GAWR).

The GAWR is the total allowable weight that can be carried by a single axle (front or rear). Never exceed the GVWR or GAWR for either the front axle or rear axle.



1) Driver's door B-pillar

Following is a discussion on how to work with the information contained on the Tire and Loading Information placard with regards to loading your vehicle.

Tire and Loading Information



↑ Warning!

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Tire and Loading Information placard

1 Data shown on Tire and Loading Information placard example are for illustration purposes only. Load limit data are specific to each vehicle and may vary from data shown in the following illustration. Refer to Tire and Loading Information placard on vehicle for actual data specific to your vehicle.

39 T	HENSE KNEMENT	NUMBER OF	MARION ET LE CHARGEMENT
Two contined	CATHO OXIVOTE NO OMBIG DE SEGOS NO Hight of ecoparts and c	as a should rever exceed	CODOL P SENSOR T
180	900 WALE	0000 18 8 PHESSURE PRESSURE (RESSURE PRESSURE RESSURE	BEE CHAMERS MANUAL FOR
HON!	295/40/2818/90731	2021074, 25 750	ADDITIONAL INFORMATIONS
SERVICE STATE	285/36/2818 (2011)	200104, 2179	en
ON THE CONTRACTOR	0'5/65 (819F	421104, 6079	


The Tire and Loading Information placard showing load limit information ① is located on the driver's door B-pillar (▷ page 193).

► Locate the statement "The combined weight of occupants and cargo should never exceed XXX kilograms or XXX lbs." on the Tire and Loading Information placard.

The combined weight of all occupants, cargo/luggage and trailer tongue load (if applicable) should never exceed the weight referenced in that statement.

Seating capacity

1 Data shown on Tire and Loading Information placard example are for illustration purposes only. Seating capacity data are specific to each vehicle and may vary from data shown in the following illustration. Refer to Tire and Loading Information placard on vehicle for actual data specific to your vehicle.



P40.00-2132-31

The seating capacity gives you important information on the number of occupants that can be in the vehicle. Observe front and rear seating capacity. The Tire and Loading Information placard showing seating capacity ① is located on the driver's door B-pillar (> page 193).

Steps for determining correct load limit

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

- ➤ Step 1: Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's Tire and Loading Information placard.
- ► Step 2: Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Step 3: Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.
- ➤ **Step 4:** The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1 400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1400 750 (5 x 150) = 650 lbs).

- ▶ Step 5: Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4.
- ▶ Step 6 (if applicable): If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle (▷ page 197).

The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a load limit of 1500 lbs. **This is for illustration purposes only.** Make sure you are using the actual load limit for your vehicle stated on the vehicle's Tire and Loading Information placard (▷ page 194).

		Example 1	Example 2	Example 3
Step 1	Combined weight limit of occupants and cargo from Tire and Loading Information placard	1 500 lbs	1 500 lbs	1 500 lbs

		Example 1	Example 2	Example 3
Step 2	Number of occupants (driver and passengers)	5	3	1
	Seating configuration	front: 2 rear: 3	front: 1 rear: 2	front: 1
	Occupants weight	Occupant 1: 150 lbs Occupant 2: 180 lbs Occupant 3: 160 lbs Occupant 4: 140 lbs Occupant 5: 120 lbs	Occupant 1: 200 lbs Occupant 2: 190 lbs Occupant 3: 150 lbs	Occupant 1: 150 lbs
	Combined weight of all occupants	750 lbs	540 lbs	150 lbs

		Example 1	Example 2	Example 3
Step 3	Available cargo/ luggage and trailer tongue weight (total load limit from Tire and Loading Information placard minus combined weight of all occupants)	1500 lbs - 750 lbs = 750 lbs	1500 lbs - 540 lbs = 960 lbs	1500 lbs - 150 lbs = 1350 lbs

The higher the weight of all occupants, the less cargo and luggage load capacity is available.

For more information, see "Trailer tongue load" (⊳ page 197).

Certification label

Even after careful determination of the combined weight of all occupants, cargo and the trailer tongue load (if applicable) (> page 197) as to not exceed the permissible load limit, you must make sure your vehicle never exceeds the Gross Vehicle

Weight Rating (GVWR) and the Gross Axle Weight Rating (GAWR) for either the front or rear axle. You can obtain the GVWR and GAWR from the certification label. The certification label can be found on the driver's door B-pillar, see the "Technical data" section (⊳ page 288).

Gross Vehicle Weight Rating (GVWR): The total weight of the vehicle, all occupants, all cargo, and the trailer tongue load (if applicable) must never exceed the GVWR.

Gross Axle Weight Rating (GAWR): The total allowable weight that can be carried by a single axle (front or rear).

To assure that your vehicle does not exceed the maximum permissible weight limits (GVWR and GAWR for front and rear axle), have the loaded vehicle (including driver, passengers and all cargo and, if applicable, trailer fully loaded) weighed on a suitable commercial scale.

Trailer tongue load

The tongue load of any trailer is an important weight to measure because it affects the load you can carry in your vehicle. If a trailer is towed, the tongue load must be added to the weight of all occupants riding and any cargo you are carrying in the vehicle. The tongue load typically is 10% of the trailer weight and everything loaded in it.

Your Mercedes-Benz has been designed primarily to carry passengers and their cargo. Mercedes-Benz does not recommend trailer towing with your vehicle.

Maximum tire load



Marning!

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result

in handling or steering problems, or brake failure.



for illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

The maximum tire load rating (1) is the maximum weight the tires are designed to support.

For more information on tire load rating, see (⊳ page 202).

For information on calculating total and cargo load capacities, see (⊳ page 194).

Direction of rotation

Unidirectional tires offer added advantages. such as better hydroplaning performance. To benefit, however, you must make sure the tires rotate in the direction specified.

An arrow on the sidewall indicates the intended direction of rotation of the tire.

Spare wheels may be mounted against the direction of rotation (spinning) even with a unidirectional tire for temporary use only until the regular drive wheel has been repaired or replaced. Always observe and follow applicable temporary use restrictions and speed limitations indicated on the spare wheel.

MOExtended system

The MOExtended system allows you to continue driving your vehicle even if there is a total loss of pressure in one or more tires.

You may only use the MOExtended system in conjunction with the tire pressure loss warning system (⊳ page 186), the TPMS (⊳ page 188), or the Advanced TPMS (⊳ page 190).

For information on driving in case of pressure loss in one or more tires (emergency mode), see the "Practical Hints" section (⊳ page 277).

Tire care and maintenance



/ Warning!

Regularly check the tires for damage. Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle.

Worn, old tires can cause accidents. If the tire tread is worn to minimum tread depth, or if the tires have sustained damage, replace them.

Check the tire inflation pressure at least once a month. For more information on checking tire inflation pressure, see "Recommended tire inflation pressure" (⊳ page 183).

Tire inspection

Every time you check the tire inflation pressure, you should also inspect your tires for the following:

- excessive treadwear (> page 198)
- cord or fabric showing through the tire's rubber
- bumps, bulges, cuts, cracks or splits in the tread or side of the tire

Replace the tire if you find any of the above conditions.

Make sure you also inspect the spare tire periodically for condition and inflation. Spare tires will age and become worn over time even if never used, and thus should be inspected and replaced when necessary.

Life of tire



↑ Warning!

Tires and spare tire should be replaced after 6 years, regardless of the remaining tread.

The service life of a tire is dependent upon varying factors including but not limited to:

- · Driving style
- Tire inflation pressure
- Distance driven

Tread depth



↑ Warning!

Although the applicable federal motor vehicle safety laws consider a tire to be worn when the treadwear indicators (TWI) become visible at approximately $^{1}/_{16}$ in (1.6 mm), we recommend that you do not allow your tires to wear down to that level. As tread depth approaches $\frac{1}{8}$ in (3 mm), the adhesion properties on a wet road are sharply reduced. Depending upon the weather and/or road surface (conditions), the tire traction varies widely.

Do not allow your tires to wear down too far. Adhesion properties on wet roads are sharply reduced at tread depths of less than 1/8 in (3 mm).

Treadwear indicators (TWI) are required by law. These indicators are located in six places on the tread circumference and become visible at a tread depth of approximately $\frac{1}{16}$ in (1.6 mm), at which point the tire is considered worn and should be replaced.

The recommended minimum tire tread depth for summer tires is $\frac{1}{8}$ in (3 mm). The recommended minimum tire tread depth for winter tires is $\frac{1}{6}$ in (4 mm).



Treadwear indicator ① appears as a solid band across the tread.

Storing tires


Keep unmounted tires in a cool, dry place with as little exposure to light as possible. Protect tires from contact with oil, grease and fuels.

Cleaning tires

Never use a round nozzle to power wash tires. The intense jet of water can result in damage to the tire.

Always replace a damaged tire.

Uniform Tire Quality Grading Standards



The Uniform Tire Quality Grading is a U.S. Government requirement designed to give drivers consistent and reliable information regarding tire performance. Tire manufacturers are required to grade tires

based on three performance factors: treadwear ①, traction ②, and temperature resistance ③. Although not a Government of Canada requirement, all tires made for sale in North America have these grades branded on the sidewall.

for illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

Quality grades can be found, where applicable, on the tire sidewall between tread shoulder and maximum section width. For example:

Treadwear	Traction	Temperature
200	AA	A

All passenger car tires must conform to federal safety requirements in addition to these grades.

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified U.S. Government test course. For example, a tire graded 150 would wear one and one-half $(1^{-1}/_2)$ times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction



The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration.

cornering, hydroplaning, or peak traction characteristics.

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

↑ Warning!

If ice has formed on the road, tire traction will be substantially reduced. Under such weather conditions, drive, steer and brake with extreme caution.

The safe speed on a wet, snow covered or icy road is always lower than on a dry road. You should pay particular attention to the condition of the road whenever the outside temperature is close to the freezing point. Mercedes-Benz recommends winter tires (⊳ page 208) with a minimum tread depth of approximately $\frac{1}{6}$ in (4 mm) on all four wheels for the winter season to ensure normal balanced handling characteristics. On packed snow, they can reduce your stopping distance compared to summer tires. Stopping distance, however, is still considerably greater than when the road is not covered with snow or ice. Exercise appropriate caution.

Avoid spinning of a drive wheel. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Temperature



↑ Warning!

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause

excessive heat build-up and possible tire failure.

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Rotating tires



/ Warning!

Rotate front and rear wheels only if the tires are of the same dimension.

If your vehicle is equipped with mixed-size tires (different tire dimensions front vs. rear), tire rotation is not possible.



Marning!

Have the tightening torque checked after changing a wheel. Wheels could become loose if not tightened with a torque of 96 lb-ft (130 Nm).

Only use genuine Mercedes-Benz wheel bolts specified for your vehicle's rims.

Tire rotation can be performed on vehicles with tires of the same dimension all around. If your vehicle is equipped with tires of the same dimension all around, tires can be rotated, observing a front-to-rear rotation pattern that will maintain the intended rotation (spinning) direction of the tire (⊳ page 197).

In some cases, such as when your vehicle is equipped with mixed-size tires (different tire dimension front vs. rear), tire rotation is not possible.


If applicable to your vehicle's tire configuration, tires can be rotated according to the tire manufacturer's recommended intervals in the tire manufacturer's warranty pamphlet located in your vehicle literature portfolio. If none is available, tires should be rotated every 3 000 to 6 000 miles (5 000 to 10 000 km), or sooner if necessary, according to the degree of tire wear. The same rotation (spinning) direction must be maintained. Rotate tires before the characteristic tire wear pattern becomes visible (shoulder wear on front tires and tread center wear on rear tires).

Thoroughly clean the mounting face of wheels and brake disks, i.e. the inner side of the wheels/tires, during each rotation. Check for and ensure proper tire inflation pressure. For information on wheel change, see "Flat tire" (> page 271).

Tire labeling

Besides tire name (sales designation) and manufacturer name, a number of markings can be found on a tire.


Following are some explanations for the markings on your vehicle's tires:



- ① Uniform Tire Quality Grading Standards(▷ page 199)
- DOT, Tire Identification Number(> page 204)
- ③ Maximum tire load (▷ page 197)
- Maximum tire inflation pressure(▷ page 192)
- (5) Manufacturer
- ⑥ Tire ply material (▷ page 205)
- ⑦ Tire size designation, load and speed rating (⊳ page 202)
- Tire name
- 1 For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

For more information, see "Rims and tires" (> page 291).

Tire size designation, load and speed rating



- Tire width
- ② Aspect ratio in %
- ③ Radial tire code
- (4) Rim diameter
- ⑤ Load index
- 6 Speed symbol
- for illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

General: Depending on the design standards used, the tire size molded into the sidewall may have no letter or a letter preceding the tire size designation.

No letter preceding the size designation (as illustrated above): Passenger car tire based on European design standards.

Letter "P" preceding the size designation: Passenger car tire based on U.S. design standards.

Letter "LT" preceding the size designation: Light Truck tire based on U.S. design standards.

Letter "T" preceding the size designation: Temporary spare tires which are high pressure compact spares designed for temporary emergency use only.

Tire width

Tire width 1 indicates the nominal tire width in millimeters.

Aspect ratio

Aspect ratio (2) is the dimensional relationship between tire section height and section width and is expressed in percentage. The aspect ratio is arrived at by dividing section height by section width.

Tire code

Tire code (3) indicates the tire construction type. The "R" stands for radial tire type. Letter "D" means diagonal or bias ply construction; letter "B" means belted-bias ply construction.

At the tire manufacturer's option, any tire with a speed capability above 149 mph (240 km/h) can include a "ZR" in the size designation (for example: 245/40 ZR 18). For additional information, see "Tire speed rating" (⊳ page 203).

Rim diameter

Rim diameter (4) is the diameter of the bead seat, not the diameter of the rim edge. The rim diameter is indicated in inches (in).

Load index



The tire load rating must always be at least half of the GAWR of your vehicle. Otherwise, tire failure may be the result which may cause an accident and/or serious injury to you or others.

Always replace rims and tires with the same designation, manufacturer and type as shown on the original part.

↑ Warning!

Do not overload the tires by exceeding the specified load limit as indicated on the Tire and Loading Information placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Load index (5) is a numerical code associated with the maximum load a tire can support.

For example, a load rating of 91 corresponds to a maximum load of 1356 lb (615 kg) the tire is designed to support. See also "Maximum tire load" (> page 197) where the maximum load associated with the load index is indicated in kilograms and lbs.

For additional information on the load index, see "Load identification" (> page 204).

Speed symbol

Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure, causing loss of vehicle control and possibly resulting in an accident and/or serious personal injury and possible death, for you and for others.

Regardless of the tire speed rating, local speed limits should be obeyed. Use prudent driving speeds appropriate to prevailing conditions.

Speed symbol (a) indicates the approved maximum speed (tire speed rating) for the tire.

Summer tires

Index	Speed rating
Q	up to 100 mph (160 km/h)
R	up to 106 mph (170 km/h)
S	up to 112 mph (180 km/h)
Т	up to 118 mph (190 km/h)
Н	up to 130 mph (210 km/h)
V	up to 149 mph (240 km/h)
W	up to 168 mph (270 km/h)
Υ	up to 186 mph (300 km/h)
ZRY	up to 186 mph (300 km/h)

Index	Speed rating
ZR(Y)	above 186 mph (300 km/h)
ZR	above 149 mph (240 km/h)

• At the tire manufacturer's option, any tire with a speed capability above 149 mph (240 km/h) can include a "ZR" in the size designation (for example: 245/40 ZR18). To determine the maximum speed capability of the tire, the service description for the tire must be referred to. The service description is comprised of load index (5) and speed symbol (6). If your tire includes "ZR" in the size designation and no service description is given, the tire manufacturer must be consulted for the maximum speed

If a service description is given, the speed capability is limited by the speed symbol in the service description. Example: 245/40 ZR 18 97Y. In this example, "97Y" is the service description. The letter "Y" designates the speed rating and the speed capability of the tire is limited to 186 mph (300 km/h).

 Any tire with a speed capability above 186 mph (300 km/h) must include a "ZR" in the size designation AND the service description must be placed in parenthesis. Example: 275/40 ZR 18 (99Y). The "(Y)" speed symbol in parenthesis designates the maximum speed capability of the tire as being above 186 mph (300 km/h). Consult the tire manufacturer for the actual maximum permissible speed of the tire.

All-season and winter tires

capability.

Index	Speed rating
Q M+S ¹¹	up to 100 mph (160 km/h)
T M+S ¹¹	up to 118 mph (190 km/h)

Index	Speed rating
H M+S ¹¹	up to 130 mph (210 km/h)
V M+S ¹¹	up to 149 mph (240 km/h)

in Not all M+S rated tires provide special winter performance. Make sure the tires you use show M+S and the mountain/snowflake marking on the tire sidewall. These tires meet specific snow traction performance requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) and have been designed specifically for use in snow conditions.

An electronic speed limiter prevents your vehicle from exceeding a speed of:

- 130 mph (210 km/h): CLS 550 CLS 550 (Sport Package)
- 155 mph (250 km/h): CLS 63 AMG
- 186 mph (300 km/h): CLS 63 AMG (Performance Package)

The factory equipped tires on your vehicle may have a tire speed rating above the maximum speed permitted by the electronic speed limiter.

Make sure your tires have the required tire speed rating as specified for your vehicle in the "Technical data" section (⊳ page 291), for example when purchasing new tires.

If you are uncertain about the correct reading of the information given on a tire's sidewall, any authorized Mercedes-Benz Center will be glad to assist you.

Load identification



for illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

In addition to the load index, special load identification ① may be molded into the tire sidewall following the letter designating the speed symbol ⑥ (> page 202).

- No specification given: absence of any text (like in above example) indicates a standard load (SL) tire.
- XL or Extra Load: designates an extra load (or reinforced) tire.
- Light Load: designates a light load tire.
- C, D, E: designates load range associated with the maximum load a tire can carry at a specified pressure.

DOT, Tire Identification Number (TIN)

U.S. tire regulations require each new tire manufacturer or tire retreader to mold a TIN into or onto a sidewall of each tire produced.



The TIN is a unique identifier. The TIN facilitates efforts by tire manufactures to notify purchasers in recall situations or other safety matters concerning tires. It gives purchasers the means to easily identify such tires.

The TIN is comprised of "Manufacturer's identification mark" (2), "Tire size" (3), "Tire type code" (4) and "Date of manufacture" (5).

• For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

DOT (Department of Transportation)

Tire branding symbol ① denotes that the tire meets requirements of the U.S. Department of Transportation.

Manufacturer's identification mark

Manufacturer's identification mark ② denotes the tire manufacturer.

New tires have a mark with two symbols. Retreaded tires have a mark with four symbols. For more information on retreaded tires, see (▷ page 182).

Tire size

Code (3) indicates the tire size.

Tire type code

Tire type code 4 may, at the option of the manufacturer, be used as a descriptive code for identifying significant characteristics of the tire.

Date of manufacture

The date of manufacture (5) identifies the week and year of manufacture.

The first two figures identify the week, starting with "01" to represent the first full week of the calendar year. The second two figures represent the year.

For example, "3208" represents the 32nd week of 2008.

Tire ply material



1 For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

This marking tells you about the type of cord and number of plies in the sidewall ① and under the tread ②.

Tire and loading terminology

Accessory weight

The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats,

radio, and heater, to the extent that these items are available as factory-installed equipment (whether installed or not).

Air pressure

The amount of air inside the tire pressing outward on each square inch of the tire. Air pressure is expressed in pounds per square inch (psi), kilopascal (kPa), or bar.

Aspect ratio

Dimensional relationship between tire section height and section width expressed in percentage.

Bar

Metric unit for air pressure. There are 14.5038 pounds per square inch (psi) to 1 bar; there are 100 kilopascals (kPa) to 1 bar.

Bead

The tire bead contains steel wires wrapped by steel cords that hold the tire onto the rim.

Cold tire inflation pressure

Tire inflation pressure when your vehicle has been sitting for at least 3 hours or driven no more than 1 mile (1.6 km).

Curb weight

The weight of a motor vehicle with standard equipment including the maximum capacity of fuel, oil, and coolant, and, if so equipped, air conditioning and additional optional equipment, but without passengers and cargo.

DOT (Department of Transportation)

A tire branding symbol which denotes the tire meets requirements of the U.S. Department of Transportation.

GAWR (Gross Axle Weight Rating)

The GAWR is the maximum permissible axle weight. The gross vehicle weight on each axle must never exceed the GAWR for the front and rear axle indicated on the certification label located on the driver's door B-pillar.

GVW (Gross Vehicle Weight)

The GVW comprises the weight of the vehicle including fuel, tools, spare wheel, installed accessories, passengers and cargo and, if applicable, trailer tongue load. The GVW must never exceed the GVWR indicated on the certification label located on the driver's door B-pillar.

GVWR (Gross Vehicle Weight Rating)

This is the maximum permissible vehicle weight of the fully loaded vehicle (weight of the vehicle including all options, passengers, fuel, and cargo and, if applicable, trailer tongue load). It is indicated on the certification label located on the driver's door B-pillar.

Kilopascal (kPa)

Metric unit for air pressure. There are 6.9 kPa to 1 psi; another metric unit for air pressure is bar. There are 100 kilopascals (kPa) to 1 bar.

Load index

Numerical code associated with the maximum load a tire can support.

Maximum load rating

The maximum load in kilograms and pounds that can be carried by the tire.

Maximum loaded vehicle weight

The sum of curb weight, accessory weight, total load limit, and production options weight.

Maximum permissible tire inflation pressure

This number is the greatest amount of air pressure that should ever be put in the tire.

Normal occupant weight

The number of occupants the vehicle is designed to seat, multiplied by 68 kilograms (150 lb).

Occupant distribution

The distribution of occupants in a vehicle at their designated seating positions.

Production options weight

The combined weight of those installed regular production options weighing over 5 lbs (2.3 kilograms) in excess of those standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim.

PSI (Pounds per square inch)

A standard unit of measure for air pressure.

Recommended tire inflation pressure

The recommended tire inflation pressure for normal driving conditions is listed on the Tire and Loading Information placard located on the driver's door B-pillar. It provides best handling, tread life and riding comfort. Supplemental information pertaining to special driving situations can be found on the tire inflation pressure label on the inside of the fuel filler flap.

Rim

A metal support for a tire or a tire and tube assembly upon which the tire beads are seated.

Sidewall

The portion of a tire between the tread and the bead.

TIN (Tire Identification Number)

Unique identifier which facilitates efforts by tire manufacturers to notify purchasers in recall situations or other safety matters concerning tires and gives purchasers the means to easily identify such tires. The TIN is comprised of "Manufacturer's identification mark", "Tire size", "Tire type code" and "Date of manufacture".

Tire ply composition and material used

This indicates the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. Tire manufacturers also must indicate the ply materials in the tire and sidewall, which include steel, nylon, polyester, and others.

Tire speed rating

Part of tire designation (speed symbol); indicates the speed range for which a tire is approved.

Total load limit

Rated cargo and luggage load plus 68 kilograms (150 lb) times the vehicle's designated seating capacity.

Traction

The adhesive friction of a tire on a surface on which it moves. The amount of grip provided.

Tread

The portion of a tire that comes into contact with the road.

Treadwear indicators

Narrow bands, sometimes called "wear bars" that show across the tread of a tire when only $^{1}/_{16}$ in (1.6 mm) of tread remains.

Uniform Tire Quality Grading Standards

A tire information system that provides consumers with ratings for a tire's traction, temperature and treadwear. Ratings are determined by tire manufacturers using U.S. government testing procedures. The ratings are molded into the sidewall of the tire.

Vehicle maximum load on the tire

Load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight and dividing it by two.

Winter driving

General information

Have your vehicle winterized at an authorized Mercedes-Benz Center.

Winter tires



/ Warning!

Winter tires with a tread depth of less than ¹/₆ in (4 mm) must be replaced. They are no longer suitable for winter operation.



/ Warning!

If you use your spare wheel when winter tires are fitted on the other wheels, be aware that the difference in tire characteristics may very well impair turning stability and that overall driving stability may be reduced. Adapt your driving style accordingly.

Have the spare wheel replaced by a regular road wheel with a winter tire at the nearest authorized Mercedes-Benz Center.

Always use winter tires at temperatures below 45°F (7°C) and whenever wintry road conditions prevail. Not all M+S rated tires provide special winter performance. Make sure the tires you use show the mountain/ snowflake A marking on the tire sidewall. These tires meet specific snow traction performance requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) and have been designed specifically for use in snow conditions. Use of winter tires is the only way to achieve the maximum effectiveness of your vehicle's driving safety systems such as the ABS and the ESP® in winter operation.

For safe handling, make sure all mounted winter tires are of the same make and have the same tread design.

For information on winter tires for your vehicle model, see the "Technical data" section (⊳ page 291).

Always observe the speed rating of the winter tires installed on your vehicle.

Snow chains

- When driving with snow chains, always select the raised level of the vehicle level control. Other settings may result in damage to your vehicle.
- I Some tire sizes do not leave adequate clearance for snow chains. To help avoid serious damage to your vehicle or tires. make sure the use of snow chains is permissible as specified in the "Technical data" section of this Operator's Manual.

Snow chains should only be driven on snowcovered roads at speeds not to exceed 30 mph (50 km/h). Remove chains as soon as possible when driving on roads without snow.

Observe the following guidelines when using snow chains:

- Use of snow chains is not permissible with all wheel/tire combinations (⊳ page 291).
- Use snow chains in pairs and on rear wheels only. Follow the manufacturer's mounting instructions.
- If snow chains are mounted to the front wheels, they may scrape against the body or axle components. The tires or the vehicle could be damaged as a result.
- Only use snow chains that are approved by Mercedes-Benz. Any authorized Mercedes-Benz Center will be glad to advise you on this subject.
- · Use of snow chains may be prohibited depending on location. Always check local and state laws before installing snow chains.
- Do not use snow chains on the spare wheel.
- 1 When driving with snow chains, you may wish to switch off the ESP® (⊳ page 59) before setting the vehicle in motion. This will improve the vehicle's traction.

Winter driving instructions

↑ Warning!

If the vehicle becomes stuck in snow, make sure snow is kept clear of the exhaust pipe and from around the vehicle with the engine running. Otherwise, deadly carbon monoxide (CO) gases may enter vehicle interior resulting in unconsciousness and death.

To assure sufficient fresh air ventilation, open a window slightly on the side of the vehicle not facing the wind.



Warning!

The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.



↑ Warning!

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

The most important rule for slippery or icy roads is to drive sensibly and to avoid abrupt acceleration, braking and steering maneuvers. Do not use the cruise control system under such conditions.

When the vehicle is in danger of skidding, shift the automatic transmission to neutral position N. Try to keep the vehicle under control by corrective steering action.

1 For information on driving with snow chains, see "Snow chains" (⊳ page 208).

Road salts and chemicals can adversely affect braking efficiency. Increased pedal force may become necessary to produce the normal brake effect.

Depressing the brake pedal periodically when traveling at length on salt-strewn roads can bring road-salt-impaired braking efficiency back to normal.

If the vehicle is parked after being driven on salt-treated roads, the braking efficiency should be tested as soon as possible after driving is resumed.



↑ Warning!

Make sure not to endanger any other road users when carrying out these braking maneuvers.

Driving instructions

Drive sensibly - save fuel

To save fuel you should:

- Keep tires at the recommended inflation pressures.
- · Remove unnecessary loads.
- · Remove roof rack when not in use.
- Allow engine to warm up under low load
- · Avoid frequent acceleration and deceleration.
- Have all maintenance work performed at the intervals specified in the Maintenance Booklet and as required by the Maintenance system. Contact an authorized Mercedes-Benz Center.

Fuel consumption is also increased by driving in cold weather, in stop-and-go traffic, on short trips and in mountainous areas.

Drinking and driving



Marning!

Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident are greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

Pedals



↑ Warning!

Make sure absolutely no objects are obstructing the pedals' range of movement. Keep the driver's footwell clear of all

obstacles. If there are any floormats or carpets in the footwell, make sure that the pedals still have sufficient clearance.

During sudden driving or braking maneuvers, the objects could get caught between the pedals. You could then no longer brake or accelerate. This could lead to accidents and injury.

Power assistance



↑ Warning!

There is no power assistance for the steering and the brake when the engine is not running. Steering and braking requires significantly more effort and you could lose control of the vehicle and cause an accident as a result. Do not turn off the engine while the vehicle is in motion.

Brakes

Downhill grades

When driving down long and steep grades, relieve the load on the brakes by shifting into a lower gear to use the engine's braking power. This helps prevent overheating of the brakes and reduces wear.

When using the engine's braking power, a drive wheel may not spin for an extended period of time, e.g. on slippery road surfaces. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Continuous or hard braking



↑ Warning!

Resting your foot on the brake pedal will cause excessive and premature wear of the brake pads.

It can also result in the brakes overheating. thereby significantly reducing their effectiveness. It may not be possible to stop the vehicle in sufficient time to avoid an accident.

After hard braking, it is advisable to drive on for some time, rather than immediately park, so that the air stream will cool down the brakes faster

Wet roads



After driving in heavy rain for some time without applying the brakes or through water deep enough to wet brake components, the first braking action may be somewhat reduced and increased pedal pressure may be necessary to obtain expected brake effect. Maintain a safe distance from vehicles in front.

To help prevent brake disk corrosion after driving on wet or salt-covered roads, it is advisable to brake the vehicle with considerable force prior to parking. The heat generated serves to dry the brakes.

Salt-covered roads



Marning!

A layer of salt on the brake discs and the brake linings may cause a delay in the braking effect, resulting in a significantly increased braking distance, which could lead to an accident.

To avoid this danger, you should:

· occasionally brake carefully when you are driving on salt-covered roads, so that any layer of salt that may have built up on the brake discs and the brake linings is

- removed without putting other road users at risk
- maintain a greater distance to the vehicle ahead and drive with particular care
- carefully apply the brakes at the end of a trip and immediately after commencing a new trip, so that salt residues are removed from the brake disc

Brake service

I The brake fluid level in the reservoir may be too low if the brake warning lamp in the instrument cluster comes on and an acoustic warning sounds although the parking brake is released. Observe additional messages in the multifunction display that may appear.

Brake pad wear or a leak in the system may be the reason for low brake fluid in the reservoir.

Have the brake system inspected immediately. Contact an authorized Mercedes-Benz Center.

All checks and service work on the brake system should be carried out by qualified technicians only. Contact an authorized Mercedes-Benz Center.

Only install brake pads and use brake fluid recommended by Mercedes-Benz.



↑ Warning!

If other than recommended brake pads are installed, or other than recommended brake fluid is used, the braking properties of the vehicle can be degraded to an extent that safe braking is substantially impaired. This could result in an accident.

Because the ESP® operates automatically, the engine and ignition must be shut off (SmartKey in starter switch position 0 or 1 or KEYLESS-GO start/stop button in position 0 or 1) when the parking brake is being tested on a brake test

dynamometer or when the vehicle is being towed with the front axle raised.

Active braking action through the ESP® may otherwise seriously damage the brake system which is not covered by the Mercedes-Benz Limited Warranty.

If your brake system is only subjected to moderate loads, you should occasionally test the effectiveness of the brakes by applying above-normal braking pressure at higher speeds. This will also enhance the grip of the brake pads.

↑ Warning!

Make sure not to endanger any other road users when carrying out these braking maneuvers.

Refer to the description of the Brake Assist System (BAS) (⊳ page 59).

High-performance brake system

The high-performance brake system is only available on CLS 63 AMG.



↑ Warning!

New vehicle brake pads and discs, and replacement brake pads and discs may take several hundred miles of driving until they provide optimum braking efficiency. Until that time, you may need to use increased brake pedal pressure while braking. Please be aware of this and adjust your driving and braking accordingly during this break-in period. Excessive high-demand braking will cause correspondingly high brake wear. Please be attentive to the brake warning lamp in the instrument cluster and brake condition messages in the multifunction display. Especially for high performance driving, it is important to maintain and have the brake system checked regularly.

The high-performance brake system is designed to operate under the extremely high operating demands required to

accommodate the performance capabilities of the vehicle.

The brakes may produce a squeaking-type noise depending on the

- vehicle speed
- brake force applied
- · ambient conditions, e.g. temperature and humidity

As with any brake system, the wear of individual brake system components such as brake pads or disks strongly depends on your driving style and the conditions under which you operate the vehicle. Thus, a driving style calling for high-demand braking will cause your vehicle's brakes to wear more quickly.

Driving off

Warm up the engine smoothly. Do not place full load on the engine until the operating temperature has been reached.

- When driving off on a slippery surface, do not allow a drive wheel to spin for an extended period with the ESP® switched off. Doing so may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.
- Simultaneously depressing the accelerator pedal and applying the brakes reduces engine performance and causes premature brake and drivetrain wear which is not covered by the Mercedes-Benz Limited Warranty.

Hydroplaning

Depending on the depth of the water layer on the road, hydroplaning may occur, even at low speeds and with new tires. In heavy rain or when conditions indicate possible hydroplaning:

- ► Reduce vehicle speed.
- ► Avoid track grooves in the road.
- Apply brakes cautiously.

Standing water

Do not drive through flooded areas. Before driving through water, determine its depth.

If you must drive through standing water, drive slowly to prevent water from entering the passenger compartment or the engine compartment. Water in these areas could cause damage to electrical components or wiring of the engine or transmission, or could result in water being ingested by the engine through the air intake causing severe internal engine damage. Any such damage is not covered by the Mercedes-Benz Limited Warranty.

Driving abroad

If you plan to drive the vehicle outside the U.S. or Canada, you should request dealer network information for your destination from any authorized Mercedes-Benz Center.

Control and operation of radio transmitter

Safety notes



Marning!

Please do not forget that your primary responsibility is to drive the vehicle. A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call.

If you choose to use the telephone 12 while driving, please use the hands-free device and only use the telephone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a mobile telephone while driving a vehicle.

Only operate the COMAND¹² (Cockpit Management and Data System) if road, weather and traffic conditions permit. Otherwise, you may not be able to observe traffic conditions and could endanger yourself and others.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Emission control

Certain systems of the engine serve to keep the toxic components of the exhaust gases within permissible limits required by law.

These systems will function properly only when maintained strictly according to factory specifications. Any adjustments on the engine should, therefore, be carried out only by qualified Mercedes-Benz Center authorized technicians.

Engine adjustments should not be altered in any way. Moreover, the specified service procedures must be carried out regularly according to Mercedes-Benz servicing requirements. For details refer to the Maintenance Booklet.



Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these

¹² Observe all legal requirements.

conditions, drive only with at least one window fully open at all times.

Maintenance

Notes

The Maintenance System in your vehicle tracks the distance driven and the time elapsed since the last maintenance service. It calculates other maintenance service work required, and calls for the next maintenance service accordingly.

We strongly recommend that you have your vehicle serviced at an authorized Mercedes-Benz Center. Have it serviced in accordance with the Maintenance Booklet at the times called for by the maintenance service indicator.

failure to have the vehicle maintained in accordance with the Maintenance Booklet and maintenance service indicator at the designated times/mileage will result in vehicle damage not covered by the Mercedes-Benz Limited Warranty.

Maintenance service indicator message

information.

Information on maintenance work and maintenance intervals are specified in the Maintenance Booklet. Contact an authorized Mercedes-Benz Center, or visit www.mbusa.com (USA only) for additional

The maintenance service indicator message will notify you when the next maintenance service is required.

Starting approximately 1 month before the next maintenance service is required, one of the following messages will appear in the multifunction display. The messages will appear while you are driving or when you switch on the ignition (example service A):

Service A Due In XXXX Miles (Km)

Service A Due In XX Days Service A Due In X Day Service A Due Now



Refer to Maintenance Booklet for a listing of maintenance services and intervals they need to be performed at.

Clearing the maintenance service indicator message

The maintenance service indicator message is cleared automatically

- after approximately 10 seconds when you switch on the ignition
- after approximately 10 seconds when reaching the service threshold while driving
- after approximately 30 seconds, once the suggested maintenance service term has passed



➤ Clearing the maintenance service indicator message manually: Press reset button ① on the instrument cluster.

The standard display appears in the multifunction display.

Maintenance service term exceeded

If you have exceeded the suggested maintenance service term, you will see the following message in the multifunction display:

Service A Exceeded By XXXXX Miles (Km)

Service A Exceeded By XXX Days Service A Exceeded By X Day In addition, a signal sounds when the

message appears.

Any authorized Mercedes-Benz Center will reset the maintenance service indicator following a completed maintenance service.

Calling up the maintenance service indicator display

 The menu overview can be found on. (⊳ page 112).

You can call up the maintenance service indicator display at any time to check when the next maintenance service is required.

- ▶ Switch on the ignition.
- ▶ Press button 🗊 or 🗐 on the multifunction steering wheel repeatedly until the standard display (⊳ page 112) appears in the multifunction display.
- ▶ Press button 🔯 or 🗘 on the multifunction steering wheel until the maintenance service indicator display with the service symbol <a> and the maintenance service deadline appears in the multifunction display.
- f the battery was disconnected, the days of disconnection will not be included in the count shown by the maintenance service indicator. To arrive at the true maintenance service deadline, you will need to subtract these days from the days shown in the maintenance service indicator message or maintenance service indicator display.

Do not confuse the maintenance service indicator with the engine oil level indicator **₩**.

Resetting the maintenance service indicator

In the event that the maintenance service on your vehicle is not carried out at an authorized Mercedes-Benz Center, you can have the maintenance service indicator reset.

The automotive maintenance facility carrying out the maintenance service will find the information for resetting the maintenance service indicator in the maintenance-relevant literature for your vehicle.

Such literature is available at any authorized Mercedes-Benz Center or directly from Mercedes-Benz.

If the maintenance service indicator was reset inadvertently, have an authorized Mercedes-Benz Center correct it. Only reset the maintenance service indicator if the proper maintenance service has been performed. Not following the proper maintenance service as described in the Maintenance Booklet will result in engine damage and/or other vehicle damage not covered by the Mercedes-Benz Limited Warranty.

Vehicle care

Cleaning and care of the vehicle

Notes

Regular and proper care will help to maintain the value of your vehicle.



↑ Warning!

Many cleaning products can be hazardous. Some are poisonous, others are flammable. Always follow the instructions on the particular container. Always open your

vehicle's doors or windows when cleaning the inside.

Never use fluids or solvents that are not designed for cleaning your vehicle.

Always lock away cleaning products and keep them out of reach of children.

When cleaning the vehicle, do not use scouring agents. Never apply strong force and only use a soft, wet cloth or sponge. Otherwise you may scratch or damage the surface to be cleaned.

While in operation, even while parked, your vehicle is subjected to varying external influences which, if gone unchecked, can attack the paintwork as well as the vehicle underbody and cause lasting damage.

Such damage is caused not only by extreme and varying climatic conditions, but also by:

- Air pollution
- · Road salt
- Tar
- · Gravel and stone chipping

To avoid paint damage, you should immediately remove:

- · Grease and oil
- Fuel
- Coolant
- Brake fluid
- · Bird droppings
- Insects
- Tree resins etc.

Frequent washing reduces and/or eliminates the aggressiveness and potency of the above adverse influences.

More frequent washings are necessary to deal with unfavorable conditions:

- · near the ocean
- in industrial areas (smoke, exhaust emissions)
- during winter operation

You should check your vehicle from time to time for stone chipping or other damage. Any damage should be repaired as soon as possible to prevent corrosion.

In doing so, do not neglect the underbody of the vehicle. A prerequisite for a thorough check is a washing of the underbody followed by a thorough inspection. Damaged areas need to be re-undercoated.

Your vehicle has been treated at the factory with a wax-base rustproofing in the body cavities which will last for the lifetime of the vehicle. Post-production treatment is neither necessary nor recommended by Mercedes-Benz because of the possibility of incompatibility between materials used in the production process and others applied later.

We have selected vehicle-care products and compiled recommendations which are specially matched to our vehicles and which always reflect the latest technology. You can obtain Mercedes-Benz approved vehicle-care products at an authorized Mercedes-Benz Center.

Scratches, corrosive deposits, corrosion or damage due to negligent or incorrect care cannot always be removed or repaired with the vehicle-care products recommended here. In such cases it is best to seek aid at an authorized Mercedes-Benz Center.

The following topics deal with the cleaning and care of your vehicle and give important "how-to" information as well as references to Mercedes-Benz approved vehicle-care products.

Power washer

Follow the instructions provided by the power washer manufacturer on maintaining a distance between the vehicle and the nozzle of the power washer.

Never use a round nozzle to power-wash tires. The intense jet of water can result in damage to the tire.

Always replace a damaged tire.

Always keep the jet of water moving across the surface. Do not aim directly at electrical parts, electrical connectors, seals, or other rubber parts.

1 Vehicles with KEYLESS-GO:
If a door handle is hit by a strong jet of water, and a SmartKey is within approximately 3 ft (1 m) of the vehicle, it could be inadvertently locked or unlocked.

Tar stains

Quickly remove tar stains before they dry and become more difficult to remove. A tar remover is recommended.

Paintwork, painted body components

Affixing stickers, magnets, adhesive tape or similar materials to painted body components may damage the paintwork.

Mercedes-Benz approved Paint Care should be applied when water drops on the paint surface do not "bead up". This should normally be done every 3 to 5 months, depending on the climate and washing detergent used.

Mercedes-Benz approved Paint Cleaner should be applied if the paint surface shows signs of embedded dirt (i.e. loss of gloss).

Do not apply any of these products or wax if your vehicle is parked in the sun or if the hood is still hot.

 Use the appropriate MB-Touch-Up Stick for quick and provisional repairs of minor paint damage (i.e. chips from stones, vehicle doors, etc.).

Vehicles with mat paint

Your vehicle is painted with mat clear-coat paint. Observe the following notes to avoid paint damage caused by improper treatment.

- ① Only use insect remover and car shampoo approved by Mercedes-Benz.
- Do not polish the vehicle. Polishing will brighten the paintwork.

Do not use paintwork cleaning agents, abrasives, polishing compounds, or wax for paintwork care. Such products are intended for use on high-polish surfaces. Using such products on mat paint causes severe damage, such as bright, spotted areas on the respective surface.

Have paintwork repairs performed at an authorized Mercedes-Benz Center.

Have stone chipping repairs as soon as possible.

Remove the following immediately if possible. Do not apply strong force.

- Soak insect remains with insect remover and rinse them of with water afterwards.
 Use a soft bristle toothbrush for remains that have not come off.
- Soak bird droppings with water and rinse them of with water afterwards. Use a soft bristle toothbrush for remains that have not come off.
- Remove tree resins, grease, oil, and gasoline with silicone remover.
- Dab off wax with silicone remover.
- Dab off tar splashes or tar stains with tar remover.

Engine cleaning

Prior to cleaning the engine compartment, make sure to protect electrical components and connectors from contact with water and cleaning agents.

Corrosion protection, such as MB
Anticorrosion Wax should be applied to the engine compartment after every engine cleaning. Before applying, all control linkage bushings and joints should be lubricated. The poly-V-belt and all pulleys should be protected from any wax.

Vehicle washing

In the winter, thoroughly remove all traces of road salt as soon as possible.

When washing the vehicle underbody, do not forget to clean the inner sides of the wheels.

1 Vehicles with KEYLESS-GO:

If a door handle is hit by a strong jet of
water, and a SmartKey is within
approximately 3 ft (1 m) of the vehicle, it
could be inadvertently locked or unlocked.

Hand-wash

- ► Do not use hot water or wash your vehicle in direct sunlight.
- ► Only use a soft, wet cloth or sponge to clean the vehicle.
- Only use a mild vehicle wash detergent, such as Mercedes-Benz approved Car Shampoo.
- ► Thoroughly spray the vehicle with a diffused jet of water.
- ▶ Do not spray directly towards the ventilation intake.
- ► Use plenty of water and rinse the sponge and chamois frequently.
- ► Rinse with clean water and dry with a chamois thoroughly.

Do not allow cleaning agents to dry on the finish

Automatic car wash

You can have your vehicle washed in an automatic car wash from the start. Brushless car washes are preferable.

▶ To protect the filter system, activate the air recirculation mode using button on the climate control panel.

■ Do not clean your vehicle in an automatic touchless car wash which uses caustic spray. Caustic spray will damage the paint or ornamental moldings.

If the vehicle is very dirty, prewash it before running it through the automatic car wash.

Make sure the combination switch is set to wiper setting o. Otherwise, the rain sensor could activate and cause the wipers to move unintentionally. This may lead to vehicle damage.

Due to the width of the vehicle, fold in exterior rear view mirrors prior to running the vehicle through an automatic car wash to prevent damage to the mirrors.

► When taking the vehicle through an automatic conveyor-type car wash: Make sure the automatic transmission remains in neutral position N.

When leaving the automatic car wash, make sure the mirrors are folded out.

After running the vehicle through an automatic car wash, wipe any wax off of the windshield and the wiper blade inserts. This will prevent smears and reduce wiping noise which can be caused by residual wax on the windshield.

Ornamental moldings


- ► For regular cleaning and care of ornamental moldings, use a damp cloth.
- Do not use chrome cleaner on ornamental moldings. Although ornamental moldings may have chrome appearance, they could be made of anodized aluminum that will be damaged when cleaned with chrome cleaner. Instead, use a damp cloth to clean those ornamental moldings.


For very dirty ornamental moldings of which you are sure are chrome-plated, use a chrome cleaner. If in doubt whether an ornamental molding is chrome-plated, contact an authorized Mercedes-Benz Center.

Headlamps, brake lamps, tail lamps, side markers, turn signal lenses

- Use a mild vehicle wash detergent, such as Mercedes-Benz approved Car Shampoo, with plenty of water.
- I Only use window cleaning solutions that are suitable for plastic lamp lenses. Window cleaning solutions which are not suitable may damage the plastic lamp lenses of the headlamps. Therefore, do not use abrasives, solvents or cleaners that contain solvents.

Cleaning the driving systems sensors





- ► Switch off the ignition.
- ► Clean Distronic system sensor cover ① by hand.

To clean Distronic system sensor cover ① and the bumper area near sensors ② observe the following:

- Use a mild vehicle wash detergent, such as Mercedes-Benz approved Car Shampoo, with plenty of water.
- Use a soft, non-scratching cloth.

- If you use a power washer to clean the sensor covers, observe the following:
 - Follow the instructions provided by the power washer manufacturer.
 - Maintain a distance between the sensor covers and the nozzle of the power washer.

Cleaning the windows and the wiper blades

■ The windshield wipers must be in a vertical position before folding them away from the windshield. They could otherwise damage the hood.

Never open the hood when the wiper arms are folded forward.

- ► Make sure the hood is fully closed.
- ▶ Switch on the ignition.
- Turn combination switch to wiper setting☐ (▷ page 92).
- ► With wiper arms in vertical position, switch off the ignition.

For safety reasons, switch off wipers and remove SmartKey from starter switch before cleaning the windshield and/or the wiper blades. Vehicles with KEYLESS-GO: Make sure the vehicle's on-board electronics have status **0**. Otherwise, the wiper motor could suddenly turn on and cause injury.

- Do not pull on the wiper blade inserts. They could tear.
- ► Fold the wiper arms forward until they snap into place.
- Clean the windshield and the wiper blade inserts with a clean cloth and mild detergent solution.
- Use a soft, clean cloth and a mild window cleaning solution on all outside and inside glass surfaces.

An automotive glass cleaner is recommended.

- I Fold the windshield wiper arms back onto the windshield before turning the SmartKey in the starter switch or pressing the KEYLESS-GO start/stop button.
 - Hold on to the wiper when folding the wiper arm back. If released, the force of the impact from the tensioning spring could crack the windshield.
- I To clean the window interior, do not use a dry cloth, abrasives, solvents or cleaners containing solvents. Do not touch the inside of the windows with hard objects such as an ice scraper or ring. Doing so may damage the windows.

Light alloy wheels

If possible, clean wheels once a week.

- ► Use Mercedes-Benz approved Wheel Care, a soft bristle brush and a strong spray of water for cleaning the light alloy wheels.
- I Only use acid-free cleaning materials. Acid may cause corrosion or damage the clear coat.
- I The vehicle should not be parked for an extended period of time immediately after it has been cleaned. This applies especially after the wheel rims have been cleaned with wheel rim cleaner. Wheel rim cleaners can lead to increased corrosion of the brake disks and brake pads. Non-approved wheel cleaners may also damage the wheel paint if the vehicle is not driven after cleaning.

Therefore, the vehicle's brake system should always be warmed-up before it is parked after cleaning. Drive your vehicle for several minutes to allow the brakes to dry. When applying Mercedes-Benz approved Tire Care and Mercedes-Benz approved Wheel Care products, take care not to spray them on the brake disks.

Plastic and rubber parts

- ▶ Use a gentle dishwashing detergent or mild detergent for delicate fabrics as a washing solution.
- ► Wipe with a cloth moistened in a lukewarm solution.

The surface may temporarily change color. If this is the case, wait for it to dry.

Marning!

Do not use cleaners or cockpit care sprays containing solvents to clean the cockpit or the steering wheel. Cleaners containing solvents will make the surface porous and vehicle occupants could suffer serious injuries from plastic parts coming loose in the event of air bag deployment.

Do not use oil, wax or scouring agents. Otherwise you may scratch or damage the surface.

Hard plastic trim items

▶ Use Mercedes-Benz approved Interior Care on a soft, lint-free cloth and apply with light pressure.

COMAND display

- I You must switch off the COMAND display and allow it to cool prior to cleaning.
- Do not use any liquids or cleaning agents. These can damage or even destroy the COMAND display screen.
- ▶ Use a standard microfiber cloth and apply with light pressure.

Steering wheel and gear selector lever

► Wipe with a damp cloth and dry thoroughly or clean with Mercedes-Benz approved Leather Care.

Carpets

▶ Use Mercedes-Benz approved Carpet and Fabric Care for cleaning the carpets.

Headliner and shelf below rear window

► Use a soft bristle brush or a dry-shampoo cleaner in case of excessive dirt.

Seat belts

- ▶ Only use clear, lukewarm water and soap.
- The seat belts must not be treated with chemical cleaning agents. Do not dry the seat belts at temperatures above 176°F (80°C) or in direct sunlight.



↑ Warning!

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Upholstery

Using aftermarket seat covers or wearing clothing that have the tendency to give off coloring (e.g. when wet, etc.) may cause the upholstery to become permanently discolored. By lining the seats with a proper intermediate cover, contact-discoloration will be prevented.



Warning!

Only use seat or head restraint covers which have been tested and approved by Mercedes-Benz for your vehicle model.

Using other seat or head restraint covers may interfere with or prevent the activation of the NECK-PRO active front head restraints and/ or the deployment of the front side impact air bags.

Contact an authorized Mercedes-Benz Center for availability.

Leather upholstery

Please note that leather upholstery is a natural product and is therefore subject to a natural aging process. Leather upholstery may also react to certain ambient influences such as high humidity or high temperature by showing wrinkles for example.

- ► Wipe leather upholstery with a damp cloth and dry thoroughly or clean with Mercedes-Benz approved Leather Care.
- To avoid damage to leather upholstery:
 - Wipe with light pressure only.
 - Do not clean with abrasive cleaning agents such as scouring milk or powder.
 - Do not soak the leather upholstery. As leather is a natural product, it could otherwise harden or become porous.
 - Exercise particular care when cleaning perforated leather as its underside should not become wet.

Wood trims

- ▶ Only use water and a damp cloth to clean wood trims in your vehicle.
- Do not use solvents like tar remover or wheel cleaner nor polishes or waxes as these may be abrasive.

Chrome-plated exhaust tip

Regular cleaning and care of chrome-plated exhaust tips will help to maintain their shine and the classy appearance.

- ▶ Use Mercedes-Benz approved Chrome Polishing Paste each time the vehicle has been washed, especially during the winter.
- Do not use alkaline cleaners such as wheel cleaners as they could cause corrosion.

Vehicle equipment	224
Where will I find?	224
Vehicle status messages in the	000
multifunction display	228
What to do if	251
Unlocking/locking manually	261
Resetting activated NECK-PRO	
active front head restraints	264
Replacing SmartKey batteries	264
Replacing bulbs	266
Replacing wiper blades	270
Flat tire	271
Battery	278
Jump starting	280
Towing the vehicle	281
Fuses	284



Vehicle equipment

1 This Operator's Manual describes all features, standard or optional, potentially available for your vehicle at the time of purchase. Please be aware that your vehicle might not be equipped with all features described in this manual.

Where will I find ...?

First aid kit

- Always keep the storage compartment under the front passenger seat closed while the vehicle is in motion.
- Check expiration dates and contents for completeness at least once a year and replace missing/expired items.

The first aid kit is located in the storage compartment at the front edge of the front passenger seat.



- ▶ Pull handle (1) upward.
- ► Fold the lid down.
- ▶ Remove the first aid kit.

Vehicle tool kit

The vehicle tool kit is located in the space underneath the trunk floor.

1 Vehicles without spare wheel are not factory-equipped with the tools required for a wheel change such as a jack or a wheel wrench. Some tools required for a wheel change are specific to your vehicle.


Contact an authorized Mercedes-Benz Center to obtain the tools approved for your vehicle.

The vehicle tool kit includes:

- Alignment bolt ¹³
- Collapsible wheel chock¹³
- Electric air pump¹⁴
- lack ¹³
- · Pair of universal pliers
- · Towing eye bolt
- Valve extractor¹⁴
- Wheel wrench¹³
- ▶ **Removing:** Open the trunk (> page 71).
- ▶ Lift the trunk floor using the floor handle.
- ► Engage the floor handle on the upper trunk lip.
- I To prevent damage, always disengage the floor handle from the upper trunk lip and lower the trunk floor before closing the trunk.
- ► Remove the luggage box (if so equipped) (> page 227).

¹³ Vehicles with spare wheel only.

¹⁴ Vehicles with spare wheel with collapsible tire only.




Example illustration

- Tool bag and jack
- 2 Collapsible wheel chock
- 3 Electrical air pump¹⁴
- 4 Storage well casing
- ▶ To access jack: Remove tool bag ①.

Collapsible wheel chock

The collapsible wheel chock serves to secure the vehicle, e.g. while changing a wheel.

► Take the collapsible wheel chock from the vehicle tool kit (> page 224).



- ▶ **Setting up:** Tilt both plates upward ①.
- ► Fold the lower plate outward ②.
- ► Guide the tabs of the lower plate all the way into the openings of base plate ③.

For information on where to place wheel chocks when changing a wheel, see "Lifting the vehicle" (> page 272).


Jack

↑ Warning!

Only use the jack supplied with your vehicle to lift the vehicle briefly for wheel changes. If you use the jack for any other purpose, you or others could be injured, as the jack is designed only for the purpose of changing a wheel.


When using the jack, observe the safety notes in the "Mounting the spare wheel" section and the notes on the jack.

► Take the jack from the vehicle tool kit (> page 224).



Storage position

► Turn the crank handle in the direction of arrow as far as it will go.



Operational position

▶ Turn the crank handle clockwise.

¹⁴ Vehicles with spare wheel with collapsible tire only.

Before placing the jack back into the vehicle tool kit:

- ► Fully collapse the jack.
- ► Fold in the crank handle (storage position).

Spare wheel


↑ Observe Safety notes, see page 271.

The spare wheel is located in the space underneath the trunk floor.

- ▶ **Removing:** Open the trunk (▷ page 71).
- ▶ Lift the trunk floor using the floor handle.
- ► Engage the floor handle on the upper trunk
- I To prevent damage, always disengage the floor handle from the upper trunk lip and lower the trunk floor before closing the trunk.

Vehicles with Minispare wheel

Remove the luggage box (▷ page 227).



- ▶ Remove spare wheel mounting ② by turning it counterclockwise.
- ▶ Remove spare wheel ①.


For information on mounting the spare wheel, see "Flat tire" (⊳ page 271).

Storing the spare wheel after use

- ▶ Place spare wheel (1) in the spare wheel well (⊳ page 226).
- ► Secure spare wheel (1) by turning spare wheel mounting (2) clockwise (⊳ page 226).

Vehicles with spare wheel with collapsible tire

► Remove the storage well casing (⊳ page 225).



- (1) Spare wheel
- ② Tensioning strap¹⁵
- ③ Retaining screw
- (4) Storage well casing base
- ▶ Remove storage well casing base (4).
- ▶ Remove retaining screw ③ by turning it counterclockwise.
- ► Remove spare wheel ①.

For information on mounting the spare wheel, see "Flat tire" (⊳ page 271).

Storing the spare wheel after use

If you wish to store the spare wheel after use, carry out the following steps. Otherwise, the spare wheel may not fit the spare wheel well.

Make sure the spare wheel is dry before storing it.

- ► Unscrew the valve cap from the valve of the collapsible tire.
- ► Unscrew the valve insert from the valve using the valve extractor integrated in the valve cap.
- ► Allow the air to escape.
- 1 It may take a few minutes for the collapsible tire to deflate completely.
- Screw the valve insert back into the valve.
- ▶ Screw the valve cap back onto the valve.
- Vehicles with 19" spare wheel only: Before placing the spare wheel in the spare wheel well fasten tensioning straps, see "Compressing the collapsible tire" (▷ page 227).
- ▶ Place spare wheel ① into the spare wheel well (▷ page 226).
- ► Secure spare wheel ① by turning retaining screw ③ clockwise (▷ page 226).

Compressing the collapsible tire

This description applies to vehicles with 19" spare wheel only.

The collapsible tire on a 19" spare wheel must be compressed with two tensioning straps before you can store it in the spare wheel well.




- ► Extend the tensioning strap by pulling the slider.
- Place tensioning strap around the spare wheel rim and collapsible tire with the buckle facing the inside of the rim.

- ► Close the buckle.
- ▶ Pull the loose end of the tensioning strap. The tensioning strap must be pulled as tight as possible.


Luggage box

Vehicles with spare wheel with collapsible tire are not equipped with a luggage box.

- ▶ **Removing:** Open the trunk (▷ page 71).
- ► Lift the trunk floor using the floor handle.
- ► Engage the floor handle on the upper trunk lip.
- To prevent damage, always disengage the floor handle from the upper trunk lip and lower the trunk floor before closing the trunk.



- ► Turn fastening clips ① to the left upwards from the fastening bolts.
- ▶ Lift luggage box ② in the area of the fastening bolts and remove it from the trunk.
- ► Installing: Insert the luggage box into the trunk so that the fastening clips are in line with the fastening bolts.



- ▶ Push the front edge of the luggage box in direction of arrows under the cover of the trunk sill.
- ▶ Press the fastening clips onto the fastening bolts until they lock into place.

Vehicle status messages in the multifunction display

Notes

Warning and malfunction messages appear in the multifunction display located in the instrument cluster.

Certain warning and malfunction messages are accompanied by an audible signal.

Address these messages accordingly and follow the additional instructions given in this Operator's Manual.

Selecting the Vehicle status message memory menu in the control system (⊳ page 117) displays both cleared and uncleared messages.

High-priority messages appear in the multifunction display in red color.

Certain messages of high priority cannot be cleared from the multifunction display using the reset button (⊳ page 109) or button \bigcirc , \bigcirc , \bigcirc or \bigcirc on the multifunction steering wheel.

Other messages of high priority and messages of less immediate priority can be cleared from the multifunction display using the reset button or button \triangle , ∇ , or on the multifunction steering wheel. They are then stored in the Vehicle status message memory menu (⊳ page 117). Remember that clearing a message will only make the message disappear. Clearing a message will not correct the condition that caused the message to appear.

↑ Warning!

All categories of messages contain important information which should be taken note of and, where a malfunction is indicated, addressed as soon as possible at an authorized Mercedes-Benz Center.

Failure to repair the condition noted may cause damage not covered by the Mercedes-Benz Limited Warranty, or result in property damage or personal injury.

Marning!

No messages will be displayed if either the instrument cluster or the multifunction display is inoperative.

As a result, you will not be able to see information about your driving conditions, such as

- speed
- outside temperature
- warning/indicator lamps
- · malfunction/warning messages
- · failure of any systems

Driving characteristics may be impaired.

If you must continue to drive, do so with added caution. Contact an authorized Mercedes-Benz Center as soon as possible.

On the pages that follow, you will find a compilation of the most important warning and malfunction messages that may appear. For your convenience the messages are divided into text messages (⊳ page 229) and

symbol messages (⊳ page 238).

Text messages

Safety systems

Display mess	sages	Possible causes/consequences and ▶ Solutions
ABS	ABS, ESP Inoperativ e See Operator's Man.	The brake system is still functioning normally but due to a malfunction, the ABS, the BAS, the ESP®, and the PRE-SAFE® system are unavailable. ▶ Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability. ▶ Have the system checked at an authorized Mercedes-Benz Center as soon as possible. Failure to follow these instructions increases the risk of an accident.
ABS	ABS, ESP Unavailabl e See Operator's Man.	The brake system still functions normally but due to insufficient power supply, the ABS, the BAS, the ESP®, and the PRE-SAFE® system are unavailable. When the voltage is above the required value again, the ABS, the BAS, the ESP®, and the PRE-SAFE® system are operational again and the message should disappear. ▶ If the message does not disappear: Have the system checked at an authorized Mercedes-Benz Center as soon as possible.
ESP	Inoperativ e See Operator's Manual	The brake system is still functioning normally but due to a malfunction the BAS, the ESP®, and the PRE-SAFE® system are unavailable. The ABS may not be operational. ► Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability. ► Have the system checked at an authorized Mercedes-Benz Center as soon as possible. Failure to follow these instructions increases the risk of an accident.
PRE-SAFE	Inoperativ e See Operator's Manual	The PRE-SAFE® system has failed. All other occupant safety systems, such as the air bags, are still available. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.

Display messages

Front
Passenger
Airbag
Enabled
See
Operator's

Manua₁

Possible causes/consequences and ▶ Solutions

USA only:

The front passenger front air bag is activated while driving even though a child, small individual, or object below the system's weight threshold is on the front passenger seat, or the front passenger seat is empty. Objects on the seat or forces acting on the seat may make the system sense supplemental weight.

- ▶ Stop the vehicle in a safe location as soon as possible.
- ► Engage the parking brake.
- ▶ Switch off the ignition.
- ▶ Open the front passenger door.
- Remove child and child restraint from front passenger seat and properly secure the child in rear seat employing the child restraint if necessary.
- ▶ Remove any other items from on and around the front passenger seat and make sure the storage bag on the back of the front passenger seat is empty.
- Make sure no objects which apply forces to the seat are present (e.g. objects such as books, briefcases etc. lodged behind or around the seat, head restraints pushing against roof etc.). The system may recognize such forces as supplemental weight and sense that an occupant on the front passenger seat is of a greater weight than actually present.
- Keep the seat unoccupied, close the front passenger door and switch on the ignition.

Monitor the PASS AIR BAG OFF [5] indicator lamp in the center console (\triangleright page 44) and the multifunction display in the instrument cluster (\triangleright page 28) for the following:

With the seat unoccupied and the ignition switched on,

- the PASS AIR BAG OFF → indicator lamp in the center console should illuminate and remain illuminated, indicating that the OCS (> page 41) has deactivated the front passenger front air bag.
- the message Front Passenger Airbag Enabled See Operator's Manual or the message Front Passenger Airbag Disabled See Operator's Manual should not appear in the multifunction display at any time the seat is unoccupied. Wait at least 60 seconds for the system to complete the necessary check cycles and to make sure neither message appears in the multifunction display.

Display messages	Possible causes/consequences and ▶ Solutions
	If above conditions are met, you can occupy the front passenger seat again. Depending on the front passenger classification sensed by the OCS, the PASS AIR BAG OFF Significator lamp will remain illuminated or go out.
	If above conditions are not met, the system is not working properly. Have the system checked at an authorized Mercedes-Benz Center as soon as possible.

Marning!

If the PASSAIR BAG OFF 2 indicator lamp remains out even after performing the above corrective steps, do not have any children 12 years old and under and other small individuals use the front passenger seat until the system has been repaired.

Display messages

Front. Passenger Airbag Disabled See Operator's Manua₁

USA only:

The front passenger front air bag is deactivated while driving even though an adult or someone larger than a small individual is occupying the front passenger seat. Forces acting on the seat may make the system sense a decrease in weight.

Possible causes/consequences and ▶ Solutions

- ▶ Stop the vehicle in a safe location as soon as possible.
- ► Engage the parking brake.
- ▶ Switch off the ignition.
- ▶ Have the front passenger vacate the seat and exit the vehicle.
- ▶ Adjust the seat height to a higher position (▷ page 78).
- ▶ Make sure no objects which apply forces to the seat are present (e.g. objects such as books, briefcases etc. lodged underneath, behind or around the seat). Such forces may cause the system to sense that an occupant of a lesser weight than actually present is on the front passenger seat.
- ► Keep the seat unoccupied, close the front passenger door and switch on the ignition.

Monitor the PASS AIR BAG OFF indicator lamp in the center console (⊳ page 44) and the multifunction display in the instrument cluster (⊳ page 28) for the following:

With the seat unoccupied and the ignition switched on,

- the PASS AIR BAG OFF | 💥 indicator lamp in the center console should illuminate and remain illuminated, indicating that the OCS (⊳ page 41) has deactivated the front passenger front air bag.
- the message Front Passenger Airbag Enabled See Operator's Manual or the message Front Passenger Airbag Disabled See Operator's Manual should not appear in the multifunction display at any time the seat is unoccupied. Wait at least 60 seconds for the system to complete the necessary check cycles and to make sure neither message appears in the multifunction display.

If above conditions are met, you can occupy the front passenger seat again. Depending on the front passenger classification sensed by the OCS, the PASS AIR BAG OFF indicator lamp will remain illuminated or go out.

If above conditions are not met, the system is not working properly. Have the system checked at an authorized Mercedes-Benz Center as soon as possible.



If the PASS AIR BAG OFF Mass and indicator lamp remains illuminated with an adult occupant on the front passenger seat even after performing the above corrective steps, do not have any passenger use the front passenger seat until the system has been repaired.

Driving systems

Display mes	sages	Possible causes/consequences and ▶ Solutions
Cruise Control And SPEEDTRONI C	Inoperativ e	The cruise control is malfunctioning. ► Have the cruise control checked at an authorized Mercedes-Benz Center.
Cruise Control	MPH	One of the activation conditions for cruise control has not been fulfilled. You may have attempted to set a speed below 20 mph (30 km/h). ▶ Drive faster than 20 mph (30 km/h) if the situation allows and set the speed. ▶ Check the activation conditions for cruise control (▷ page 128).
DISTRONIC	MPH	One of the activation conditions for Distronic has not been fulfilled. You may have attempted to set a speed below 20 mph (30 km/h). ▶ Drive faster than 20 mph (30 km/h) if the situation allows and set the speed. ▶ Check the activation conditions for Distronic (▷ page 133).
DISTRONIC	Inoperativ e	The Distronic or the display are malfunctioning. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.
DISTRONIC	Override	You have accelerated. The Distronic has switched off. ▶ Stop accelerating.

Display mes	sages	Possible causes/consequences and ▶ Solutions
DISTRONIC	Currently Unavailable See Operator's Manual	 Distronic is deactivated because: The Distronic cover in the radiator grille is dirty. The functionality is impaired by heavy precipitation or fog. The system is overheated. ▶ If necessary, clean the Distronic cover in the area of the radiator grille (▷ page 219). ▶ If necessary, wait until the system has cooled down. ▶ Restart the vehicle. Distronic becomes operational again without the engine being restarted when dirt on the radiator grille has fallen off while driving (e.g. slush or snow) the system recognizes full sensor availability (due to lessening rain or the road surface drying) the message in the multifunction display disappears the speed last stored flashes in the display for 5 seconds You can then operate Distronic as usual again.
DISTRONIC	Currently Unavailable See Operator's Manual	Distronic is deactivated because the functionality is impaired by external interferences, e.g. high-frequency sources such as toll stations, speed measuring systems etc. ▶ Leave the area of the external interference. ▶ Activate Distronic again (▷ page 133) when the message in the multifunction display disappears.
		Distronic is deactivated because the Distronic sensor has not sensed any other vehicles or objects, e.g. road sign or such, for a long time. ▶ Activate Distronic again (▷ page 133) when the message in the multifunction display disappears.



Marning!

Distronic cannot take weather conditions into account. Switch off Distronic or do not turn it on if the sensor is dirty or visibility is diminished as a result of snow, rain or fog. The distance control may be impaired even before the system is able to detect a dirty sensor. The message DISTRONIC Currently Unavailable See Operator's Manual will be displayed in the multifunction display and Distronic will be turned off.

Vehicle

Display mes	sages	Possible causes/consequences and ▶ Solutions
P	Gear Selector Lever In P Position	You have opened the driver's door while the engine was not running and the automatic transmission was not in park position P . ▶ Shift the automatic transmission into park position P .
		You have attempted to turn off the engine with the KEYLESS-GO start/stop button while the automatic transmission was not in park position P . ▶ Shift the automatic transmission into park position P .
P/N	Please Shift To N or P	You have attempted to start the engine with the KEYLESS-GO start/stop button while the automatic transmission was in reverse gear R or drive position D . ▶ Shift the automatic transmission into park position P or neutral position N Make sure the brake pedal is depressed.

Tires

Display mes	sages	Possible causes/consequences and ▶ Solutions
Check tires,	then restart Run Flat Indicator.	 There has been a warning message about a loss in the tire inflation pressure and the tire pressure loss warning system was not restarted yet. ▶ Make sure the correct tire inflation pressure is set for each tire. ▶ Then restart the tire pressure loss warning system (> page 186).
Run Flat Indicator	Inoperativ e	The tire pressure loss warning system is malfunctioning. ▶ Have the tire pressure loss warning system checked at an authorized Mercedes-Benz Center.

Display mes	ssages	Possible causes/consequences and ▶ Solutions
Tire Pressure	Check tires	 The tire pressure loss warning system indicates that the tire inflation pressure is too low in at least one tire. ▶ Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you. ▶ Check the tires and, if necessary, change the wheel (▷ page 271). ▶ Check and adjust tire inflation pressure as required (▷ page 185). ▶ Restart the tire pressure loss warning system after adjusting the tire inflation pressure values (▷ page 186).
Tire pressure	is only displayed after driving for a few minutes.	Vehicles with Advanced TPMS (Canada only): The tire inflation pressure is being checked. ▶ Drive the vehicle for a few minutes.
Tire Pressure Monitor	Inoperativ e	The TPMS (USA only) or Advanced TPMS (Canada only) is malfunctioning. ▶ Have the TPMS or Advanced TPMS checked at an authorized Mercedes-Benz Center.
Tire Pressure Monitor	Inoperativ e No Wheel Sensors	There are wheels without appropriate wheel sensors mounted (e.g. winter tires). ► Have the TPMS or Advanced TPMS checked at an authorized Mercedes-Benz Center. ► Have the appropriate wheel sensors installed at an authorized Mercedes-Benz Center.

Display mes	sages	Possible causes/consequences and ▶ Solutions
Tire Pres. Monitor	Wheel Sensor Missing	Vehicles with Advanced TPMS (Canada only): At least one sensor is defect (e.g. battery is empty). The respective tire is indicated by instead of the tire inflation pressure in the multifunction display. ▶ Have the Advanced TPMS checked at an authorized Mercedes-Benz Center. ▶ Have the wheel sensors installed at an authorized Mercedes-Benz Center.
		At least one wheel without appropriate wheel sensors is mounted (e.g. spare wheel). The respective tire is indicated by instead of the tire inflation pressure in the multifunction display. ▶ Have the Advanced TPMS checked at an authorized Mercedes-Benz Center. ▶ Have the wheel sensors installed at an authorized Mercedes-Benz Center.
Tire Pressure Monitor	Currently Unavailabl e	The TPMS (USA only) or Advanced TPMS (Canada only) cannot monitor the tire inflation pressure due to a nearby radio interference source or insufficient power supply. As soon as the causes of the malfunction have been rectified, the TPMS or Advanced TPMS becomes active again automatically after a few minutes of driving.
Please correct the tire pressure.		Vehicles with Advanced TPMS (Canada only): The tire inflation pressure is too low in at least one tire. or The tire inflation pressures of the individual tires differ from each other significantly. The tire inflation pressure values are shown in the multifunction display. ▶ Check and correct tire inflation pressure as required (▷ page 185). ▶ Restart the Advanced TMPS (▷ page 192).
Caution Tire Pressure Tire Defect		Vehicles with Advanced TPMS (Canada only): At least one tire is deflating. The respective tire is indicated in the multifunction display. ▶ Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. ▶ If necessary, change the wheel (▷ page 271).

Display messages	Possible causes/consequences and ▶ Solutions
Check Tires	Vehicles with Advanced TPMS (Canada only): The tire inflation pressure in at least one tire is significantly below the reference value. The respective tire is indicated in the multifunction display.
	 Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Check and adjust tire inflation pressure as required. If necessary, change the wheel (▷ page 271).



Marning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.



/ Warning!

Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Symbol messages

Brake

Display messages		Possible causes/consequences and ▶ Solutions
	Brake Wear	The brake pads have reached their wear limit. ▶ Have the brake pads replaced as soon as possible at an authorized Mercedes-Benz Center.

I Brake pad thickness must be visually inspected by a qualified technician at the intervals specified in the Maintenance Booklet.

Display mes	sages	Possible causes/consequences and ▶ Solutions
(USA only) (Canada only)	EBV, ABS, ESP Inoperativ e See Operator's Man.	 The brake system is still functioning normally but due to a malfunction, the ABS, the BAS, the EBP, the ESP®, and the PRE-SAFE® system are unavailable. ▶ Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability. ▶ Adjust driving to be consistent with reduced braking responsiveness. ▶ Have the system checked at an authorized Mercedes-Benz Center as soon as possible. Failure to follow these instructions increases the risk of an accident.
(USA only) (Canada only)	Release Parking Brake	You are driving with the parking brake engaged. In addition an acoustic warning sounds. ▶ Release the parking brake.
(USA only) (Canada only)	Check Brake Fluid Level	 There is insufficient brake fluid in the reservoir. Risk of accident! ▶ Stop the vehicle in a safe location or as soon as it is safe to do so. ▶ Engage the parking brake. ▶ Do not drive any further. ▶ Contact an authorized Mercedes-Benz Center or call Roadside Assistance. Do not add brake fluid! This will not solve the problem.

Marning!

Driving with the message Check Brake Fluid Level displayed can result in an accident. Have your brake system checked immediately.

Do not add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks.

Safety systems

Display messages		Possible causes/consequences and ▶ Solutions
ESOS	Tele Aid Inoperativ e	One or more main functions of the Tele Aid system are malfunctioning. ▶ Have the Tele Aid system checked at an authorized Mercedes-Benz Center.
SRS	Restraint System Malfunctio n Service Required	The system is malfunctioning. ▶ Drive with added caution to the nearest authorized Mercedes-Benz Center and have the system checked immediately.

Marning!

In the event a malfunction of the SRS is indicated as outlined above, the SRS may not be operational.

For your safety, we strongly recommend that you contact an authorized Mercedes-Benz

Center immediately to have the system checked. Otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

Driving systems

Display mes	sages	Possible causes/consequences and ▶ Solutions
	Vehicle Rising	The vehicle is adjusting to your level selection.
	Vehicle Rising Please Wait	The vehicle level is too low. ▶ Wait until the message disappears from the multifunction display.
	STOP Vehicle Too Low	 The AIRMATIC DC is malfunctioning. ▶ Avoid excessive steering maneuvers. The fenders or tires could otherwise be damaged. Listen for scraping noises. ▶ Do not drive faster than 50 mph (80 km/h). ▶ Drive to the side of the road and select a higher vehicle level (> page 138). Depending on the type of malfunction, this may raise the vehicle's level. ▶ Contact an authorized Mercedes-Benz Center as soon as possible. There is otherwise danger of an accident.

Display messages		Possible causes/consequences and ▶ Solutions
	Malfunctio n	The system is functional only to a limited extent. The system display or the system is malfunctioning. ▶ Do not drive faster than 50 mph (80 km/h). ▶ Have the vehicle checked at an authorized Mercedes-Benz Center.

Vehicle

Display mes	sages	Possible causes/consequences and ▶ Solutions
		The trunk is open. ▶ Close the trunk (▷ page 72).
		You are driving with the hood open. ► Stop the vehicle in a safe location as soon as it is safe to do so. ► Close the hood (▷ page 179). There is otherwise danger of an accident.
		You are driving with at least one door open. ▶ Close all doors.
	Key Detected In Vehicle	A SmartKey with KEYLESS-GO left in the vehicle was recognized while trying to lock the vehicle from the outside. ▶ Take the SmartKey out of the vehicle.
	Please don't forget your key.	This message appears for a maximum of 60 seconds if the driver's door is opened with the engine turned off and no SmartKey in the starter switch. This message is only a reminder. ▶ Take the SmartKey with you when leaving the vehicle.
	Remove Key	You have forgotten to remove the SmartKey. ▶ Remove the SmartKey from the starter switch.
	Please get a new key.	The SmartKey is malfunctioning. ▶ Contact an authorized Mercedes-Benz Center.
	Change Key Batteries	The batteries in the SmartKey with KEYLESS-GO are discharged. ▶ Replace the batteries (▷ page 264).

Display me	essages	Possible causes/consequences and ▶ Solutions
	Key Not Detected (message appears in red)	The SmartKey with KEYLESS-GO is not detected while the engine is running because the SmartKey is not in the vehicle. ▶ Stop the vehicle as soon as it is safe to do so. ▶ Engage the parking brake. ▶ Search for the SmartKey. The vehicle cannot be locked centrally nor can the engine be started again after the engine is stopped.
	Key Not Detected (message appears in red)	The SmartKey with KEYLESS-GO is not detected while the engine is running because there is strong radio-frequency interference. ▶ Stop the vehicle as soon as it is safe to do so. ▶ Engage the parking brake. ▶ Operate the vehicle with the SmartKey in the starter switch.
	Key Not Detected (message appears in white)	The SmartKey with KEYLESS-GO is momentarily not detected. ► Change the position of the SmartKey in the vehicle. ► Operate the vehicle with the SmartKey in the starter switch if necessary.
	Bluetooth Ready	The telephone has not yet been connected to the COMAND system via Bluetooth®. ▶ Connect the telephone to the COMAND system via Bluetooth®.
(4)	Top Up Washer Fluid	The fluid level has dropped to approximately ¹ / ₃ of total reservoir capacity. ▶ Add washer fluid (▷ page 181).

Engine

Display mes	sages	Possible causes/consequences and ▶ Solutions
check engine (USA only) (Canada only)	Engine Service	There may be a malfunction in • the fuel management system • the ignition system • the exhaust system • the fuel system ▶ Have the engine checkedas soon as possible at an authorized Mercedes-Benz Center.
	Display Malfunctio n Service Required	Certain electronic systems are unable to relay information to the control system. The coolant temperature display or the tachometer may have failed. In the electronic systems checked at an authorized Mercedes-Benz Center.
	Top Up Coolant See Operator's Man.	The coolant level is too low. ► Add coolant (▷ page 180). ► If you have to add coolant frequently, have the cooling system checked at an authorized Mercedes-Benz Center.

Marning!

Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts. You could be seriously burned.

Do not ignore the low engine coolant level warning. Extended driving with the message and symbol displayed may cause serious engine damage not covered by the Mercedes-Benz Limited Warranty.

Do not drive without sufficient amount of coolant in the cooling system. The engine will overheat causing major engine damage.

Possible causes/consequences and ▶ Solutions Display messages Coolant. The coolant is too hot. Stop ▶ Stop the vehicle immediately as soon as it is safe to do so. Vehicle. ► Turn off the engine immediately. turn ► Engage the parking brake. engine ▶ Only start the engine again after the message disappears. off. You could otherwise damage the engine. ▶ Observe the coolant temperature indicator in the instrument cluster. ▶ If the temperature rises again: Contact an authorized Mercedes-Benz Center immediately. During severe operation conditions and stop-and-go city traffic, the coolant temperature may rise close to 248°F

/ Warning!

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

(120°C).

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

If the engine should not be operated with the coolant temperature above 248°F (120°C). Doing so may cause serious damage which is not covered by the Mercedes-Benz Limited Warranty.

Possible causes/consequences and ▶ Solutions Display messages Coolant. The poly-V-belt could be broken. Stop ▶ Stop the vehicle immediately as soon as it is safe to do so. Vehicle. ► Turn off the engine immediately. turn ► Check the poly-V-belt. engine ▶ If it is broken: Do not continue to drive. Otherwise the off. engine will overheat due to an inoperative water pump which may result in damage to the engine. Contact an authorized Mercedes-Benz Center. ▶ If it is intact: Do not continue to drive the vehicle with this message displayed. Doing so could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty. ▶ Observe the coolant temperature indicator in the instrument cluster. ▶ Drive to the nearest authorized Mercedes-Benz Center immediately. The radiator cooling fan is malfunctioning. __E_ ▶ Observe the coolant temperature indicator in the instrument cluster. If the coolant temperature is below 248°F (120°C), you may continue driving to an authorized Mercedes-Benz Center. ▶ Avoid placing heavy loads on the engine (e.g. by driving uphill) as well as stop-and-go traffic. ▶ Have the fan replaced as soon as possible. The battery is no longer charging. Possible causes: · alternator malfunctioning broken poly-V-belt • a malfunction in the electronic system ▶ Stop immediately in a safe location or as soon as it is safe to do so and check the poly-V-belt. ▶ If it is broken: Do not continue to drive. Otherwise the engine will overheat due to an inoperative water pump which may result in damage to the engine. Contact an authorized Mercedes-Benz Center.

► If it is intact: Drive to the nearest authorized Mercedes-Benz Center immediately. Adjust driving to be consistent

with reduced braking responsiveness.

Display messages		Possible causes/consequences and ▶ Solutions
= +	Low Voltage Start Engine	The battery has insufficient voltage. ▶ Start the engine.
	Check oil level at next refueling.	 The engine oil has dropped to a critical level. ▶ Check the engine oil level (▷ page 179) and add engine oil as required (▷ page 180). ▶ If you must add engine oil frequently, have the engine checked for possible leaks.

If the message Check oil level at next refueling, appears while the engine is running and at operating temperature, the engine oil level has dropped to approximately the minimum level.

The message will be stored in the vehicle status message memory after you have cleared it from the multifunction display.

Visually check for oil leaks. If there are no obvious oil leaks, drive to the nearest service station to refill your engine oil to the required level.

For information on approved engine oils contact an authorized Mercedes-Benz Center or visit **www.mbusa.com** (USA only).

■ Engine oil level warnings should not be ignored. Extended driving with the symbol displayed could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

Display mes	sages	Possible causes/consequences and ▶ Solutions
		The fuel level is low. ▶ Refuel at the next gas station.
	Reserve Fuel	The fuel level has dropped below the reserve mark. ▶ Refuel at the next gas station.
	Gas Cap Is Open	A loss of pressure has been detected in the fuel system. The fuel cap may not be closed properly or the fuel system may be leaking. ▶ Check the fuel cap (▷ page 177). ▶ If it is not closed properly: Close the fuel cap. ▶ If it is closed properly: Have the fuel system checked at an authorized Mercedes-Benz Center.
- 111 -	Replace Air Filter	The air filter is clogged. ▶ Have the air filter checked at an authorized Mercedes-Benz Center.

Lamps

Display mes	Display messages Possible causes/consequences and ▶ Solutions		
☆	Active Headlamps Inoperativ	The active Bi-Xenon headlamp system is malfunctioning. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.	
<u>\$</u>	Active Headlamps Auxiliary Bulb On	The active Bi-Xenon headlamps are malfunctioning. Another light is being used. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.	
<u>-₩</u> -	Reverse Lamp Left or Reverse Lamp Right	The left or right backup lamp is malfunctioning. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.	
₩	Brake-/ Tail Lamp Left Auxiliary Bulb On or Brake-/ Tail Lamp Right Auxiliary Bulb On	The left or right brake/tail lamp is malfunctioning. This message will only appear if all LEDs have stopped working. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.	
<u> </u>	3rd Brake Lamp	The high-mounted brake lamp is malfunctioning. This message will only appear if all LEDs have stopped working. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.	
₩	Front Foglamp Left or Front Foglamp Right	The left or right front fog lamp is malfunctioning. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.	

Display mes	CAGAC	Possible causes/consequences and ▶ Solutions
- 🌣	Marker Lamp Front Left or Marker Lamp Front Right	The front left side or right side marker lamp is malfunctioning. Contact an authorized Mercedes-Benz Center as soon as possible.
₩	Parking Lamp Front Left Auxiliary Bulb On or Parking Lamp Front Right Auxiliary Bulb On	 The left or right front parking lamp is malfunctioning. A substitute bulb is being used. ▶ Halogen headlamp: Replace the bulb as soon as possible (> page 266). ▶ Bi-Xenon headlamp: Contact an authorized Mercedes-Benz Center as soon as possible.
<u>-\$</u> -	High Beam Left or High Beam Right	The left or right high-beam lamp is malfunctioning. ▶ Replace the bulb as soon as possible (▷ page 266).
- ∰-	License Plate Lamp Left or License Plate Lamp Right	The left or right license plate lamp is malfunctioning. ▶ Replace the bulb as soon as possible (▷ page 266).
- Φ;	AUTO- Light Inoperativ e	 The light sensor is malfunctioning. The headlamps come on automatically. ▶ Contact an authorized Mercedes-Benz Center as soon as possible. To switch off the headlamps (U.S. vehicles only): ▶ In the control system, set daytime running lamp mode to manual (▷ page 121). ▶ Switch off the headlamps using the exterior lamp switch (▷ page 87).

Display mes	sages	Possible causes/consequences and ▶ Solutions
- ∰-	Low Beam Left or Low Beam Right	The left or right low-beam lamp is malfunctioning. ► Halogen headlamp: Replace the bulb as soon as possible (> page 266). ► Bi-Xenon headlamp: Contact an authorized Mercedes-Benz Center as soon as possible.
<u>-</u> \$-	Rear Left Foglamp	The rear fog lamp is malfunctioning. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.
<u>-₩</u> -	Switch Off Lights	You have removed the SmartKey from the starter switch, opened the driver's door and left the headlamps on or removed the SmartKey with KEYLESS-GO from the vehicle and left the headlamps on. Turn the exterior lamp switch to or auto (> page 87). or With the rear fog lamp switched on: Push in the exterior lamp switch to its stop.
₩	Tail Lamp Left Auxiliary Bulb On or Tail Lamp Right Auxiliary Bulb On	The left or right tail lamp is malfunctioning. A substitute bulb is being used. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.
<u>-∯-</u>	Cornering Lamp Left or Cornering Lamp Right	The left or right corner-illuminating front fog lamp is malfunctioning. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.
<u>\$</u>	Rear Left Turn Signal or Rear Right Turn Signal	The left or right rear turn signal lamp is malfunctioning. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.

Display messages		Possible causes/consequences and ▶ Solutions
- ₩-	Front Left Turn Signal or Front Right Turn Signal	The left or right front turn signal lamp is malfunctioning. ▶ Replace the bulb as soon as possible (▷ page 266).
₩	Left Mirror Turn Signal or Right Mirror Turn Signal	The turn signal in the left or right exterior rear view mirror is malfunctioning. This message will only appear if all LEDs have stopped working. ▶ Contact an authorized Mercedes-Benz Center as soon as possible.

Tires

Display messages		Possible causes/consequences and ▶ Solutions
(!)	Please correct the tire pressure.	The tire inflation pressure is too low in at least one tire. or The tire inflation pressure of the individual tires differ from each other significantly. ▶ Check and correct tire inflation pressure as required (▷ page 185).
<u>(i)</u>	Tire Pressure Caution Tire Defect	 At least one tire is deflating. ▶ Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. ▶ If necessary, change the wheel (▷ page 271).
	Tire Pressure Check Tires	 The tire inflation pressure in at least one tire is significantly below the reference value. ▶ Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. ▶ Check and adjust tire inflation pressure as required. ▶ If necessary, change the wheel (▷ page 271).



Marning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.



↑ Warning!

Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and/or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

What to do if ...

Lamps in instrument cluster

Notes

If any of the following lamps in the instrument cluster fails to come on during the bulb selfcheck when switching on the ignition, have the respective bulb checked and replaced if necessary.

When you switch on the ignition, all lamps in the instrument cluster come on. The lowbeam headlamp indicator lamp, high-beam headlamp indicator lamp, and turn signal indicator lamps will only come on if activated. If a lamp in the instrument cluster fails to come on when the ignition is switched on, have it checked and replaced if necessary.

Brake

Problem Possible causes/consequences and ▶ Solutions The yellow ABS The ABS has detected a malfunction and switched off. The BAS, the ESP®, the EBP, and the PRE-SAFE® system are also switched indicator lamp comes on while off. the engine is The brake system is still functioning normally but without the running. systems specified above available. If the ABS control unit is malfunctioning, other systems such as the navigation system or the automatic transmission may also be malfunctioning. ► Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability. ▶ Adjust driving to be consistent with reduced braking responsiveness. ▶ Read and observe messages that may appear in the multifunction display (▷ page 228). ▶ Have the system checked at an authorized Mercedes-Benz Center as soon as possible. Failure to follow these instructions increases the risk of an accident. │ (│ The yellow ABS The ABS has switched off due to insufficient power supply. indicator lamp The battery might not be charged sufficiently. comes on while When the voltage is above the required value again, the ABS is the engine is operational again. The ABS indicator lamp should go out. running. ► Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability. ▶ Adjust driving to be consistent with reduced braking responsiveness. ▶ Read and observe messages that may appear in the multifunction display (▷ page 228). ▶ If the ABS indicator lamp does not go out: Have the alternator and the battery checked. BRAKE (USA only) You are driving with the parking brake engaged. (Canada only) ► Release the parking brake. The red brake warning lamp comes on while driving and an acoustic warning sounds.

Problem

BRAKE (USA only) (Canada only)

The red brake warning lamp comes on while the engine is running and an acoustic warning sounds.

Possible causes/consequences and ▶ Solutions

There is insufficient brake fluid in the reservoir.

Risk of accident!

- ▶ Do not drive any further. Stop the vehicle in a safe location as soon as it is safe to do so.
- ► Engage the parking brake.
- ▶ Read and observe messages that may appear in the multifunction display (⊳ page 228).
- ► Contact an authorized Mercedes-Benz Center.

Do not add brake fluid! This will not solve the problem.



↑ Warning!

Driving with the brake warning lamp illuminated can result in an accident. Have your brake system checked immediately if the brake warning lamp stays on. Do not add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and

the brake fluid catching fire. You can be seriously burned.

If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks.

Safety systems

Problem

The red seat belt telltale comes on for a maximum of 6 seconds after starting the engine.

Possible causes/consequences and ▶ Solutions

The seat belt telltale reminds you and your passengers to fasten your seat belts before driving off.

► Fasten your seat belts.

Regardless of whether the seat belts are fastened or not, the seat belt telltale always comes on and remains lit for 6 seconds after starting the engine.

茶

The red seat belt telltale comes on. In addition you hear a warning chime for a maximum of 6 seconds after starting the engine.

You have forgotten to fasten your seat belt.

► Fasten your seat belt.

The warning chime stops sounding.

Problem



The red seat belt telltale comes on while the vehicle is standing still and the engine is running or while driving.

Possible causes/consequences and ▶ Solutions

You and/or your front passenger have forgotten to fasten your seat belts.

► Fasten your seat belts. The seat belt telltale goes out.

There are items placed on the front passenger seat and therefore the system senses the front passenger seat as being occupied.

▶ Remove the items from the front passenger seat and put them in a safe place.

The seat belt telltale goes out.



The red seat belt telltale flashes while driving. In addition, an intermittent warning chime sounds with increasing intensity.

The vehicle's speed once exceeded 15 mph (25 km/h) and you and/or your front passenger have forgotten to fasten your seat belts.

► Fasten your seat belts. The seat belt telltale goes out and the warning chime stops sounding.

There are items placed on the front passenger seat and therefore the system senses the front passenger seat as being occupied.

▶ Remove the items from the front passenger seat and put them in a safe place.

The seat belt telltale goes out and the warning chime stops sounding.

1 After 60 seconds with an unfastened seat belt the warning chime stops sounding and the seat belt telltale illuminates continuously. The seat belt telltale will only go out if both, the driver and front passenger's seat belt are fastened, or the vehicle is standing still and a front door is opened.

Problem

Possible causes/consequences and ▶ Solutions



The red SRS indicator lamp comes on while driving.

There is a malfunction in the restraint systems. The air bags or Emergency Tensioning Devices (ETDs) could deploy unexpectedly or fail to activate in an accident.

▶ Drive with added caution to the nearest authorized Mercedes-Benz Center.



↑ Warning!

In the event a malfunction of the SRS is indicated as outlined above, the SRS may not be operational.

For your safety, we strongly recommend that you contact an authorized Mercedes-Benz Center immediately to have the system checked. Otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it

might deploy unexpectedly and unnecessarily which could also result in injury.

Problem

⚠ The yellow ESP® warning lamp comes on while the engine is running.

Possible causes/consequences and ▶ Solutions

The ESP® has been switched off.

Risk of accident!

When the ESP® is switched off it will not stabilize the vehicle if the system recognizes that the vehicle starts to skid or that a wheel is spinning.

- ► Switch the ESP® back on. Exceptions: (⊳ page 60).
- ► If leaving the ESP® switched off, adapt your speed and driving to the prevailing road and weather conditions.
- ▶ If the ESP® cannot be switched back on: Have the system checked at an authorized Mercedes-Benz Center as soon as possible.

The yellow ESP® warning lamp comes on while the engine is running.

The ESP® is not operational due to a malfunction.

Risk of accident!

- ▶ Read and observe additional messages that may appear in the multifunction display.
- ► Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability.
- ▶ Adapt your speed and driving to the prevailing road and weather conditions.
- ▶ Have the system checked at an authorized Mercedes-Benz Center as soon as possible.

⚠ The yellow ESP® warning lamp flashes while driving.

The ESP® or the Electronic Traction System (ETS) has come into operation because of detected traction loss in at least one tire.

- ▶ When driving off, apply as little throttle as possible.
- ▶ While driving, ease up on the accelerator pedal.
- ▶ Adapt your speed and driving to the prevailing road and weather conditions.
- ▶ Do not deactivate the ESP®. Exceptions: (⊳ page 60).

Failure to follow these instructions increases the risk of an accident.

Driving systems

Problem	Possible causes/consequences and ▶ Solutions
The red distance warning lamp comes on while driving and an acoustic warning sounds.	You are gaining too rapidly on the vehicle ahead of you or the distance warning system has recognized a stationary obstacle on your probable line of travel. ▶ Apply the brakes immediately. ▶ Carefully observe the traffic situation. You may need to brake or maneuver to avoid hitting an obstacle.

Vehicle

Problem	Possible causes/consequences and ▶ Solutions
The yellow fuel tank reserve warning lamp comes on when the engine is running.	The fuel level has gone below the reserve mark. ▶ Refuel at the next gas station.

Engine

Problem Possible causes/consequences and ▶ Solutions check engine (USA only) There may be a malfunction in (Canada only) the fuel management system The yellow engine • the ignition system malfunction indicator • the emission control system lamp comes on when the engine is running. systems which affect emissions Such malfunctions may result in excessive emissions values and may switch the engine to limp-home (emergency operation) mode. ▶ Have the vehicle checked as soon as possible at an authorized Mercedes-Benz Center. Some states may by law require you to visit a workshop as soon as the engine malfunction indicator lamp comes on. Check local requirements. check engine (USA only) A loss of pressure has been detected in the fuel system. The fuel cap may not be closed properly or the fuel system may be leaky. (Canada only) ► Check the fuel cap (> page 176). The yellow engine malfunction indicator ▶ If it is not closed properly: Close the fuel cap. lamp comes on when ▶ If it is closed properly: Have the fuel system checked by an the engine is running. authorized Mercedes-Benz Center. The red coolant There is insufficient coolant in the reservoir. temperature If this warning lamp comes on frequently, there is a leak in the warning lamp cooling system. comes on when If the coolant level is correct, the electric radiator fan may be the engine is broken. running. ▶ Immediately add coolant to prevent engine from overheating (⊳ page 180). ► Have the cooling system checked. ▶ If the coolant temperature is below 248°F (120°C), you can continue driving to the nearest authorized Mercedes-Benz Center. ▶ Avoid high engine loads (e.g. driving uphill) and stop-and-go

driving.

Problem



The red coolant temperature warning lamp comes on when the engine is running and an acoustic warning sounds.

Possible causes/consequences and ▶ Solutions

The coolant temperature has exceeded 248°F (120°C).

▶ Stop in a safe location as soon as possible and allow the engine and coolant to cool down.



Marning!

Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns which can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Stop the vehicle in a safe location away from other traffic. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

Tires

Problem

USA only: Combination low tire pressure telltale/TPMS malfunction telltale for the **TPMS** illuminates continuously. Canada only: Low tire pressure telltale for the

> Advanced TPMS illuminates continuously.

Possible causes/consequences and ▶ Solutions

The TPMS (USA only) or Advanced TPMS (Canada only) detects a loss of pressure in at least one tire.

- ► Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you.
- ► Read and observe messages in the multifunction display (⊳ page 228).

If the tire inflation pressure in the respective tire(s) has (have) been corrected, the combination low tire pressure/TPMS malfunction telltale goes out after a few minutes of driving.

USA only:

Combination low tire pressure telltale/TPMS malfunction telltale for the TPMS flashes 60 seconds and then stays illuminated.

There is a malfunction in the TPMS.

- ▶ Read and observe messages in the multifunction display (⊳ page 228).
- ▶ Have the TPMS checked at an authorized Mercedes-Benz Center.

After the malfunction has been remedied, the combination low tire pressure/TPMS malfunction telltale goes out after a few minutes of driving.



/ Warning!

Each tire, including the spare (if provided), should be checked at least once a month when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the Tire and Loading Information placard on the driver's door Bpillar or the tire inflation pressure label on the inside of the fuel filler flap. If your vehicle has tires of a different size than the size indicated on the Tire and Loading Information placard or the tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires are significantly underinflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly underinflated tire causes the tire to overheat and can lead to tire failure. Underinflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that

the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if underinflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale.

USA only:

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately 1 minute and then remain continuously illuminated. This

sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of incompatible replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

Lamp in center console

Problem

PASS AIR BAG OFF

The front passenger front air bag off indicator lamp illuminates and remains illuminated with the weight of a typical adult or someone larger than a small individual on the front passenger seat.

Possible causes/consequences and ▶ Solutions

The system is malfunctioning.

- Have the system checked as soon as possible at an authorized Mercedes-Benz Center.
- ▶ Read and observe messages in the multifunction display and follow corrective steps (▷ page 228).

↑ Warning!

If the PASS AIR BAG OFF 2 indicator lamp illuminates and remains illuminated with the weight of a typical adult or someone larger

than a small individual on the front passenger seat, do not have any passenger use the front passenger seat until the system has been repaired.

Problem

PASS AIR BAG OFF

The front passenger front air bag off indicator lamp does not illuminate and/or does not remain illuminated with the weight of a typical 12-month-old child in a standard child restraint or less on the front passenger seat.

Possible causes/consequences and ▶ Solutions

The system is malfunctioning.

- ► Make sure there is nothing between seat cushion and child seat and check installation of the child seat.
- ► Make sure no objects applying supplemental weight onto the seat are present.
- ► Make sure no objects which apply forces to the seat are present (e.g. objects such as books, briefcases etc. lodged behind or around the seat, head restraints pushing against roof etc.). The system may recognize such forces as supplemental weight.
- ▶ If the front passenger front air bag off indicator lamp remains out, have the system checked as soon as possible at an authorized Mercedes-Benz Center. Do not transport a child on the front passenger seat until the system has been repaired.
- ▶ Read and observe messages in the multifunction display and follow corrective steps (▷ page 228).

Marning!

If the PASS AIR BAG OFF 2 indicator lamp does not illuminate or remains out with the weight of a typical 12-month-old child in a standard child restraint or less on the front passenger seat, do not transport a child on the front passenger seat until the system has been repaired.

Unlocking/locking manually

Unlocking the vehicle


If you cannot unlock the vehicle with the SmartKey or with KEYLESS-GO, unlock the driver's door and the trunk using the mechanical key.

The anti-theft alarm system will trigger when you


- unlock the driver's door or the trunk with the mechanical key and
- open the driver's door or the trunk

To cancel the alarm, insert the SmartKey into the starter switch.

Removing the mechanical key



SmartKey



SmartKey with KEYLESS-GO

- ► Move locking tab ① in the direction of arrow.
- ► Slide mechanical key ② out of the housing.

Unlocking the driver's door



- ▶ Insert mechanical key ② into the driver's door lock.
- ► Turn mechanical key ② counterclockwise to position 1 until the locking knob moves up.

The driver's door is unlocked.

- ▶ Pull the door handle to open the driver's door.
- ► Turn mechanical key ② back and remove it from the driver's door lock.

Unlocking the trunk

A minimum height clearance of 5.9 ft (1.8 m) is required to open the trunk lid.



- ► Insert mechanical key ① into the trunk lid lock.
- ► Turn mechanical key ① counterclockwise to position 3 and hold it in this position.
- ▶ Pull handle (2) and lift the trunk lid.
- When you open the trunk, the trunk lid swings open upwards. Always make sure there is sufficient overhead clearance.
- ► Turn mechanical key ① back and remove it from the trunk lid lock.

Locking the vehicle

If you cannot lock the vehicle with the SmartKey or with KEYLESS-GO, lock it as follows:

- ► Open the driver's door.
- ► Close the passenger door, the rear doors, and the trunk.
- ▶ Press the central locking switch (▷ page 71).
- ► Check to see whether the locking knobs on the doors have moved down.
- ▶ If necessary, push them down manually.
- ► Remove the mechanical key from the SmartKey (> page 261).
- ▶ Check whether the trunk is locked.
- ▶ If it is not locked, lock it with the mechanical key (▷ page 75). Except for the driver's door, the vehicle should now be locked.



- ► Insert mechanical key ② into the driver's door lock.
- ► Turn mechanical key ② clockwise to position 1.
 - The driver's door is locked.
- ► Turn mechanical key ② back and remove it from the driver's door lock.
- 1 This procedure does not arm the antitheft alarm system, nor does it lock the fuel filler flap.

Manually unlocking the gear selector lever

If the vehicle's electrical system is malfunctioning, the gear selector lever could remain locked in park position **P**. In this case the gear selector lever can be unlocked manually, e.g. to tow the vehicle.

► Engage the parking brake.



- Do not use sharp objects to loosen the gear selector lever cover in the center console, as this could damage the gear selector lever cover or the center console.
- ► Insert a flat, blunt object into the left edge of gear selector lever cover ① at the positions indicated by the arrows.
- ► Loosen gear selector lever cover ① using this object.

- ▶ Pull gear selector lever cover ① out and remove.
- ► Simultaneously push down release ② and move the gear selector lever out of park position **P**.

The gear selector lever is unlocked.

 The gear selector lever is locked again as soon as you move it back to park position P.

Fuel filler flap

\wedge


Marning!

Avoid contact with the vehicle walls as they may contain sharp edges. Otherwise, you could injure yourself while releasing the fuel filler flap.

In case the central locking system does not release the fuel filler flap, you can open it manually.

The fuel filler flap release is located on the passenger side in the trunk behind the side trim panel.

- ▶ Open the trunk (> page 71).
- ► Remove side trim panel.
- Removing the side trim panel is a demanding process. We recommend that you contact Roadside Assistance (▷ page 166) if you do not feel to have the ability to perform this process.



▶ Pull fuel filler flap release ① in direction of arrow.

The fuel filler flap is unlocked.

- ▶ Open the fuel filler flap (> page 176).
- ► Reinstall side trim panel.
- ▶ Close the trunk.

Resetting activated NECK-PRO active front head restraints

If the NECK-PRO active front head restraints have been triggered in a rear-end collision, they must be reset.

You can tell that the NECK-PRO active front head restraints have been triggered when they have been moved forward and cannot be adjusted.


↑ Warning!

For safety reasons, have the NECK-PRO active front head restraints checked at an authorized Mercedes-Benz Center after a rear-end collision.

↑ Warning!

When pushing back the head restraint cushion, make sure your fingers do not become caught between the head restraint cushion and the cover. Failing to do so may lead to injury.

- Be careful not to damage upholstery.
- 1 For your convenience, we recommend that you have this work carried out at an authorized Mercedes-Benz Center.



- ► Take reset tool ① out of the Mercedes-Benz literature pouch.
- ► Guide reset tool ① into rectangular opening ③ between head restraint cushion ② and head restraint cover.
- ► Press reset tool ① downward in direction of arrow until you hear the head restraint release mechanism audibly engage.
- ▶ Pull out reset tool ①.
- ► Firmly press the head restraint cushion ② backward towards the head restraint cover in direction of arrow until it engages.
- Repeat this procedure for the second front seat.
- ► After resetting the NECK-PRO active front head restraints store reset tool ① in the Mercedes-Benz literature pouch.

For information on NECK-PRO active front head restraints, see "NECK-PRO active front head restraints" (> page 50).

For information on head restraint adjustment, see "Seats" (> page 77).

Replacing SmartKey batteries

If the batteries in the SmartKey are discharged, the vehicle can no longer be locked or unlocked. It is recommended to have the batteries replaced at an authorized Mercedes-Benz Center.

Batteries contain poisonous and corrosive substances. Therefore, keep the batteries out of reach of children.

If a battery is swallowed, seek medical help immediately.



↑ Warning!

SmartKey batteries contain perchlorate material, which may require special handling and regard for the environment. Check with your local government's disposal guidelines. California residents, see www.dtsc.ca.gov/ HazardousWaste/Perchlorate/ index.cfm.

Batteries contain materials that can harm the environment if disposed of improperly. Recycling of batteries is the preferred method of disposal. Many states (USA only) or provinces (Canada only) require sellers of batteries to accept old batteries for recycling. When inserting the batteries, make sure they are clean and free of lint.


When replacing batteries, always replace both batteries.

1 The required replacement batteries are available at any authorized Mercedes-Benz Center.

Replacement batteries: Lithium, type CR 2025 or equivalent.

▶ Remove the mechanical key from the SmartKey (⊳ page 261).

SmartKey




▶ Press mechanical key ② into the SmartKey opening until battery compartment cover (1) opens. Do not keep the cover shut.



- ▶ Remove the battery compartment cover.
- ▶ Pat the SmartKey against the palm of your hand until battery (3) falls out.
- ▶ Insert the new battery with the positive terminal (+) facing up. Use a lint-free cloth.
- ▶ Insert the tabs of the battery compartment cover into the housing and press the cover closed.
- ▶ Slide mechanical key (1) back into the SmartKey.
- ► Check the operation of the SmartKey.


SmartKey with KEYLESS-GO



- ▶ Insert mechanical key (1) into opening.
- ▶ Press mechanical key (1) in direction of

Battery compartment (2) is unlatched.

▶ Pull battery compartment ② out of the SmartKey housing.



- ▶ Pull out batteries (3).
- ► Insert new batteries (3) under contact springs (4) with the positive terminal (+) side facing up.
- ▶ Return battery compartment ② into SmartKey housing until it locks into place.
- ▶ Slide mechanical key (1) back into the SmartKey.
- ► Check the operation of the SmartKey as well as the KEYLESS-GO function.

Replacing bulbs

Safety notes

Safe vehicle operation depends on proper exterior lighting and signaling to a large degree.

Correct headlamp adjustment is extremely important. Have headlamps checked and readjusted at regular intervals and when a bulb has been replaced. Contact an authorized Mercedes-Benz Center for headlamp adjustment.

/ Warning!

Bulbs and bulb sockets can be very hot. Allow the lamp to cool down before changing a bulb.

Keep bulbs out of reach of children.

Halogen lamps contain pressurized gas. A bulb can explode if you

- · touch or move it when hot
- · drop the bulb
- · scratch the bulb

Wear eve and hand protection.

Because of high voltage in Xenon lamps, it is dangerous to replace the bulb or repair the lamp and its components. We recommend that you have such work done by a qualified technician.



/ Warning!

The bulbs in the tail lamps cannot be replaced individually. The tail lamp bulbs are under pressure and could explode during an attempt to replace them.

If the tail lamps are malfunctioning, have them replaced at an authorized Mercedes-Benz Center.

- Since replacing bulbs is a technically highly demanding process, we recommend to have them replaced at an authorized Mercedes-Benz Center.
- 1 If the headlamps or front fog lamps are fogged up on the inside as a result of high

humidity, driving the vehicle a distance with the lights on should clear up the fogging.

Bulbs


You can replace the following bulbs yourself:

Halogen headlamps

Туре


- ① Turn signal lamp: 3457AK
- ② High-beam lamp: H7 55 W
- 3 Parking and standing lamp: W 5 W
- 4 Low-beam lamp: H7 55 W

Bi-Xenon headlamps



Туре

- 1 Turn signal lamp: 3457AK
- ② High-beam lamp: H7 55 W





Туре

① License plate lamps: C 5 W

Notes on bulb replacement

■ Do not replace LEDs or bulbs not described in this section. You could otherwise damage the LEDs, the bulbs or parts of the vehicle. Only have the LEDs and bulbs replaced at an authorized Mercedes-Benz Center.

↑ Observe Safety notes, see page 266.

- Only use 12-volt bulbs of the same type and with the specified watt rating.
- Switch the lights off before changing a bulb to prevent short circuits.
- Always use a clean lint-free cloth when handling bulbs.
- · Your hands should be dry and free of oil and grease.
- If the newly installed bulb does not come on, contact an authorized Mercedes-Benz Center.
- Mercedes-Benz recommends using Longlife (LL) bulbs.

Replacing bulbs for front lamps




↑ Warning!


Do not remove the cover for the Bi-Xenon headlamp. Because of high voltage in Xenon lamps, it is dangerous to replace the bulb or repair the lamp and its components. It is recommended to have such work done by a qualified technician.

Before you start to replace a bulb for a front lamp, do the following:

- ▶ Switch off the ignition.
- ► Turn the exterior lamp switch to position 0 .
- ▶ Open the hood (> page 178).



- 1 Housing cover for low-beam halogen or Bi-Xenon headlamp
- (2) Housing cover for high-beam headlamp/ high-beam flasher bulb and for parking and standing lamp bulb



- (3) Bulb socket for turn signal lamp bulb
- (4) Bulb socket for high-beam bulb
- (5) Bulb socket for parking and standing lamp bulb
- (6) Bulb socket for low-beam bulb

Low-beam bulb (halogen headlamps only)

- ► Turn housing cover (1) counterclockwise and remove it.
- ► Turn bulb socket ⑥ with the bulb counterclockwise and remove it.
- ▶ Pull the bulb out of bulb socket ⑥.
- ► Gently press the new bulb into bulb socket 6).

- ▶ Place bulb socket (6) back into the housing and turn it clockwise until it engages.
- ▶ Align housing cover (1) and turn it clockwise until it engages.

High-beam and high-beam flasher bulb (halogen headlamps only)/high-beam flasher bulb (Bi-Xenon headlamps only)

- ► Turn housing cover (2) counterclockwise and remove it.
- ► Turn bulb socket (4) with the bulb counterclockwise and remove it.
- ▶ Pull the bulb out of bulb socket (4).
- ► Gently press the new bulb into bulb socket (4).
- ▶ Place bulb socket (4) back into the housing and turn it clockwise until it engages.
- ▶ Align housing cover ② and turn it clockwise until it engages.

Front turn signal lamp bulb

- ► Turn bulb socket ③ with the bulb counterclockwise and remove it.
- ► Gently press onto the bulb and turn it counterclockwise out of bulb socket (3).
- ► Gently press the new bulb into bulb socket (3) and turn it clockwise until it engages.
- ▶ Place bulb socket (3) back into the housing and turn it clockwise until it engages.

Parking and standing lamp bulb

Halogen headlamps

- ► Turn housing cover (2) counterclockwise and remove it.
- ▶ Pull out bulb socket (5) with the bulb.
- ▶ Pull the bulb out of bulb socket (5).
- ► Gently press the new bulb into bulb socket (5).
- ▶ Press bulb socket (5) back into the lamp.
- ▶ Align housing cover ② and turn it clockwise.

Bi-Xenon headlamps

In vehicles with Bi-Xenon headlamps, the bulbs of the parking and standing lamps are LEDs.

Do not replace the LEDs yourself. You could otherwise damage the LEDs or parts of the vehicle. Only have the LEDs replaced at an authorized Mercedes-Benz Center.


Replacing bulbs for rear lamps

Tail lamp unit

The tail lamps are equipped with HiP bulbs and LEDs. Have them replaced at an authorized Mercedes-Benz Center.

↑ Observe Safety notes, see page 266.

License plate lamps



- ▶ Switch off the ignition.
- ► Turn the exterior lamp switch to position 0 .
- ▶ Open the trunk.
- ▶ Loosen screws (1) of lamp cover to be removed.
- ► Remove lamp cover ②.
- ► Replace the bulb.
- ▶ Reinstall lamp cover ②.
- ► Retighten screws (1).

Replacing wiper blades

Safety notes



↑ Warning!

For safety reasons, switch off the wipers and remove the SmartKey from the starter switch (vehicles with KEYLESS-GO: Make sure the vehicle's on-board electronics have status 0) before replacing a wiper blade. Otherwise, the wiper motor could suddenly turn on and cause injury.



/ Warning!

Wiper blades are components that are subject to wear and tear. Replace the wiper blades twice a year, preferably in the spring and fall. Otherwise the windshield will not be wiped properly. As a result, you may not be able to observe surrounding traffic conditions and could cause an accident.

- To avoid damage to the hood, the wiper arms should only be folded forward when in the vertical position.
- Never open the hood when a wiper arm is folded forward.

Hold on to the wiper when folding a wiper arm back. If released, the force of the impact from the tensioning spring could crack the windshield.

Do not allow a wiper arm to contact the windshield glass without a wiper blade inserted.

Mercedes-Benz recommends that you have this work carried out at an authorized Mercedes-Benz Center.

Placing wiper arms in vertical position



Wiper arms in vertical position

Make sure the hood is fully closed.

Vehicles with SmartKey

- ► Turn the SmartKey in the starter switch to position 1.
- ► Turn the combination switch to wiper setting —.
- ► With wiper arms in vertical position, turn the SmartKey in the starter switch to position 0.
- ▶ Remove the SmartKey from the starter switch.

Vehicles with KEYLESS-GO

- ► Turn off the engine. With the driver's door closed, the starter switch is now in position 1.
- ► Turn the combination switch to wiper setting — .
- ▶ With wiper arms in vertical position, open the driver's door.
 - The starter switch is set to position **0**, same as the SmartKey removed from the starter switch.
- ► Turn the combination switch to wiper setting **0**.

Removing wiper blades

- Do not pull on the wiper blade inserts. They could tear.
- ► Fold the wiper arm forward until it snaps into place.



- ► Turn the wiper blade at a right angle to wiper arm.
- ► Slide the wiper blade sideways out of the retainer.

Installing wiper blades

- ► Slide the wiper blade onto the wiper arm until it locks in place.
- ► Rotate the wiper blade into a position parallel to the wiper arm.
- ► Fold the wiper arm backward to rest on the windshield.
 - Make sure you hold on to the wiper when folding the wiper arm back.
- Make sure the wiper blades are installed properly. Improperly installed wiper blades may cause windshield damage.

Flat tire

Safety notes

Your vehicle may be equipped with a Minispare wheel or a spare wheel with collapsible tire.

For information on your vehicle's equipment, see "Rims and tires" (▷ page 291).

The dimensions of the spare wheel are different from those of the road wheels. As a result, the vehicle handling characteristics change when driving with a spare wheel mounted. Adapt your driving style accordingly.

The spare wheel is for temporary use only. When driving with a spare wheel mounted, ensure proper tire inflation pressure and do not exceed a vehicle speed of 50 mph (80 km/h).

Contact the nearest authorized Mercedes-Benz Center as soon as possible to have the spare wheel replaced with a regular road wheel.

Never operate the vehicle with more than one spare wheel mounted.

Do not switch off the ESP® when a spare wheel is mounted.

Preparing the vehicle

- Whenever possible, park the vehicle in a safe distance from moving traffic on a hard, flat surface.
- ► Turn on the hazard warning flasher.
- ► Turn the steering wheel so that the front wheels are in a straight-ahead position.
- ► Engage the parking brake.
- ► Shift the automatic transmission into park position **P**.
- ► Turn off the engine.
- ► Remove the SmartKey from the starter switch.

or

▶ Vehicles with KEYLESS-GO: Open the driver's door (this puts the starter switch in position **0**, same as with the SmartKey removed from the starter switch). The driver's door can then be closed again.

Open doors only when conditions are safe to do so.

▶ Have any passenger exit the vehicle at a safe distance from the roadway. Open doors only when conditions are safe to do so.

Mounting the spare wheel

Introduction

- ▶ Prepare the vehicle as described (⊳ page 271).
- ► Take the following out of the vehicle:
 - spare wheel
 - jack
 - · vehicle tool kit
 - · wheel wrench
 - electric air pump (required for vehicles with spare wheel with collapsible tire only)


For information on where to find the respective items, see "Where will I find ...?" (▷ page 224) and (▷ page 226).

1 Vehicles without spare wheel are not factory-equipped with the tools required for a wheel change such as a jack or a wheel wrench. Some tools required for a wheel change are specific to your vehicle. Contact an authorized Mercedes-Benz Center to obtain the tools approved for vour vehicle. This section describes the wheel change using the tools approved and recommended for your vehicle.

Removing tensioning straps from spare wheel

This description applies to vehicles with 19" spare wheel with collapsible tire only.

A 19" spare wheel with collapsible tire has two tensioning straps on it that must be removed before mounting the spare wheel.



- ▶ Press on both clips ② simultaneously to release buckle 1.
- ▶ Store the tensioning straps in a safe place. You will need them to store the spare wheel in the trunk after use (▷ page 226).

Lifting the vehicle

↑ Warning!

When jacking up the vehicle, only use the jack which has been specifically approved by Mercedes-Benz for your vehicle.

The jack is designed exclusively for jacking up the vehicle at the jack take-up brackets built into both sides of the vehicle. Make sure the jack arm is fully seated in the jack take-up bracket. The jack must always be vertical when in use, especially on inclines or declines.

The jack is intended only for lifting the vehicle briefly for wheel changes. It is not suited for performing maintenance work under the vehicle. To help avoid personal injury, use the jack only to lift the vehicle during a wheel change.

Never get beneath the vehicle while it is supported by the jack. Keep hands and feet away from the area under the lifted vehicle. Always lower the vehicle onto sufficient capacity jackstands before working under the vehicle.

Always engage the parking brake firmly and block the wheels with wheel chocks or other sizeable objects before raising the vehicle

with the jack. Do not disengage the parking brake while the vehicle is raised.

Make sure that the ground on which the vehicle is standing and where you place the jack is solid, level and not slippery. If necessary, use a large underlay. On slippery surfaces, such as tiled floors, you should use a non-slip underlay, for example a rubber mat.

Do not use wooden blocks or similar objects to support the jack. Otherwise the jack may not be able to achieve its load-bearing capacity if it is not at its full height.

Never start the engine when the vehicle is raised.

Also observe the notes on the jack.

 Prevent the vehicle from rolling away by blocking wheels with wheel chocks or other sizeable objects.

When your vehicle is equipped with a wheel chock, it is included with the vehicle tool kit (> page 224). For information on setting up the collapsible wheel chock, see (> page 225).

When changing a wheel on a level surface:


Place a wheel chock or other sizeable object in front of and another wheel chock or other sizeable object behind the wheel that is diagonally opposite to the wheel being changed.

Always try lifting the vehicle using the jack on a level surface. However, should circumstances require you to do so on a hill:

Place wheel chocks or other sizeable objects on the downhill side in front of both wheels on the side opposite to the side on which the wheel is to be changed.

↑ Warning!

Only jack up the vehicle on level ground or on slight inclines/declines. Otherwise, the vehicle could fall off the jack and injure you or others.



► On the wheel to be changed, loosen but do not yet remove the wheel bolts (approximately one full turn with wheel wrench (1)).


The jack take-up brackets are located directly behind the front wheel housings and in front of the rear wheel housings.

♠ Warning!


The jack is designed exclusively for jacking up the vehicle at the jack take-up brackets. Make sure the jack arm is fully seated in the jack take-up bracket.

If you do not position the jack correctly in the jack take-up bracket, the vehicle can fall off the jack and seriously or fatally injure you or others.

■ Do not position the jack on the body of the vehicle, as this may cause damage to the vehicle.



- ▶ Place jack (3) on firm ground.
- ► Position jack (3) under take-up bracket (2) so that it is always vertical as seen from the side, even if the vehicle is parked on an incline.



P40.00-2147-31

- ► Turn crank (4) clockwise until jack (3) is fully seated in take-up bracket (2) and the jack base evenly meets the ground.
- ▶ Jack up the vehicle until the wheel is a maximum of 1.2 in (3 cm) from the ground.

Removing the wheel



- ▶ Unscrew the uppermost wheel bolt and remove it.
- ► Replace this wheel bolt with alignment bolt (1).
- ► Remove the remaining bolts.
- Do not place wheel bolts in sand or dirt. This could result in damage to the wheel bolts and wheel hub threads.
- ▶ Remove the wheel

Attaching the spare wheel

♠ Warning!

Vehicles with spare wheel with collapsible tire only: Inflate collapsible tire only after the wheel is properly attached.

Inflate the collapsible tire using the electric air pump before lowering the vehicle.



↑ Warning!

Always replace wheel bolts that are damaged or rusted.

Never apply oil or grease to wheel bolts.

Damaged wheel hub threads should be repaired immediately. Do not continue to drive under these circumstances! Contact an authorized Mercedes-Benz Center or call. Roadside Assistance.


Incorrect wheel bolts or improperly tightened wheel bolts can cause the wheel to come off. This could cause an accident. Make sure to use the correct wheel bolts.

↑ Warning!

Only use genuine Mercedes-Benz wheel bolts. Other wheel bolts may come loose.

Do not tighten the wheel bolts when the vehicle is raised. Otherwise the vehicle could fall off the jack.

- ► Clean contact surfaces of wheel and wheel hub.
- I To avoid paint damage, place wheel flat against hub and hold it there while installing first wheel bolt.



- ► Guide the spare wheel onto the alignment bolt and push it on.
- ▶ Insert the wheel bolts and tighten them slightly.
- ► Unscrew the alignment bolt.
- ▶ Install the last wheel bolt and tighten it slightly.
- ▶ Vehicles with spare wheel with collapsible tire: Continue the procedure by following the instructions under "Inflating the collapsible tire" (⊳ page 275) and then "Lowering the vehicle" (⊳ page 276).

▶ Vehicles with Minispare wheel: Continue the procedure by following the instructions under "Lowering the vehicle" (⊳ page 276).

Inflating the collapsible tire



Marning!

Inflate collapsible tire only after the wheel is properly attached.

Inflate the collapsible tire using the electric air pump before lowering the vehicle.

/ Warning!


Observe safety instructions on air pump label.

■ Do not lower the vehicle before inflating the collapsible tire. Otherwise the rim may be damaged.


Your vehicle may be equipped with either of two versions of the electric air pump:

- Version 1: The air hose with pressure gauge and the electrical plug are located behind a flap.
- Version 2: The pressure gauge is located in the pump housing. The air hose and electrical plug are located at the bottom of the pump housing.

The following description applies to both versions. Differences in usage are expressly declared.



Version 1



Version 2

- ▶ Version 1 only: Open flap (1) on electric air pump.
- ► Version 1 only: Pull out electrical plug (3) and air hose with pressure gauge and vent screw (4).
- ▶ Version 2 only: Pull electrical plug (3) and the air hose out of the pump housing bottom.
- ▶ Version 1 only: Close vent screw on air hose (4).
- ▶ Remove the valve cap from the collapsible tire valve.
- ► Screw union nut (5) onto the collapsible tire
- ► Make sure air pump switch ② is set to 0.
- ▶ Insert electrical plug ③ into the cigarette lighter socket (⊳ page 163) or a power outlet (⊳ page 163).

► Turn the SmartKey in the starter switch to position 1.

or

- ▶ Vehicles with KFYLESS-GO: Press the KEYLESS-GO start/stop button once. Do not depress the brake pedal.
- ▶ Press I on electric air pump switch (2). The electric air pump switches on and inflates the collapsible tire.
- ▶ Inflate the collapsible tire to the recommended tire inflation pressure as specified for your vehicle (⊳ page 296). This should take approximately 5 minutes.

↑ Warning!

The air hose and the union nut can become hot during inflation. Exercise proper caution to avoid burning yourself when using the equipment.

Do not operate the electric air pump longer than 8 minutes without interruption. Otherwise it may overheat.

You may operate the air pump again after it has cooled off.

- Compare the recommended tire inflation pressure for your vehicle with the tire inflation pressure on the yellow label located on the spare wheel rim. If the tire inflation pressure on the yellow label on the spare wheel rim differs from the values given in this Operator's Manual, inflate the tire to the recommended tire inflation pressure given on the yellow label on the spare wheel rim.
- ▶ Press **0** on electric air pump switch (2).
- ► Turn the SmartKey in the starter switch to position **0**.

or

- ▶ Vehicles with KEYLESS-GO: Press the KEYLESS-GO start/stop button twice. Do not depress the brake pedal.
- ▶ Version 1 only: If the tire inflation pressure is above the recommended tire inflation

- pressure as specified for your vehicle (⊳ page 296), decrease tire pressure using the vent screw on air hose (4).
- ▶ Version 2 only: If the tire inflation pressure is above the recommended tire inflation pressure as specified for your vehicle (⊳ page 296), decrease tire pressure using deflate button (6).

↑ Observe Safety notes, see page 185.

- ▶ Detach the electric air pump.
- ► Reinstall collapsible tire valve cap.
- ► Version 1 only: Store electrical plug (3) and air hose (4) behind flap (1).
- ► Version 2 only: Store electrical plug (3) and the air hose back into the pump housing bottom.
- ▶ Place the electric air pump back in its designated storage space.
- ▶ I ower the vehicle.

Lowering the vehicle




/ Warning!

Vehicles with spare wheel with collapsible tire only: Inflate collapsible tire only after the wheel is properly attached.

Inflate the collapsible tire using the electric air pump before lowering the vehicle.

- ► Lower the vehicle by turning the crank counterclockwise until the vehicle is resting fully on its own weight.
- ▶ Remove the jack.



▶ Tighten the five wheel bolts evenly, following the diagonal sequence illustrated (1) to (5), until all bolts are tight. Observe a tightening torque of 96 lb-ft (130 Nm).

Marning!

Have the tightening torque checked after changing a wheel. The wheels could come loose if they are not tightened to a torque of 96 lb-ft (130 Nm).

- ► Fully collapse the jack, with handle folded in (storage position), see (\triangleright page 225).
- ▶ Store the jack and the other vehicle tools in the designated storage space.
- ▶ Wrap the damaged wheel in the protective wrap that comes with the spare wheel and put the wheel in the trunk.

You can also place the damaged wheel down into the spare wheel well. In this case, you must store the luggage bowl in the trunk.

For information on storing the spare wheel after it has been replaced by a regular road wheel, see (⊳ page 226).

Vehicles with TPMS or Advanced TPMS: Do not restart the tire inflation pressure monitor until a full size wheel/tire with functioning sensor has been placed back into service on the vehicle.

MOExtended system

The MOExtended system allows you to continue driving your vehicle even if there is a total loss of pressure in one or more tires.

You may only use the MOExtended system in conjunction with the tire pressure loss warning system (▷ page 186), the TPMS (⊳ page 188), or the Advanced TPMS (⊳ page 190).

The maximum distance in emergency mode depends on the vehicle's load. It is 50 miles (80 km) if the vehicle is partially loaded and 18 miles (30 km) if the vehicle is fully loaded. The point at which the maximum driving

distance in emergency mode begins is when the warning message appears in the multifunction display indicating that there is a loss of tire inflation pressure.

▶ Do not exceed the maximum speed of 50 mph (80 km/h).



↑ Warning!

In emergency mode, your vehicle's driving characteristics are diminished in such situations as:

- driving around curves
- · while braking
- while accelerating rapidly

Therefore, your driving style must be adapted accordingly. Avoid abrupt steering and driving maneuvers, as well as driving over obstacles (road curbs, potholes, or off-road areas). This is especially important if the vehicle is heavily loaded.

The emergency driving distance that can be achieved greatly depends on the demands placed on the vehicle. Depending on speed, load, driving maneuvers, road conditions, outside temperature, etc., the distance can be significantly shorter or, if the vehicle is driven cautiously, somewhat longer.

Do not continue driving in emergency mode if

- · you notice knocking sounds
- the vehicle starts to shake
- smoke develops and you smell rubber
- ESP® is intervening continuously
- · you notice tears on the tire sidewalls

After driving in emergency mode, you must have the rims inspected by an authorized Mercedes-Benz Center to check if they are suitable for further use. The failed tire must be replaced in any case.

When replacing individual or all tires on the vehicle, make sure only tires marked with "MOExtended" are mounted in the size specified for your vehicle (⊳ page 291).

Battery

Safety notes

A battery should always be sufficiently charged in order to achieve its rated service life. Refer to Maintenance Booklet for battery maintenance intervals.

If you use your vehicle mostly for shortdistance trips, you will need to have the battery charge checked more frequently.

When replacing a battery, always use a battery approved by Mercedes-Benz.

If you do not intend to operate your vehicle for an extended period of time, contact an authorized Mercedes-Benz Center about steps you need to observe.



/ Warning!

Observe all safety instructions and precautions when handling automotive batteries.



Risk of explosion.



Fire, open flames and smoking are prohibited when handling batteries. Avoid creating sparks.



Battery acid is caustic. Do not allow it to come into contact with skin, eyes or clothing.

Wear suitable protective clothing, especially gloves, apron and faceguard.



Wear eye protection. Rinse any acid spills immediately with clear water. Contact a physician if necessary.



Keep children away.



Follow the instructions in this Operator's Manual.

A battery contains materials that can harm the environment if disposed of improperly. A large 12 V storage battery contains lead. Recycling of the battery is the preferred method of disposal. Many states (USA only) or provinces (Canada only) require sellers of batteries to accept the old battery for recycling.



↑ Warning!

Failure to follow these instructions can result in severe injury or death.

Never lean over batteries while connecting. You might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking etc.



Marning!

Do not place metal objects on the battery as this could result in a short circuit.

Use leak-proof batteries only to avoid the risk of acid burns in the event of an accident.

Take care that you do not become statically charged, e.g. by wearing synthetic clothing or rubbing against textiles. For this reason, you also should not pull or push the battery over carpets or other synthetic materials.

Never touch the battery first. First touch the outside body of the vehicle in order to release any possible electrostatic charges.

Do not rub the battery with rags or cloths. The battery could explode if touched due to electrostatic charge or due to spark formation.

■ The battery is a <u>Valve-Regulated Lead</u> <u>Acid</u> (VRLA) battery, also referred to as "fleece" battery.

Such batteries do not require topping-up of the electrolyte level. VRLA batteries therefore do not have cell caps and the battery cover is non-removable. Do not attempt to open the battery as otherwise the battery will be damaged.

VRLA batteries do not require topping-up of the electrolyte level. They cannot be opened to check the electrolyte level. However, the battery condition must be checked periodically by performing a battery conductance test. Refer to Maintenance Booklet for battery condition testing intervals.

The factory-equipped battery may only be replaced with a battery that

- · has the same security features
- · is of identical size
- is of identical voltage
- is of identical capacity
- As any other battery, the battery may discharge if you do not operate the vehicle for an extended period of time. Have the battery disconnected at a qualified workshop or an authorized Mercedes-Benz Center in such a case. You may also connect an accessory battery charge unit expressly approved by Mercedes-Benz for your vehicle model to maintain the battery charge. Contact an authorized Mercedes-Benz Center for further information.

The battery, the battery ventilation hose and the lateral plug must always be securely installed when the vehicle is in operation.

Never loosen or detach battery terminal clamps while the engine is running or the SmartKey is in the starter switch or KEYLESS-GO button is in position 1. Otherwise the alternator and other electronic components could be severely damaged.

Have the battery checked regularly at an authorized Mercedes-Benz Center.

Refer to Maintenance Booklet for maintenance intervals or contact an authorized Mercedes-Benz Center for further information.

- **1** After battery power was interrupted, do the following:
 - Synchronize the power windows (> page 95).
 - Synchronize the tilt/sliding sunroof (> page 154).

Charging the battery

Marning!

Never charge a battery while still installed in the vehicle unless the accessory battery charge unit approved by Mercedes-Benz is being used. Gases may escape during charging and could cause an explosion that may result in personal injury, paint damage or corrosion.

An accessory battery charge unit specially adapted for Mercedes-Benz vehicles and tested and approved by Mercedes-Benz is available. It permits the charging of the battery in its installed position. Contact an authorized Mercedes-Benz Center for information and availability.

Charge battery in accordance with the separate instructions for the accessory battery charger.

Have the battery charged at an authorized Mercedes-Benz Center. If you charge the

battery yourself, follow the operating instructions for your charging device. Only use a battery charge unit with a maximum charging voltage of 14.8 V.

► Charge battery in accordance with the instructions of the battery charger manufacturer.

Jump starting

Marning!

Failure to follow these directions will cause damage to the electronic components, and can lead to a battery explosion and severe injury or death.

Never lean over batteries while connecting or jump starting. You might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water, and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking, etc.

Attempting to jump start a frozen battery can result in it exploding, causing personal injury. Read all instructions before proceeding.

- Do not tow-start the vehicle. You could otherwise seriously damage the automatic transmission which is not covered by the Mercedes-Benz Limited Warranty.
- Jump starting should only be performed using the jump-start terminals located in the engine compartment.

Avoid repeated and lengthy starting attempts.

Do not attempt to start the engine using a battery quick-charge unit.

If the engine does not run after several unsuccessful starting attempts, have it checked at the nearest authorized Mercedes-Benz Center.

Excessive unburned fuel generated by repeated failed starting attempts may damage the catalytic converter and may present a fire risk.

Make sure the jumper cables do not have loose or missing insulation.

Make sure the cable clamps do not touch any other metal part while the other end is still attached to a battery.

If the battery is discharged, the engine can be started with jumper cables and the fully charged battery of another vehicle or an equivalent starter pack. Observe the following:


- Access to the battery is not possible on all vehicles. If you cannot access the battery of the other vehicle, provide jump start power by an external battery or starter pack.
- Jump starting should only be performed when the engine and catalytic converter are cold.
- Do not jump start the engine or charge the battery if the battery is frozen. Let the battery thaw out first.
- Only jump start from batteries with the same voltage rating (12 V). Jump starting with a more powerful battery could damage the vehicle's electrical system. Such damage will not be covered by the Mercedes-Benz Limited Warranty.
- · Only use jumper cables with sufficient cross-section and insulated terminal clamps.
- Always make sure the jumper cables are not on or near pulleys, fans or other parts that move when an engine is started or running.
- Should the battery be drained completely, let the donating power source charge the

vehicle for several minutes before reattempting the starting process.

The battery is located in the trunk underneath the luggage box (\triangleright page 227).

- ▶ Make sure the two vehicles do not touch.
- Switch off all electrical consumers.

- ► Engage the parking brake.
- ► Make sure the automatic transmission is in park position **P**.
- ▶ Open the trunk.



Position (5) represents the charged battery of another vehicle or an equivalent starter pack.

- ► Remove cover from battery positive terminal ②.
- I Never invert the terminal connections!
- ► Connect positive terminal ① of charged battery ⑤ with positive terminal ② with a jumper cable. Clamp the cable to positive terminal ① of charged battery ⑤ first.
- ► Start engine of the vehicle with charged battery ⑤ and run at idle speed.
- ► Connect negative terminal ③ of charged battery ⑤ with negative terminal ④ with a jumper cable. Clamp the cable to negative terminal ③ of charged battery ⑤ first.

- ► Start engine of the vehicle with the discharged battery and run at idle speed. You can now turn on the electrical consumers. Do not switch on the headlamps under any circumstances.
- ► Remove the jumper cables from negative terminals ③ and ④ first.
- ► Remove the jumper cables from positive terminals ① and ②.

 You can now switch on the headlamps.
- ► Have the battery checked at the nearest authorized Mercedes-Benz Center.

Towing the vehicle

Safety notes

Mercedes-Benz recommends that the vehicle be transported with all wheels off the ground using flatbed or appropriate wheel lift/dolly equipment. This method is preferable to other types of towing.

To prevent damage during transport, do not tie down vehicle by its chassis or suspension parts.

If circumstances do not permit the recommended towing methods, the vehicle may be towed with all wheels on the ground or one axle raised only so far as necessary to have the vehicle moved to a safe location where the recommended towing methods can be employed.

- Before towing the vehicle observe the following instructions:
 - Do not tow-start the vehicle. You could otherwise seriously damage the automatic transmission which is not covered by the Mercedes-Benz Limited Warranty.
 - Do not tow with sling-type equipment.
 Towing with sling-type equipment over bumpy roads will damage radiator and supports.
 - Towing of the vehicle should only be done using the properly installed towing eye bolt. Never attach a tow cable, tow rope or tow rod to the vehicle chassis, frame or suspension parts.

↑ Warning!

With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle. Adapt your driving accordingly.

- Avoid pulling the vehicle abruptly or diagonally, since it could result in damage to the chassis alignment.
- Do not use the towing eye bolt for recovery, as this could damage the vehicle. If in doubt, recover the vehicle with a crane.

- If the battery is disconnected or discharged
 - the SmartKey will not turn in the starter switch
 - the automatic transmission will remain in park position P

For more information see "Battery" (▷ page 278) or "Jump starting" (▷ page 280).

For information on manually unlocking the gear selector lever, see (▷ page 263).

Installing towing eye bolt

Depending on whether you are towing a vehicle or you are being towed, the towing eye bolt can be screwed into threaded holes which are located behind covers on each bumper.

The towing eye bolt is supplied with the vehicle tool kit, located underneath the trunk floor (> page 224).

► Take the vehicle tool kit out of the trunk.

Removing cover in front bumper



- ▶ Press mark on cover ① as indicated by the arrow.
- ► Lift cover ① off to reveal the threaded hole for the towing eye bolt.

Removing cover in rear bumper

↑ Warning!

In order to avoid possible serious burns or injury, use extreme caution when removing the rear cover, because the rear exhaust pipe is extremely hot.



- ▶ Press on cover (1) as indicated by the arrow.
- ► Fold cover (1) down to reveal the threaded hole for the towing eye bolt.

Fixing towing eye bolt



Example illustration front bumper

- ► Take the towing eye bolt and, if so equipped, the wheel wrench from the vehicle tool kit (⊳ page 224).
- ► Screw towing eye bolt ② clockwise into threaded hole to its stop.

▶ Insert wheel wrench into towing eye and tighten towing eye bolt (2) by turning it clockwise.

or

► If your vehicle is not equipped with a wheel wrench, use a suitable object to turn the towing eye bolt.

Removing towing eye bolt

- ▶ Loosen towing eye bolt ② by turning it counterclockwise.
- ▶ Unscrew towing eye bolt ②.
- ▶ Reinstalling cover: Fit cover (1) (⊳ page 282) and snap it into place.
- ▶ Store the towing eye bolt ② and wheel wrench back into the vehicle tool kit.

Towing with front axle raised

- The vehicle may be towed only for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h).
- ▶ Make sure the ignition is switched on.
- ▶ With the vehicle at a standstill, depress the brake pedal and keep it pressed.
- ▶ Shift the automatic transmission into neutral position N.
- ► Release the brake pedal.
- ▶ If engaged, release the parking brake.
- ► Switch off the automatic central locking (⊳ page 123).
- ► Switch off the ignition and leave the SmartKey in the starter switch.
- ► Switch on the hazard warning flasher (⊳ page 90).
- Because the ESP® operates automatically, the engine and ignition must be shut off (SmartKey in starter switch position **0** or **1** or KEYLESS-GO start/stop button in position 0 or 1) when the vehicle is being towed with the front axle raised.

Active braking action through the ESP® may otherwise seriously damage the brake system which is not covered by the Mercedes-Benz Limited Warranty.

Towing with all wheels on the ground

↑ Warning!

If circumstances require towing the vehicle with all wheels on the ground, always tow with a tow bar if:

- · the engine will not run
- there is a malfunction in the brake system
- there is a malfunction in the power supply or in the vehicle's electrical system

This is necessary to adequately control the towed vehicle.

Prior to towing the vehicle with all wheels on the ground, make sure the SmartKey is in starter switch position 2.

If the SmartKey is left in the starter switch position **0** for an extended period of time, it can no longer be turned in the switch. In this case, the steering is locked. To unlock, remove SmartKey from starter switch and reinsert.



/ Warning!

With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle. Adapt your driving accordingly.

- ▶ Make sure the ignition is switched on.
- ▶ With the vehicle at a standstill, depress the brake pedal and keep it pressed.
- ▶ Shift the automatic transmission into neutral position N.
- ► Release the brake pedal.
- ▶ If engaged, release the parking brake.
- ► Switch on the hazard warning flasher (⊳ page 90).

- The vehicle may be towed only for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h).
- While being towed with the hazard warning flasher in use, use the combination switch in the usual manner to signal turns. Only the selected turn signal will operate. Upon canceling the turn signal, the hazard warning flasher will operate again.

Fuses

Introduction

The electrical fuses in your vehicle serve to switch off malfunctioning power circuits. If a fuse is blown, the components and systems secured by that fuse will stop operating.



↑ Warning!

Only use fuses approved by Mercedes-Benz with the specified amperage for the system in question and do not attempt to repair or bridge a blown fuse. Using other than approved fuses or using repaired or bridged fuses may cause an overload leading to a fire, and/or cause damage to electrical components and/or systems. Have the cause determined and remedied by an authorized Mercedes-Benz Center.

A blown fuse must be replaced by an appropriate spare fuse (recognizable by its color or the fuse rating given on the fuse) of the amperage recommended in the fuse chart. Any Mercedes-Benz Center will be glad to advise you on this subject.

1 In case of a blown fuse contact Roadside Assistance or an authorized Mercedes-Benz Center.

If a newly inserted fuse blows again, have the cause determined and rectified by an authorized Mercedes-Benz Center.

The fuse chart is located in the fuse box in the passenger compartment. The fuse chart

explains the fuse allocation and fuse amperages.

Before replacing fuses

- ► Engage the parking brake.
- ► Make sure the automatic transmission is in park position **P**.
- ▶ Switch off all electrical consumers.
- ► Turn off the engine.
- ► Remove the SmartKey from the starter switch.
- ▶ Vehicles with KEYLESS-GO: Open the driver's door (this puts the starter switch in position **0**, same as with the SmartKey removed from the starter switch). The driver's door then can be closed again.

Fuse box in passenger compartment


■ Do not use sharp objects such as a screwdriver to open the fuse box cover in the dashboard. You could damage the fuse box cover or the dashboard.



- ► Open the driver's door.
- ➤ Opening: Insert flat, blunt object as a lever in-between the edge of fuse box cover ① and the dashboard at the position indicated by the arrow.
- ► Loosen fuse box cover ① from the dashboard using the lever.
- ► Using your hands, pull cover ① in direction of arrow and remove it.

- Closing: Hook fuse box cover 1 into the opening at the front.
- ▶ Press fuse box cover ① back on until it engages.
- I The fuse box cover must be properly positioned as described. Otherwise, moisture or dirt could enter the fuse box and possibly impair fuse operation.

Fuse box in trunk



- ▶ Open the trunk.
- ▶ Opening: Insert flat, blunt object as a lever into the edge of cover ① and remove cover ①.
- ► Closing: Install cover ①.

Vehicle equipment	288
Parts service	288
Warranty coverage	288
Identification labels	288
Vehicle specification CLS 550	
(219.372)	290
Vehicle specification CLS 63 AMG	
(219.377)	290
Rims and tires	29 1
Fuels, coolants, lubricants, etc	296



Vehicle equipment

1 This Operator's Manual describes all features, standard or optional, potentially available for your vehicle at the time of purchase. Please be aware that your vehicle might not be equipped with all features described in this manual.

Parts service

All authorized Mercedes-Benz Centers maintain a stock of Genuine Mercedes-Benz Parts required for maintenance and repair work. In addition, strategically located parts distribution centers provide quick and reliable parts service.

More than 300 000 different parts for Mercedes-Benz models are available.

Genuine Mercedes-Benz Parts are subjected to stringent quality inspections. Each part has been specifically developed, manufactured or selected for and adapted to Mercedes-Benz vehicles.

Therefore, Genuine Mercedes-Benz Parts should be installed.

Do not use non-genuine Mercedes-Benz parts and accessories not authorized by Mercedes-Benz. Doing so could damage the vehicle, which is not covered by the Mercedes-Benz Limited Warranty. Also, it could compromise the vehicle's durability or safety.

Warranty coverage

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet.

Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:


- New Vehicle Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Connecticut, Maine, Massachusetts, New York, Pennsylvania, Rhode Island, and Vermont Emission Control Systems Warranty
- State Warranty Enforcement Laws (Lemon Laws)

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories warranties, copies of which are available at any authorized Mercedes-Benz Center.

Loss of Service and Warranty Information booklet

Should you lose your Service and Warranty Information booklet, have an authorized Mercedes-Benz Center arrange for a replacement. It will be mailed to you.

Identification labels



The Vehicle Identification Number (VIN) can be found

- on certification label ① on the driver's door
 B-pillar
- embossed underneath a cover in the front passenger footwell (> page 289)
- on the lower edge of the windshield
 (▷ page 289)



Example certification label (U.S. vehicles)


- (2) VIN
- ③ Paintwork code




Example certification label (Canada vehicles)

- (2) VIN
- ③ Paintwork code
- Data shown on certification label are for illustration purposes only. These data are

specific to each vehicle and may vary from data shown in the illustration. Refer to certification label on vehicle for actual data specific to your vehicle.



- ▶ Move the front passenger seat backward as far as possible (> page 78).
- ► Fold cover ④ backward. VIN ⑤ is now visible.



- Emission control information label, includes both federal and California certification exhaust emission standards
- VIN (on lower edge of windshield)
- ® Engine number (engraved on engine)
- **1** When ordering parts, please specify vehicle identification and engine number.

Vehicle specification CLS 550 (219.372)

The quoted data apply only to the standard vehicle. Contact an authorized Mercedes-Benz Center for the corresponding data of all special bodies and special equipment.

Engine CLS 550	
Engine, type	273
Mode of operation	4-stroke engine, gasoline injection
No. of cylinders	8
Bore	3.86 in (98.00 mm)
Stroke	3.56 in (90.50 mm)
Total piston displacement	333.2 cu in (5461 cm³)
Compression ratio	10.7:1
Output acc. to SAE J 1349 ¹⁶	382 hp/6 000 rpm (285 kW/6 000 rpm)
Maximum torque acc. to SAE J 1349	391 lb-ft/ 2 800 - 4 800 rpm (530 Nm/ 2 800 - 4 800 rpm)
Maximum engine speed	6 500 rpm
Firing order	1-5-4-2-6-3-7-8
Poly-V-belt	2 398 mm

Electrical system CLS 550		
Alternator 14 V/180 A		
Starter motor	12 V/1.7 kW	
Battery 12 V/100 Ah		

Electrical system CLS 550	
Spark plugs, type	Bosch F8 DPP 332U
	NGK PFR 5R-11
Spark plugs, electrode gap	0.039 in (1.0 mm)
Spark plugs, tightening torque	18 - 22 lb-ft (25 - 30 Nm)

Main dimensions CLS 550		
Overall vehicle length	193.7 in (4920 mm)	
Overall vehicle width ¹⁷	83.0 in (2 107 mm)	
Overall vehicle height	55.7 in (1414 mm)	
Wheelbase	112.4 in (2854 mm)	
Track, front	62.5 in (1587 mm)	
Track, rear	61.8 in (1570 mm)	
Turning circle	36.8 ft (11.2 m)	

Weights CLS 550	
Roof load	max. 220 lb (100 kg)
Trunk load	max. 220 lb (100 kg)

Vehicle specification CLS 63 AMG (219.377)

The quoted data apply only to the standard vehicle. Contact an authorized Mercedes-Benz Center for the corresponding data of all special bodies and special equipment.

¹⁶ Premium fuel required. Performance may vary with fuel octane rating.

¹⁷ Exterior rear view mirrors folded out.

Engine CLS 63 AMG		
Engine, type	156	
Mode of operation	4-stroke engine, gasoline injection	
No. of cylinders	8	
Bore	4.02 in (102.20 mm)	
Stroke	3.72 in (94.60 mm)	
Total piston displacement	378.8 cu in (6 208 cm³)	
Compression ratio	11.3:1	
Output acc. to SAE J 1349 ¹⁸	507 hp/6 800 rpm (378 kW/6 800 rpm)	
Maximum torque acc. to SAE J 1349	465 lb-ft/5 200 rpm (630 Nm/5 200 rpm)	
Maximum engine speed	7 200 rpm	
Firing order	1-5-4-2-6-3-7-8	
Poly-V-belt	2360 mm	

Electrical system CLS 63 AMG	
Alternator	14 V/180 A
Starter motor	12 V/2.1 kW
Battery	12 V/95 Ah
Spark plugs, type	NGK ILZKAR 7A10
Spark plugs, electrode gap	0.039 in (1.0 mm)
Spark plugs, tightening torque	15 - 18 lb-ft (20 - 25 Nm)

Main dimensions CLS 63 AMG		
Overall vehicle length	193.5 in (4915 mm)	
Overall vehicle width ¹⁹	83.0 in (2 107 mm)	
Overall vehicle height	54.7 in (1389 mm)	
Wheelbase	112.4 in (2854 mm)	
Track, front	63.0 in (1599 mm)	
Track, rear	62.3 in (1583 mm)	
Turning circle	37.7 ft (11.5 m)	

Weights CLS 63 AMG	
Roof load	max. 220 lb (100 kg)
Trunk load	max. 220 lb (100 kg)

Rims and tires

Notes

- Only use tires which have been tested and approved by Mercedes-Benz. Tires approved by Mercedes-Benz are developed to provide best possible performance in conjunction with the driving safety systems on your vehicle such as the ABS or the ESP®. Tires specially developed for your vehicle and tested and approved by Mercedes-Benz can be identified by finding the following on the tire's sidewall:
 - MO = <u>Mercedes-Benz Original</u> equipment tires
 - MOE = Mercedes-Benz Original Extended (tires with limited run-flat characteristics) original equipment tires

Using tires other than those approved by Mercedes-Benz may result in damage that

¹⁸ Premium fuel required. Performance may vary with fuel octane rating.

¹⁹ Exterior rear view mirrors folded out.

is not covered by the Mercedes-Benz Limited Warranty.

For information on driving with MOExtended tires, see the "Practical hints" section (> page 277).

- Using tires other than those approved by Mercedes-Benz can have detrimental effects, such as
 - · poor handling characteristics
 - · increased noise
 - · increased fuel consumption

Moreover, tires and rims not approved by Mercedes-Benz may, under load, exhibit dimensional variations and different tire deformation characteristics that could cause them to come into contact with the vehicle body or axle parts. Damage to the tires or the vehicle may be the result.

Further information on tires and rims is available at any authorized Mercedes-Benz Center. The Tire and Loading Information placard with the recommended tire inflation pressures for cold tires is located on the driver's door B-pillar. Supplemental tire inflation pressure information for driving at high speeds or for vehicle loads less than the maximum loaded vehicle condition can be found on the tire inflation pressure label. The tire inflation pressure label is located on the inside of the fuel filler flap. The tire inflation pressure should be checked regularly and should only be adjusted on cold tires. Follow tire manufacturer's maintenance recommendation included with the vehicle.

For information on recommended tire inflation pressure and supplemental tire inflation pressure information for special driving situations, see (> page 183).

- 1 Please keep in mind that the vehicle must be equipped
 - with wheels of identical dimensions on each axle (left and right)
 - with tires of identical characteristics all around, i.e. summer tires, winter tires, all-season tires, or MOExtended tires etc.
- 1 The following pages also list the approved rim and tire sizes for equipping your vehicle with winter tires. Winter tires are not available as standard or optional factory equipment, but can be purchased from an authorized Mercedes-Benz Center.

Equipping your vehicle with winter tires approved for your vehicle model may require the purchase of rims of the recommended size for use with these winter tires. This depends on vehicle model and the standard or optional factory-equipped wheel rim/tire configuration on your vehicle. For more information contact an authorized Mercedes-Benz Center.

Same size tires

■ Winter tires on rims with different wheel offset front vs. rear cannot be rotated.

		CLS 550
18" wheels	Rims (light alloy) Wheel offset (front axle) Wheel offset (rear axle)	8.5 J x 18 H2 1.10 in (28 mm) 0.71 in (18 mm)
	Winter tires ^{20,21}	245/40 R18 97V XL (Extra Load) M+S or 245/40 R18 97V XL (Extra Load) M+S MOExtended ²²

		CLS 550 (AMG Sport Package) CLS 550 (Grand Edition) CLS 63 AMG
18" wheels	AMG rims (light alloy) Wheel offset	8.5 J x 18 H2 0.98 in (25 mm)
	Winter tires ^{20,21}	245/40 R18 97V XL (Extra Load) M+S 🛕

		CLS 63 AMG (Performance Package)	
19" wheels	AMG rims (light alloy)	8.5 J x 19 H2	
	Wheel offset	0.98 in (25 mm)	
	Winter tires ^{20,21,23}	245/35 R19 93V XL (Extra Load) M+S 🛕	

²⁰ Radial-ply tires.

²¹ Not available as factory equipment.

²² Must be used in conjunction with Tire Pressure Monitoring System (U.S. vehicles), tire pressure loss warning system (Canada vehicles), or Advanced Tire Pressure Monitoring System (Canada vehicles) only.

²³ Maximum permissible vehicle speed of 137 mph (220 km/h).

Mixed size tires			
			CLS 550
18" wheels	Front axle	Rims (light alloy) Wheel offset	8.5 J x 18 H2 1.10 in (28 mm)
		Summer tires ^{24,25}	245/40 R18 93Y MOExtended
	Rear axle	Rims (light alloy) Wheel offset	9.5 J x 18 H2 1.30 in (33 mm)
		Summer tires ^{24,25,26}	275/35 R18 95Y MOExtended
			CLS 550 ²⁷
18" wheels	Front axle	Rims (light alloy) Wheel offset	8.5 J x 18 H2 1.10 in (28 mm)
		All-season tires ²⁴	245/40 R18 93V M+S
	Rear axle	Rims (light alloy) Wheel offset	9.5 J x 18 H2 1.30 in (33 mm)
		All-season tires ^{24,26}	275/35 R18 95V M+S
			CLS 550 (AMG Sport Package) ²⁷ CLS 550 (Grand Edition)
18" wheels	Front axle	AMG rims (light alloy)	8.5 J x 18 H2

			CLS 550 (AMG Sport Package) ²⁷ CLS 550 (Grand Edition)
18" wheels	Front axle	AMG rims (light alloy)	8.5 J x 18 H2
		Wheel offset	0.98 in (25 mm)
		Summer tires ²⁴	255/40 ZR18 99Y XL (Extra Load)
	Wheel offset	9.5 J x 18 H2	
		Wheel offset	1.10 in (28 mm)
		Summer tires ^{24,26}	285/35 ZR18 101Y XL (Extra Load)

²⁴ Radial-ply tires.

²⁵ Must be used in conjunction with Tire Pressure Monitoring System (U.S. vehicles), tire pressure loss warning system (Canada vehicles), or Advanced Tire Pressure Monitoring System (Canada vehicles) only.

²⁶ Must not be used with snow chains.

²⁷ USA only.

275/30 R19 96V XL (Extra Load)

M+S

			CLS 550 ²⁸ CLS 63 AMG
19" wheels	Front axle	AMG rims (light alloy)	8.5 J x 19 H2
		Wheel offset	0.98 in (25 mm)
		Summer tires ²⁹	255/35 ZR19 96Y XL (Extra Load)
	Rear axle	AMG rims (light alloy)	9.5 J x 19 H2
		Wheel offset	1.10 in (28 mm)
		Summer tires ^{29,30}	285/30 ZR19 98Y XL (Extra Load)
			CLS 63 AMG (Performance Package)
19" wheels	Front axle	AMG rims (light alloy)	
19" wheels	Front axle	AMG rims (light alloy) Wheel offset	(Performance Package)
19" wheels	Front axle		(Performance Package) 8.5 J x 19 H2
19" wheels	Front axle	Wheel offset	(Performance Package) 8.5 J x 19 H2 0.98 in (25 mm)
19" wheels	Front axle Rear axle	Wheel offset Summer tires ²⁹	(Performance Package) 8.5 J x 19 H2 0.98 in (25 mm) 255/35 ZR19 96Y XL (Extra Load) 245/35 R19 93V XL (Extra Load)
19" wheels		Wheel offset Summer tires ²⁹ Winter tires ^{29,31}	(Performance Package) 8.5 J x 19 H2 0.98 in (25 mm) 255/35 ZR19 96Y XL (Extra Load) 245/35 R19 93V XL (Extra Load) M+S

Winter tires^{29,30,31}

²⁸ Canada only.

²⁹ Radial-ply tires.

³⁰ Must not be used with snow chains.

³¹ Not available as factory equipment.

Spare wheel

- Compare the recommended tire inflation pressure for your vehicle with the tire inflation pressure on the yellow label located on the spare wheel rim.
 - If the tire inflation pressure on the yellow label on the spare wheel rim differs from the values given in this Operator's Manual, inflate the tire to the recommended tire inflation pressure given on the yellow label on the spare wheel rim.
- Please note that the tire inflation pressure of the spare wheel differs from the tire inflation pressure of the road tires.

	CLS 550 (all models)	CLS 63 AMG	CLS 63 AMG (Performance Package)
Rim (steel) Wheel offset	4.0 B x 17 H2 1.34 in (34 mm)	-	_
Rim (light alloy) Wheel offset	_	6.0 B x 18 H2 0.98 in (25 mm)	6.5 B x 19 H2 0.55 in (14 mm)
Minispare tire ³²	T 155/70 R17 110M	_	-
Collapsible tire ³²	_	175/55-18 95P	175/50-19 97P
Recommended tire inflation pressure	61 psi (4.2 bar)	51 psi (3.5 bar)	51 psi (3.5 bar)

Fuels, coolants, lubricants, etc.

Capacities

Vehicle components and their respective lubricants must match. Therefore only use products tested and approved by Mercedes-Benz.

For information on tested and approved products, contact an authorized Mercedes-Benz Center or visit www.mbusa.com (USA only).



/\ Warning!

Comply with all valid regulations with respect to handling, storing, and disposing of service fluids. Otherwise you could endanger persons or the environment.

Keep service fluids out of the reach of children.

For health reasons, you should prevent service fluids from coming into direct contact with your skin or clothing.

If a service fluid is swallowed, contact a physician immediately.

		a !:	
	Model	Capacity	Fuels, coolants, lubricants, etc.
Engine with oil	CLS 550	9.0 US qt (8.5 I)	Approved engine oils
filter	CLS 63 AMG ³³	9.3 US qt (8.8 I)	
Automatic	CLS 550	9.7 US qt (9.2 I)	MB Automatic Transmission Fluid
transmission	CLS 63 AMG	9.3 US qt (8.8 I)	
Rear axle	CLS 550	1.3 US qt (1.2 l)	MB Hypoid Gear Oil (SAE 85W-90)
	CLS 63 AMG	1.3 US qt (1.2 I)	Fuchs Titan EG 5010 D
	CLS 63 AMG ³⁴	1.3 US qt (1.2 l)	Castrol SAF-XJ (SAE 75W-140)
Power steering	CLS 550	approx. 1.0 US qt (0.9 I)	MB Power Steering Fluid (Chevron Texaco PSF 9109)
	CLS 63 AMG	approx. 1.3 US qt (1.2 l)	
Brake system	All models	0.63 US qt (0.6 I)	MB Brake Fluid (DOT 4+)
Cooling system	CLS 550	approx. 11.9 US qt (11.3 l)	MB 325.0
	CLS 63 AMG	approx. 12.5 US qt (11.8 I)	Anticorrosion/ Antifreeze
Fuel tank	All models	21.1 US gal (80.0 I)	Premium unleaded
Fuel tank	CLS 550	approx. 2.4 US gal (9.0 I)	gasoline (Minimum Posted Octane 91 [Avg. of 96 RON/86 MON])
reserve	CLS 63 AMG	approx. 3.7 US gal (14.0 l)	
Air conditioning system	All models	_	R134a refrigerant and special PAG lubricant oil (never R 12)
Washer system	All models	4.8 US qt (4.5 I)	MB Windshield
Washer system and headlamp cleaning system	All models	6.9 US qt (6.5 I)	Washer Concentrate ³⁵ (▷ page 302) Washer fluid mixing ratio (▷ page 302)

³³ Engine with oil cooler.

³⁴ With Performance Package.

 $^{^{35}}$ Mixed with water or commercially available premixed washer solvent/antifreeze.

Approved engine oils

Engine oils are specifically tested for their suitability in our engines and durability for our service intervals. Therefore, only use approved engine oils and oil filters required for vehicles with the Maintenance System. For a listing of approved engine oils and oil filters, contact an authorized Mercedes-Benz

Center or visit www.mbusa.com (USA only).

Using engine oils and oil filters of a specification other than those expressly required for the Maintenance System, or changing of oil and oil filter at change intervals longer than those called for by the Maintenance System will result in engine or emission control system damage not covered by the Mercedes-Benz Limited Warranty.

Please follow Maintenance System recommendations for scheduled oil changes. Failure to do so will result in engine or emission control system damage not covered by the Mercedes-Benz Limited Warranty.


Mercedes-Benz recommends MOBIL OIL. Use the table below to determine the MB sheet number.

Model	Engine, type	MB sheet number
CLS 550	273	229.5
CLS 63 AMG	156	229.5 ³⁶

MB sheet numbers are printed on the outside of oil containers.

Viscosity grades for engine oils

Using the chart below, select oil viscosity according to the lowest air temperature expected before the next oil change.



Engine oil additives

Do not blend oil additives with engine oil. They may damage the engine. Damage or malfunctions resulting from blending oil additives are not covered by the Mercedes-Benz Limited Warranty.

Air conditioning refrigerant

R134a (HFC) refrigerant and special PAG lubricating oil are used in the air conditioning system.

Never use R 12 (CFC) or mineral-based lubricating oil. Otherwise damage to the system will occur.

Brake fluid



During vehicle operation, the boiling point of the brake fluid is continuously reduced through the absorption of moisture from the atmosphere.

Under extremely strenuous operating conditions, this moisture content can lead to the formation of bubbles in the system, thus reducing the system's efficiency.

Therefore, the brake fluid must be replaced regularly. Refer to your vehicle's Maintenance Booklet for replacement interval.

Only brake fluid approved by Mercedes-Benz is recommended. Any authorized Mercedes-Benz Center will provide you with additional information.

Premium unleaded gasoline

Marning!

Gasoline is highly flammable and poisonous. It burns violently and can cause serious personal injury.

Never allow sparks, flames or smoking materials near gasoline!

Turn off the engine before refueling.

Whenever you are around gasoline, avoid inhaling fumes and any skin or clothing contact. Extinguish all smoking materials.

Direct skin contact with fuels and the inhalation of fuel vapors are damaging your health.

I To maintain the engine's durability and performance, premium unleaded gasoline must be used.

If premium unleaded gasoline is not available and low octane gasoline is used, follow these precautions:

- Have the fuel tank only partially filled with unleaded regular gasoline and fill up with premium unleaded gasoline as soon as possible.
- Avoid full throttle driving and abrupt acceleration.
- · Do not exceed an engine speed of 3000 rpm if the vehicle is loaded with a

- light load such as two persons and no luggage.
- Do not exceed ²/₃ of maximum accelerator pedal position if the vehicle is fully loaded or operating in mountainous terrain.

Fuel requirements

Only use premium unleaded gasoline. The octane number (posted at the pump) must be 91 min. It is an average of both the Research Octane Number (RON) and the Motor Octane Number (MON): (RON+MON)/2. This is also known as the ANTI-KNOCK INDEX.

Reformulated gasolines (RFG) and/or unleaded gasoline containing oxygenates such as ethanol, TAME, ETBE, IPA, IBA, and TBA can be used provided the ratio of any one of these oxygenates to gasoline does not exceed 10%; MTBE must not exceed 15%.

The ratio of methanol to gasoline must not exceed 3% plus additional cosolvents.

Using mixtures of ethanol and methanol is not allowed. Gasohol, which contains 10% ethanol and 90% unleaded gasoline, can be used.

These blends must also meet all other fuel requirements, such as resistance to spark knock, boiling range, vapor pressure, etc.

Gasoline additives

A major concern among engine manufacturers is carbon build-up caused by gasoline. Mercedes-Benz recommends only the use of quality gasoline containing additives that prevent the build-up of carbon deposits.

After an extended period of using fuels without such additives carbon deposits can build up, especially on the intake valves and in the combustion area, leading to engine performance problems such as:

- · Warm-up hesitation
- Unstable idle
- · Knocking/pinging
- Misfire
- Power loss

In areas where carbon deposits may be encountered due to lack of availability of gasoline which contains these additives, the use of Mercedes-Benz approved additives is recommended.

Contact an authorized Mercedes-Benz Center or visit **www.mbusa.com** (USA only) for a listing of approved products. Follow directions on the product label.

Do not blend other fuel additives with fuel. This only results in unnecessary cost and may be harmful to the engine operation.

Damage or malfunction resulting from poor fuel quality or from blending additional fuel additives other than those tested and approved by us for use on Mercedes-Benz vehicles are not covered by the Mercedes-Benz Limited Warranty or by any pre-owned or Extended Limited Warranties.

Coolants

The engine coolant is a mixture of water and anticorrosion/antifreeze, which provides:

- Corrosion protection
- Freeze protection
- Boiling protection (by increasing the boiling point)

The cooling system was filled at the factory with a coolant providing freeze protection to approximately -35°F (-37°C) and corrosion protection.

Add premixed coolant solution only.

Adding water and MB 325.0 Anticorrosion/
Antifreeze separately from each other,
could cause engine damage not covered by
the Mercedes-Benz Limited Warranty.

If the antifreeze mixture is effective to -35°F (-37°C), the boiling point of the coolant in the pressurized cooling system is reached at approximately 266°F (130°C).

The coolant solution must be used year round to provide the necessary corrosion protection and increase boil-over protection. Refer to the Maintenance Booklet for replacement interval.

Coolant system design and coolant used determine the replacement interval. The replacement interval published in the Maintenance Booklet is only applicable if MB 325.0 Anticorrosion/Antifreeze solution or other Mercedes-Benz approved products of equal specification are used to renew the coolant concentration or bring it back up to the proper level.

For information on other Mercedes-Benz approved products of equal specification, contact an authorized Mercedes-Benz Center or visit **www.mbusa.com** (USA only).

To provide important corrosion protection, the solution must be at least 50% anticorrosion/antifreeze (equivalent to freeze protection to approximately -35°F [-37°C]).

If you use a solution that is more than 55% anticorrosion/antifreeze (freeze protection to approximately -49°F [-45°C]), the engine temperature will increase due to the lower heat transfer capability of the solution. Therefore, do not use more than this amount of anticorrosion/antifreeze.

If the coolant level is low, water and MB 325.0 Anticorrosion/Antifreeze should be used to bring it up to the proper level (have cooling system checked for signs of leakage). Please make sure the mixture is in accordance with label instructions.

The water in the cooling system must meet minimum requirements, which are usually satisfied by normal drinking water.

If you are not sure about the water quality, contact an authorized Mercedes-Benz Center.

Anticorrosion/antifreeze

Your vehicle contains a number of aluminum parts. The use of aluminum components in motor vehicle engines necessitates that anticorrosion/antifreeze coolant used in such engines be specifically formulated to protect the aluminum parts. Failure to use such anticorrosion/antifreeze coolant will result in a significantly shortened service life.

Therefore, the following product is strongly recommended for use in your vehicle: MB 325.0 Anticorrosion/Antifreeze agent.

Before the start of the winter season (or once a year in hot southern regions), you should have the anticorrosion/antifreeze concentration checked.

The coolant is also regularly checked each time you bring your vehicle to an authorized Mercedes-Benz Center for service.

	Model	Approximate freeze protection	
		-35°F (-37°C)	-49°F (-45°C)
Cooling system	CLS 550	6.0 US qt (5.65 I)	6.6 US qt (6.2 I)
	CLS 63 AMG	6.2 US qt (5.9 I)	6.9 US qt (6.5 I)

Washer system and headlamp cleaning system



Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/ antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned.

- ▶ Use MB Windshield Washer Concentrate "MB SummerFit".
- ► Mix with water for temperatures above freezing point.
- ▶ Mix with commercially available premixed washer solvent/antifreeze for temperatures below freezing point.

Washer fluid mixing ratio

For temperatures above the freezing point: 1 part "MB SummerFit" to 100 parts water (1.34 fl oz [40 ml] "MB SummerFit" to 1 gal [4.0 I] water)

For temperatures below freezing point: 1 part "MB SummerFit" to 100 parts solvent (1.34 fl oz [40 ml] "MB SummerFit" to 1 gal [4.0 I] solvent)

Service and Literature

Your authorized Mercedes-Benz Center has trained technicians and Genuine Mercedes-Benz Parts to service your vehicle properly. For expert advice and quality service, contact an authorized Mercedes-Benz Center.

If you are interested in obtaining service literature for your vehicle, please contact an authorized Mercedes-Benz Center.

We consider this the best way for you to obtain accurate information for your vehicle.

For further information you can find us on the Mercedes-Benz web site www.mbusa.com (USA only) or www.mercedes-benz.ca (Canada only).



↑ Warning!

To help avoid personal injury, be extremely careful when performing any service work or repairs. Improper or incomplete service or the use of incorrect or inappropriate parts or materials may damage the vehicle or its equipment, which may in turn result in personal injury.

If you have any questions about carrying out any type of service, turn to the advice of an authorized Mercedes-Benz Center.

We reserve the right to make changes in design and equipment.

Therefore, information, illustrations and descriptions in this Operator's Manual might differ from your vehicle.

Reprinting, translation and copying, even of excerpts, is not permitted without our prior authorization in writing.

Press time May 13, 2009 GSP/OIS Printed in U.S.A.



Order no. 6515 1451 13 Part no. 219 584 81 83 Edition A 2010