

GLC Brief overview

Mercedes-Benz

Cockpit overview



MARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Cockpit overview

(1)	MBUX	Main functions		
	TEL	Calls up telephone		
	NAVI MAP	Calls up navigation		
	RADIO MEDIA	Calls up radio or media		
	2	Calls up vehicle functions (e.g. assistance systems)		
	\star	Favorites button		
		Press and hold: adds a favorite		
		Hazard warning lights		
(12)	MBUX multimedia system touchpad			
	►	Back button		
		Press: audio control menu Swipe: next/previous track or radio station		
		Displays Home screen		
(13)	Buttons on the right of the touchpad			
	VOLUME	Adjusts the volume		
	₫ /७	Press briefly: mute function Press and hold: switches off the MBUX multimedia system		
	P	Active Parking Assist		

(14) Buttons on the left of the touchpad


- ▼▲ DYNAMIC SELECT
- Vehicle level (0±0)
- Manual gearshifting Μ
- ECO start/stop function A
 - 1 The ECO start/stop function cannot be permanently deactivated.
- (5) Start/stop button for starting/stopping the engine
- (P) Electric parking brake (16)
- তpens or closes the trunk lid (17)
- (18) Door control panel with controls for power windows, exterior mirror settings and the override feature for the rear side windows
 - 1 If the front passenger mirror is selected and you engage reverse gear, the front passenger mirror moves into the stored parking position.



Overhead control panel

- ① Buttons for interior lighting and reading lights
- Button for Mercedes me connect* 2
- esos SOS button* 3
 - (Mercedes-Benz emergency call system) Opens/closes the sliding sunroof
- (4) Roller sunblind

* Not available in all countries




Wipes the windshield once 1 Wipes with washer fluid

- (2) Sets windshield wipers Off, normal/frequent interval, slow/fast continuous wiping
- Rear window wiper (3)

हिंह ESP[®] OFF

- Turn signal, left/right 4
- Headlamp flasher 5
- Adaptive Highbeam Assist Plus 6
- Switches the steering wheel heating on/off \bigcirc
- (8) Adjusts the steering wheel



Active Distance Assist DISTRONIC

- 1 Activates or deactivates Active Distance Assist DISTRONIC
- ③ SET+ Active Distance Assist Activates DISTRONIC/limiter with current SET- Action speed
- (4) MRES Activates with the stored speed/pulls away with Active Distance Assist DISTRONIC
 - **CNCL** Deactivates Active Distance Assist DISTRONIC/limiter

Changing the speed/distance

2	/_/	Reduces the specified minimum distance
		Increases the specified minimum distance
3	SET+	Increases the speed
	SET-	Decreases the speed

Active Distance Assist DISTRONIC maintains a constant speed which has been stored. The lowest speed that can be set is 12 mph (20 km/h).

You can change the set speed:

- 1 mph increment (1 km/h): Briefly press rocker switch (3) up or down.
- 5 mph increment (10 km/h): Press rocker switch ③ up or down past the point of resistance.

Using rocker switch 2, you can change the specified minimum distance to the vehicle in front. The specified minimum distance depends on the currently driven speed.

MARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Climate control



Operating possibilities

You can adjust climate control using the button climate control panel (1).

If you change any settings, media display (2) br shows the current settings of the climate contr system.

Air conditioning control panel			
		Sets the temperature	
	فتر ْ	Sets the air distribution	
	GO OFF	Sets the air flow, switches automatic climate control off completely	
	AUTO	Sets climate control to automatic mode	
	MAX	Defrosts the windshield	
1	MENU	Calls up the air conditioning menu	
V_{-}		If you press and hold the $\frac{\text{MENU}}{\text{ResT}}$ button for approximately 4 seconds, automatic	
is on		climate control will be reset to the basic settings.	
riefly		Residual heat with the engine off	
rol	tttREAR	Defrosts the rear window	
	SYNC	Synchronized operation	

anditioning control n

- Air-recirculation mode
- The air in the interior is recirculated; the windows may fog up more quickly.
- A/C Cooling with air dehumidification

General notes

Optimum operation of the climate control system is only achieved when the side windows and the roof are closed. To prevent the windows from fogging up, please observe the following information:

- Switch on the cooling function. A/C In warm weather, the air inside the vehicle will be cooled. This function also dries the air inside the vehicle.
- As far as possible, do not switch off climate control
- <u></u> W MAX
- Switch on air-recirculation mode only briefly If necessary, briefly switch on the windshield defroster function
- Note that your vehicle may not be equipped with all of the features described.

Buttons on the multifunction steering wheel



Operating the multifunction display

- () Sack/Home button Press and hold: shows the standard display (speedometer, trip meter and rev counter)
- Touch Control for the multifunction display Press: confirms your selection
- **Operating the MBUX multimedia system**
- G Home screen 3
- Touch Control for the MBUX multimedia 4 system
 - Press: confirms your selection
- 5 5 Back button Ends a dialog with the Voice Control System

6	Accepts a telephone call		
	Rejects a telephone call Ends a call		
	Ends a dialog with the Voice Control System		
7	VOL Adjusts the volume		
	Press: switches sound on or off		
8	ार्ट्स Starts a dialog with the Voice Control System		
	Press and hold: activates the voice control system of the mobile end device currently connected		

★ Displays favorites



Adjusting the multifunction display

Content ④ can be freely selected.

- Swipe Touch Control (2) to the left or right to wipe.
 - The selected area will be highlighted.
- Swipe Touch Control ② up or down in order to select the desired display content.


The index points (6) show the selected display content

Operating the menu bar

- Content (5) can be set using menu bar (3).
- To call up the menu bar: press button (1)
- If you press and hold button (1), the standard 0 display of the multifunction display is shown.
- To select content: swipe Touch Control (2) to the left or right and press to confirm the menu.

MARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Head-up Display and MBUX Interior Assistant





MBUX Interior Assistant

The MBUX Interior Assistant recognizes certain hand movements and gestures made between the Media Display and the center console, including those made on the touchpad. For example, you can switch the reading light on/off by using the back of the hand to briefly touch the rear view mirror. Further control functions:

- Operation of functions by moving the hand closer to the touchscreen or touchpad, e.g. adjusting seat settings.
- Calling up a previously stored favorite with a hand movement.

MBUX multimedia system Home screen



- Main applications
- (2) Quick-access (e.g. direct destination entry or navigating home)
- Global search (3) (search for functions in the system, e.g. Music or Navigation, as well as those external to the system, e.g. Internet)
- Creates, modifies and switches profiles (4)You can, for example, store the seat and steering wheel position, multifunction display contents, ambient lighting settings, favorites and personalized suggestions.
- (5) Calls up the notification center
- Number of applications and the currently 6 selected display area

Note that your vehicle may not be equipped with all of the features described.

- (7) Calls up the air conditioning menu
- (8) Calls up favorites/suggestions and themes

Favorites

Almost every function can be stored as a favorite. Quick-access occurs using favorites button 😿 on the steering wheel or on the touchpad.

Suggestions

The system learns the habits of the driver. Using artificial intelligence, for example, places which are visited regularly, numbers which are called regularly or favorite music styles are stored as suggestions in the profile and can be called up more quickly.

Themes

Via a set of themes pre-configured ex-factory, a number of settings, e.g. display content, music stations, drive program, ambient lighting, can be stored simultaneously

You can create new themes yourself.

MARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Starting a dialog

For the dialog with the Voice Control System, you can use complete sentences as voice commands.

Activation with a keyword: Say "Hi Mercedes" and combine it with a voice command or a question.

or

Activation using the rocker switch on the multifunction steering wheel: Press up and after the acoustic signal say a voice command or a question.

Help functions

- **Optimum operation:** Say the "Help Voice Control System" voice command.
- Help for the current function:
- Say the "Help" voice command during the dialog. Help for a specific system:
- Say the voice command for the desired system, e.g. "Help telephone".

You can change the language via the system language settings. If the Voice Control System does not support the set system language, English is selected.

Selected examples

Navigation voice commands

- "Navigate to 25 Woodward Avenue, Detroit" Starts route guidance to an address. The order of the road, town or building number is irrelevant.
- "Navigate to John Doe" Starts route guidance to a contact from your address book.
- "Show alternative routes"
- The navigation shows alternative routes for route guidance.
- "Navigate to nearest gas station" Starts route guidance to the nearest gas station.

Telephone voice commands

- "Call John Doe'
- The telephone number of a stored contact is dialed.
- "Read out new text messages"
- All new text messages will be read out. "Call my father on his cell number. The telephone number of the contact "Father cell" will be called.

Media/radio voice commands

- "Switch to station Z100" If you are listening to the radio, you can say the name of a station to which you would like to listen
- "Play Bob Dylan"

The system searches through the names of all available albums, tracks, artists, music genres and playlists. If the result is unambiguous, playback starts immediately.

Vehicle voice commands

- "Open the Assistance menu" "Temperature to 72 °F (22 °C)"
- "When is the next service due?
- "Front passenger reading light on" "Ambient lighting to blue
- "Head-up Display on/off"

Online voice commands

- To use this feature, you must have a connection to the Internet.
- "What will the weather be like tomorrow in Nashville?"
- "Is it raining at my destination?"

Note that your vehicle may not be equipped with all features described.

Bluetooth[®] connection and external media sources



- Changing mobile phones 1
- Device manager

Connecting a mobile phone

Requirements:

Bluetooth[®] is switched on on the mobile phone and the device is visible for other devices (see the manufacturer's operating instructions).

On the MBUX multimedia system, select 🔝 > Phone ▶ 🔋 .

Searching for a mobile phone

Select Connect New Device.

Select the desired mobile phone. If your mobile phone is not found, try searching on the mobile phone itself.

Authorizing a mobile phone


A code is displayed in the multimedia system and on the mobile phone.

If the codes match: confirm the code on the mobile phone.

Further information

Detailed information on Bluetooth[®] connections with your mobile phone can be found at: www.mercedes-benz.com/connect





Connecting external media sources

1	∙←	USB cor
2		

nnection (type C) nnection for Apple CarPlay™ or Android Auto™

Depending on the vehicle equipment, there are further USB ports in the stowage compartment in the front center console or in the rear folding compartment.

MARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Further information on your vehicle



HANDS-FREE ACCESS

If you carry the KEYLESS-GO key on your person, you will be detected by a sensor Do not touch the bumper and maintain a distance of around 12 in (30 cm).

- To open or close: kick into the center of the sensor detection range under the bumper with your foot.
- The kicking movement must be towards the vehicle and back again, and it must not be A carried out too slowly.



Deactivating the KEYLESS-GO key function If you wish to reduce the energy consumption of the key, you can deactivate the KEYLESS-GO function.

- To deactivate: press twice in succession on
- button (1). The battery check lamp of the key
- lights up twice briefly and once for a longer period.
- To activate: press any button on the key.

Further information

Further information about Mercedes-Benz vehicles and about Daimler AG can be found on the following website:

http://www.mbusa.com

Mercedes-Benz Guides app

The Mercedes-Benz Guides app contains the complete Operator's Manual and is available free-of-charge in the familiar app stores.





How-To Videos

Registering in the Mercedes me portal

Register in the Mercedes me portal in order to be able to use the full scope of your vehicle's functions.



