

## >> Quick Guide.

smart fortwo coupé and smart fortwo cabriolet



## Let the fun begin

---

This Quick Guide will quickly and efficiently inform you about the most important functions of your vehicle. It does not, however, in any way, replace the Operator's Manual.

This is especially significant with regard to warnings and cautions. This Quick Guide should only be used as a reference.

Therefore it is imperative that you read the Operator's Manual carefully and completely before your first drive, paying special attention to the chapter "Safety". Doing so will help you obtain the maximum pleasure from your vehicle and avoid endangering yourself and others.

Items of optional equipment are marked with an asterisk \*. The equipment in your vehicle may vary, depending on the model and availability.

smart is constantly updating its vehicles to the very latest state of the art and therefore reserves the right to introduce changes in design, equipment and technical features at any time. You cannot, therefore, base any claims on the data, illustrations or descriptions in this Quick Guide.

The Operator's Manual, Quick Guide and Maintenance/Warranty Booklet (USA only) or Service/Warranty Booklet (Canada only) belong to the vehicle. You should always keep these documents in the vehicle and make sure that you pass them on to the next owner if and when you come to sell your smart.

Please contact an authorized smart center if you have any further questions.

The Technical Documentation team at Daimler wishes you many happy hours at the wheel.

### **Warning!**

Various warning stickers are affixed to your vehicle. Their purpose is to draw your attention, and the attention of others, to

various dangers. Therefore, do not remove any warning stickers unless the sticker clearly states that you may do so. If you remove the warning stickers, you or others could be injured by failing to recognize certain dangers.

## Symbols

---

Trademarks®:


- ESP® is a registered trademark of Daimler.

\* Optional equipment

### **Warning!**

Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

 Highlights hazards that may result in damage to your vehicle.

 Helpful hints or further information you may find useful.

► This symbol points to instructions for you to follow.

► A number of these symbols appearing in succession indicates a multiple-step procedure.


▷▷ This continuation symbol marks a warning or procedure which is continued on the next page.

<b>At a glance</b> .....	<b>2</b>	Starting .....	14
Cockpit .....	2	Parking .....	15
Steering wheel gearshift control .....	3		
Instrument cluster (miles) .....	4	<b>Operation</b> .....	<b>16</b>
Instrument cluster (kilometers) .....	6	At the gas station .....	16
Upper center console .....	8	Refueling .....	16
Lower center console .....	8	Service flap .....	16
Overhead control panel .....	9		
Door control panel .....	9	<b>Practical hints</b> .....	<b>17</b>
		Where will I find ...? .....	17
<b>Getting started</b> .....	<b>10</b>	First-aid kit* .....	17
Opening and closing .....	10		
Key .....	10		
Opening the upper tailgate on the coupé .....	10		
Opening the lower tailgate on the coupé .....	10		
Closing the tailgate(s) on the coupé .....	10		
Opening the tailgate on the cabriolet .....	10		
Opening and closing the rear soft top (cabriolet only) .....	11		
Starter switch positions .....	11		
Seats .....	11		
Mirrors .....	11		
Exterior rear view mirrors .....	11		
Interior rear view mirror .....	12		
Fastening the seat belts .....	12		
Lighting .....	13		
Low-beam headlamps .....	13		
Combination switch (high beam, high-beam flasher and turn signals) . .	13		
High beam and high-beam flasher .....	13		
Turn signals .....	13		
Windshield wipers .....	14		
Switching windshield wipers on and off .....	14		
Wiping with windshield washer fluid .....	14		
Rear window wiper/washer (coupé only) .....	14		
Driving and parking .....	14		



## Cockpit

&gt;&gt; At a glance.



P68.10-4075-31

	Function
①	Exterior lamp switch: Low beam Turn signals High beam
②	Steering wheel <sup>1</sup>
③	Instrument cluster: Miles Kilometers
④	Wiper switch: Windshield wipers Rear window wiper <sup>2</sup>
⑤	Tachometer*
⑥	Cockpit clock*
⑦	Overhead control panel
⑧	Upper center console

	Function
⑨	Glove box
⑩	smart MP3 interface* (AUX-socket*)
⑪	Gear selector lever
⑫	Starter switch
⑬	Coin holder Retractable soft top switch <sup>3</sup>
⑭	Cup holder
⑮	Horn
⑯	On-board Diagnostics Socket (OBD)
⑰	Door control panel
⑱	Inside door handle

<sup>1</sup> Model pure only: The steering wheel in this vehicle varies from steering wheel illustrated.


<sup>2</sup> coupé only.

<sup>3</sup> cabriolet only.

**Risk of injury**

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.

Steering wheel gearshift control




P46.10-3055-31

	Function
①	Left shift paddle <sup>4</sup> : Downshift
②	Multifunction display
③	Right shift paddle <sup>4</sup> : Upshift

**i** Model pure only:  
The steering wheel in this vehicle varies from steering wheel illustrated.


>> At a glance.

<sup>4</sup> Model passion and BRABUS only.











 **Risk of injury**





Make sure that you read the detailed Operator’s Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.


Instrument cluster (miles)



Instrument cluster (U.S. vehicles)

	Function
①	Selecting display for status indicator Setting digital clock
②	Left indicator lamp display with: <ul style="list-style-type: none"> <li> Low-beam headlamp indicator lamp</li> <li> High-beam headlamp indicator lamp</li> <li> Combination low tire pressure/TPMS malfunction telltale*</li> <li> Seat belt telltale</li> <li> SRS indicator lamp</li> </ul>
③	 Left turn signal indicator lamp
④	 ESP® warning lamp
⑤	 Right turn signal indicator lamp
⑥	Speedometer
⑦	Right indicator lamp display with: <ul style="list-style-type: none"> <li> EPS* warning lamp</li> <li> Engine malfunction indicator lamp</li> <li><b>ABS</b> ABS indicator lamp</li> <li><b>BRAKE</b> Brake warning lamp</li> </ul>


	Function
⑧	Adjusting instrument cluster illumination Setting digital clock
⑨	Right center indicator lamp display with: <ul style="list-style-type: none"> <li> Engine oil pressure indicator lamp</li> <li> Coolant temperature warning lamp</li> </ul>
⑩	Multifunction display
⑪	Left center indicator lamp display with: <ul style="list-style-type: none"> <li> Battery indicator lamp</li> <li> Fuel cap indicator lamp</li> </ul>



**Risk of injury**

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.

## Instrument cluster (kilometers)



















Instrument cluster (Canada vehicles)


**Risk of injury**

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.



	Function
①	Selecting display for status indicator Setting digital clock
②	Left indicator lamp display with: <ul style="list-style-type: none"> <li> Low-beam headlamp indicator lamp</li> <li> High-beam headlamp indicator lamp</li> <li> Combination low tire pressure/TPMS malfunction telltale*</li> <li> Seat belt telltale</li> <li> SRS indicator lamp</li> </ul>
③	 Left turn signal indicator lamp
④	 ESP® warning lamp
⑤	 Right turn signal indicator lamp
⑥	Speedometer
⑦	Right indicator lamp display with: <ul style="list-style-type: none"> <li> EPS* warning lamp</li> <li> Engine malfunction indicator lamp</li> <li> ABS indicator lamp</li> <li> Brake warning lamp</li> </ul>
⑧	Adjusting instrument cluster illumination Setting digital clock


	Function
⑨	Right center indicator lamp display with: <ul style="list-style-type: none"> <li> Engine oil pressure indicator lamp</li> <li> Coolant temperature warning lamp</li> </ul>
⑩	Multifunction display
⑪	Left center indicator lamp display with: <ul style="list-style-type: none"> <li> Battery indicator lamp</li> <li> Fuel cap indicator lamp</li> </ul>



**Risk of injury**

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.


## Upper center console



P68.20-4090-31

	Function
①	Tachometer*
②	Cockpit clock*
③	HVAC
④	Audio system*
⑤	Hazard warning flasher switch
⑥	Switching tow-away protection*/ interior motion sensor* on/off
⑦	Switching seat heating* on/off, passenger side
⑧	Restarting TPMS button
⑨	Central unlocking switch
⑩	Central locking switch
⑪	Switching front fog lamps* on/off
⑫	Switching seat heating* on/off, driver's side

## Lower center console




P68.20-4091-31

	Function
①	Auxiliary power outlet
②	Gear selector lever
③	Starter switch
④	Parking brake lever
⑤	Coin holder Retractable soft top switch <sup>5</sup>

<sup>5</sup> cabriolet only.**Risk of injury**


Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.

## Overhead control panel



	Function
①	Passenger front air bag off indicator lamp
②	Switching interior lighting on/off
③	Interior rear view mirror

## Door control panel



	Function
①	Inside door handle
②	Adjusting exterior rear view mirrors: Manually Electrically <sup>6</sup>
③	Opening and closing right side window: Manually Electrically <sup>6</sup>
④	Opening and closing left side window: Manually Electrically <sup>6</sup>

<sup>6</sup> Model passion and BRABUS only.




## Risk of injury

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.

## Opening and closing

## Key



Key with remote control

- ① Lock button
- ② Opening the retractable soft top<sup>7</sup>/  
unlocking the upper tailgate<sup>8</sup>
- ③ Unlock button

## Opening the upper tailgate on the coupé



- ① Release handle in handle recess

## Opening the lower tailgate on the coupé



- ① Release levers

## Closing the tailgate(s) on the coupé



## Opening the tailgate on the cabriolet



<sup>7</sup> cabriolet only.

<sup>8</sup> coupé only.



## Risk of injury

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.


- ▶ Press button ① on the key twice.
- ▶ Pull the release handle in handle recess ① of the tailgate.  
The tailgate is unlocked.
- ▶ Swivel the tailgate downwards to open.

### Opening and closing the rear soft top (cabriolet only)



- ① Release levers


### Starter switch positions



Starter switch

- |   |   |
|---|---|
| 0 | For removing key  |
| 1 | Ignition (power supply for all electrical consumers) and driving position |
| 2 | Starting  |

### Seats




- ① Seat backrest tilt
- ② Seat fore and aft adjustment

### Mirrors

#### Exterior rear view mirrors


#### Manually adjustable exterior rear view mirrors



- ① Adjustment lever


#### Power exterior rear view mirrors

This feature is only available on the model passion and BRABUS.




**Risk of injury**

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others. >>>




- ① Knob for selecting the mirror
- ② Adjustment button

#### Interior rear view mirror



- ① Lever for selecting antiglare position

#### Fastening the seat belts



- ① Seat belt outlet
- ② Seat belt guide
- ③ Seat belt buckle
- ④ Release button
- ⑤ Latch plate




#### Risk of injury

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.


## Lighting

## Low-beam headlamps



Exterior lamp switch (USA only)

- 0 Lamps off
- Low-beam headlamps or high-beam headlamps




Exterior lamp switch (Canada only)

- 0 Lamps off
- Daytime running lamp mode
- Low-beam headlamps or high-beam headlamps

► **Switching on:** Turn the exterior lamp switch to position .

## Combination switch (high beam, high-beam flasher and turn signals)


## High beam and high-beam flasher



Combination switch


- 1 High beam
- 2 High-beam flasher

## Turn signals



Combination switch

- 1 Turn signals, right
- 2 Turn signals, left



**Risk of injury**


Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.



>> Getting started.

Windshield wipers


Switching windshield wipers on and off



Wiper switch

- 0 Windshield wipers off
- 1 Intermittent wiping
- 2 Slow continuous wiping
- 3 Fast continuous wiping


Wiping with windshield washer fluid



Wiper switch

- 1 Wiping with windshield washer fluid

Rear window wiper/washer (coupé only)




Wiper switch

- 0 Deactivating intermittent wiping
- 1 Rear window intermittent wiping
- 2 Wiping rear window with windshield washer fluid

Driving and parking

Starting





Gearshift pattern for transmission

- 1 Release button


P	Park position
R	Reverse gear
N	Neutral position
D	Drive position
M	Manual gear shifting



	Upshifting
	Downshifting

- ▶ Make sure the gear selector lever is set to park position **P**.  
The transmission position indicator should be on **P**.
- ▶ Do not depress the accelerator pedal.
- ▶ Turn the key to starter switch position **2** and release it again immediately.  
The engine starts automatically ("touch-start" function).

### Parking



- ① Parking brake lever
- ② Release button




#### Risk of injury

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.


## At the gas station

## Refueling



- ① Opening the fuel filler flap
- ② Inserting the fuel filler cap
- ③ Fuel filler cap
- ④ Fuel type label
- ⑤ Holder

## Service flap



- ① Lever
- ② Service flap




## Risk of injury

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.

## Where will I find ...?

## First-aid kit\*



① First-aid kit

**Risk of injury**

Make sure that you read the detailed Operator's Manual. You could otherwise fail to recognize dangers, which could result in injury to yourself and/or others.







## Service and Literature

---

Your authorized smart center has trained technicians and Genuine smart Parts to service your vehicle properly.

For expert advice and quality service, contact an authorized smart center.

For further information you can find us on the smart web-site **www.smartusa.com** (USA only) or **www.thesmart.ca** (Canada only).

### **Warning!**

To help avoid personal injury, be extremely careful when performing any service work or repairs. Improper or incomplete service or the use of incorrect or inappropriate parts or materials may damage the vehicle or its equipment, which may in turn result in personal injury.

If you have any questions about carrying out any type of service, turn to the advice of an authorized smart center.

We reserve the right to make changes in design and equipment.

Therefore, information, illustrations and descriptions in this Quick Guide might differ from your vehicle.

Reprinting, translation and copying, even of excerpts, is not permitted without our prior authorization in writing.

Press time July 27, 2009

GSP/OIS

Printed in Germany

