




GLE

Brief overview

Mercedes-Benz



Cockpit – overview



- 1 **Door handle**
 - Locks the vehicle centrally
 - Unlocks the vehicle centrally
- 2 **Seat functions**
 - Adjusts the seat electrically
 - Memory function and presets
 - 1 2 3
- 3 Light switch
- 4 Steering wheel paddle shifters
- 5 Multifunction steering wheel buttons
- 6 DIRECT SELECT selector lever
- 7 Multimedia system display
- 8 Multimedia system

WARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Cockpit – overview

- 9 **Upper control panel**
 - Seat heater
 - Seat ventilation
 - ESP® OFF
 - Hazard warning lights
 - ECO start/stop function
 - Parking Assist PARKTRONIC
- 10 Automatic climate control
- 11 **Control panel for driving functions**
 - Selector wheel for level control
 - Driving status menu
 - LOW RANGE off-road gear
 - DSR (Downhill Speed Regulation)
 - Manual shifting

- 12 **DYNAMIC SELECT CONTROLLER**
 - Individual setting
 - Sporty driving manner
 - Comfort and consumption-oriented
 - Slippery or snow-covered roads
 - Offroad (easily negotiable off-road terrain)
 - Offroad Plus (rough off-road terrain)
- 13 **Multimedia system controller and touchpad**
 - Back button
 - Favorites button
- 14 Electric parking brake
- 15 Opens or closes the trunk lid
- 16 Door control panel with controls for power windows, exterior mirror settings and the override feature for the rear side windows




- Overhead control panel**
- 1 Sliding sunroof
Roller sunblind
- 2 Buttons for interior lighting and reading light
- 3 Info call* (mbrace system)
E.g. for questions on vehicle operation.
- 4 SOS button* (mbrace system)
- 5 Breakdown assistance call* (mbrace system)


* Not available in all countries

Note that your vehicle may not be equipped with all features described.

Lever on the steering wheel



- Overview**
- 1 Combination switch for turn signals, high-beam headlamps and windshield wipers
- 2 Lever for electrical steering wheel adjustment
- 3 Lever for cruise control/Distance Pilot DISTRONIC



- Combination switch – windshield wiper functions**
- 1 Single wipe
- Wipes the windshield using washer fluid
- 1 0 Windshield wipers off
- 2 ... Intermittent wiping, normal
- 3 Intermittent wiping, frequent
- 4 — Continuous wiping, slow
- 5 == Continuous wiping, fast
- 2 Operates the rear window wiper



- Combination switch – lighting functions**
- 1 High-beam headlamps or Adaptive Highbeam Assist Plus
- 2 Turn signal, right
- 3 High-beam flasher
- 4 Turn signal, left

WARNING Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Distance Pilot DISTRONIC



- Activating/deactivating**
- 1 Switches on with the current speed or calls up the last set speed
- 2 Deactivates Distance Pilot DISTRONIC

- Changing the speed**
- 3 Increases the speed or stores the current speed
- 4 Decreases the speed or stores the current speed
- 5 Increases the specified minimum distance
- 6 Reduces the specified minimum distance

Distance Pilot DISTRONIC maintains a constant speed which has been stored. The lowest speed that can be set is 20 mph (30 km/h). You can change the set speed:

- 1 mph (1 km/h) step:** Briefly press the lever up or down.
- 5 mph (10 km/h) step:** Press the lever up or down past the pressure point.

When Distance Pilot DISTRONIC is activated, one or two segments in the set speed range light up in the speedometer. Using the controller on the DISTRONIC lever, you can change the specified minimum distance to the vehicle in front. The specified minimum distance depends on the currently driven speed.

Note that your vehicle may not be equipped with all features described.

Climate control



- Adjusting automatic climate control**
- You can adjust automatic climate control using the buttons on control panel 1.
- If you change any settings, the lower edge of display 2 briefly shows the current settings of automatic climate control.

- Automatic climate control panel**
- MAX Defrosts the windshield
- ZONE Sets climate zones separately
- A/C Activates or deactivates the cooling function of automatic climate control.
- REST Residual heat with the engine off (Canada only)
- OFF Defrosts the rear window
- Reduces the airflow
- Increases the airflow
- OFF Completely activates or deactivates automatic climate control.
- AUTO Sets climate control to automatic mode
- Air-recirculation mode
The air in the interior will be recirculated. In air-recirculation mode, the windows can fog up more quickly.
- Settings the air distribution
- Setting the climate mode
- MAX Maximum cooling (USA only)

- General notes**
- Climate control regulates the temperature and the humidity in the vehicle interior and filters undesirable substances out of the air. Climate control is only operational when the engine is running. Optimum operation is only achieved when the side windows and the roof are closed. To prevent the windows from fogging up, please observe the following information:
- OFF Switch off automatic climate control only briefly
- Switch on air-recirculation mode only briefly
- A/C Switch on the cooling function. In warm weather, the air inside the vehicle will be cooled. This function also dries the air inside the vehicle.
- MAX If necessary, briefly switch on the windshield defroster.



Order no. P166 0410 13 Part no. 166 584 60 07 Edition A-2018

Buttons on the multifunction steering wheel



Operating the menu of the on-board computer

- 1 ▲ Scrolls through lists
▼ Selects a submenu or function
- 2 ◀ Calls up the menu and menu bar
▶
- 3 OK Confirms the selected entry
- 4 ↶ Back button

Telephone/media functions

- 5 ☎ Accepts a telephone call
- 6 ☎ Rejects a telephone call
Ends a call
- 7 + Increases the volume
- 8 - Decreases the volume
- 9 🔇 Mute function

Operating the Voice Control System

- 10 🗣 Starts a dialog
- 4 ↶ Cancels a dialog

⚠ **WARNING** Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Voice Control System

Starting a dialog

The Voice Control System allows you to comfortably operate the majority of the multimedia system's functions.

▶ **To say a command:** Press the 🗣 button and say a command after the audible signal.

Voice Control System help functions

- **General information:**
Say the "Help Voice Control System" command.
- **Help for the current function:**
Say the "Help" command.
- **Help for a specific system:**
Say the help command for the desired system, e.g. "Help telephone".

If you press the 🗣 button, the possible commands are shown in a help window. You can switch off the display of this help window in the multimedia system.

Examples

Navigation commands

- "Enter destination"
A dialog for entering a destination in the navigation system will be started. Thereafter, say the destination address.
- "Nearest gas station"
Many more categories for points of interest are available, e.g. restaurant or tourist attraction.
- "Navigate to John Doe"
Start route guidance to a contact from your address book.

Telephone commands

- "Call John Doe"
The telephone number of a stored contact is dialed.
- "New message"
A dialog for entering a text message (SMS) will be started.

Audio commands

- "Station Z100"
If you are listening to the radio, you can say the name of a station to which you would like to listen.
- "Search for music"
A dialog in which you can search through your music files will be started.

Note that your vehicle may not be equipped with all features described.

Overview of the multimedia system



You can operate the menus of the multimedia system using the controller or the touchpad.

- ▶ **Controller:** Turn or slide in the direction of the desired entry.
- ▶ Confirm your choice by pressing the controller.

- ▶ **Touchpad:** Swipe in the direction of the desired entry.
- ▶ Confirm the selection by pressing on the sensitive surface.
- ◀ Leaves a menu or switches to the basic menu
- ★ Calls up or changes favorites
- ▶▶▶ Rapid access to audio sources




Direct buttons for the multimedia system

- RADIO Radio menu
- NAVI Navigation menu
- MEDIA Media menu
- TEL Telephone menu
- Vehicle/system settings menu

⚠ **WARNING** Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Operating the multimedia system




Vehicle and sound settings

- ▶ **Touchpad:** With two fingers spread slightly apart, turn to the left or right.
- ▶ **Controller:** Turn left or right.




Zooming the map

- ▶ **Touchpad:** Move two fingers apart or together.



Rapid access to audio sources

- Depending on the audio source to which you are currently listening, you can move to the next radio station or music track.
- ▶ **To open the access bar:** Swipe up with two fingers.
- or
- ▶ Press the ▶▶▶ button on the touchpad.
- ▶ **To select the previous or next station/music track:** Swipe to the left or right.
- ▶ **To close the access bar:** Swipe down with two fingers.



Handwriting recognition

- You can enter individual letters.
- ▶ **To delete** [c]: Swipe to the left.
- ▶ **To insert a space** []: Swipe to the right.
- Quickly storing radio stations**
If you are listening to the radio and the Radio menu is shown in the multimedia system:
 - ▶ Press and hold the controller or touchpad until the station list is shown.
 - ▶ Select the desired preset in the station list and confirm.
 - A tone confirms the save.

Note that your vehicle may not be equipped with all features described.

Establishing a Bluetooth® connection



Example image: COMAND

Requirement

- Bluetooth® is switched on on the mobile phone (see the manufacturer's operator's manual).
- Bluetooth® is switched on on the multimedia system.

Searching for a mobile phone

- ▶ Press the TEL button on the center console.
- ▶ Select Conn. Device (1).
- ▶ **Audio 20:** Select **Connect New Device**.
- ▶ Select **Connect via Vehicle**.
- ▶ Select the desired mobile phone.
- ▶ If possible, select the intended usage of the mobile phone (main or secondary phone).
- ▶ **COMAND:** Select **Search for Phones**.
- ▶ Select **Start Search**.
- ▶ Select the desired mobile phone.

If your mobile phone is not found, try searching on the mobile phone itself.

Authorizing a mobile phone

- ▶ A code is displayed in the multimedia system and on the mobile phone.
- ▶ **If the codes match:** If necessary, confirm in the multimedia system with **Yes**.
- ▶ Confirm the code on the mobile phone.

Further information

Detailed information on Bluetooth® connections with your mobile phone can be found at:
www.mercedes-benz.com/connect



⚠ **WARNING** Make sure that you read the entire Operator's Manual. Otherwise, you may not recognize dangers.

Further information on your vehicle



Connecting external media sources

- 1 SD card slot
- 2 USB connections

The USB connection for Apple CarPlay™ and Android Auto™ is marked with the [] symbol.

Further information

You can find further information on your vehicle at:

<http://www.mbusa.com>

If you have any questions, you can optionally also press the [] button in the overhead control panel.



How-to videos



Operator's Manuals

Note that your vehicle may not be equipped with all features described.