

BENEFITS:

- ▶ Assistance locating vehicle
- ▶ Ability to remotely activate the vehicle's horn as an alarm

REQUIREMENTS:

- ▶ MY2013 and newer vehicle
- ▶ Apple iPhone® iOS 7.0, Android™-based phone (OS 2.3 or later)
- ▶ mbrace Mobile Application v.5.0 or later
- ▶ Vehicle cellular service
- ▶ Vehicle GPS satellite signal to identify location

FEATURES:

- ▶ Remote access from a smartphone or the Web

Remote Horn & Lights:

Find your car in a dark parking lot or sound an alarm by remotely flashing the lights and honking the horn.

Service Description:

The Remote Horn & Lights service allows the customer to find their vehicle in a dark parking lot or sound an alarm by remotely flashing the lights and honking the horn. The customer can use the Remote Horn & Lights feature through the mbrace® Mobile Application or through the mbrace Customer Portal. Once the customer initiates the Remote Horn & Lights feature using either method, a command is sent to their vehicle to honk the horn and flash the lights for five seconds.

How It Works on the mbrace Mobile Application:

- STEP 1:** The customer launches the mbrace Mobile Application.
- STEP 2:** The customer logs in by entering the 8-digit mbrace account number and a secure 4-digit PIN (This is the same PIN that is established during the mbrace activation process.)
- STEP 3:** The customer taps the Remote Horn / Lights Icon on the key fob image to send a command to the vehicle to honk the horn and flash the lights for five seconds.

How It Works on the mbrace Customer Portal:

- STEP 1:** The customer logs in to the mbrace Customer Portal and selects "Online Tools."
- STEP 2:** The customer selects the Horn / Lights Icon to initiate the service.
- STEP 3:** A message is sent to the vehicle to honk the horn and flash the lights for five seconds.

